

CNC

MELDAS C6/C64

NETWORK MANUAL



MELDAS and MELSEC are registered trademarks of Mitsubishi Electric Corporation. Microsoft, Windows and Windows NT are registered trademarks of Microsoft Corp. in the United States and/or other countries. Other company and product names that appear in this manual are trademarks or registered trademarks of the respective company.

Introduction

This manual explains the interfaces and functions related to the MELDAS C6/C64 network connection.

Always read this manual before starting use. To ensure safe use of the MELDAS C6/C64, always read the "Precautions for Safety" given on the next page.

Details described in this manual

CAUTION

-  For items described as "Restrictions" or "Usable State" in this manual, the instruction manual issued by the machine maker takes precedence over this manual.
-  Items not described in this manual must be interpreted as "not possible".
-  This manual is written on the assumption that all option functions are added. Confirm with the specifications issued by the machine maker before starting use.
-  The screens and functions may differ or be disabled depending on the NC system version.

General precautions

Refer to the following documents.

- | | | |
|------------------------|--|--|
| (1) MELDAS C6/C64/C64T | Operation Manual | BNP-B2259 |
| (2) MELDAS C6/C64/C64T | Parameter Manual | BNP-B2267 |
| (3) MELDAS C6/C64/C64T | PLC I/F Manual | BNP-B2261 |
| (4) MELDAS C6/C64 | PLC Programming Manual | BNP-B2309
(Ladder Section with MELSEC Tool) |
| (5) MELDAS C6/C64 | Connection and Maintenance Manual..... | BNP-B2255 |

Precautions for Safety

Always read the specifications issued by the machine maker, this manual, related manuals and attached documents before installation, operation, programming, maintenance or inspection to ensure correct use.

Understand this numerical controller, safety items and cautions before using the unit. This manual ranks the safety precautions into "DANGER", "WARNING" and "CAUTION".

DANGER

When the user may be subject to imminent fatalities or major injuries if handling is mistaken.

WARNING

When the user may be subject to fatalities or major injuries if handling is mistaken.

CAUTION

When the user may be subject to bodily injury or when physical damage may occur if handling is mistaken.

Note that even items ranked as " **CAUTION**", may lead to major results depending on the situation. In any case, important information that must always be observed is described.

DANGER

Not applicable in this manual.

WARNING

1. Items related to prevention of electric shocks

-  Do not operate the switches with wet hands. Failure to observe this could lead to electric shocks.
-  Do not damage, apply forcible stress, place heavy things on, or catch the cables. Failure to observe this could lead to electric shocks.

2. Items related to program development

-  Do not set any of the touch keys on the GOT as a start switch for the C6/C64. If a communication error (including cable disconnection) occurs between the GOT and C6/C64, the communication will be cut off and the GOT operation will be disabled. Even if the start switch is released, it will not be recognized that the start signal has been cut off, so the operation will continue. This could result in serious accidents.

CAUTION

1. Items related to product and manual

-  For items described as "Restrictions" or "Usable State" in this manual, the instruction manual issued by the machine maker takes precedence over this manual.
-  Items not described in this manual must be interpreted as "not possible".
-  This manual is written on the assumption that all option functions are added. Confirm with the specifications issued by the machine maker before starting use.
-  The screens and functions may differ or be disabled depending on the NC system version.
-  Do not turn "Use prohibited" signal ON. Failure to observe this could result in malfunction in units.

2. Items related to installation and assembly

-  Always ground the signal cable to ensure stable operation of the system. Use a one-point ground so that the control unit body, power distribution panel and machine are at the same potential.

3. Items related to maintenance

-  Do not connect or disconnect the cables connected between each unit while the power is ON.
-  Do not mount or remove each PCB while the power is ON.
-  Do not pull the cables when connecting/disconnecting them.

Contents

I. MELSECNET/10

1. Outline	1
2. Performance Specifications.....	1
3. Available Functions	2
4. Cyclic Transmission	3
4.1 Flow of Network Data	3
4.2 Flow of Data Transmitting/Receiving	4
5. Parameter Setting	5
5.1 Control Station Parameter	5
5.2 Normal Station Parameter	5
6. Other Functions.....	6
6.1 Refresh of SB and SW.....	6
6.2 Devices Possible to Refresh.....	6
7. Transient Transmission	7
7.1 Dedicated Command	7
7.2 Access to Other Stations	7
8. Setting and Display	8
9. Name and Setting of Each Part of MELSECNET/10 Card	9
10. Others.....	12
10.1 Backup of MELSECNET/10 Related Parameters	12
10.2 Replacement of MELSECNET/10 Card.....	12

II. DeviceNet Interface

1. Outline	1
1.1 Features.....	1
1.2 Restrictions	1
2. Detailed Explanations.....	2
2.1 General Configuration.....	2
2.2 Setting the Configuration Parameters.....	2
2.2.1 Configurator	2
2.2.2 Parameter Setting Function	3
3. Communication Data.....	4
3.1 Assigning the Input Data.....	4
3.1.1 Setting with SyCon2.....	4
3.1.2 Setting with the PLC Program.....	5
3.2 Assigning the Output Data.....	6
3.2.1 Setting with SyCon2.....	6
3.2.2 Setting with the PLC Program.....	6
3.3 Message Communication	7
3.3.1 Message Communication Commands	7
3.3.2 Message Communication Results	8
3.3.3 Message Communication Data.....	9
4. Interface with Communication Card (HR871).....	12
4.1 Outline of Interface Signals.....	13
4.2 Details of Interface Signals	14
4.2.1 Refresh Request, Refreshing.....	14
4.2.2 Message Communication Request, Message Communication Completion, Message Communication Error	14
4.2.3 Error Reset Request, Error Set.....	15
4.2.4 Slave Down.....	16

4.2.5	Parameter Set Request, Setting Parameters, Parameter Setting Completion.....	16
4.2.6	System Ready.....	17
4.3	Details of Word Data.....	18
4.3.1	Mounted Card Information	18
4.3.2	Master Communication Status.....	18
4.3.3	Error Information	19
4.3.4	Parameter Set Head Register No.	19
4.3.5	No. of Set Parameters	20
4.3.6	Down Station Detection Prohibit Setting.....	20
5.	Diagnosis Information.....	21
5.1	Details of Diagnosis Information	21
5.1.1	Master Communication Status.....	21
5.1.2	Error Information	21
5.1.3	Bus Error Counter	22
5.1.4	Bus OFF Counter.....	22
5.1.5	Each Station's Configuration Status	22
5.1.6	Each Station's Communication Status.....	23
5.1.7	Each Station's Trouble Status.....	23
6.	Setting the Communication Parameters.....	24
6.1	Setting the Parameters with Configurator.....	24
6.1.1	Setting the Configuration	24
6.1.2	Setting the Master Station Parameters	24
6.1.3	Setting the Bus Parameters	24
6.1.4	Setting the Slave Station Parameters	25
6.2	Setting the Parameters with the PLC Program.....	26
6.2.1	Example of Circuit Creation	27
7.	Error Displays.....	29
7.1	Communication Error Codes	29
7.2	Message Communication Execution Error Codes	32
8.	Details on Expected Packet Rate and Production Inhibit Time	34

III. CC-Link Master/Local Unit

1.	Outline.....	1
2.	Performance Specifications.....	1
3.	Usable Functions.....	2
4.	Input/output Signals.....	3
5.	Flow of Communication Data	5
5.1	Automatic Refresh	6
6.	Transient Function.....	7
6.1	Outline	7
6.2	Transient Command (READ/SREAD/WRITE/SWRITE) Format.....	7
6.3	Transient Command (RIRD/RIWT) Format.....	8
6.4	Precautions.....	8
7.	Names and Settings of Each CC-Link Card Section	9
8.	Miscellaneous.....	13
8.1	Backing Up CC-Link Related Parameters	13
8.2	Replacing the CC-Link Card	13

IV. Setting the Ethernet IP Address

1.	Outline.....	1
2.	Explanation of function	1
2.1	Confirming the IP Address.....	1
2.2	Initializing the IP Address	1

2.3	Setting the IP Address	1
3.	Operation Procedure	2
3.1	Confirming the Address	2
3.2	Initializing the IP Address	3
3.3	Setting the IP Address	4

V. Ethernet 2-channel Connection

1.	Outline	1
2.	Hardware Configuration	1
2.1	Unit No.	1
2.2	Correspondence with Unit Numbers	2
3.	Setting the Parameters	2
4.	Precautions	2
5.	Supplement	3
5.1	Setting the Gateway Address	3
5.2	EXT3 Compatible Version	3

VI. Ethernet Interface Communication Function (MELSEC Communication Protocol Section)

1.	Outline	1
2.	Functions for Accessing the PLC CPU with MC Protocol	1
3.	Example of Connection Configuration	3
3.1	Example of Connecting Peripheral Devices on Single Network	3
3.2	Example of Connecting Peripheral Devices to a Multilevel Network	3
3.3	Example of Connecting MELSEC CPU and C6/C64 to a Multilevel Network	4
4.	Setting the Parameters	5
4.1	Setting the NC Side	5
4.2	Setting the GX Developer Side	5
4.2.1	Setting the Network Parameters	5
4.2.2	Setting the GX Developer Connection Destination	6
5.	Comparison of Functions	6
6.	Performance Specifications	7

VII. Ethernet Interface Communication Function Using PLC (Client Function Section)

1.	Outline	1
2.	Detailed Explanation	1
2.1	Connection No. in Connecting with Client Device	1
2.2	Control Signals	2
2.3	Response Monitor Timer	2
2.4	Transmission Control Method	3
2.5	Reception Control Method	4
3.	Data Format	5
3.1	Header	5
3.2	Application Data	5
4.	Details of Dedicated Commands	7
4.1	OPEN Command	7
4.2	CLOSE Command	8
4.3	BUFSND Command	9
4.4	BUFRCV Command	10
4.5	Details of Error Codes	11
4.6	Precautions for Programming	11
5.	Example of Data Communication Program	12

VIII. I/O/Intelligent Function Unit Connection Function

1. Outline	1
2. Basic Specification	1
3. Detailed Explanation	3
3.1 Connection.....	3
3.2 Allocation of I/O I/F (Interface).....	3
3.3 Access to Intelligent Function Units.....	6
3.3.1 Reading Buffer Memory (by FROM command).....	6
3.3.2 Writing in Buffer Memory (by TO command)	7
3.3.3 Restrictions in Using FROM/TO Commands	8
3.3.4 Access to I/O of Intelligent Function Units	9
4. Other Notices	10
4.1 Notices in Connecting Remote I/O Unit	10
4.2 Built-in PLC's Scan Time	12
4.3 Buffer Memory Address	12
5. Alarm List	13
6. Supplement (Example of built-in PLC when FL-net unit is used)	14
6.1 Input/Output Signal List	15
6.2 Initial Setting	16
6.3 Cyclic Transmission.....	18
6.4 Message Transmission.....	19
6.4.1 Outline of Message Transmission.....	19
6.4.2 Transaction Code.....	20
6.4.3 Support Message List	21
6.4.4 Support Message Details.....	22
6.5 Checking various status of other nodes.....	36
6.6 Reference	38

IX. Connection Function with GOT

1. Outline	1
2. Available Function	2
3. Connection Mode	3
3.1 CPU Direct Connection.....	4
3.2 CC-Link Connection.....	5
3.3 Ethernet Connection	6
3.3.1 Initial setting of Ethernet Connection	7
4. Device Range Referenced on the GOT	14
5. Related Documents.....	15

X. GOT Window Function

1. Outline	1
2. Displaying the NC data.....	2
3. Displaying the NC data (Method 2): GOT window function	3
4. Designating the window area	4
5. Retrieving window data	6
6. Data change request and complete signals	7
6.1 Data change request signal (GOT → NC).....	7
6.2 Data change complete signal (NC → GOT)	8
7. Window commands/responses	9
7.1 List of command codes	9
7.2 Command area.....	9
7.3 Response area	10
8. Details of commands.....	11
8.1 melGetCurrentPrgPack	11

8.2 melGetGmodalPack	12
8.3 melGetAxisPosition	14
8.4 melGetCurrentAlarmMsg2.....	18
8.5 mmelGetAlarmHistory	23

XI. Remote Monitor Tool

1. Outline	1
2. System Configuration	1
2.1 System Requirements	1
2.2 Contents of Software Package	1
3. Installation of Remote Monitor Tool.....	2
4. Uninstalling th Remote Monitor Tool	4
5. How to Start and Operate.....	5
5.1 Starting Remote Monitor Tool	5
5.2 Screen Makeup of Remote Monitor Tool	6
5.3 Basic Operation of Remote Monitor Tool.....	6
5.3.1 Title Bar.....	6
5.3.2 Menu Bar	7
5.3.3 Connect with Machine Tools (NC)	7
5.3.4 Send and Receive a Parameter File	8
5.3.5 Send and Receive the Program.....	9
5.3.6 Receiving a Maintenance Data	10
5.3.7 Refer to NC Information	10
5.3.8 Search the Topics	11
5.3.9 Confirm the Remote Monitor Tool Version.....	11
5.3.10 Using a Tool Bar	12
5.3.11 Using a Status Bar	12
6. Setting NC Parameters	13
7. Error Message and Its Remedy.....	14
8. Supplement	15

I. MELSECNET/10

I. MELSECNET 10

1. Outline

1. Outline

As a control station or normal station of MELSECNET/10, MELDAS C6/C64 can be directly connected to the network.

To connect, insert the MELSECNET/10 communication unit into extension slots. The maximum number of communication units possible to insert is 2.

2. Performance Specifications

Item		Optical loop system (HR879)	Coaxial bus system (HR878)	
Max. link points per network	LX/LY	8192 points		
	LB	8192 points		
	LW	8192 points		
Max. link points per station		$\left\{ \frac{B+Y}{8} \right\} + (2 \times W) \leq 2000$ bytes		
Max. link device in NC	B	8192 points		
	W	8192 points		
Communication speed		10MBPS (equivalent to 20MBPS for multiple transmission)	10MBPS	
Communication method		Token ring	Token bus	
Synchronization method		Frame synchronization		
Encoding method		NRZI (Non Return to Zero Inverted)	Manchester encoding	
Transmission route format		Duplex loop	Simplex bus	
Transmission format		Conform to HDLC (frame format)		
Max. number of networks		255		
Max. number of groups		9		
Number of stations for connection per network		64 stations (Control station: 1, Normal station: 63)	32 stations (Control station: 1, Normal station: 31)	
Total extension distance per network	30Km (Station to station 500m)	3C-2V	5C-2V	
		300m (Station to station 300m)	500m (Station to station 500m)	
Error control method		Retry with CRC ($X^{16}+X^{12}+X^5+1$) and overtime		
RAS function		Loop back function with error detection and cable disconnection (only for optical loop systems) Host link line check diagnosis function System fault prevention due to control station migration Error detection using special relay or register Network monitor, various types of diagnosis functions		
Transient transmission		N: N communication (such as monitoring or program upload/download) ZNRD/ZNWR (N: N)		
Connection cable		SI-200/250	3C-2V or 5C-2V equivalent product	
Connector		2-core optical connector plug CA7003	BNC-P-3-Ni-CAU, BNC-P-5-Ni-CAU (DDK) equivalent products	
Cable transmission loss		12db/Km max.	Conform to JIS C 3501 standard	

I. MELSECNET 10

3. Available Functions

3. Available Functions

Among the functions of MELSECNET/10 network, available functions with MELDAS C6/C64 are as follows.

Function		MELSEC	MELDAS C6/C64	
Network function	Control station function	Available	Available	
	Control station transfer function	Available	Available	
	Cyclic transmission	Communication by B/W (1: N)	Available	Available
		Communication by X/Y (1: 1)	Available	Available
		Constant link scan function	Available	Available
		Stopping/Restarting data link	Available	Available
		Inter data link transmission	Available	Available
		Station specific parameter	Available	Not available
	Transient transmission	N: N communication	Available	Available
		Routing function	Available	Available
		Group function	Available	Not available
	RAS function	Automatic recovery function	Available	Available
		Loop back function	Available	Available
		Station detachment function	Available	Available
		Data link status detection function	Available	Available
Remote I/O net	Available	Not available		
Multiplex transmission function	Available (Optical loop only)	Available (Optical loop only)		
Reserve station function	Available	Available		
Setting and display	LED diagnosis function	22 point display	4 point (coaxial) 7 point (optical loop) display	
	Network No. setting	Switch on the front of the unit	Setting switch on the card	
	Group No. setting			
	Station No. setting			
	Condition setting			
	Mode setting switch			
	Display changeover switch		Switch on the front of the card	
Self diagnosis function	Hardware testing	Available	Not available	
	Internal self-loop back testing	Available	Not available	
	Self-loop back testing	Available	Not available	
	Station to station testing	Available	Not available	
	Forward loop / Reverse loop testing	Available (Optical loop only)	Not available	
	Loop testing	Available	Not available	
	Setting switch check	Available	Not available	
	Station order check testing	Available	Not available	
	Line monitoring	Available	Not available	
	Status monitoring	Available	Not available	
	Error history monitoring	Available	Not available	
	Network nesting	Available	Not available	
	Dedicated command	READ/SREAD	Available	Available
WRITE/SWRITE		Available	Available	

I. MELSECNET 10
4. Cyclic Transmission


4. Cyclic Transmission

The cyclic transmission function is for periodical data transfer between the stations in the network. (The transfer period is in proportional to the size of the entire data in the network.)

4.1 Flow of Network Data

Data that can be transmitted within the MELSECNET/10 network is as follows.

Device	Unit	The max. number of points per 1 network
Link relay (B)	1 bit	8192 points
Link register (W)	1 word	8192 points
Link input (X)	1 bit	8192 points
Link output (Y)	1 bit	8192 points




All stations' data is transmitted into the network. Each station outputs its data to the network, and takes the other stations' data in. So each station can refer to all the other stations' output information. However, it is not possible to output to the data allocated for the other stations. Each station's size of data can be set by a parameter.

I. MELSECNET 10
 4. Cyclic Transmission

4.2 Flow of Data Transmitting/Receiving

Data transfer (link refresh) between the network card and PLC device in the NC is executed automatically. The size of data to transmit and the device to which the data is transmitted can be set by parameters.



I. MELSECNET 10
5. Parameter Setting

5. Parameter Setting

Set parameters related to MELSECNET/10 with MELSEC's peripheral devices in the same way as parameter setting of MELSEC CPU, and write them on C64 by PC. However, in the case of using the default parameters or not requiring separate settings due to normal stations, it is not necessary to set the network parameters.

5.1 Control Station Parameter

If you wish to place the control station in C64 and set the common parameters, set the network parameters by peripheral device and write them on C64. An example of parameter setting by GPPW is as follows. Set the first I/O No. as follows according to the expansion slot to which the unit is inserted.

Slot	First I/O No.
EXT1 (Bottom)	0200
EXT2 (Top)	0280

	Module No.1	Module No.2	Module No.3	Module No.4
Network type	MNET/10(Controller station)	MNET/10(Normal station)	None	None
Start I/O No.	0020	0280		
Network No.	1	1		
Total stations	3			
Group No.				
Station No.				
IP addressDEC				
	Network range assignment			
		Station inherent parameters		
	Refresh parameters	Refresh parameters		

Necessary setting(No setting / Already set) Set if it is needed(No setting / Already set)

Start I/O No.: Valid module during other station access:

Interlink transmission parameters: Input the start I/O No. installed in the module in 16-point unit.

Set essential settings. Set other parameters if necessary.

5.2 Normal Station Parameter

As for normal stations, it is not necessary to set parameters unless separate settings are required. The refresh parameters are set and written as required. In this case, the parameter setting of the first I/O No. is the same as in the case of the control station.

I. MELSECNET 10

6. Other Functions

6. Other Functions

This section introduces functions whose specifications are different from MELSEC.

6.1 Refresh of SB and SW

SB and SW devices are automatically refreshed according to the allocation below depending on the slot.

Slot	Refresh range of SB	Refresh range of SW
EXT1	SB0000 to SB00FF	SW0000 to SW00FF
EXT2	SB0100 to SB01FF	SW0100 to SW01FF

6.2 Devices Possible to Refresh

The refresh parameters have extended setting. By the extended setting, various devices can be set as devices to be refreshed. In the case of C64, the range of devices is as follows.

Devices possible to refresh	Unit	Range possible to use
B	1 bit	B0 to B1FFF
X	1 bit	X0 to X1FF (Avoid overlapping with the range for real I/O)
Y	1 bit	Y0 to Y1FF (Avoid overlapping with the range for real I/O)
M	1 bit	M0 to M8191
L	1 bit	L0 to L255
W	16 bit	W0 to W1FFF
R	16 bit	R0 to R8191 (Avoid overlapping with the range for NC I/F)
D	16 bit	D0 to D8191 (Note 1)
T	16 bit	T0 to T255
C	16 bit	C0 to C127

(Note 1) D0 to D8191 can be used with software version D0 and above.

I. MELSECNET 10

7. Transient Transmission

7. Transient Transmission

The transient transmission function is used to communicate only when a station requests communication to another.

In the transient transmission, it is possible to read and write devices of the other stations.

7.1 Dedicated Command

If C64 is set as either of the command execution station or the target station among the dedicated commands of transient transmission of MELSECNET/10, only the commands below can be used.

Dedicated command possible to use	Outline of the command
READ	The host reads the word device data from the specified station.
SREAD	The host reads the word device data from the specified station (with the target station completion).
WRITE	The host writes data in the word device data of the specified station.
SWRITE	The host writes data in the word device data of the specified station (with the target station completion).

7.2 Access to Other Stations

By setting the access to other stations valid for peripheral device connected to a station in the MELSECNET/10 network, operation of the peripheral device targeting the other stations in the network becomes possible. The PLC in C64 is also targeted. It is also possible to access the other stations via the peripheral device connected to C64.

I. MELSECNET 10

8. Setting and Display

8. Setting and Display

Set network settings by MELSEC's peripheral devices.
Available functions are shown in the table below.

Setting and display		Availability with C64	
Setting	Number of unit settings	Available	
	Common parameter	Available	
	Network refresh parameter	Available	
	Station specific parameter	-	
	Transfer parameters for data link	Available	
	Routing parameter	Available	
Monitor display	Line monitor	Line monitor	Not available
		Detailed line monitor	Not available
		Line monitor (other stations)	Not available
	Status monitor	Status monitor	Not available
		Detailed status monitor	Not available
		Test monitor	Not available
	Error history monitor	Error history monitor	Not available
		Loop switching data display	Not available
		Transient transmission error	Not available


I. MELSECNET 10

9. Name and Setting of Each Part of MELSECNET/10 Card

9. Name and Setting of Each Part of MELSECNET/10 Card



Name and setting of each part of HR879 for the optical loop system and HR878 for the coaxial bus system are as follows.

<Figure of unit>






I. MELSECNET 10

9. Name and Setting of Each Part of MELSECNET/10 Card

No.	Name	Description									
(1)	Condition setting switch 	Set the operation condition.									
		SW	Description	OFF	ON						
		1	Network type	Inter-PC net (PC)	Remote I/O net						
		2	Station type	Normal station (N.ST)	Control station (MNG)						
		3	Used parameter	Common parameters (PRM)	Default parameter (D.PRM)						
		4	Number of stations (Valid when SW3 is ON)	OFF	8 stations	ON	16 stations	OFF	32 stations	ON	64 stations
		5		OFF	2K points	ON	4K points	OFF	6K points	ON	8K points
		6	B/W total points (Valid when SW3 is ON)	OFF	2K points	ON	4K points	OFF	6K points	ON	8K points
		7		OFF	2K points	ON	4K points	OFF	6K points	ON	8K points
		8	Not used	Always OFF							
(2)	Setting switch of station No., group No. and network No. 	Station number setting <Setting range> 1 to 64: Station number Other than 1 to 64: Setting error									
		Group number setting Not used, fixed to 0									
		Network number setting <Setting range> 1 to 255: Network number Other than 1 to 255: Setting error									
(3)	Mode setting switch	Sets the mode.									
		Mode	Name	Description							
		0	Online (with auto recovery)	Data link with auto recovery							
		1	Cannot be used								
		2	Offline								
		3	Test mode 1	Loop test (Forward loop)							
		4	Test mode 2	Loop test (Reverse loop)							
		5	Test mode 3	Station to station test (Master station)							
		6	Test mode 4	Station to station test (Slave station)							
		7	Test mode 5	Self loop back test							
		8	Test mode 6	Internal self loop back test							
		9	Test mode 7	H/W test							
		A	-	Cannot be used							
		B	-	Cannot be used							
C	-	Cannot be used									
D	Test mode 8	Network No. check									
E	Test mode 9	Group No. check									
F	Test mode 10	Station No. check									

I. MELSECNET 10

9. Name and Setting of Each Part of MELSECNET/10 Card

No.	Name	Description			
		Name	Status	Description	
(4)		RUN	ON	Unit normal	
			OFF	WDT error occurred	
		ERR	ON	Hardware error	
		SD	ON in dim light	Sending data	
		RD		Receiving data	
(5)		RUN	ON	Unit normal	
			OFF	WDT error occurred	
		F.ERR	ON	Forward loop Hardware error	
		R.ERR	ON	Reverse loop Hardware error	
		F.SD	ON in dim light	Forward loop Sending data	
		F.RD		Forward loop Receiving data	
		R.SD		Reverse loop Sending data	
		R.RD		Reverse loop Receiving data	
(6)		Connect coaxial cable (F shape connector).			
(7)		Connect optical fiber cable.			
			R T	4 3	1 Forward (F) loop RD
			R T	2 1	2 Reverse (R) loop SD
					3 Reverse (R) loop RD
				4 Forward (F) loop SD	

I. MELSECNET 10

10. Others

10. Others

10.1 Backup of MELSECNET/10 Related Parameters

The parameters related to MELSECNET/10 are only the network parameters written from MELSEC's peripheral device. Their storage area is different from that of usual NC parameters, and the parameters are stored in the Ladder program area in the NC. In order to backup the network parameters out of the NC, it is necessary to output and save the data as follows.

No.	Data output operation	Devices to use
1	Read the data by selecting the PC read parameter by MELSEC's peripheral device, and store it as a file in the PC. In writing, execute PC writing as above.	MELSEC peripheral devices GPPQ, GPPW, etc.
2	Output the PLC program area in the NC data output screen. Output by #(99) DATA (ALL2). In inputting, use the data input screen.	External storage unit (PC, etc.)

10.2 Replacement of MELSECNET/10 Card

Even if the MELSECNET/10 card inserted in the NC is faulty and the cards are replaced, data recovery is not necessary as no parameters are stored in the card.

II. DeviceNet Interface

II. DeviceNet Interface

1. Outline

1. Outline

This function is used to connect MELDAS C6/C64 to DeviceNet as the master station. The dedicated interface card HR871 is required to use this function.

1.1 Features

This function has the following features.

- (1) Compliant with DeviceNet Standards Revision 2.0.
- (2) Operates as a DeviceNet group 2 dedicated client, and communicates with a Group 2 dedicated server.
- (3) Can input and output 256 bytes (2048 points) each using I/O communication.

1.2 Restrictions

- (1) This MELDAS C6/C64 operates as a Group 2 dedicated client using the HR871, but cannot communicate with the other masters. In other words, neither communication to the configurator on the network nor dynamic establishment of the connection is supported.
- (2) A Hilsher (hereinafter, Company H) communication PCB is used, so when the network analyzer is installed, it will appear as a Company H product. (This is because the Company H vender ID is recognized.)
- (3) The DeviceNet communication parameters must be set (configured) with the Windows based SYNERGETIC Configurator SyCon Ver. 2.0 or with the built-in PLC program.


II. DeviceNet Interface

2. Detailed Explanations

2. Detailed Explanations

2.1 General Configuration

The general configuration when using the C64 as the master station is shown below.



2.2 Setting the Configuration Parameters

2.2.1 Configurator

The parameters can be set in the HR871 using the SYNERGETIC (hereinafter Company S) Configurator SyCon Ver. 2.0 (hereinafter SynCon2). Connect HR871 and SyCon2 with a RS-232C cross cable. The SyCon2 system requirements are as follows.


Item	System Requirements
CPU	Intel 486 processor or more
OS	Windows95, WindowsNT3.51, WindowsNT4.0
Open disk space	10MB or more
RAM	16MB or more
Display resolution	800 × 600 dots or more
External memory	CD-ROM drive (for installation)

II. DeviceNet Interface

2. Detailed Explanations

Connect the cross cable as shown below.

The connections shown with dotted lines are not required, but may be connected without problem to eliminate the cable orientation.



RS-232C cross cable connection diagram

(Note) The details set with SyCon2 are written into the flash ROM on the communication PCB mounted on HR871.
 This data cannot be read or written from the NC main system (it can only be erased).
 Back up the setting data with the personal computer.

2.2.2 Parameter Setting Function

The configuration parameters can be set with the PLC program.

(Note) The details set with the PLC program are written into the EEPROM on the HR871's base PCB. When the parameters are written, the data in the flash ROM set with the SyCon2 will be erased. Always invalidate the EEPROM parameters when writing the parameters with SyCon2 again.

The relation of the flash ROM and EEPROM parameters is as follows.

		Flash ROM	
		Parameters not set	Parameters set
EEPROM	Invalid Local station MAC ID is FFFF	Communication does not start.	Communicates with the flash ROM parameters.
	Valid	Communicates with the EEPROM parameters.	<Use prohibited>

(Note) The EEPROM can be invalidated by setting the local station's station No. (MAC ID) to FFFF. Refer to section "6.2 Setting the parameters with the PLC program" for details on setting the station No., etc.

II. DeviceNet Interface

3. Communication Data

3. Communication Data

The communication data is assigned to device B (or device W).
The device assignments are as shown below.

Input/output data	HR871 mounting slot	
	Extension slot 1	Extension slot 2
Input data 2048 points	B0000 to B07FF	B1000 to B17FF
Output data 2048 points	B0800 to B0FFF	B1800 to B1FFF

Message communication	HR871 mounting slot	
	Extension slot 1	Extension slot 2
Message communication command (16word, W)	W0000 to W000F	W1000 to W100F
Message communication results (16word, R)	W0010 to W001F	W1010 to W101F
Message communication data (120word, R/W)	W0020 to W0097	W1020 to W1097

(Note) Programming and monitor of the device B (or device W) are currently not supported with onboard. These are possible only with GPP until supported.

3.1 Assigning the Input Data

The input data arrangement follows the parameter settings.

3.1.1 Setting with SyCon2

The assignment of the input data for each station is indicated with SyCon2's "Customized I/O data" "I. Addr". This value follows the address mode set with another SyCon2 screen (Master Settings screen).

(1) Byte addressing mode

If the address mode is byte address, the devices and I. Addr correspond as shown below.

Device	I. Addr
B0007-B0000	0
B000F-B0008	1
B0017-B0010	2
B001F-B0018	3
B0027-B0020	4
B002F-B0028	5

(2) Word addressing mode

If the address mode is word address, the devices and I. Addr correspond as shown below.

Device	I. Addr
B0007-B0000	0
B000F-B0008	
B0017-B0010	1
B001F-B0018	
B0027-B0020	2
B002F-B0028	

II. DeviceNet Interface

3. Communication Data

3.1.2 Setting with the PLC Program

When the data is set with the PLC program, the settings are the same as the word addressing mode. Note that the byte modules, word modules and double-word modules must be grouped per each slave station in the order as previously indicated.

(Layout example)

Device	Module		
B000F to B0000	Byte module 2	Byte module 1	Input data for 1st station
B001F to B0010	(Open due to alignment)	Byte module 3	
B002F to B0020	Word module 1		
B003F to B0030	Word module 2		
B004F to B0040	Double-word module 1 (low-order)		
B005F to B0050	Double-word module 1 (high-order)		
B006F to B0060	Byte module 2	Byte module 1	Input data for 2nd station
B007F to B0070	Byte module 4	Byte module 3	

II. DeviceNet Interface

3. Communication Data

3.2 Assigning the Output Data

The output data arrangement follows the parameter settings.

3.2.1 Setting with SyCon2

The assignment of the output data for each station is indicated with SyCon2's "Customized I/O data" "O. Addr". This value follows the address mode set with another SyCon2 screen (Master Settings screen).

(1) Byte addressing mode

If the address mode is byte address, the devices and O. Addr correspond as shown below.

Device	O. Addr
B0807-B0800	0
B080F-B0808	1
B0817-B0810	2
B081F-B0818	3
B0827-B0820	4
B082F-B0828	5

(2) Word addressing mode

If the address mode is word address, the devices and O. Addr correspond as shown below.

Device	O. Addr
B0007-B0000	0
B000F-B0008	
B0017-B0010	1
B001F-B0018	
B0027-B0020	2
B002F-B0028	

3.2.2 Setting with the PLC Program

When the data is set with the PLC program, the settings are the same as the word addressing mode. Note that the byte modules, word modules and double-word modules must be grouped per each slave station in the order as previously indicated.

(Layout example)

Device	Module		
B080F to B0800	Byte module 2	Byte module 1	Output data for 1st station
B081F to B0810	(Open due to alignment)	Byte module 3	
B082F to B0820	Word module 1		
B083F to B0830	Word module 2		
B084F to B0840	Double-word module 1 (low-order)		
B085F to B0850	Double-word module 1 (high-order)		
B086F to B0860	Byte module 2	Byte module 1	Output data for 2nd station
B087F to B0870	Byte module 4	Byte module 3	

II. DeviceNet Interface

3. Communication Data

3.3 Message Communication

3.3.1 Message Communication Commands

The following information can be handled with Message Communication.

- Reading of error information for the slave in which error occurred
- Getting/Setting of the slave attribute data
- Resetting of objects

(1) Reading the communication error information

Device No.		Item	Details	
W0000	W1000	Command No.	0001H	Communication error information read
W0001	W1001	Slave station No. (Slave MAC ID)	High-order byte	Not used (always 0)
			Low-order byte	Number of the slave station from which error information is read

(2) Getting the attribute data (Get Attribute)

Device No.		Item	Details	
W0000	W1000	Command No.	0101H	Attribute get
W0001	W1001	Slave station No./ class ID	High-order byte	Class ID of the object from which attribute are gotten
			Low-order byte	No. of the slave station (MAC ID) from which attributes are gotten
W0002	W1002	Instance ID		Instance ID of the object from which attributes are gotten
W0003	W1003	Attribute ID	High-order byte	Not used (always 0)
			Low-order byte	Attribute ID of the object from which attributes are gotten

(3) Setting the attribute data (Set Attribute)

Device No.		Item	Details	
W0000	W1000	Command No.	0102H	Attribute set
W0001	W1001	Slave station No./ class ID	High-order byte	Class ID of the object to which attributes are set
			Low-order byte	No. of the slave station (MAC ID) to which attributes are set
W0002	W1002	Instance ID		Instance ID of the object to which attributes are set
W0003	W1003	Attribute ID / Data length	High-order byte	Byte length of the attribute data to be set (1 to 240)
			Low-order byte	Attribute ID of the object to which attributes are set

(4) Resetting

Device No.		Item	Details	
W0000	W1000	Command No.	0201H	Reset
W0001	W1001	Slave station No./ class ID	High-order byte	Class ID of the object to be reset
			Low-order byte	Slave Station No. containing target object
W0002	W1002	Instance ID		Instance ID of the object to be reset

II. DeviceNet Interface

3. Communication Data

3.3.2 Message Communication Results

When the "message communication command" process results are set, "Message completion" signal (Y202/Y282) turns ON. The PLC program must confirm that "Message completion" signal is ON before reading the data.

Refer to section "7.2 Message communication execution error codes" for details on the execution error codes.

(1) Reading the communication error information

Device No.		Item	Details	
W0010	W1010	Command No.	0001H	Communication error information read
W0011	W1011	Execution error code	0000H	Normal end
			Other than 0000H	Error end (execution error code)

(2) Getting the attribute data (Get Attribute)

Device No.		Item	Details	
W0010	W1010	Command No.	0101H	Attribute get
W0011	W1011	Execution error code	0000H	Normal end
			Other than 0000H	Error end (execution error code)
W0012	W1012	Slave station No./ class ID	High-order byte	Class ID of the object from which attributes were gotten
			Low-order byte	No. of the slave station (MAC ID) from which attributes were gotten
W0013	W1013	Instance ID		Instance ID of the object from which attributes were gotten
W0014	W1014	Attribute ID/data length	High-order byte	Byte length of the gotten attribute data (1 to 240)
			Low-order byte	Attribute ID of the object from which attributes were gotten

(3) Setting the attribute data (Set Attribute)

Device No.		Item	Details	
W0010	W1010	Command No.	0102H	Attribute set
W0011	W1011	Execution error code	0000H	Normal end
			Other than 0000H	Error end (execution error code)
W0012	W1012	Slave station No./ class ID	High-order byte	Class ID of the object to which attributes were set
			Low-order byte	No. of the slave station (MAC ID) to which attributes were set
W0013	W1013	Instance ID		Instance ID of the object to which attributes were set
W0014	W1014	Attribute ID / Data length	High-order byte	Byte length of the set attribute data (1 to 240)
			Low-order byte	Attribute ID of the object to which attributes were set

II. DeviceNet Interface

3. Communication Data

(4) Resetting

Device No.		Item	Details	
W0010	W1010	Command No.	0201H	Reset
W0011	W1011	Execution error code	0000H	Normal end
			Other than 0000H	Error end (execution error code)
W0012	W1012	Slave station No./ class ID	High-order byte	Class ID of the reset object
			Low-order byte	Slave Station No. containing the target object
W0013	W1013	Instance ID		Instance ID of the reset object

3.3.3 Message Communication Data


(1) Reading the communication error information

Device No.		Item	Details
W0020	W1020	Slave status	Indicates whether the slave is set in the parameters, and whether the slave responded or not. Refer to the explanation (a) below.
W0021	W1021	(Not used)	
W0022	W1022	Communication error	The error code is stored. Refer to section "7.1 Communication error codes" for details on the error codes.
W0023	W1023	General error codes	General error codes sent from the slave station. This is valid only when the communication error code is 35 (0023H). The general meanings stipulated with DeviceNet are shown in (b) below. Refer to the manual for each slave for details on the actual trouble and countermeasures.
W0024	W1024	Additional error code	Additional error codes sent from the slave station. Refer to the manual for the slave for the meaning of each error code.
W0025	W1025	No. of heartbeat timeouts	No. of times the slave station was asked whether it was down. A higher value indicates that the network state is poor.

(Note) Refer to each slave station manual for details on the general error codes and additional error codes.

(a) Slave status

Problems in the slave station are notified by the ON/OFF state of each bit.



II. DeviceNet Interface

3. Communication Data

(b) General DeviceNet error codes

Error code		Name	Meaning
Hexa-decimal	Decimal		
0000	0	–	This is reserved by DeviceNet.
0001	1	–	This is reserved by DeviceNet.
0002	2	Resource unavailable	The requested service could not be executed because the required resources were not found.
0003 to 0007	3 to 7	–	This is reserved by DeviceNet.
0008	8	Service not supported	The requested service is not supported, or is not defined with this object class/instance.
0009	9	Invalid attribute value	The attribute data is incorrect.
000A	10	–	This is reserved by DeviceNet.
000B	11	Already in requested mode/state	The object is already in the mode/status requested by the server.
000C	12	Object settable	The object cannot execute the requested service in the current mode/status.
000D	13	–	This is reserved by DeviceNet.
000E	14	Attribute not settable	Attributes that cannot be changed were changed.
000F	15	Prevelege violation	Access rights are not available.
0010	16	Device state conflict	The requested service cannot be executed in the current device state.
0011	17	Reply data too large	The response data length is longer than the buffer.
0012	18	–	This is reserved by DeviceNet.
0013	19	Not enough data	Enough data to execute the designated operation has not been provided.
0014	20	Attribute not supported	The designated attribute is not supported.
0015	21	Too much data	Invalid data was found.
0016	22	Object does not exist	The designated object does not exist in the slave.
0017	23	–	This is reserved by DeviceNet.
0018	24	No stored attribute data	The designated object's attribute data was not saved before the service was requested.
0019	25	Store operation failure	The attribute data could not be saved because a problem occurred during the save process.
001A to 001E	26 to 30	–	This is reserved by DeviceNet.
001F	31	Vender specific error	A vender specific error occurred. The details are shown in the additional error code area (W0024/W1024). Refer to the slave station manual for details on the vender specific error.
0020	32	Invalid parameter	The parameters for the requested service are incorrect.
0021 to 0027	33 to 39	Future extensions	This is reserved by DeviceNet.
0028	40	Invalid Member ID	The requested member ID designated a class, instance or attribute that is not mounted.
0029	41	Member not settable	The requested setting service designated a write disabled member.
002A to 00CF	42 to 204	–	This is reserved by DeviceNet.
00D0 to 00FF	207 to 225	Reserved for Object Class and service errors	An object class specific error was indicated. The details may be displayed in the additional error code area (W0024/S1024). Refer to the slave station manual for details.

II. DeviceNet Interface

3. Communication Data

(2) Getting the attribute data (Get Attribute)

The gotten attribute data is stored as a byte string.

(3) Setting the attribute data (Set Attribute)

Set the attribute data to be set as a byte string.

(4) Reset

There is no message communication data.

II. DeviceNet Interface

4. Interface with Communication Card (HR871)


4. Interface with Communication Card (HR871)

The interface assignments for the communication card and main system are shown below. The assignment will change according to the interface card mounted in this area.

Slot's local information		HR871 mounting slot	
		Extension slot 1	Extension slot 2
Bit data	HR871 → Main (256 points)	X200 to X27F	X280 to X2FF
	Main → HR871 (256 points)	Y200 to Y27F	Y280 to Y2FF
Word data	(10 words)	R60 to R69	R70 to R79

(Note) This interface assignment differs according to the communication card to be used. Thus, when using the PLC program with another interface card, each mounted communication card must be identified.

(Example of circuit creation)



II. DeviceNet Interface
4. Interface with Communication Card (HR871)

4.1 Outline of Interface Signals

Bit data (HR871 → Main)

Slot 1	Slot 2	Details	Slot 1	Slot 2	Details
X200	X280	(Not used)	X208	X288	(Not used)
X201	X281	Refreshing	X209	X289	(Not used)
X202	X282	Message communication completion	X20A	X28A	(Not used)
X203	X283	Error set	X20B	X28B	(Not used)
X204	X284	Slave down	X20C	X28C	(Not used)
X205	X285	Message communication error	X20D	X28D	(Not used)
X206	X286	Setting parameters	X20E	X28E	(Not used)
X207	X287	Parameter setting completion	X20F	X28F	System ready

Bit data (Main → HR871)

Slot 1	Slot 2	Details	Slot 1	Slot 2	Details
Y200	Y280	(Not used)	Y208	Y288	(Not used)
Y201	Y281	Refresh request	Y209	Y289	(Not used)
Y202	Y282	Message communication request	Y20A	Y28A	(Not used)
Y203	Y283	Error reset request	Y20B	Y28B	(Not used)
Y204	Y284	(Not used)	Y20C	Y28C	(Not used)
Y205	Y285	(Not used)	Y20D	Y28D	(Not used)
Y206	Y286	(Not used)	Y20E	Y28E	(Not used)
Y207	Y287	Parameter set request	Y20F	Y28F	(Not used)

Word data

Slot 1	Slot 2	Details	Slot 1	Slot 2	Details
R60	R70	Mounted card information (0871H)	R65	R75	No. of set parameters
R61	R71	Master communication status	R66	R76	Down station detection prohibit setting
R62	R72	Error information	R67	R77	
R63	R73	(Not used)	R68	R78	
R64	R74	Parameter set Head register No.	R69	R79	

II. DeviceNet Interface

4. Interface with Communication Card (HR871)

4.2 Details of Interface Signals


4.2.1 Refresh Request, Refreshing

B contact	Signal name	Abbreviation	PC	Slot 1	Slot 2	Applicable type
–	Refresh request			Y201	Y281	

This signal turns ON when the details of device B are refreshed on the network. Refreshing starts when the master communication state is "operating". Refreshing will not start if the communication status is "stop" or "clear". Turn this signal OFF to stop refreshing. 0 (or OFF) will be sent forcibly to the network when refreshing stops.

B contact	Signal name	Abbreviation	PC	Slot 1	Slot 2	Applicable type
–	Refreshing			X201	X281	

This signal turns ON when refreshing has started followed by "Refresh request" signal (Y201/Y281) turned ON, and the master communication status being "operating". This signal turns OFF when refreshing stops.



4.2.2 Message Communication Request, Message Communication Completion, Message Communication Error

B contact	Signal name	Abbreviation	PC	Slot 1	Slot 2	Applicable type
–	Message communication request			Y202	Y282	

This signal turns ON during message communication. The signal turns ON after the data (command) is set in the message communication area. This signal turns OFF after the message communication results are received. "Message communication completion" signal (or "Message communication error" signal) turns OFF when this signal turns OFF.

B contact	Signal name	Abbreviation	PC	Slot 1	Slot 2	Applicable type
–	Message communication completion			X202	X282	


This signal turns ON when the message communication for "Message communication request" signal (Y202/Y282) has ended, and the results have been written into the message communication area. If an error occurs during the message communication, "Message communication error" signal will also turn ON. When the message communication request signal turns OFF, this signal will also turn OFF.

II. DeviceNet Interface

4. Interface with Communication Card (HR871)

B contact	Signal name	Abbreviation	PC	Slot 1	Slot 2	Applicable type
–	Message communication error			X205	X285	

This signal turns ON if an error occurs during message communication.
When "Message communication request" signal turns OFF, this signal will also turn OFF.



4.2.3 Error Reset Request, Error Set


B contact	Signal name	Abbreviation	PC	Slot 1	Slot 2	Applicable type
–	Error reset request			Y203	Y283	

"Error set" signal and error code reset are executed when this signal is issued.

B contact	Signal name	Abbreviation	PC	Slot 1	Slot 2	Applicable type
–	Error set			X203	X283	

This signal turns ON when an error occurs and the error code is set in the file register's error information area.

This signal automatically turns OFF when the cause of the error is eliminated.



II. DeviceNet Interface

4. Interface with Communication Card (HR871)

4.2.4 Slave Down

B contact	Signal name	Abbreviation	PC	Slot 1	Slot 2	Applicable type
–	Slave down			X204	X284	

This signal turns ON if there is a slave with inactive communication status.

The signal will turn OFF when the slave with inactive communication status is recovered.

The communication status of each slave station is indicated with "each station communication status (from SD56/from SD88)".

To disable the slave down detection for any slave, designate the slave with the "down station detection prohibit setting (from R66/from R76)".

4.2.5 Parameter Set Request, Setting Parameters, Parameter Setting Completion

B contact	Signal name	Abbreviation	PC	Slot 1	Slot 2	Applicable type
–	Parameter set request			Y207	Y287	

Use this signal to set the parameters with the PLC program.

This signal turns ON after the data is prepared in the parameter send area.

The data is written into the EEPROM when this signal turns ON. The data (set with SyCon2) in the flash ROM is cleared at this time.

"Refreshing" signal (X201/X281) must be OFF to set the parameters.

(Note) If this signal turns ON when "Refreshing" signal (X201/X281) is ON, it will be ignored. In this case, confirm that "Refreshing" signal (X201/X281) is OFF, and then turn this signal ON again.

B contact	Signal name	Abbreviation	PC	Slot 1	Slot 2	Applicable type
–	Setting parameters			X206	X286	

When "Parameter set request" signal is received and the parameter analysis is completed, the parameter write process will start. This signal turns ON during the parameter write process.


Communication is stopped during the parameter write process.

II. DeviceNet Interface

4. Interface with Communication Card (HR871)

B contact	Signal name	Abbreviation	PC	Slot 1	Slot 2	Applicable type
-	Parameter setting completion			X207	X287	

This signal turns ON when the parameter write process is completed.



4.2.6 System Ready

B contact	Signal name	Abbreviation	PC	Slot 1	Slot 2	Applicable type
-	System ready			X20F	X28F	

This signal turns ON when initialization of the module for DeviceNet communication has been completed, and data can be received.

This signal must be ON as a condition for the program related to DeviceNet.

II. DeviceNet Interface

4. Interface with Communication Card (HR871)

4.3 Details of Word Data

4.3.1 Mounted Card Information

B contact	Signal name	Abbreviation	PC	Slot 1	Slot 2	Applicable type
-	Mounted card information			R60	R70	

Information on the card mounted in the expansion slot is set in this signal.
When using the DeviceNet master station card (HR871), 0871 (hexadecimal) is set.

This is used in the PLC program to determine that the DeviceNet master station card (HR871) is mounted.

(Note) The card information may not be set depending on the mounted card.

4.3.2 Master Communication Status


B contact	Signal name	Abbreviation	PC	Slot 1	Slot 2	Applicable type
-	Master communication status			R61	R71	

[High-order byte]

The I/O communication status is indicated. The status values are as follow.
Use this information to confirm that the communication status is "operating" before starting message communication.

Value	Name	Operation
00H	Offline	Initializing
40H	Stop	I/O communication stopped
80H	Clear	Resetting each slave's output data by transmitting 0 data
C0H	Operating	In I/O communication

Each communication status shifts in the following order.




II. DeviceNet Interface

4. Interface with Communication Card (HR871)

[Low-order byte]

Problems in the master are notified with the ON/OFF state of each bit.



4.3.3 Error Information

B contact	Signal name	Abbreviation	PC	Slot 1	Slot 2	Applicable type
–	Error information			R62	R72	

This signal indicates information on the problem, such as a parameter error, which occurred during unit initialization or communication.

When a valid error is set in the register, "Error set" signal (X203/X283) turns ON.

Even if the error information is eliminated, and "Error set" signal is automatically turned OFF, the error information is held. "Error reset request" signal (Y203/Y283) must be turned ON to clear the error information.

[High-order byte]

The error code is indicated. (Refer to section "7.1 Communication error code" for details.)

[Low-order byte]

Station No. (MAC ID) of the station in which problem was detected

Data	Details	Related NC error
FF	Local station (type 1)	L10
FE	Local station (type 2)	L11
0 to 3F (63)	Station No. (MAC ID) of the station in which problem was detected	L12

4.3.4 Parameter Set Head Register No.

B contact	Signal name	Abbreviation	PC	Slot 1	Slot 2	Applicable type
–	Parameter set head register No.			R64	R74	

When setting the configuration parameters with the PLC program, set the head No. of the file register (random) in which the data is stored. For example, if the parameters are set from R4000, set "4000". This data must be set before "Parameter set request" signal is turned ON.

II. DeviceNet Interface

4. Interface with Communication Card (HR871)

4.3.5 No. of Set Parameters

B contact	Signal name	Abbreviation	PC	Slot 1	Slot 2	Applicable type
-	No. of set parameters			R65	R75	

When setting the configuration parameters with the PLC program, set the number of file registers (random) in which the data is stored. For example, if the parameters are set from R4000 to R4019, set "20". This data must be set before "Parameter set request" signal is turned ON.

4.3.6 Down Station Detection Prohibit Setting

B contact	Signal name	Abbreviation	PC	Slot 1	Slot 2	Applicable type
-	Down station detection prohibit setting			R66 to R69	R76 to R79	

Set whether to reflect the down information for each slave station onto "Slave down" signal (X204/X284).

- When corresponding bit is ON : "Slave down" signal does not turn ON even if the station is down.
- When corresponding bit is OFF : "Slave down" signal turns ON when the station is down.

If the slave station is set as a reserved station with the configuration, set the corresponding bit ON. If the bit is not ON, the reserved station will be recognized as a down station, and "Slave down" signal (X204/X284) will turn ON.

Slave station corresponding to each bit					
Slot 1/Slot 2	Bit 15	Bit 14	...	Bit 1	Bit 0
R66/R76	15	14	...	1	0
R67/R77	31	30	...	17	16
R68/R78	47	46	...	33	32
R69/R79	63	62	...	49	48

II. DeviceNet Interface

5. Diagnosis Information

5. Diagnosis Information

The diagnosis information is indicated in the special register SD.
 The details of the diagnosis information are held even when the power is turned OFF.

Slot 1	Slot 2	Details	Slot 1	Slot 2	Details
SD48	SD80	Master communication status	SD56	SD88	Each station's communication status
SD49	SD81	Error information	SD57	SD89	
SD50	SD82	Bus error counter	SD58	SD90	
SD51	SD83	Bus OFF counter	SD59	SD91	
SD52	SD84	Each station's configuration status	SD60	SD92	Each station's trouble status
SD53	SD85		SD61	SD93	
SD54	SD86		SD62	SD94	
SD55	SD87		SD63	SD95	

Slot 1	Slot 2	Details	Slot 1	Slot 2	Details
SD64	SD96	(Not used)	SD72	SD104	Communication PCB version information (ASCII)
SD65	SD97	(Not used)	SD73	SD105	
SD66	SD98	(Not used)	SD74	SD106	
SD67	SD99	(Not used)	SD75	SD107	
SD68	SD100	(Not used)	SD76	SD108	
SD69	SD101	(Not used)	SD77	SD109	
SD70	SD102	(Not used)	SD78	SD110	
SD71	SD103	(Not used)	SD79	SD111	

5.1 Details of Diagnosis Information

5.1.1 Master Communication Status

B contact	Signal name	Abbreviation	PC	Slot 1	Slot 2	Applicable type
–	Master communication status			SD48	SD80	

Refer to section "4.3.2 Master communication status".

5.1.2 Error Information

B contact	Signal name	Abbreviation	PC	Slot 1	Slot 2	Applicable type
–	Error information			SD49	SD81	

Refer to section "4.3.3 Error information".
 The R62/R72 error information is cleared with "Error reset request" signal (Y203/Y283), but the details of this register are held.

II. DeviceNet Interface

5. Diagnosis Information

5.1.3 Bus Error Counter

B contact	Signal name	Abbreviation	PC	Slot 1	Slot 2	Applicable type
-	Bus error counter			SD50	SD82	

The number of times the illegal frame counter for the communication chip (CAN chip) exceeded the limit value (96) is indicated.

5.1.4 Bus OFF Counter

B contact	Signal name	Abbreviation	PC	Slot 1	Slot 2	Applicable type
-	Bus OFF counter			SD51	SD83	

The number of times that bus OFF (communication error) was detected is indicated.

5.1.5 Each Station's Configuration Status

B contact	Signal name	Abbreviation	PC	Slot 1	Slot 2	Applicable type
-	Each station's configuration status			SD52 to SD55	SD84 to SD87	

The status of each slave station's configuration (communication parameter settings) is indicated.

- When corresponding bit is ON : Parameters for that station are set.
- When corresponding bit is OFF : Parameters for that station are not set.

Slot 1/Slot 2	Slave station corresponding to each bit				
	Bit 15	Bit 14	...	Bit 1	Bit 0
SD52/SD84	15	14	...	1	0
SD53/SD85	31	30	...	17	16
SD54/SD86	47	46	...	33	32
SD55/SD87	63	62	...	49	48

II. DeviceNet Interface

5. Diagnosis Information

5.1.6 Each Station's Communication Status

B contact	Signal name	Abbreviation	PC	Slot 1	Slot 2	Applicable type
-	Each station's communication status				SD56 to SD59	SD88 to SD91

The I/O communication status of each slave station is indicated.

- When corresponding bit is ON : I/O communication with that station is taking place normally.
- When corresponding bit is OFF : I/O communication with that station is not taking place normally.

Slave station corresponding to each bit					
Slot 1/Slot 2	Bit 15	Bit 14	...	Bit 1	Bit 0
SD56/SD88	15	14	...	1	0
SD57/SD89	31	30	...	17	16
SD58/SD90	47	46	...	33	32
SD59/SD91	63	62	...	49	48

5.1.7 Each Station's Trouble Status

B contact	Signal name	Abbreviation	PC	Slot 1	Slot 2	Applicable type
-	Each station's trouble status				SD60 to SD63	SD92 to SD95

The status of any communication trouble occurring during communication with each slave station are indicated.

- When corresponding bit is ON : Communication trouble information found.
- When corresponding bit is OFF : Communication trouble information not found.

The communication error information for the corresponding slave station must be read out with the message communication function in order to turn the corresponding bit OFF.

Slave station corresponding to each bit					
Slot 1/Slot 2	Bit 15	Bit 14	...	Bit 1	Bit 0
SD60/SD92	15	14	...	1	0
SD61/SD93	31	30	...	17	16
SD62/SD94	47	46	...	33	32
SD63/SD95	63	62	...	49	48

6. Setting the Communication Parameters

6.1 Setting the Parameters with Configurator

Configuration using SyCon2 is carried out in the following manner.

- (1) Setting the configuration
- (2) Setting the master station parameters
- (3) Setting the bus parameters
- (4) Setting the slave station parameters

Refer to the SyCon2 manual for details on using SyCon2.

6.1.1 Setting the Configuration

Write the configuration of the network to be configured into the file.

Select the master station and slave station device name from the list. If the applicable device is not listed, the EDS file for that device must be read in. The EDS file can be downloaded from the ODVA website.

<http://web.kyoto-inet.or.jp/org/odva-j/>

6.1.2 Setting the Master Station Parameters

Set the following items on the Master Settings screen.

- (1) Startup behavior after system initialization
Always select "Controlled release of the communication by the application program".
- (2) User program monitoring
For Watchdog time, set the time (ms unit) to monitor whether the carrier PCB OS is running properly.
For C64, set a value of 56ms or higher.
- (3) Addressing mode
Set whether to assign the I/O data with a byte unit or word unit.
(Refer to section "3. Communication data".)
- (4) Storage format (word module)
Always select "Little Endian".
- (5) Handshake of the process data
Always select "Buffered, device controlled".
- (6) Hardware parameter
Always select "8 kB dual-port memory".

6.1.3 Setting the Bus Parameters

Set the following items on the Bus Parameter screen

- (1) Baudrate
Set the baud rate.
- (2) MAC ID Master
C64 station No. (MAC ID)
- (3) Heartbeat timeout
Set the interval to recognize the slave existence. (ms)
- (4) Auto Clear mode on
Select this to turn the output from all stations OFF when there is a communication error in any station.

II. DeviceNet Interface

6. Setting the Communication Parameters

6.1.4 Setting the Slave Station Parameters

Set the following items on the Device Configuration screen.

- (1) MAC ID
Set the slave station No.
- (2) Description
Set the slave name.
- (3) Activate device in actual configuration
Set whether the station actually communicates, or if it is a reserved station.
Checking this item will activate the station.
- (4) Actual chosen IO connection
Select the I/O data communication methods.
- (5) UCMM Check
This system is a Group 2 only system, so this cannot be selected.
- (6) Fragmented Timeout
Designate the time to wait for confirming the reception from the slave when carrying out split transmission/reception of messages.
- (7) Expected packet rate
Set the expected packet rate. (Refer to section "8. Details on expected packet rate and production inhibit time".)
- (8) Production inhibit time
Set the production inhibit time. (Refer to section "8. Details on expected packet rate and production inhibit time".)
- (9) Watchdog timeout action
Set the action taken at watchdog timeout.

	Details
Timeout	Timeout : The connection times out. The communication is manually halted, and is not recovered until manually restarted.
Auto delete	Auto delete: The connection is automatically deleted. The communication is halted, and automatically restarted. The output is cleared to 0 once.
Auto reset	Auto reset : Communication continues while holding the connection.

- (10) Configured I/O connection data and its offset address
Designate the I/O module configuration. Designate the method for assigning the input/output data for that I/O module with I.Addr and O.Addr.

II. DeviceNet Interface

6. Setting the Communication Parameters

6.2 Setting the Parameters with the PLC Program

To set the communication parameters with the PLC program, set the data in a random file register (R register).

The set file register's head No. and number (offset) are set in R64 (R74) and R65 (R75) respectively.

The setting item "1st station" and "2nd station" are not the station No. (MAC ID). If three slave stations are connected, set the data in the parameter areas for the 1st station to the 3rd station.

Offset	Item	Details
0	Local station No. (Local station MAC ID)	C64 (master) station No. 0000H to 003FH (0 to 63) If FFFFH is set and the parameters are set, the EEPROM data will be invalidated.
1	Baud rate	Select the baud rate. 1 : 500Kbps, 2 : 250Kbps, 3 : 125Kbps
2	(Reserved for future use)	Fixed to 0
3	(Reserved for future use)	Fixed to 0
4	1st station's slave station No.	Low-order byte : Station No. (MAC ID) for 1st station's slave 0 to 63 High-order byte: 1st station's slave type 01H : Actual communicating station 80H : Reserved station
5	1st station's slave connection type	Select the I/O communication connection type. 0001H: Poling 0002H: Bit strobe 0004H: Change of state 0008H: Cyclic
6	No. of byte module points for 1st station's slave	Low-order byte : No. of input byte modules High-order byte: No. of output byte modules (The bit module is calculated as 8 points equaling to 1 byte module.)
7	No. of word module points for 1st station's slave	Low-order byte : No. of input word modules High-order byte: No. of output word modules
8	No. of double-word module points for 1st station's slave	Low-order byte : No. of input double-word modules High-order byte: No. of output double-word modules
9	Expected packet rate for 1st station (EXPECTED PACKETRATE)	Set the expected packet rate for the 1st station's slave. (Note) 0000H : 500ms (default value) Other than 0000H : Watchdog timer value ... Setting value -1 (ms)
10	Watchdog timeout action for 1st station (WATCHDOG TIMEOUT ACTION)	Select the action taken when a watchdog timeout occurs in the slave. 0000H : (Default value) Same as following timeout. 0001H : Timeout... The connection times out. The communication is manually halted, and is not recovered until manually restarted. 0002H : Auto delete ... The connection is automatically deleted. The communication is halted, and automatically restarted. The output is cleared to 0 once. 0003H : Auto reset ... Communication continues while holding the connection. The output is not cleared to 0.
11	Production inhibit time for 1st station's slave (PRODUCTION INHIBIT TIME)	Set the production inhibit time for the 1st station's slave. (Note) 0000H : 10ms (default value) Other than 0000H : Production inhibit time ... Setting value -1 (ms)
12 to 19		Settings for 2nd station's slave
20 to 27		Settings for 3rd station's slave
:		:
500 to 507		Settings for 63rd station's slave


(Note) Refer to section "8. Details on expected packet rate and production inhibit time" for details on the expected packet rate and production inhibit time.

II. DeviceNet Interface

6. Setting the Communication Parameters

6.2.1 Example of Circuit Creation

An example of creating the circuit when connecting two slave stations is shown below. Since the parameters are written into the EEPROM, they are saved even when the power is turned OFF. Once the program is executed, it does not need to be executed again.




(Continued on next page)

II. DeviceNet Interface

6. Setting the Communication Parameters

(Continued from previous page)



II. DeviceNet Interface

7. Error Displays

7. Error Displays

7.1 Communication Error Codes

Display		Error detected when initializing DeviceNet unit (Type 1: Configuring with SyCon2)
Screen	L10 DN initialization error 1	
7-segment	 →  → 	
Error No.	Details	Countermeasures
0035	 The baud rate setting is not within the valid range.	<ul style="list-style-type: none"> Correctly set the baud rate.
0036	 The local station No. (MAC ID) value is not within the valid range.	<ul style="list-style-type: none"> Set the local station No. between 0 and 63.
0039	 There are two or more stations with the same station No. (MAC ID) in the network.	<ul style="list-style-type: none"> Set the station numbers so that they are not duplicated.
00D2	 The parameters are not set in the communication PCB's flash ROM.	<ul style="list-style-type: none"> This is not particularly a problem when using the EEPROM parameters.

Display		Error detected when initializing DeviceNet unit (Type 2: Configuring with PLC program)
Screen	L11 DN initialization error 2	
7-segment	 →  → 	
Error No.	Details	Countermeasures
0001	 The local station No. (MAC ID) value is not within the range.	<ul style="list-style-type: none"> Set the local station No. within 0000H to 003FH, or to FFFFH.
0002	 The baud rate is not within the valid range.	<ul style="list-style-type: none"> Set a value between 1 and 3.
0003	 The slave station No.'s low-order byte is not within the valid range.	<ul style="list-style-type: none"> Set a value between 0 and 63.
0004	 The slave station No.'s high-order byte is not within the valid range.	<ul style="list-style-type: none"> Set 01H or 80H.
0005	 The connection type is not within the valid range.	<ul style="list-style-type: none"> Set 0001H, 0002H, 0004H or 0008H.
0006	 A slave station with the same station No. as the local station No. is already set.	<ul style="list-style-type: none"> Set the slave station numbers so that they are not duplicated within all stations.
0007	 No slave station is set.	<ul style="list-style-type: none"> Set at least one slave station.
0008	 The total input data length for all slave stations is too long.	<ul style="list-style-type: none"> The total length must be 256 bytes or less for all slave stations.
0009	 The total output data length for all slave stations is too long.	<ul style="list-style-type: none"> The total length must be 256 bytes or less for all slave stations.
000A	 The parameter watchdog timeout action value is illegal.	<ul style="list-style-type: none"> Set 0000H, 0001H, 0002H or 0003H.
000B	 The expected packet rate value is smaller than the production inhibit time value.	<ul style="list-style-type: none"> Set so that the expected packet rate value is greater than or equal to the production inhibit time value.
000C	 EEPROM check sum error	<ul style="list-style-type: none"> Write the parameters again. Do not turn the power OFF or reset the system while writing the parameters.

II. DeviceNet Interface

7. Error Displays

Display			
Screen	L12 DN link error □□□□ □□ Error No. _____ Error detected station No. _____	Error detected during DeviceNet communication process	
	7-segment  →  → (Station No.)		
Error No.		Details	Countermeasures
0001		Network trouble was detected after communication started.	<ul style="list-style-type: none"> Check that the cable is connected correctly.
001E		The slave did not respond.	<ul style="list-style-type: none"> Comprehensively check the state of the network and slave, and check that the MAC ID and baud rate are correct, that the slave is not down, and that the terminator is not disconnected, etc.
0020		The slave responded with an unspecified error.	<ul style="list-style-type: none"> Read the communication error information, read the error information, and take appropriate measures for that error.
0023		The slave responded with an error when establishing the connection.	<ul style="list-style-type: none"> Read the communication error information, read the error information, and take appropriate measures for that error.
0024		The parameter input data size and actual slave size do not match.	<ul style="list-style-type: none"> Check the slave manual and set the correct input data size.
0025		The parameter output data size and actual slave size do not match.	<ul style="list-style-type: none"> Check the slave manual and set the correct output data size.
0026		Response data for a function not supported by the HR871 card was received.	<ul style="list-style-type: none"> Check the slave manual, and set so that functions not supported by HR871 are not sent. Comprehensively check the state of the network and slave, and confirm that the terminator is not disconnected, etc.
0027		The connection is already in the designated mode.	<ul style="list-style-type: none"> Comprehensively check the state of the network and slave, and confirm that the terminator is not disconnected, etc.
0028		Unpredicted illegal data was received when establishing the connection.	<ul style="list-style-type: none"> Comprehensively check the state of the network and slave, and confirm that the terminator is not disconnected, etc.
0029		A connection is already established with that slave.	<ul style="list-style-type: none"> Observe the state for a while, and if the connection cannot be established, reset the slave.
002A		The poling response data length differs from the data length read from the slave when the connection was established.	<ul style="list-style-type: none"> Comprehensively check the state of the network and slave, and confirm that the terminator is not disconnected, etc.
002B		When receiving a split poling response, the first split data was received twice.	<ul style="list-style-type: none"> Comprehensively check the state of the network and slave, and confirm that the terminator is not disconnected, etc.
002C		When receiving a split poling response, the received split data No. differed from the one available.	<ul style="list-style-type: none"> Comprehensively check the state of the network and slave, and confirm that the terminator is not disconnected, etc.
002D		When receiving a split poling response, the middle data or final data was received before receiving the first split data.	<ul style="list-style-type: none"> Comprehensively check the state of the network and slave, and confirm that the terminator is not disconnected, etc.

II. DeviceNet Interface

7. Error Displays

Error No.		Details	Countermeasures
003B		The same station No. (MAC ID) was detected two or more times in the parameters.	<ul style="list-style-type: none">• There are two or more slaves with the same station No. in the parameters. Correct the station numbers.• A slave with the same station No. as the local station No. was found in the parameters.
0045		O.Addr in the parameters exceeds 255.	<ul style="list-style-type: none">• Set O.Addr to 255 or less.
0046		I.Addr in the parameters exceeds 255.	<ul style="list-style-type: none">• Set I.Addr to 255 or less.
0047		An illegal connection type was designated.	<ul style="list-style-type: none">• Confirm that the connection type value is correct.
0049		The expected packet rate value is smaller than the production inhibit time value.	<ul style="list-style-type: none">• Set the expected packet rate value higher than the production inhibit time value.

II. DeviceNet Interface

7. Error Displays

7.2 Message Communication Execution Error Codes

Display		
Screen	L13 DN message communication error <input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/> Error No. _____	Error detected while executing message communication
7-segment	 → <input type="text"/> → 	
Error No.	Details	Countermeasures
0002	 The resources required for executing the required service could not be used.	<ul style="list-style-type: none"> Referring to the slave manual, check the conditions for the slave to notify this error, and remedy accordingly.
0008	 The requested service is not mounted or is not defined for this object class or instance.	<ul style="list-style-type: none"> Check that the designated MAC ID, class ID, instance ID and attribute ID are correct. Referring to the slave manual, check the conditions for the slave to notify this error, and remedy accordingly.
0009	 Invalid attribute data was detected.	<ul style="list-style-type: none"> Check that the designated MAC ID, class ID, instance ID and attribute ID are correct. Referring to the slave manual, check the conditions for the slave to notify this error, and remedy accordingly.
000B	 The object is already in the mode or state requested by the service.	<ul style="list-style-type: none"> Check that the designated MAC ID, class ID, instance ID and attribute ID are correct. Check the current status using attribute get. Referring to the slave manual, check the conditions for the slave to notify this error, and remedy accordingly.
000C	 The object cannot execute the requested service in the current mode or state.	<ul style="list-style-type: none"> Check that the designated MAC ID, class ID, instance ID and attribute ID are correct. Check the current status using attribute get. Referring to the slave manual, check the conditions for the slave to notify this error, and remedy accordingly.
000E	 A request to change a change prohibited attribute was received.	<ul style="list-style-type: none"> Check that the designated MAC ID, class ID, instance ID and attribute ID are correct. Referring to the slave manual, check the conditions for the slave to notify this error, and remedy accordingly.
000F	 The enable/special rights check failed.	<ul style="list-style-type: none"> Check that the designated MAC ID, class ID, instance ID and attribute ID are correct. Referring to the slave manual, check the conditions for the slave to notify this error, and remedy accordingly.
0010	 The requested service cannot be executed in the current device state.	<ul style="list-style-type: none"> Check that the designated MAC ID, class ID, instance ID and attribute ID are correct. Referring to the slave manual, check the conditions for the slave to notify this error, and remedy accordingly.
0011	 The slave did not respond.	<ul style="list-style-type: none"> Comprehensively check the state of the network and slave, and check that the slave is not down, and that the terminator is not disconnected, etc.

II. DeviceNet Interface

7. Error Displays

Error No.		Details	Countermeasures
0013		Sufficient data to execute the designated operation has not been provided.	<ul style="list-style-type: none"> • Check that the designated MAC ID, class ID, instance ID and attribute ID are correct. • When executing attribute set, check that the designated data is not insufficient, and that the data length is correct. • Referring to the slave manual, check the conditions for the slave to notify this error, and remedy accordingly.
0014		The designated attributes are not supported.	<ul style="list-style-type: none"> • Check that the designated MAC ID, class ID, instance ID and attribute ID are correct. • Referring to the slave manual, check the conditions for the slave to notify this error, and remedy accordingly.
0015		The service provided with an unexpected volume of data.	<ul style="list-style-type: none"> • The data returned by the slave must be 240 bytes or less.
0016		The designated object does not exist in the slave.	<ul style="list-style-type: none"> • Check that the designated MAC ID, class ID, instance ID and attribute ID are correct. • Referring to the slave manual, check the conditions for the slave to notify this error, and remedy accordingly.
0032		The response data format is illegal.	<ul style="list-style-type: none"> • Comprehensively check the state of the network and slave, and confirm that the terminator is not disconnected, etc.
0037		The designated slave station No. is not within 0 to 63.	<ul style="list-style-type: none"> • Designate a value between 0 and 63.
0039		The split response order is illegal.	<ul style="list-style-type: none"> • Comprehensively check the state of the network and slave, and confirm that the terminator is not disconnected, etc.
00C8		The parameters are not set for the designated slave.	<ul style="list-style-type: none"> • Designate a slave with which the parameters have been set.
0101		The set data length exceeds 241.	<ul style="list-style-type: none"> • The data length must be 240 or less.
0102		An illegal value was set for the command No. in the message communication command area.	<ul style="list-style-type: none"> • Set 0001H, 0101H, 0102H or 0201H for the command No.

II. DeviceNet Interface

8. Details on Expected Packet Rate and Production Inhibit Time

8. Details on Expected Packet Rate and Production Inhibit Time

	Expected packet rate	Production inhibit time
Poling	(1) The communication watchdog timer value for the slave is set. If communication is cut off at the set time, the slave will carry out the action designated with the watchdog timeout action.	(1) Slave's minimum transmission cycle = Set the minimum time in which the slave can prepare the send data. The master sends the poling request to the slave at this time cycle.
	(2) If the expected packet rate setting value is $\neq 1$, meaning if the expected packet rate $\neq 0\text{ms}$, then the expected packet rate \geq the production inhibit time must be observed.	
	(3) If 1 is set, meaning if the expected packet rate is 0ms , the watchdog timer monitor function is invalid.	(3) The production inhibit time $\geq 3\text{ms}$, or in other words, the setting value ≥ 4 must be observed..
Bit strobe	(1) The communication watchdog timer value for the slave is set. If the communication between the master and slave is cut off at the set time, the slave will carry out the action designated with the watchdog timeout action.	(1) Slave's minimum transmission cycle = Set the minimum time in which the slave can prepare the send data. The master sends the poling request to the slave at this time cycle.
	(2) If the expected packet rate setting value is $\neq 1$, meaning if the expected packet rate $\neq 0\text{ms}$, then the expected packet rate \geq the production inhibit time must be observed.	
	(3) If 1 is set, meaning if the expected packet rate is 0ms , the watchdog timer monitor function is invalid.	(3) The production inhibit time $\geq 3\text{ms}$, or in other words, the setting value ≥ 4 must be observed.
		(4) This value must be the same for all bit strobe connections.
Change of state	(1) 1 must always be set. In other words, the expected packet rate must be set to 0ms .	(1) 1 must always be set. In other words, the production inhibit time must be set to 0ms .
Cyclic	(1) Designate the cycle to send the data from the slave to the master.	(1) Designate the cycle to send the data from the master to the slave.
	(2) If the expected packet rate setting value is $\neq 1$, meaning if the expected packet rate $\neq 0\text{ms}$, then the expected packet rate \geq the production inhibit time must be observed.	
	(3) The expected packet rate $\geq 3\text{ms}$, or in other words, the setting value ≥ 4 must be observed.	(3) The production inhibit time $\geq 3\text{ms}$, or in other words, the setting value ≥ 4 must be observed.

III. CC-Link Master/Local Unit

III. CC-LINK Master/Local Unit

1. Outline

1. Outline

The MELDAS C6/C64 can be directly connected to the network as a MELSEC CC-Link master/local station. The CC-Link master/local unit (HR865) must be mounted in the expansion slot to use this connection. Up to two communication units can be mounted.

2. Performance Specifications

Item	CC-Link master/local unit (HR865)
Transmission speed	156kbps; 625kbps; 2.5Mbps; 5Mbps; 10Mbps selective
Maximum transmission distance	1200m; 600m; 200m; 150m/110m; 100m/80m/50m depending on the transmission speed selected above
Maximum number of connected units	64 units Note that the following conditions must be satisfied: $\{(1 \times a) + (2 \times b) + (3 \times c) + (4 \times d)\} \leq 64$ a : Number of units that occupies 1 station b : Number of units that occupies 2 stations c : Number of units that occupies 3 stations d : Number of units that occupies 4 stations $\{(16 \times A) + (54 \times B) + (88 \times C)\} \leq 2304$ A : Number of remote I/O stations (not more than 64 units) B : Number of remote device stations (not more than 42 units) C : Number of local stations, standby master stations and intelligent device stations (not more than 26 units)
Number of occupied stations (Number of local stations)	1 to 4 stations (change with DIP switch)
Maximum number of link points per system (Note 1)	Remote input/output (RX, RY): 2048 points each for input/output Remote register (RWw): 256 points (master station → remote/local station) Remote register (RWr) : 256 points (remote/local station → master station)
Number of link points per remote station/local station	Remote input/output (RX, RY): 32 points (30 points for local station) Remote register (RWw): 4 points (master station → remote/local station) Remote register (RWr) : 4 points (remote/local station → master station)
Communication method	Poling method
Synchronization method	Frame synchronization method
Coding method	NRZI method
Transmission path format	Bus (RS-485)
Transmission format	HDLC compliant
Error control method	CRC ($X^{16} + X^{12} + X^5 + 1$)
Connection cable	Twisted pair cable with shield
RAS function	<ul style="list-style-type: none"> • Automatic online return function • Slave station cutoff function • Error detection with link special relay/register
Number of occupied input/output points	32 points

(Note 1) When the CC-Link master station is mounted on the C64, the maximum number of remote input/output points may drop slightly depending on the number of device points that can be secured on the C64 side.

III. CC-LINK Master/Local Unit

3. Usable Functions

3. Usable Functions

The following CC-Link functions can be used with the MELDAS C6/C64.

Function item		MELSEC	MELDAS C6/C64
Method	Ver.1	○	○
	Ver.2	○	×
Master functions	Communication with remote I/O station	○	○
	Communication with remote device station	○	○
	Communication with local station	○	○
	Communication with mixed system	○	○
	Reserved station function	○	○
	Error invalid station function	○	○
	Data link status setting at master station CPU error	○	○
	Parameter registration in EEPROM	○	○
	Input data status setting from data link error station	○	○
	Unit reset by sequence program	○	○
	Data link stop/restart	○	○
	Parameter registration function	○	○
	Automatic refresh function	○	○
	Scan synchronization function	Synchronous mode	○
Asynchronous mode		○	○
	Local station	○	○
Setting and display functions	LED diagnosis function	16-point display (A1SJ61QBT11)	16-point display
	Station No. setting	Switches on the front of unit	Setting switch on card
	Baud rate setting		Switch on the front of card
	Mode setting switch		
	Condition setting		
RAS function	Automatic online return function	○	○
	Slave station cutoff function	○	○
	Data link status confirmation (SB/SW)	○	○ Automatic refreshing to SB/SW
	Offline test	○	○
	Online test	○	○
	Monitor diagnosis	○	×
	Standby master function	○	○
	Temporary error invalid station designation function	○	○
Dedicated commands	READ command, SREAD command	○	○
	WRITE command, SWRITE command	○	○
	RIRD command, RIWT command (Note 1)	○	○

(Note 1) Transient execution using this command is applicable only to the software Version D and above.

III. CC-LINK Master/Local Unit

4. Input/output Signals

4. Input/output Signals

The input/output signal device numbers used to control the CC-Link card mounted in the C64 expansion slot with the built-in PLC are determined according to the slot in which the card is inserted.

Slot	Input device number	Output device number
EXT1 (bottom)	X200 to X21F	Y200 to Y21F
EXT2 (top)	X280 to X29F	Y280 to Y29F

Signal direction: Built-in PLC ← master/local card				Signal direction: Built-in PLC → master/local card			
Input No.	Signal name	Usability		Output No.	Signal name	Usability	
		Master station	Local station			Master station	Local station
X2n0	Unit error	○	○	Y2n0	Refresh command	○	○
X2n1	Data link status at host station	○	○	Y2n1	(Prohibited to use)	-	-
X2n2	Parameter setting status	○	×	Y2n2			
X2n3	Data link status at other stations	○	○	Y2n3			
X2n4	Unit reset acceptance complete	○	○	Y2n4	Unit reset request	○	○
X2n5	(Prohibited to use)	-	-	Y2n5	(Prohibited to use)	-	-
X2n6	Data link startup normal completion	○	×	Y2n6	Data link startup request	○	×
X2n7	Data link startup error completion	○	×	Y2n7	(Prohibited to use)	-	-
X2n8	Data link startup by EEPROM parameter normal completion	×	×	Y2n8	Data link startup request from the EEPROM parameters	×	×
X2n9	Data link startup by EEPROM parameter error completion	×	×	Y2n9	(Prohibited to use)	-	-
X2nA	Parameter registration to EEPROM normal completion	×	×	Y2nA	Parameter registration request to EEPROM	×	×
X2nB	Parameter registration to EEPROM error completion	×	×	Y2nB	(Prohibited to use)	-	-
X2nC	(Prohibited to use)	-	-	Y2nC			
X2nD				Y2nD			
X2nE				Y2nE			
X2nF				Y2nF			
X2nF	Unit ready	○	○	Y2nF			

III. CC-LINK Master/Local Unit

4. Input/output Signals

Signal direction: Built-in PLC ← master/local card				Signal direction: Built-in PLC → master/local card			
Input No.	Signal name	Usability		Output No.	Signal name	Usability	
		Master station	Local station			Master station	Local station
X2 (n+1) 0	(Prohibited to use)	-	-	Y2 (n+1) 0	(Prohibited to use)	-	-
X2 (n+1) 1				Y2 (n+1) 1			
X2 (n+1) 2				Y2 (n+1) 2			
X2 (n+1) 3				Y2 (n+1) 3			
X2 (n+1) 4				Y2 (n+1) 4			
X2 (n+1) 5				Y2 (n+1) 5			
X2 (n+1) 6				Y2 (n+1) 6			
X2 (n+1) 7				Y2 (n+1) 7			
X2 (n+1) 8				Y2 (n+1) 8			
X2 (n+1) 9				Y2 (n+1) 9			
X2 (n+1) A				Y2 (n+1) A			
X2 (n+1) B				Y2 (n+1) B			
X2 (n+1) C				Y2 (n+1) C			
X2 (n+1) D				Y2 (n+1) D			
X2 (n+1) E				Y2 (n+1) E			
X2 (n+1) F				Y2 (n+1) F			

○: Usable ×: Not usable

(Note 1) n is either 0 or 8 according to the slot.

(Note 2) Refer to the MELSEC "CC-Link System Master/Local Unit User's Manual" for details on the input/output signals.


Normally only "Refresh command (Y2n0)" signal and "Data link start (Y2n6)" signal with the buffer memory parameters are turned ON.

III. CC-LINK Master/Local Unit

5. Flow of Communication Data

5. Flow of Communication Data

The flow of data communicated with the CC-Link scan is as shown below.



(Note 1) Both master stations and local stations can be used by using the MELSEC CPU.

III. CC-LINK Master/Local Unit


5. Flow of Communication Data

5.1 Automatic Refresh

Data is automatically sent between the CC-Link card and the NC built-in PLC device. The transmission size and the transmission destination device are set with the parameters using the MELSEC peripheral device. An example for setting this with the GX Developer is given below.

The parameters cannot be set with the PLC program, and the system cannot be started with the EEPROM parameters.

When setting the parameters, the network parameters must also be set for the master station.



The setting is invalid. The data will be refreshed automatically to the SB and SW devices.

Set the number designated for each slot as the head I/O No.

The devices that can be set as the transmission destination for automatic refresh are as follow.

Device name	Device range	RX, RY	RWr, RWw
X	X0 to X1FF (Must not be duplicated with actual I/O)	Only RX	×
Y	Y0 to Y1FF (Must not be duplicated with actual I/O)	Only RY	×
M	M0 to M8191	○	○
L	L0 to L255	○	○
B	B0 to B1FFF	○	○
D	D0 to D8191 (Note 1)	○	○
R	R4000 to R4499, R6400 to R7199	○	○
W	W0 to W1FFF	○	○

(Note 1) D0 to D8191 can be used in the software version D0 and above.

SB and SW are automatically refreshed to the internal devices SB and SW. The setting is invalid.

Slot	SB refresh range		SW refresh range	
	Output (C64 → CC-Link)	Input (CC-Link → C64)	Output (C64 → CC-Link)	Input (CC-Link → C64)
EXT1	SB0000 to SB002F	SB0030 to SB00FF	SW0000 to SW003F	SW0040 to SW00FF
EXT2	SB0100 to SB012F	SB0130 to SB01FF	SW0100 to SW013F	SW0140 to SW01FF

III. CC-LINK Master/Local Unit

6. Transient Function


6. Transient Function

6.1 Outline

The transient function does not constantly send data. Instead, the data is written and read to and from arbitrary stations when necessary. The client station must be compatible with the transient function. The C6/C64 is compatible with the READ(SREAD)/WRITE(SWRITE) and RIRD/RIWT commands.

6.2 Transient Command (READ/SREAD/WRITE/SWRITE) Format

	Usable devices																			Index	Digit designation
	Bit device									Word device							Constant	Pointer			
	X	Y	M	L	F	B	SB	T	SM	T	C	D	R	W	SW	Z	SD	K	H		
S1										○	○	○	○	○	○		○				
S2										○	○	○	○	○	○		○				
D1										○	○	○	○	○	○		○				
D2	○	○	○	○	○	○	○		○												
D3	○	○	○	○	○	○	○		○												



(Note) The station targeted for this command is either QnCPU, QnACPU or MELDAS's master/local station.

<Setting data>

READ/SREAD

Setting data	Details
Un	Local station head input/output No.
S1	Head device of local station storing the control data
S2	Head device of target station storing the data to be read
D1	Head device of local station where the read data is to be stored
D2	Local station device that turns 1 scan ON at completion of command
D3	Target station device that turns 1 scan ON at completion of command

WRITE/SWRITE

Setting data	Details
Un	Local station head input/output No.
S1	Head device of local station storing the control data
S2	Head device of local station storing the data to be written
D1	Head device of target station where the written data is to be stored
D2	Local station device that turns 1 scan ON at completion of command
D3	Target station device that turns 1 scan ON at completion of command


(Note) Designate the Un value as U20 for the EXT1 card, and as U28 for the EXT2 card.

III. CC-LINK Master/Local Unit

6. Transient Function

6.3 Transient Command (RIRD/RIWT) Format

	Usable devices																			Index	Digit designation
	Bit device									Word device							Constant	Pointer			
	X	Y	M	L	F	B	SB	T	SM	T	C	D	R	W	SW	Z	SD	K	H		
S										○	○	○	○	○	○		○				
D1										○	○	○	○	○	○		○				
D2	○	○	○	○	○	○	○		○												



(Note) The station targeted for this command is either the QnCPU, QnACPU, ACPU or MELDAS's master/local station.

<Setting data>

RIRD command

Setting data	Details
Un	Local station head input/output No.
S1	Head device of local station storing the control data
D1	Head No. of device storing read data
D2	Device that turns 1 scan ON at completion of read. (D2)+1 device also turns ON at error completion.

RIWT command

Setting data	Details
Un	Local station head input/output No.
S1	Head device of local station storing the control data
D1	Head No. of device storing write data
D2	Device that turns 1 scan ON at completion of write. (D2)+1 device also turns ON at error completion.

(Note) Designate the Un value as U20 for the EXT1 card, and as U28 for the EXT2 card.

6.4 Precautions

- (1) If the target station is MELDAS, only the device memory can be designated in the access code. The buffer memory in the CC-Link unit cannot be designated.
- (2) This command is usable only with the FCU6-HR865 unit card version B and above. A timeout error will occur with earlier card versions.

III. CC-LINK Master/Local Unit


7. Names and Settings of Each CC-Link Card Section

7. Names and Settings of Each CC-Link Card Section

The names and settings of each section on the HR865 are explained in this section.


<Unit drawing>

HR865 CC-Link system




III. CC-LINK Master/Local Unit

7. Names and Settings of Each CC-Link Card Section

No.	Name	Description						
(1)	Condition setting switch 	This switch sets the operation conditions.						
		No.	Setting details	Switch status			Setting validity	
				OFF	ON	Master station (Standby master station)	Local station (Standby master station)	
		SW1	Station type	Master station/local station	Standby master station	(Valid)	(Valid)	
		SW2	(Not used)	Always OFF			–	–
		SW3	(Not used)	Always OFF			–	–
		SW4	Data link error station input data status	Clear	Hold	Valid	Valid	
		SW5 SW6	Number of occupied stations	No. of occupied stations	SW5	SW6	Invalid	Valid
				1 station	OFF	OFF		
				2 stations	OFF	ON		
				3 stations	ON	ON		
		4 stations	ON	OFF				
SW7	(Not used)	Always OFF			–	–		
SW8	(Not used)	Always OFF			–	–		
(2)	Mode switch 	This switch sets the unit operation status.						
		No.	Name	Details	Settability			
					Master station	Local station		
		0	Online	Automatic online return provided when data link is enabled	Yes	Yes		
		1		Link with remote I/O net mode	Yes	No		
		2	Offline	Data link offline state	Yes	Yes		
		3	Line test 1	Line test 1 in offline state	Yes	No		
		4	Line test 2	Line test 2 in offline state	Yes	No		
		5	Parameter confirmation test	Checks the parameter details	Yes	No		
		6	Hardware test	Test of isolated HR865 card	Yes	Yes		
		7	(Not usable)	Used internally; cannot be set.	–	–		
		8	(Not usable)	Used internally; cannot be set.	–	–		
		9	(Not usable)	Used internally; cannot be set.	–	–		
		A	(Not usable)	Setting error ("SW" LED lights)	–	–		
		B	(Not usable)	Setting error ("SW" LED lights)	–	–		
		C	(Not usable)	Setting error ("SW" LED lights)	–	–		
		D	(Not usable)	Setting error ("SW" LED lights)	–	–		
		E	(Not usable)	Setting error ("SW" LED lights)	–	–		
		F	(Not usable)	Setting error ("SW" LED lights)	–	–		

III. CC-LINK Master/Local Unit

7. Names and Settings of Each CC-Link Card Section

No.	Name	Description										
(3)	Transmission speed setting switch 	This switch sets the unit transmission speed.										
		No.	Details									
		0	156 kbps									
		1	625 kbps									
		2	2.5 Mbps									
		3	5 Mbps									
		4	10 Mbps									
		5	Setting error ("SW" "L.ERR" LED lights)									
		6	Setting error ("SW" "L.ERR" LED lights)									
		7	Setting error ("SW" "L.ERR" LED lights)									
		8	Setting error ("SW" "L.ERR" LED lights)									
9	Setting error ("SW" "L.ERR" LED lights)											
(4)	Station No. setting switch 	This switch sets the unit station No.										
		<Setting range> Master station : 0 Local station : 1 to 64 Standby master station : 1 to 64 If a value other than 0 to 64 is set, the "SW" and "L.ERR." LED will turn ON.										
(5)	Connector 	A twisted pair cable is connected here to establish the data link.										
		<table border="1"> <thead> <tr> <th>Pin</th> <th>Signal name</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>DA</td> </tr> <tr> <td>2</td> <td>DB</td> </tr> <tr> <td>3</td> <td>DG</td> </tr> <tr> <td>4</td> <td>SLD</td> </tr> <tr> <td>5</td> <td>FG</td> </tr> </tbody> </table>	Pin	Signal name	1	DA	2	DB	3	DG	4	SLD
Pin	Signal name											
1	DA											
2	DB											
3	DG											
4	SLD											
5	FG											

III. CC-LINK Master/Local Unit

7. Names and Settings of Each CC-Link Card Section

No.	Name	Description						
		No.	LED name	Details	LED display status			
Master station (Standby master station)					Local station (Standby master station)			
Normal	Error	Normal	Error					
(6)		LED1	RUN	ON Unit is in normal state OFF Watchdog timer error	ON	OFF	ON	OFF
		LED2	ERR.	Indicates the status of communication with the station set in parameters ON Communication with all stations error Flicker Station with error communication found	OFF	ON or flicker	OFF	ON or flicker
		LED3	MST	ON Set to master station	ON	–	OFF	–
		LED4	S.MST	ON set to standby master	ON	–	ON	–
		LED5	LOCAL	ON Set to local station	OFF	–	ON	–
		LED6	CPU R/W	ON Communicating with PLC CPU	ON	OFF	ON	OFF
		LED7	L RUN	ON Executing data link	ON	OFF	ON	OFF
		LED8	L ERR.	ON communication error (local station) Flicker Switches 1 to 3 changed during power ON	OFF	ON or flicker	OFF	ON or flicker
		LED9	SW	ON Switch setting is incorrect	OFF	ON	OFF	ON
		LED10	M/S	ON Master station already exists in same line	OFF	ON	–	–
		LED11	PRM	ON Error in parameter details	OFF	ON	–	–
		LED12	TIME	ON Data link monitor timer activated (All stations error)	OFF	ON	–	–
		LED13	LINE	ON Cable is disconnected Transmission path is affected by noise, etc.	OFF	ON	OFF	ON
		LED14		(Not used)	–	–	–	–
		LED15	SD	ON Sending data	ON	OFF	ON	OFF
		LED16	RD	ON Receiving data	ON	OFF	ON	OFF

III. CC-LINK Master/Local Unit

8. Miscellaneous

8. Miscellaneous

8.1 Backing Up CC-Link Related Parameters

The CC-Link related parameters are only network parameters written into from the MELSEC peripheral devices. These parameters are usually stored in a different area than the NC parameters, and are stored in the ladder program area of the NC. To store these network parameters externally, the data must be output and saved with the following methods.

No.	Data output operation	Usable devices
1	Select PC read, then parameters with the MELSEC peripheral device, read the parameters and store them as a file in the personal computer. To write the parameters, carry out PC write in the same manner.	MELSEC peripheral device GPPQ, GPPW, etc.
2	Output the PLC program area with the NC Data Out screen. Output by setting #(99) DATA (ALL2). The data is input with the Data In screen.	External storage device (personal computer, etc.)

8.2 Replacing the CC-Link Card

If any defect is found in the CC-Link card mounted in the NC, the card must be replaced. There are no such parameters on the card which must be saved, so the data does not need to be recovered.

IV. Setting the Ethernet IP Address

IV. Setting the Ethernet IP Address

1. Outline

1. Outline

With this function, the communication parameters can be confirmed and set using the 7-segment LED display and rotary switches mounted on the C6/C64. These parameters, such as the IP address, are required for establishing Ethernet communication with the personal computer to monitor the C6/C64 and carry out setting operations.

2. Explanation of function

2.1 Confirming the IP Address

The IP address, gateway address, subnet mask and port No. set in the parameter area can be confirmed with the 7-segment LED display mounted on the C6/C64.

Set communication parameters confirmed above in the application setting file in the personal computer used to monitor the C6/C64 and carry out settings. When the application is started up, Ethernet communication will start between the C6/C64 and personal computer.

2.2 Initializing the IP Address

The IP address, gateway address, subnet mask and port No. can be initialized using the rotary switches mounted on the C6/C64.

The default values are shown below.

IP address	:	192.	168.	1.	2
Gateway address	:	0.	0.	0.	0
Subnet mask	:	255.	255.	255.	0
Port No.	:	64758			

After initializing the parameters with this function, reboot C6/C64. Ethernet communication will be enabled with the default values.

Set the above default values in the application setting file in the personal computer used to monitor the C6/C64 and carry out settings. When the application is started up, Ethernet communication will start between the C6/C64 and personal computer.

2.3 Setting the IP Address

Once Ethernet communication is established between the C6/C64 and personal computer with the above method, the communication parameters, such as the IP address, can be set on the Parameter Setting screen of the application used for C6/C64 monitoring and setting operations.

After setting the communication parameters, such as the IP address, on the Parameter Setting screen, turn the C6/C64 power OFF once. When the power is turned ON again, Ethernet communication with the new parameter setting values will be possible.

Set the parameters set above in the application setting file in the personal computer used to monitor the C6/C64 and carry out settings. When the application is started up, Ethernet communication will start between the C6/C64 and personal computer using the new parameter setting values.

The IP address, gateway address, subnet mask and port No. can be set using the 7-segment LED display and rotary switches mounted on the C6/C64.

IV. Setting the Ethernet IP Address



3. Operation Procedure

3. Operation Procedure

3.1 Confirming the Address


(Example) Display when parameters are set as follows

IP address	:	192.	255.	11.	3
Gateway address	:	192.	255.	11.	254
Subnet mask	:	255.	255.	255.	0
Port No.	:	64758			



→ The IP address, gateway address, subnet mask and port No. will appear on the 7-segment LED display as shown below.


(Note) The IP address is normally indicated as a decimal, but is displayed as a hexadecimal on the 7-segment LED.



IV. Setting the Ethernet IP Address

3. Operation Procedure

3.2 Initializing the IP Address





IV. Setting the Ethernet IP Address


3. Operation Procedure

3.3 Setting the IP Address


The methods for setting the IP address, gateway address, subnet mask and port No. using the 7-segment LED display and rotary switches mounted on the C6/C64 are explained in this section.





→ The IP address, gateway address, subnet mask and port No. will appear on the 7-segment LED display.



This indicates that the IP address will be set.



(Example)
If the IP address is "C0. FF. 0B. 03", the first "C0" will appear.



The lit dot LED indicates the settable digit.
In this example, the "C" section can be set.

(Continued on next page)



IV. Setting the Ethernet IP Address

3. Operation Procedure

(Continued from previous page)

Change the setting with rotary switch CS2.
(Example: To change "C" to "0")

As CS2 is changed, the settable section will flicker and change.





If the rotary switch CS2 is already set to the required value (example: "0") as shown above, change the switch to another value once, and then reset it to the required value.

In the above case, the rotary switch CS2 was already set to "0", so the setting was changed to "1" once, and then changed to "0" again.



Change the rotary switch from "8" to "9", and change the settable section.

The settable section will change, and the dot LED will move.



Change the setting with rotary switch CS2.
(Example: To change "0" to "A")

As CS2 is changed, the settable section will flicker and change.



(Continued on next page)


IV. Setting the Ethernet IP Address

3. Operation Procedure


(Continued from previous page)

Change the rotary switch CS1 from "9" to "8", and change the settable section.

The settable section will change, and the second IP address delimited with "." will appear.





IP address C0 FF.0B.03



Indicates that the left section can be set.



Change the setting with rotary switch CS2. (Example: To change "F" to "0")

As CS2 is changed, the settable section will flicker and change.



Change the rotary switch CS1 from "8" to "9", and change the settable section.



The settable section will change, and the dot LED will move.



Indicates that the right section can be set.

Change the setting with rotary switch CS2. (Example: To change "F" to "C")

As CS2 is changed, the settable section will flicker and change.



(Continued on next page)


IV. Setting the Ethernet IP Address

3. Operation Procedure


(Continued from previous page)

Change the rotary switch CS1 from "9" to "8", and change the settable section.

The settable section will change, and the third IP address delimited with "." will appear





IP address C0. FF.0B.03





Change the setting with rotary switch CS2. (Example: To change "0" to "1")

As CS2 is changed, the settable section will flicker and change.





Change the rotary switch CS1 from "8" to "9", and change the settable section.

The settable section will change, and the dot LED will move.



Change the setting with rotary switch CS2. (Example: To change "B" to "D")

As CS2 is changed, the settable section will flicker and change.



(Continued on next page)


IV. Setting the Ethernet IP Address

3. Operation Procedure


(Continued from previous page)

Change the rotary switch CS1 from "9" to "8", and change the settable section.

The settable section will change, and the fourth IP address delimited with "." will appear.





IP address C0. FF. 0B.03



Indicates that the left section can be set.



Change the setting with rotary switch CS2. (Example: To change "0" to "3")

As CS2 is changed, the settable section will flicker and change.



Change the rotary switch CS1 from "8" to "9", and change the settable section.



The settable section will change, and the dot LED will move.



Indicates that the right section can be set.

Change the setting with rotary switch CS2. (Example: To change "3" to "6")

As CS2 is changed, the settable section will flicker and change.




(Continued on next page)

IV. Setting the Ethernet IP Address


3. Operation Procedure

(Continued from previous page)

Change the rotary switch CS1 from "9" to "8", and change the settable section.




The 7-segment LED display will change as shown below, and all of the IP address settings set above will be validated.




The display above indicates the gateway address setting.

Change the rotary switch CS1 from "8" to "9".



The first gateway address will appear on the 7-segment LED display.

Gateway address C0.FF.0B.FE




The lit dot LED indicates the settable digit. In this example, the "C" section can be set.


Using the same methods as setting the IP address, select the digit to be set with rotary switch CS1, and change the setting with rotary switch CS2.

The settable section will change as rotary switch CS1 is operated, and the settable section on the 7-segment LED display will flicker and change as the rotary switch CS2 is operated.

Change the rotary switch CS1 from "8" to "9", and change the settable section.



The 7-segment LED display will appear as shown below. All of the gateway addresses set above will be validated.



The display above indicates the subnet mask setting.

(Continued on next page)


IV. Setting the Ethernet IP Address

3. Operation Procedure


(Continued from previous page)

Change the rotary switch CS1 from "9" to "8".

The first subnet mask setting value will appear on the 7-segment LED display.




Subnet mask FF FF. FF. 00



Using the same methods as setting the IP address, select the digit to be set with rotary switch CS1, and change the setting with rotary switch CS2.


The settable section will change as rotary switch CS1 is operated, and the settable section on the 7-segment LED display will flicker and change as the rotary switch CS2 is operated. When the subnet mask has been set to the last digit, the 7-segment LED display will appear as shown below. All of the subnet mask settings set above will be validated.




The display above indicates the port No. setting.

Change the rotary switch CS1 from "8" to "9".

The two high-order digits of the port No. will appear on the 7-segment LED display.




Port No. F C F 6.



Using the same methods as setting the IP address, select the digit to be set with rotary switch CS1, and change the setting with rotary switch CS2.

The settable section will change as rotary switch CS1 is operated, and the settable section on the 7-segment LED display will flicker and change as the rotary switch CS2 is operated. When the port No. has been set to the last digit, the 7-segment LED display will appear as shown below. All of the port No. settings made above will be validated.



Turn the C6/C64 power OFF, set the slide switch SW1 to "OFF", and turn the rotary switch CS1 back to "0".

Turn the C6/C64 power ON.

Ethernet communication using the IP address, gateway address, subnet mask and port No. set with the above operations will be possible.

V. Ethernet 2-channel Connection

V. Ethernet 2-channel Connection

1. Outline

1. Outline

When two Ethernet I/F cards HR876 are mounted in the C6/C64 (hereinafter, C64), two network channels can be connected with Ethernet.


2. Hardware Configuration

The Ethernet I/F card HR876 can be mounted in the C64's internal expansion slot (EXT1, EXT2) and the external expansion slot (EXT3).


2.1 Unit No.

When two Ethernet I/F cards are mounted, unit numbers are assigned to each card to identify the I/F card. The I/F card's mounting state and the unit numbers correspond as shown below.


When mounted in EXT1 and EXT2




When mounted in EXT1 and EXT3




When mounted in EXT2 and EXT3




When mounted in EXT1 only



When mounted in EXT2 only



When mounted in EXT3 only



V. Ethernet 2-channel Connection

2. Hardware Configuration

2.2 Correspondence with Unit Numbers

The operation of the Ethernet I/F card corresponds to each unit No. as indicated below.

Operation	Unit 1	Unit 2
Recommended connection	HMI (Human Machine Interface)	Information network
Corresponding IP address setting	#1926 IP address	#1931 IP address (2)
Corresponding Subnet mask setting	#1927 Subnet mask	#1932 Subnet mask (2)
Corresponding port number setting	#1929 Port number	#1933 Port number (2)
Processing priority	High	Low
Others	IP address setting available off-line	

3. Setting the Parameters

Set the parameters for each Ethernet I/F card on the BASIC SPECIFICATION PARAMETER screen. You can set the parameters from #1926 to #1929 in the off-line mode. (Refer to "Chapter IV. Setting the IP Address" in this manual.)

[BASIC SPECIFICATION PARAMETER]		SETUP PARAM 1.18/21			
#					
1925					
1926	IP address	192.	168.	1.	2
1927	Subnet mask	255.	255.	255.	0
1928	Gateway address	0.	0.	0.	0
1929	Port number				64758
1930	Speed 10M/auto				0
1931	IP address (2)	192.	168.	2.	2
1932	Subnet mask (2)	255.	255.	255.	0
1933	Port number (2)				64758
1934	Speed (2) 10M/auto				1
1935					
1936					
#() DATA (. . .)					
EMG STOP					
BASIC		AXIS	SERVO	SPINDLE	MENU CHANGE

(Note 1) If "#1926 IP address" is not set, "192.168.1.2" will be set as the initial setting.

(Note 2) If you set or change the Ethernet parameters, reboot C64.

4. Precautions

- (1) When two Ethernet cards are mounted, do not use the IP address in the same net ID as correct transmission may be inhibited.
The same net ID refers to when the masked (valid) section is duplicated by the subnet mask.

V. Ethernet 2-channel Connection


5. Supplement

5. Supplement

5.1 Setting the Gateway Address

Routing is not used with the WEP compatible specifications, so the gateway address does not need to be set. To use routing, set "#1927 Gateway address". Routing will be validated for unit 1.

Setting example



5.2 EXT3 Compatible Version

The HR876 Ethernet I/F card can be mounted in the EXT3 with the software version D and above.

VI. Ethernet Interface Communication Function (MELSEC Communication Protocol Section)

VI. Ethernet Interface Communication Function (MELSEC Communication Protocol Section)

1. Outline

1. Outline

This section explains the methods of communication using MELSEC communication protocol (hereinafter, MC protocol) which is one of the Ethernet interface card communication functions.

MC protocol is a MELSEC communication method used to read and write, etc., the data in the MELSEC CPU.


The sequence programs and data in the C6/C64 can be accessed from a MELSEC peripheral device connected by Ethernet using this protocol.

This section generically labels the C6/C64 and MELSEC CPU as the "PLC CPU".

2. Functions for Accessing the PLC CPU with MC Protocol

The main functions for accessing the PLC CPU with MC protocol are explained here.

On the PLC side, the Ethernet unit sends and receives data based on the commands from the client device. Thus, a sequence program for data communication is not required on the PLC CPU side.



VI. Ethernet Interface Communication Function (MELSEC Communication Protocol Section)

2. Functions for Accessing the PLC CPU with MC Protocol

(1) Reading and writing data

This function reads and writes data to and from the device memory of the PLC CPU in the local station or other station on MELSECNET/10, and to and from the intelligent function unit's buffer memory. By reading and writing the data, the PLC CPU's operation can be monitored, data can be analyzed, and production can be controlled with the client device. In addition, production commands, etc., can be issued from the client device.

(2) Reading and writing files

This function reads and writes the files, such as the sequence programs and parameters, stored in the PLC CPU. By reading and writing the files, the PLC CPU files can be controlled with the client device. The execution programs, etc., can be changed (interchanged) from the client device.

(3) PLC CPU remote control

This function executes remote RUN/STOP. Remote operation of the PLC CPU from the client device is possible using the PLC CPU remote control function.

(4) Accessing other stations' PLC using data link command

The PLC CPU can exchange data with PLC CPUs in the following stations using the data link commands. Note that the only data link commands supported by C6/C64 are READ, SREAD/WRITE and SWRITE.

- Other station's PLC CPU on same Ethernet
- Other Ethernet via MELSECNET/H or MELSECNET/10, or PLC CPU on MELSECNET/H or MELSECNET/10
(Use MELSECNET/H or MELSECNET/10 relay communication function)

(Note) The MELSECNET/H cannot be connected directly to C6/C64.


VI. Ethernet Interface Communication Function (MELSEC Communication Protocol Section)
3. Example of Connection Configuration

3. Example of Connection Configuration

An example of the actual connection configuration is shown below.

3.1 Example of Connecting Peripheral Devices on Single Network


This is the most simple configuration for connecting peripheral devices with Ethernet.



3.2 Example of Connecting Peripheral Devices to a Multilevel Network

This configuration connects peripheral devices to a multilevel network consisting of Ethernet and MELSECNET /10.

The communication settings for other stations are set on the peripheral device side in this case.




VI. Ethernet Interface Communication Function (MELSEC Communication Protocol Section)

3. Example of Connection Configuration

3.3 Example of Connecting MELSEC CPU and C6/C64 to a Multilevel Network

This configuration connects the MELSEC CPU and C6/C64 to a multilevel network consisting of Ethernet and MELSECNET /10.

Each can access (read/write) each other's devices.



VI. Ethernet Interface Communication Function (MELSEC Communication Protocol Section)

4. Setting the Parameters

4. Setting the Parameters

4.1 Setting the NC Side

The local station's IP address is set with the NC.

The IP address set here is shared with the other Ethernet communication functions (GOT connection, etc.).

Parameter No.	Parameter name	Setting example
#1926	IP address	192. 182. 1. 2
#1927	Subnet mask	255. 255. 255. 0
#1928	Gateway address	192. 182. 1. 254
#1929	Port number	64758

4.2 Setting the GX Developer Side

4.2.1 Setting the Network Parameters

The network parameters set with the GX Developer are included in the parameter files.

The parameter files set here are written into the target C6/C64.

These settings include the MELSECNET/10 routing parameters.

Set the following value for the head I/O No. according to the slot in which the Ethernet unit is inserted.

Inserted slot	Head I/O No.
EXT1 (bottom)	200
EXT2 (top)	280


(Note) When C6/C64 is set, the NC parameter setting is validated for the IP address, and the IP address set with this network parameter is invalidated.

VI. Ethernet Interface Communication Function (MELSEC Communication Protocol Section)

4. Setting the Parameters

4.2.2 Setting the GX Developer Connection Destination

These parameters set the GX Developer connection method. These parameters are included in the GX Developer project data.



5. Comparison of Functions

A comparison of the functions with the Ethernet unit mounted in the MELSEC CPU is given below.

Function	C6/C64	MELSEC (Note 2)
Communication with MC protocol	○	○
Communication with fixed buffers	×	○
Communication with random access buffer	×	○
Sending/receiving by e-mail	×	○
Communication with data link buffer (data link command)	○ (Note 1)	○
File transmission (FTP server function)	×	○
Communication with Web function	×	○
MELSECNET/H, MELSECNET/10 relay communication	Automatic response method	○
	IP address calculation method	○
	Table conversion method	○
	Combined method	○
Router relay communication (router relay function) (Note 3)	×	○
Client device existence check	×	○
Communication with pairing open	×	○
Communication with automatic open UDP port	○	○
Simultaneous broadcast communication	×	○
Compliance with QCPU remote password function	×	○
Multi-CPU system compliance	×	○
Ethernet parameter setting using GX Developer	○	○
Access to QCPU using GX Developer (TCP/IP or UDP/IP)	○	○

(Note 1) Only the READ, SREAD, WRITE, and SWRITE commands are supported.

(Note 2) Compliance with each MELSEC function depends on the CPU model.

(Note 3) If the network is configured with only one router installed for each network, the units can communicate with each other across routers even without the router relay function.

VI. Ethernet Interface Communication Function (MELSEC Communication Protocol Section)
6. Performance Specifications

6. Performance Specifications

The Ethernet unit (FCU6-EX875) performance specifications are as shown below.

	Item	Specifications
Transmission specifications	Interface	10BASE-T (RJ-45)
	Transmission method	Base band
	Maximum segment length	100 m
	Maximum number of nodes/connection	Up to four levels with cascade connection
Transmission/reception data storage memory	Number of simultaneously opened connections	8 connections
	Fixed buffer	—
	Random access buffer	—
	e-mail	—

VII. Ethernet Interface Communication Function Using PLC (Client Function Section)

VII. Ethernet Interface Communication Function Using PLC (Client Function Section)

1. Outline

1. Outline

Using the built-in PLC dedicated commands, this function sends and receives the PLC device data to and from the devices (host computer, etc.) connected with Ethernet.

The communication method (protocol) can be selected from TCP/IP or UDP/IP for each connection.

The following four dedicated commands are used with this function.

Dedicated command	Function
OPEN	Establishes (opens) a connection with the client device with which data is to be communicated.
BUFSND	Sends data to the client device.
BUFRCV	Reads data received from the client device.
CLOSE	Ends (closes) the connection with the client device with which data is being communicated.

The following two communication procedures (protocol) are available for communicating with the client device. These can be selected for each connection.

Protocol type	Communication procedure
Procedural	Data is communicated while establishing a handshake with the client device. A response must be made to the communication request. The maximum send data size is 1017 words.
Non-procedural	No response is made in respect to the data reception. The maximum send data size is 2046 bytes.

2. Detailed Explanation


2.1 Connection No. in Connecting with Client Device

The client device with which data is communicated is connected with a connection port identified with a connection No.

Up to eight connections, with connection No. 1 to 8, can be opened simultaneously.

One connection only allows to be connected for either sending or receiving data. Thus, two connection numbers are required when sending and receiving data to and from the client device.

Once the connection is closed, it can be switched to another client device.



VII. Ethernet Interface Communication Function Using PLC (Client Function Section)

2. Detailed Explanation

2.2 Control Signals

Control signals are assigned to control the Ethernet I/F card from the built-in PLC. These control signal devices' are automatically assigned as shown below according to the slot in which the Ethernet I/F card is mounted. When two Ethernet I/F cards are mounted, the control signals are assigned to the devices with the smaller number.

Ethernet I/F card mounting position	Devices to which control signals are assigned
EXT1 (bottom built-in slot)	From X200/From Y200
EXT2 (top built-in slot)	From X280/From Y280
EXT3 (left external slot)	From X300/From Y300

Device No.	Details	Device No.	Details
X200 /X280 /X300	Initialization normal completion	Y200 to Y20F /Y280 to Y28F /Y300 to Y30F	Blank
X210 to X217 /X290 to X297 /X310 to X317	Connections 1 to 8 Open completion	Y210 to Y21F /Y290 to Y29F /Y310 to Y31F	Blank
X220 to X227 /X2A0 to X2A7 /X320 to X327	Connections 1 to 8 Data reception status	Y220 to Y22F /Y2A0 to Y2AF /Y320 to Y32F	Blank

2.3 Response Monitor Timer

When the send connection is opened with "procedural", once the data is sent, the Ethernet I/F card will wait for a response from the client device to which the data was sent. The maximum value for this wait time is set as the response monitor timer value. If a response is not received within the set timer value time, the BUFSND command will end as an error. (The control data completion status will become C022_H.)

The response monitor timer is set in the following file register.



File register No.	Details	Setting range	Default value	Setting unit
R123	Response monitor timer	2 to 32767	60	500 ms

VII. Ethernet Interface Communication Function Using PLC (Client Function Section)

2. Detailed Explanation

2.4 Transmission Control Method

The method of control when sending data from the Ethernet I/F card to the client device is explained below using connection 1 as an example.





VII. Ethernet Interface Communication Function Using PLC (Client Function Section)

2. Detailed Explanation

2.5 Reception Control Method

The method of control when receiving data from the client device is explained below using connection 1 as an example.




VII. Ethernet Interface Communication Function Using PLC (Client Function Section)

3. Data Format

3. Data Format

The data format used when communicating data between the Ethernet I/F card and client device is explained in this section.

The communication data consists of the "header" and "application data" as shown below.



3.1 Header


The header is for TCP/IP and UDP/IP. The header is automatically added and deleted within the Ethernet I/F card, and does not need to be set in the program.

3.2 Application Data

The application data format differs according to the procedure setting.

(1) For procedural


When procedural is selected, the format is as shown below.



(a) Sub-header

The sub-header format is shown below.

The sub-header is automatically added and deleted within the Ethernet I/F card, and does not need to be set in the program.



VII. Ethernet Interface Communication Function Using PLC (Client Function Section)

3. Data Format

(b) Data length setting section

The data capacity of the text (command) section is indicated. (Indicate in number of words.)

(c) Text

This is the text section actually to be sent.


(d) End code

When the client device normally receives the data, the end code indicates 00H. If an error occurs, a corresponding error code is entered. The following end codes are used.

End code	Details
00 _H	Normal completion
50 _H	Command/response type in sub-header is not specified code.

(2) For non-procedural

When non-procedural is selected, all of the data is handled as valid text.



Application data section Max. 2046 bytes


VII. Ethernet Interface Communication Function Using PLC (Client Function Section)

4. Details of Dedicated Commands

4. Details of Dedicated Commands

4.1 OPEN Command

	Usable devices																			Index	Digit designation
	Bit device									Word device							Constant	Pointer			
	X	Y	M	L	F	B	SB	T	SM	T	C	D	R	W	SW	Z	SD	K	H		
S1											○	○	○	○	○		○	○	○		
S2											○	○	○	○	○		○				
D1		○	○	○	○	○	○		○												



Setting data

Setting data	Details	Data type
"Un"	Head input/output No. for Ethernet I/F card	BIN16 bit
S1	Connection No. (1 to 8)	BIN16 bit
S2	Head device of local station storing control data	BIN16 bit
D1	Local device that turns 1 scan ON at completion of command. (D1)+1 device also turns ON at error completion.	Bit

Control data

Device	Item	Setting data	Setting range	Setting side															
(S2) + 0	Execution type/ completion type	Fix to a setting not used by GX Developer.	8000 _H	User															
(S2) + 1	Completion status	The status at completion is stored. 0000 _H : Normal completion Other than 0000 _H : Error completion (error code)	–	System															
(S2) + 2	Application setting area	Designate the connection application. <table border="1" style="margin-left: 20px;"> <tr> <td style="text-align: center;">b15</td> <td style="text-align: center;">b9</td> <td style="text-align: center;">b8</td> <td style="text-align: center;">b1</td> <td style="text-align: center;">b0</td> </tr> <tr> <td style="text-align: center;">□</td> <td style="text-align: center;">□</td> <td style="text-align: center;">(5)</td> <td style="text-align: center;">(4)</td> <td style="text-align: center;">□</td> </tr> <tr> <td></td> <td></td> <td></td> <td></td> <td style="text-align: center;">(1)</td> </tr> </table> <p>(1) Buffer application (bit 0) 0 : Transmission 1 : Reception (4) Communication method (bit 8) 0 : TCP/IP 1 : UDP/IP (5) Communication procedure (bit 9) 0 : Procedural 1 : Non-procedural</p>	b15	b9	b8	b1	b0	□	□	(5)	(4)	□					(1)	(Indicated on the left)	User
b15	b9	b8	b1	b0															
□	□	(5)	(4)	□															
				(1)															


VII. Ethernet Interface Communication Function Using PLC (Client Function Section)

4. Details of Dedicated Commands

Device	Item	Setting data	Setting range	Setting side
(S2) + 3	Blank		0	
(S2) + 4 to (S2) + 5	Client device IP address	Designate the client device's IP address. (Set 0xA8C00101 for IP = 168.192.1.1)	1 _H to FFFFFFFF _H	User
(S2) + 6	Client device port No.	Designate the port No. for the client device.	1025 to 65535	User
(S2) + 7 to (S2) + 9	Blank		0	

4.2 CLOSE Command

	Usable devices																		Index	Digit designation	
	Bit device									Word device							Constant				Pointer
	X	Y	M	L	F	B	SB	T	SM	T	C	D	R	W	SW	Z	SD	K			H
S1											○	○	○	○	○		○	○	○		
S2											○	○	○	○	○		○				
D1		○	○	○	○	○	○		○												



Setting data

Setting data	Details	Data type
"Un"	Head input/output No. for Ethernet I/F card	BIN16 bit
S1	Connection No. (1 to 8)	BIN16 bit
S2	Head device of local station storing control data	BIN16 bit
D1	Local device that turns 1 scan ON at completion of command. (D1)+1 device also turns ON at error completion.	Bit

Control data


Device	Item	Setting data	Setting range	Setting side
(S2) + 0	System area	–	–	–
(S2) + 1	Completion status	The status at completion is stored. 0000 _H : Normal completion Other than 0000 _H : Error completion (error code)	–	System

VII. Ethernet Interface Communication Function Using PLC (Client Function Section)

4. Details of Dedicated Commands

4.3 BUFSND Command

	Usable devices																			Index	Digit designation		
	Bit device									Word device							Constant		Pointer				
	X	Y	M	L	F	B	SB	T	SM	T	C	D	R	W	SW	Z	SD	K	H			P	
S1											○	○	○	○	○		○	○	○				
S2											○	○	○	○	○		○						
S3											○	○	○	○	○		○						
D1		○	○	○	○	○	○		○														



Setting data

Setting data	Details	Data type
"Un"	Head input/output No. for Ethernet I/F card	BIN16 bit
S1	Connection No. (1 to 8)	BIN16 bit
S2	Head device of local station storing control data	BIN16 bit
S3	Head No. of device to store the data to be sent	BIN16 bit
D1	Local device that turns 1 scan ON at completion of command. (D1)+1 device also turns ON at error completion.	Bit

Control data

Device	Item	Setting data	Setting range	Setting side
(S2) + 0	System area	–	–	–
(S2) + 1	Completion status	The status at completion is stored. 0000 _H : Normal completion Other than 0000 _H : Error completion (error code)	–	System

Send data


Device	Item	Setting data	Setting range	Setting side
(S3) + 0	Send data length	Designate the send data length. Designate the data length according to the communication procedure.		User
		Procedural : No. of words	1 to 1017	
		Non-procedural : No. of bytes	1 to 2046	
(S3) + 1 to (S3) + n	Send data	Designate the send data.	–	User

VII. Ethernet Interface Communication Function Using PLC (Client Function Section)

4. Details of Dedicated Commands

4.4 BUFRCV Command

	Usable devices																			Index	Digit designation		
	Bit device									Word device							Constant		Pointer				
	X	Y	M	L	F	B	SB	T	SM	T	C	D	R	W	SW	Z	SD	K	H			P	
S1											○	○	○	○	○		○	○	○				
S2											○	○	○	○	○		○						
D1											○	○	○	○	○		○						
D2		○	○	○	○	○	○		○														



Setting data

Setting data	Details	Data type
"Un"	Head input/output No. for Ethernet I/F card	BIN16 bit
S1	Connection No. (1 to 8)	BIN16 bit
S2	Head device of local station storing control data	BIN16 bit
D1	Head No. of device to store the received data	BIN16 bit
D2	Local device that turns 1 scan ON at completion of command (D1)+1 device also turns ON at error completion.	Bit

Control data

Device	Item	Setting data	Setting range	Setting side
(S2) + 0	System area	–	–	–
(S2) + 1	Completion status	The status at completion is stored. 0000 _H : Normal completion Other than 0000 _H : Error completion (error code)	–	System

Received data

Device	Item	Setting data	Setting range	Setting side
(D1) + 0	Received data length	Designate the received data length. Designate the data length according to the communication procedure.		System
		Procedural : No. of words	1 to 1017	
		Non-procedural : No. of bytes	1 to 2046	
(D1) + 1 to (D1) + n	Received data	Designate the received data.	–	System

VII. Ethernet Interface Communication Function Using PLC (Client Function Section)

4. Details of Dedicated Commands

4.5 Details of Error Codes

The errors that occur when each dedicated command is executed, along with the error codes, are as shown below.

Error code	Details	OPEN	BUFSND	BUFRCV	CLOSE
2111 _H	The input/output No. is not 20, 28, or 30. The head character of the input/output No. is not "U". The Ethernet I/F card is not mounted in the designated slot.	○	○	○	○
4100 _H	The device designation in the command is illegal.	○	○	○	○
C014 _H	The initialization process or open process is not completed.		○	○	
C017 _H	An error occurred when opening the TCP connection.	○			
C020 _H	The data length exceeds the tolerable range.		○	○	
C021 _H	An error completion response was received.		○		
C022 _H	The response was not received within the response monitor timer value.		○		
C030 _H	A transmission error occurred.		○		
C033 _H	A client device with the set IP address does not exist.	○			
C1A6 _H	BUFSND was executed in a connection opened for reception. BUFRCV was executed in a connection opened for transmission. An opened connection was tried to be opened again. The connection No. is not within the specified range.	○	○	○	○

4.6 Precautions for Programming

- (1) Even if the dedicated commands (OPEN, CLOSE, BUFSND, BUFRCV) are executed with the high-speed PLC, the actual operation will take place at the same timing as the medium-speed PLC. Thus, the dedicated command should be executed with the medium-speed PLC.
- (2) Do not update the BUFSND command transmission buffer until the command is completed. Failure to observe this could result in malfunctions.
- (3) Refer to the BUFRCV command reception buffer after the command is completed. Failure to observe this could result in malfunctions.
- (4) Open transmission using TCP after the client device's reception has been opened. If transmission is opened before reception is opened, an error completion (completion status C033) will occur. If transmission is opened for a client device with a nonexistent IP address, an error completion (completion status C033) will occur after one minute.
- (5) If a connection opened with TCP is closed, and is tried to be opened again within a minute, an error completion (completion status C017) will occur. Wait a while before opening the connection again.
- (6) If the connection No. is not within the specified range, an error completion (completion status C1A6) will occur, but the completion device and completion device +1 will not turn ON.

VII. Ethernet Interface Communication Function Using PLC (Client Function Section)


5. Example of Data Communication Program

5. Example of Data Communication Program

The following is an example of the program that executes sending (BUFSND) and receiving (BUFRCV). UDP/IP, non-procedural type are used for both commands.


The send destination IP address is 192.168.1.3, and the applicable port No. is 6000. Connection 5 is used. In the actual program, the send data is set in R500 and above.

For the reception, the port No. is 6001, and connection 1 is used.



VII. Ethernet Interface Communication Function Using PLC (Client Function Section)

5. Example of Data Communication Program



VIII. MELSEC Q Series I/O/Intelligent Function Unit Connection Function

VIII. I/O/Intelligent Function Unit Connection Function

1. Outline

1. Outline

This function is for connecting an I/O unit / intelligent function unit of MELSEC-Q series to the NC (MELDAS C6/C64).

2. Basic Specification

By adding a Q bus bridge card HR863, connection with the following specifications becomes possible. Only one Q bus bridge card can be mounted, but the maximum 4 extension base units can be mounted on the Q bus bridge card. The maximum number of slots (No. of units) is 24.

MELSEC I/O connection basic specification

Item	Basic specification
The numbers of I/O points	The maximum number of input points: 512 points The maximum number of output points: 512 points
Access to buffer memory of intelligent unit	The accessible size of MELSEC intelligent unit's buffer memory per scan is up to 12k words with FROM/TO command from the built-in PLC of C6/C64.

Connectable MELSEC units

Product	Model	Description	
Input unit	AC	QX10	100-120VAC/7-8mA, 16 points, response time: 20ms, terminal block
		QX28	240VAC, 8 points, terminal block
	DC	QX40	24VDC/4mA, positive common, 16 points, response time: 1/5/10/20/70ms, terminal block
		QX40-S1	24VDC, 16 positive common input points, terminal block for high-speed input (Possible to set the response time to 0.1ms.)
		QX41	24VDC/4mA, positive common, 32 points, response time: 1/5/10/20/70ms, connector
		QX42	24VDC/4mA, positive common, 64 points, response time: 1/5/10/20/70ms, connector
		QX80	24VDC/4mA, negative common, 16 points, response time: 1/5/10/20/70ms, terminal block
QX81	24VDC/4mA, negative common, 32 points, response time: 1/5/10/20/70ms, connector		
Output unit	Contact	QY10	240VAC/24VDC, 2A/point, 8A/common, 16 points (16 points/common), output delay:12ms, without fuse, terminal block
		QY18A	240VAC/24VDC 2A, 8 independent output points, terminal block, without fuse
	AC triac	QY22	240VAC, 0.6A, 16 points, terminal block, without fuse
	Transistor (Sink)	QY40P	12/24VDC, 0.1A/point, 1.6A/common, 16 points (16 points/common), output delay:1ms, terminal block, with short protection function
		QY41P	12/24VDC, 0.1A/point, 2A/common, 32 points (32 points/common), output delay:1ms, connector, with short protection function
		QY42P	12/24VDC, 0.1A/point, 2A/common, 64 points (32 points/common), output delay:1ms, connector, with short protection function
		QY50	12/24VDC, 0.5A/point, 4A/common, 16 points (16 points/common), output delay:1ms, with fuse, terminal block
	Transistor	QY68A	5-24VDC, 2A/point, 8A/unit, 8 points, all points independent, sink/source, terminal block, without fuse
	TTL CMOS (Sink)	QY70	5/12VDC, 16mA/point, 16 points (16 points/common), output delay:0.3ms, with fuse, terminal block
		QY71	5/12VDC, 16mA/point, 32 points (32 points/common), output delay:0.3ms, with fuse, connector
	Transistor (Source)	QY80	12/24VDC, 0.5A/point, 4A/common, 16 points (16 points/common), output delay:1ms, with fuse, terminal block
QY81P		12/24VDC, 0.1A/point, 2A/common, 32 points (32 points/common), output delay:1ms, connector, with short protection function	

VIII. I/O/Intelligent Function Unit Connection Function

2. Basic Specification

Intelligent unit

Product	Model	Description
FL-net (OPCN-2) unit	QJ71FL71-T-F01	
	QJ71FL71-B5-F01	
	QJ71FL71-B2-F01	
AS-i master unit	QJ71AS92	Supports AS-i Standard Ver.2.11

Others

Product	Model	Description
Extension base unit	Q63B	Power supply + 3 I/O slots, for mounting on Q series unit
	Q65B	Power supply + 5 I/O slots, for mounting on Q series unit
	Q68B	Power supply + 8 I/O slots, for mounting on Q series unit
	Q612B	Power supply + 12 I/O slots, for mounting on Q series unit
Power supply unit	Q61P-A1	100-120VAC input/5VDC 6A output
	Q61P-A2	200-240VAC input/5VDC 6A output
	Q62P	100-240VAC input/5VDC 3A, 24VDC/0.6A output
	Q63P	24VDC input/5VDC 6A output
	Q64P	100-120/200-240VAC input, 5VDC 8.5A output

(Note 1) Maximum 4 extension base units can be mounted.

(Note 2) Extension base unit without power supply cannot be used.

VIII. I/O/Intelligent Function Unit Connection Function


3. Detailed Explanation

3. Detailed Explanation

3.1 Connection

Connect the NC and the MELSEC units as shown below.


MELSEC unit connection



3.2 Allocation of I/O I/F (Interface)

The I/O I/F between C6/C64 and MELSEC unit is 512 points (X000 to X1FF) for input and 512 points (Y000 to Y1FF) for output.


By using the following devices in the built-in PLC of C6/C64, you can access to the I/O of the MELSEC units. The device number to each unit is determined by the I/O number of each unit. The I/O No. of each unit is expressed in HEX. The left end slot, which is the closest to the power supply unit, of the first extension base unit is 0H. To find the I/O No. of the next unit (the one on the right hand of the first unit), add the number of I/O points of the first unit (the one on the left hand) and express it in HEX. (A slot without a unit also occupies 16 points.) Refer to the next page for calculation examples.



VIII. I/O/Intelligent Function Unit Connection Function

3. Detailed Explanation

(1) Example of calculation of I/O numbers and device numbers




VIII. I/O/Intelligent Function Unit Connection Function

3. Detailed Explanation


(2) MELSEC I/O unit connection and access devices from C6/C64

The followings are examples of device correspondence of C6/C64.

(E.g. 1) When only I/O units are mounted



(E.g. 2) When intelligent function units and I/O units are mounted




VIII. I/O/Intelligent Function Unit Connection Function

3. Detailed Explanation

3.3.3 Restrictions in Using FROM/TO Commands

Using FROM/TO command by the built-in PLC in C6/C64 has the restrictions below.

- (1) The number of FROM and TO commands that can be used in one scan (including multiple program) is 50 each. Using more than 50 will cause the alarm "Q01 EMERGENCY STOP LAD 0005", and will stop the built-in PLC.
- (2) The accessible size of buffer memory in one scan (including multiple program) by FROM/TO command is up to 12k words. Exceeding 12k words will cause the alarm "Q01 EMERGENCY STOP LAD 0006", and will stop the built-in PLC.
- (3) Actual transfer from the buffer memory to read devices by FROM command, and transfer from write devices to the buffer memory by TO command are done at the execution of END command. (In multiple programs, at the execution of END command at the end of all the programs.) Thus, device data renewal will be delayed by 1 scan.



- (4) FROM/TO commands cannot be used in high-speed program processing. If FROM/TO command is executed in high-speed program processing, the alarm "Q01 EMERGENCY STOP LAD 0007" will occur and the built-in PLC will stop.
- (5) If bit device is used for FROM/TO command, the only available unit for designation is 16 bits. If bit device is not designated in the unit of 16 bits, the alarm "Q01 EMERGENCY STOP LAD 0008" will occur and the built-in PLC will stop.

Correct example : FROM H0 H1C00 K4B20 K32
TO H0 H1C80 K4M64 K32

Incorrect example : FROM H0 H1C00 K4B28 K32 → "Q01 EMERGENCY STOP LAD 0008"
TO H0 H1C80 K4M100 K32 → "Q01 EMERGENCY STOP LAD 0008"

VIII. I/O/Intelligent Function Unit Connection Function

3. Detailed Explanation


3.3.4 Access to I/O of Intelligent Function Units

MELSEC intelligent function unit occupies I/O as I/O units do, and the I/O controls the unit itself or judges the status.

In an access from C6/C64's built-in PLC to I/O of an intelligent function unit, use X000 to X1FF and Y000 to Y1FF (the I/O I/F).

Device numbers are determined by I/O numbers allocated to the intelligent function unit.

Each device number will be "I/O number + 00 to 1F".



The I/O devices of each intelligent unit in the case that the units are mounted as shown in the figure above are as follows.

Intelligent unit	Input devices	Output devices
FL-net unit 1	X000 to X01F	Y000 to Y01F
AS-i master unit	X020 to X03F	Y020 to Y03F



VIII. I/O/Intelligent Function Unit Connection Function

4. Other Notices

4. Other Notices

4.1 Notices in Connecting Remote I/O Unit

- (1) When a remote I/O unit is connected, the priority is on the input signals from the remote I/O unit. If a remote I/O unit that occupies 32 points is connected to Channel 1 for remote I/O as shown in the figure below, the I/O signals from MELSEC (X000 to X01F) will be ignored, and the I/O signals from the remote I/O unit will be validated. As for output signals, the same signals are output to the remote I/O unit and MELSEC.





VIII. I/O/Intelligent Function Unit Connection Function

4. Other Notices

- (2) When intelligent function unit and remote I/O unit are connected

When an intelligent function unit is used, access to the unit's buffer memory needs to be controlled by I/O signals from the unit, so access to the unit may not be done properly if I/O signals from the remote I/O unit lap over.

To use an intelligent function unit and remote I/O unit together, connect the remote I/O unit to Channel 2, so that their I/O signals will not lap over.



VIII. I/O/Intelligent Function Unit Connection Function

4. Other Notices

4.2 Built-in PLC's Scan Time

As mentioned in the section of restrictions, up to 50 FROM/TO commands are available in one scan, and the maximum size of access to the buffer memory by FROM/TO command is 12k words. However, as FROM/TO command takes longer for processing compared with other commands, it greatly affects on the scan time of the built-in PLC. Keep the number of FROM/TO commands as low as possible.

Reference: FROM/TO command processing time

Command	Command base processing time	Data transfer time
FROM command	115 μ s	1.29 μ s/word
TO command	110 μ s	1.29 μ s/word

Example of processing time calculation: FROM H0 H2000 D1000 K64

(Read 64 words of the address 2000H of the buffer memory and write them in D1000)

$$\begin{aligned} \text{Command processing time} &= \text{Command base processing time} + \text{Data transfer time} \\ &= 115 \qquad \qquad \qquad + 1.29 * 64 \\ &= 197.56 \mu\text{s} \end{aligned}$$

4.3 Buffer Memory Address

Trying to access to an illegal address (that doesn't exist in terms of MELSEC intelligent unit's spec) with the intelligent unit's buffer memory access by FROM/TO command will cause the alarm "Q01 EMERGENCY STOP LAD 0009", and will stop the built-in PLC.

VIII. I/O/Intelligent Function Unit Connection Function

5. Alarm List

5. Alarm List

Descriptions and remedies for the alarms that may occur during using this function.

Message	Description	Remedy
Q01 EMERGENCY STOP LAD 0002	FROM/TO command was issued without mounting a Q bus bridge card HR863.	Mount a Q bus bridge card HR863.
Q01 EMERGENCY STOP LAD 0003	In FROM/TO command, a minus value was set as the head I/O number.	Correct the head I/O number.
Q01 EMERGENCY STOP LAD 0004	In FROM/TO command, a minus value was set as the transfer size.	Correct the transfer size.
Q01 EMERGENCY STOP LAD 0005	There are more than 50 FROM/TO commands in one scan.	Review the built-in PLC's program so that the number of each FROM command and TO command does not exceed 50.
Q01 EMERGENCY STOP LAD 0006	The size of access to the buffer memory by FROM/TO command in one scan exceeded 12k words.	Review the built-in PLC's program.
Q01 EMERGENCY STOP LAD 0007	FROM/TO command was used in high-speed program processing.	As FROM/TO command is not available in high-speed program processing, delete the command.
Q01 EMERGENCY STOP LAD 0008	The unit when designating bit device in FROM/TO command is not 16 bits.	Change the unit of bit device number to 16 bits.
Q01 EMERGENCY STOP LAD 0009	In access to MELSEC intelligent unit's buffer memory by FROM/TO command, an illegal address (that doesn't exist in terms of the unit's spec) was accessed.	Of the built-in PLC's FROM/TO command, review the part that designates the buffer memory address.
Q01 EMERGENCY STOP LAD 000A	An alarm occurred in the MELSEC unit mounted on an extension base unit.	Check the MELSEC unit that is mounted on an extension base unit.
Q01 EMERGENCY STOP LAD 000B	The head I/O No. designated by FROM/TO command and the actual position of the mounted intelligent function unit (the unit's I/O No.) don't match.	Check if the head I/O No. and the unit's mounted position are correct. If wrong, correct the head I/O No. of the FROM/TO command.
	The head address designated by FROM/TO command is out of the range of the intelligent function unit's buffer memory address.	Check the head address of the FROM/TO command. If it's wrong, correct the head address.


(Note) To release the alarm, reboot the NC after completing the remedy.

VIII. I/O/Intelligent Function Unit Connection Function


6. Supplement

6. Supplement (Example of built-in PLC when FL-net unit is used)

The following is an example of built-in PLC when MELSEC FL-net unit is connected as below.



This example is on the assumption that FL-net is used when its common memory Area 1 and 2 are allocated to each node as shown in the left of the figure below, and the C64's built-in PLC (node 3) allocates devices as shown in the right of the figure below.



VIII. I/O/Intelligent Function Unit Connection Function

6. Supplement

6.1 Input/Output Signal List

FL-net unit's input/output signals are explained in this section. The input/output signal assignment is performed on the assumption that the FL-net unit is mounted in the slot on an extended base unit. Note that device X indicates the input signal from FL-net unit to NC, and device Y indicates the output signal from NC to FL-net unit.

Signal direction: NC ← FL-net unit		Signal direction: NC → FL-net unit	
Input No.	Signal name	Output No.	Signal name
X00	Message send normal completion ON: Normal completion OFF: -	Y00	Message send request ON: Request OFF: -
X01	Message send error completion ON: Error completion ending OFF: -	Y01	Use prohibited
X02	Message being received ON: Being received OFF: Not received	Y02	Message reception completion ON: Request OFF: -
X03 to X0F	Use prohibited	Y03 to Y0F	Use prohibited
X10	Network parameter write completion ON: Completed OFF: -	Y10	Network parameter write request ON: Request OFF: -
X11	Network parameter read completion ON: Completed OFF: -	Y11	Network parameter read request ON: Request OFF: -
X12	Use prohibited	Y12	Use prohibited
X13	Device profile read completion ON: Completed OFF: -	Y13	Device profile read request ON: Request OFF: -
X14	Log data clear completion ON: Completed OFF: -	Y14	Log data clear request ON: Request OFF: -
X15	Log data read completion ON: Completed OFF: -	Y15	Log data read request ON: Request OFF: -
X16	Use prohibited	Y16 to Y1F	Use prohibited
X17	Use prohibited		
X18	Parameter setting status ON: Error OFF: Normal		
X19	Token participation status ON: Participation OFF: Released		
X1A	Use prohibited		
X1B	Use prohibited		
X1C	Unit ready ON: Preparation completed OFF: In initialization		
X1D	Use prohibited		
X1E	Use prohibited		
X1F	Watchdog timer error detection ON: Detected OFF: Not detected		

CAUTION


-  Do not turn "Use prohibited" signal ON among the signals output to FL-net unit (Y00 to Y1F). Failure to observe this could result in malfunction the device mounted on the extension base unit.

VIII. I/O/Intelligent Function Unit Connection Function

6. Supplement


6.2 Initial Setting

The following is an example of initial processing of FL-net unit. (The local node number is Node 03.)



VIII. I/O/Intelligent Function Unit Connection Function

6. Supplement



(Note) Automatic refresh cannot be set. Execute refresh by programming with FROM/TO commands.

Data and description of parameter setting errors (List of error data in D100 and its description)


D100's data	Description of error	Remedy
C021H	Wrong IP address (network address) setting	Correct the IP address and perform initial process again.
C022H	Wrong IP address (host address) setting	Correct the IP address and perform initial process again.
C023H	Wrong setting value for common memory area 1 head address	Correct setting value for common memory area 1 head address and perform initial process again.
C024H	Wrong setting value for common memory area 1 size	Correct setting value for common memory area 1 size and perform initial process again.
C025H	Setting value for common memory area 1 head address or size is outside permissible range.	Correct setting value for common memory area 1 head address and size and perform initial process again.
C026H	Wrong setting value for common memory area 2 head address	Correct setting value for common memory area 2 head address and perform initial process again.
C027H	Wrong setting value for common memory area 2 size	Correct setting value for common memory area 2 size and perform initial process again.
C028H	Setting value for common memory area 2 head address or size is outside permissible range.	Correct setting value for common memory area 2 head address and size and perform initial process again.
C029H	Wrong setting value for token monitoring timeout time	Correct setting value for token monitoring timeout time and perform initial process again.
C02AH	Wrong setting value for minimum permissible frame interval	Correct setting value for minimum permissible frame interval and perform initial process again.
C02CH	Setting for common memory area overlaps other node setting range	Correct setting value for common memory and perform initial processing.

VIII. I/O/Intelligent Function Unit Connection Function

6. Supplement

6.3 Cyclic Transmission

The following is an example of communication processing by cyclic transmission of FL-net unit.



VIII. I/O/Intelligent Function Unit Connection Function

6. Supplement


6.4 Message Transmission

6.4.1 Outline of Message Transmission


Message transmission is the function supporting the asynchronous data exchange generated among nodes.

- (1) When a node receives a token, it sends up to one (message) frame before transmitting cyclic frames.
- (2) Data volume that can be transmitted in a frame is equal to or less than 1024 bytes (512 words).
- (3) Algorithm is provided so as not to exceed allowable refresh cycle time for cyclic transmission.
- (4) Both "1:1 transmission" transmitting to a specific destination node and "1:n broadcast transmission" transmitting to all nodes are provided.
- (5) Delivery acknowledgement function is provided to confirm successful delivery of data to the destination node on the "1:1 transmission".

1:1 Transmission



1:n Broadcast transmission



VIII. I/O/Intelligent Function Unit Connection Function

6. Supplement

6.4.2 Transaction Code

Each message has a header with a transaction code for requesting or responding, which is used for identifying the message frame.

Transaction code		Application
Decimal	Hex	
0 to 59999	0000H to EA5FH	Transparent type message
60000 to 64999	EA60H to FDE7H	Reserved
65000	FDE8H	Cyclic header (with token)
65001	FDE9H	Cyclic header (without token)
65002	FDEAH	Participation request frame header
65003	FDEBH	Byte block data read (request)
65004	FDECH	Byte block data write (request)
65005	FDEDH	Word block data read (request)
65006	FDEEH	Word block data write (request)
65007	FDEFH	Network parameter read (request)
65008	FDF0H	Network parameter write (request)
65009	FDF1H	Stop command (request)
65010	FDF2H	Operate command (request)
65011	FDF3H	Profile read (request)
65012	FDF4H	Trigger header
65013	FDF5H	Log read (request)
65014	FDF6H	Log clear (request)
65015	FDF7H	For message return test (request)
65016 to 65202	FDF8H to FEB2H	Reserved
65203	FEB3H	Byte block data read (response)
65204	FEB4H	Byte block data write (response)
65205	FEB5H	Word block data read (response)
65206	FEB6H	Word block data write (response)
65207	FEB7H	Network parameter read (response)
65208	FEB8H	Network parameter write (response)
65209	FEB9H	Stop command (response)
65210	FEBAH	Operate command (response)
65211	FEBBH	Profile read (response)
65212	FEBCH	Reserved
65213	FEBDH	Log read (response)
65214	FEBEH	Log clear (response)
65215	FEBFH	For message return test (response)
65216 to 65399	FEC0H to FF77H	Reserved
65400 to 65535	FF78H to FFFFH	Reserved

VIII. I/O/Intelligent Function Unit Connection Function

6. Supplement

6.4.3 Support Message List

This section explains available message transmissions from C64's user PLC.

- (1) Transparent type message transmission
 Message data (up to 512 words) can be sent and received to and from the message area of a specified node.
 Possible to use arbitrary transaction codes (0 to 59999).
- (2) Return data response
 It is possible to return the received data as-is whenever a return command is received.
- (3) Reading of the parameters
 It is possible to read the network parameters (such as vendor name, token monitoring time, etc.) for each node.
- (4) Reading and clearing of log data
 It is possible to read and clear the communication log data held by each node.
- (5) Reading of device profile
 It is possible to read the device profile data held by each node.

Support message list

No.	Message	1:1	1:n	Server function (*1)	Client function (*2)	
						Transparent type message transmission (*3)
1	Byte block read (*4)	×	×	×	×	○
2	Byte block write (*4)	×	×	×	×	○
3	Word block read (*4)	×	×	×	×	○
4	Word block write (*4)	×	×	×	×	○
5	Network parameter read	○	×	○	○	×
6	Network parameter write	×	×	×	×	×
7	Operate/stop command	×	×	×	×	○
8	Profile read	○	×	○	○	×
9	Log data read	○	×	○	○	×
10	Log data clear	○	○	○	○	×
11	Message return	○	×	○	×	×
12	PING	○	×	○	×	×
13	Transparent type message transmission	○	○	○	○	○

*1: Server function Functions that create a response frame for the request message that has been received and send it.

*2: Client function..... Functions that send the request message and receive the response frame.

*3: Realized by the transparent type message transmission. Refer to the next page for the transparent type message transmission procedures.

*4: If this message is received not in the transparent type message, the device data which can be read/written is not of C6/C64.

VIII. I/O/Intelligent Function Unit Connection Function

6. Supplement

6.4.4 Support Message Details

This section explains details of message transmission available from C64's user PLC.


(1) Transparent type message transmission

This function writes messages to the corresponding node's received message area from the network. Arbitrary transaction codes (0 to 59999) are available.

By arranging transaction codes with the destination node, various messages can be transmitted.

As FL-net itself doesn't return response messages, if response messages are necessary, response message creation process has to be carried out with the user PLC program.

Item	Request	Response
Transaction code	0 to 59999	-
Parameter	<ul style="list-style-type: none"> Object node number Data size (Word unit) 	-
User data	Data (512 word space)	-





VIII. I/O/Intelligent Function Unit Connection Function

6. Supplement

[Example of user PLC program]

(a) Message send



VIII. I/O/Intelligent Function Unit Connection Function

6. Supplement

A : Check if FL-net unit's "Token participation status" signal (X19) is ON.

B : After setting data below in message send devices, transfer the message to the message data send area, then turn "Message send request" signal (Y00) ON.

- Object node number
- Transaction code
- Send data size
- Send data

C : Check the completion of the message send.

<At normal completion>

- "Message send normal completion" signal (X00): ON
- "Message send error completion" signal (X01): OFF

<At error completion>

- "Message send normal completion" signal (X00): OFF
- "Message send error completion" signal (X01): ON

At an error completion, refer to the diagnosis data in D101 (see the table below) and correct the FL-net parameters or user PLC, then reboot C6/C64.

After confirming that "Message send normal completion" signal (X00) or "Message send error completion" signal (X01) is ON, turn "Message send request" signal (Y00) OFF.


Data and description of message transmission errors (List of error data in D101 and its description)

D101's data	Description of error	Remedy
C321H	Setting value for object node number is outside permissible range.	Correct setting value for object node number.
C322H	Object node does not exist.	Correct setting value for object node number. Check operation of corresponding equipment.
C323H	No response from object node for 10 seconds or more.	Correct setting value for object node number. Check operation of corresponding equipment.
C324H	Error in send data.	Correct send data.
C325H	The transaction code includes the process that is not supported by FL-net unit.	Correct transaction code.
C326H	No empty capacity in object node buffer.	Re-execute after waiting for a while.
C328H	Not participating in token.	Check the status of the PLC and wires. Review the settings for the initial process.

VIII. I/O/Intelligent Function Unit Connection Function


6. Supplement

(b) Message receive



VIII. I/O/Intelligent Function Unit Connection Function

6. Supplement



A : After the received message data is set in message receive device, turn "Message being received" signal (X02) ON.

B : After transferring (writing) the message data to device, turn "Message reception completion" signal (Y02) ON.

C : After confirming that "Message being received" signal (X02) is OFF, turn "Message reception completion" signal (Y02) OFF.


(Note) If response is necessary at receiving message data, create a sequence program for responding.

(2) Message return

This function returns the received message.

The message return is performed automatically within the FL-net unit. Thus, there is no necessity for C6/C64's user PLC to perform processing.

Item	Request	Response
Transaction code	65015	65215
Parameter	Object node number	-
User data	Test data (512 words space)	Test data (512 words space)




VIII. I/O/Intelligent Function Unit Connection Function

6. Supplement

(3) Read network parameters

This function reads network parameters (such as vendor name, token monitoring time, etc.) for each node.



Item	Request	Response
Transaction code	65007	65207
Parameter	Object node number	-
User data	-	<ul style="list-style-type: none"> • Node number • Vendor name • Manufacturer's model • Node name (equipment name) • Address and size of common memory • Token monitoring timeout time • Refresh cycle time • Refresh cycle time (Actual value) • Permissible minimum frame interval • Upper layer status • FL-net (OPCN-2) status • Protocol version



VIII. I/O/Intelligent Function Unit Connection Function

6. Supplement

Example of user PLC program



- A : Check if "Token participation status" signal (X19) of FL-net unit is ON.
- B : After setting the parameter reading object node number in the message send device D2000 (node number setting device), set the number in the buffer memory by "TO" command, then turn "Network parameter read request" signal (Y11) ON.
- C : FL-net unit stores the object node's parameter data in the buffer memory (address: 1200H to 121bH). After stored, the parameter data is transferred to the message reception device D3003 and later.
- D : Check the completion of the parameter reading.
 - <At normal completion>
 - "Network parameter read completion" signal (X11): ON
 - Parameter reading result (D103): 0
 - <At error completion>
 - "Network parameter read completion" signal (X11): ON
 - Parameter reading result (D103): Other than 0

VIII. I/O/Intelligent Function Unit Connection Function

6. Supplement

At an error completion, refer to the diagnosis data in D103 (see the table below) and correct the FL-net parameters or user PLC, then reboot C6/C64.

After confirming "Network parameter read completion" signal (X11) is ON, turn "Network parameter read request" signal (Y11) OFF.


Data and description of parameter reading result errors (List of error data in D103 and its description)

D103's data	Description of error	Remedy
C321H	Setting value for object node number outside permissible range.	Correct setting value for object node number.
C322H	Object node does not exist.	Correct setting value for object node number. Check operation of corresponding equipment.
C323H	No response from object node for 10 seconds or more.	Correct setting value for object node number. Check operation of corresponding equipment.
C324H	Error in send data.	Correct send data.
C326H	No empty capacity in object node buffer.	Re-execute after waiting for a while.
C328H	Not participating in token	Check the status of the PLC and wires. Review the settings for the initial process.

(4) Log data read

Message function for reading corresponding node log data from the network.



Item	Request	Response
Transaction code	65013	65213
Parameter	Object node number	-
User data	-	<ul style="list-style-type: none"> • Send and receive log • Frame log • Cyclic transmission error log • Message transmission error log • ACK error log • Token error log • Status data • Participation node list



VIII. I/O/Intelligent Function Unit Connection Function

6. Supplement

Example of user PLC program



- A : Check if FL-net unit's "Token participation status" signal (X19) is ON.
- B : After setting the log data read object node No. in message send device D2000 (node No. setting device), set the data in the buffer memory by "TO" command, and turn "Log data read request" (Y15) ON.
- C : FL-net unit stores the log data of the object node in the buffer memory (address: from 1600H). After stored, the log data is transferred to the message reception device D3003 and later.
- D : Check the log data read completion.
- <At normal completion>
- "Log data read completion" signal (X15): ON
 - Log data reading result (D104): 0
- <At error completion>
- "Log data read completion" signal (X15): ON
 - Log data reading result (D104): Other than 0

VIII. I/O/Intelligent Function Unit Connection Function

6. Supplement

At an error completion, refer to the diagnosis data of D104 (see the table below) and correct the FL-net parameters or user PLC, then reboot C6/C64.

After confirming that "Log data read completion" signal (X15) is ON, turn "Log data read request" signal (Y15) OFF.


Data and description of log data reading result errors (List of error data in D104 and its description)

D104's data	Description of error	Remedy
C321H	Setting value for object node number is outside permissible range.	Correct setting value for object node number.
C322H	Object node does not exist.	Correct setting value for object node number. Check operation of corresponding equipment.
C323H	No response from object node for 10 seconds or more.	Correct setting value for object node number. Check operation of corresponding equipment.
C324H	Error in send data.	Correct send data.
C326H	No empty capacity in object node buffer.	Re-execute after waiting for a while.
C328H	Not participating in token.	Check the status of the PLC and wires. Review the settings for the initial process.

(5) Log data clear

Message function for clearing corresponding node log data from the network.



Item	Request	Response
Transaction code	65014	65214
Parameter	Object node number	-
User data	-	-



VIII. I/O/Intelligent Function Unit Connection Function

6. Supplement

Example of user PLC program



- A : Check if FL-net unit's "Token participation status" signal (X19) is ON.
- B : After setting the log data clear object node number is set in message send device D2000 (node number setting device), set the data in the buffer memory by "TO" command, and turn "Log data clear request" signal (Y14) ON.
- C : Check the log data clear completion.
- <At normal completion>
- "Log data clear completion" signal (X14): ON
 - Log data clear result (D105): 0
- <At error completion>
- "Log data clear completion" signal (X14): ON
 - Log data clear result (D105): Other than 0

At an error completion, refer to the diagnosis data in D105 (see the table below) and correct the FL-net parameters or user PLC, then reboot C6/C64.

VIII. I/O/Intelligent Function Unit Connection Function

6. Supplement

After confirming that "Log data clear completion" signal (X14) is ON, turn "Log data clear request" signal (Y14) OFF.


Data and description of log data clear result errors (List of error data in D105 and its description)

D105's data	Description of error	Remedy
C321H	Setting value for object node number outside permissible range.	Correct setting value for object node number.
C322H	Object node does not exist.	Correct setting value for object node number. Check operation of corresponding equipment.
C323H	No response from object node for 10 seconds or more.	Correct setting value for object node number. Check operation of corresponding equipment.
C324H	Error in send data.	Correct send data.
C326H	No empty capacity in object node buffer.	Re-execute after waiting for a while.
C328H	Not participating in token.	Check the status of the PLC and wires. Review the settings for the initial process.

(6) Device profile read

This function reads the device profile data that is the data for the corresponding node from the network. The data format for the device profile data is based on ASN1.1 (Abstract Syntax Notation One) conversion rules for transmission encoding as stipulated in ASN1.1 Basic Encoding Rule (ISO/IEC 8825).



Item	Request	Response
Transaction code	65011	65211
Parameter	Object node number	-
User data	-	System parameter



VIII. I/O/Intelligent Function Unit Connection Function

6. Supplement

Example of user PLC program



- A : Check if FL-net unit's "Token participation status" signal (X19) is ON.
- B : After setting the device profile reading object node number in message send device D2000 (node number setting device), set the data in the buffer memory by "TO" command, and turn "Device profile read request" signal (Y13) ON.
- C : FL-net unit stores the device profile data of the object node in the buffer memory (address: from 1400H). After stored, the parameter data is transferred to the message reception device D3003 and later.
- D : Check device profile reading completion.
 - <At normal completion>
 - "Device profile read completion" signal (X13): ON
 - Device profile read result (D106): 0
 - <At error completion>
 - "Device profile read completion" signal (X13): ON
 - Device profile read result (D106): Other than 0

VIII. I/O/Intelligent Function Unit Connection Function

6. Supplement

At an error completion, refer to the diagnosis data of D106 (see the table below) and correct the FL-net parameters or user PLC, then reboot C6/C64.

After confirming that "Device profile read completion" signal (X13) is ON, turn "Device profile read request" signal (Y13) OFF.



Data and description of device profile read result errors (List of error data in D106 and its description)

D106 data	Description of error	Remedy
C321H	Setting value for object node number outside permissible range.	Correct setting value for object node number.
C322H	Object node does not exist.	Correct setting value for object node number. Check operation of corresponding equipment.
C323H	No response from object node for 10 seconds or more.	Correct setting value for object node number. Check operation of corresponding equipment.
C324H	Error in send data.	Correct send data.
C326H	No empty capacity in object node buffer.	Re-execute after waiting for a while.
C328H	Not participating in token.	Check the status of the PLC and wires. Review the settings for the initial process.

VIII. I/O/Intelligent Function Unit Connection Function
6. Supplement

6.5 Checking various status of other nodes

The information on the other nodes can be obtained by referring to the information area of the other nodes as shown in the table below.

Buffer memory address	Name	Description	Reference to other nodes from C64 user PLC	Reference to C64 side from other nodes
9E0H to 9EFH	Participation node list	<p>Indicates the token participation status at the other node in bits.</p>  <p>0: Participation 1: Release</p>	Possible	Possible
9F0H to 9FFH	Other node parameter setting status	<p>Indicates the parameter setting status at the other nodes in bits. *1</p>  <p>0: Setting 1: No setting</p>	Possible	Possible

VIII. I/O/Intelligent Function Unit Connection Function

6. Supplement

Buffer memory address	Name	Description	Reference to other nodes from C64 user PLC	Reference to C64 side from other nodes
A00H to A0FH	Other node CPU execution status	<p>Indicates the execution status of QnCPU, etc. at the other node in bits. *1</p> <p style="text-align: center;"> b15 b0 A00H A00H Node 15 Node 1 A01H A01H Node 31 Node 16 </p> <p>0: RUN status (RUN,STEP_RUN) 1: STOP status (STOP,PAUSE)</p>	Possible	Not possible (Note)
A10H to A1FH	Other node CPU operation status (Low level error) *2	<p>Indicates the results of self-diagnosis of QnCPU, etc. at the other node in bits. *1</p> <p style="text-align: center;"> b15 b0 A10H A10H Node 15 Node 1 A11H A11H Node 31 Node 16 </p> <p>0: Normal 1: Warning</p>	Possible	Not possible (Note)
A20H to A2FH	Other node CPU operation status (Medium, high level errors) *3	<p>Indicates the results of self-diagnosis of QnCPU, etc. at the other node in bits. *1</p> <p style="text-align: center;"> b15 b0 A20H A20H Node 15 Node 1 A21H A21H Node 31 Node 6 </p> <p>0: Normal 1: Alarm</p>	Possible	Not possible (Note)

VIII. I/O/Intelligent Function Unit Connection Function

6. Supplement

*1: For the participation nodes only.

*2: CPU unit's operation continues when the low level error occurs.

*3: CPU unit's operation stops when the medium to high level error occurs.

[Note]

Because C64 is not provided with QnCPU, CPU status, such as CPU execution status or operation status of C64, cannot be referred to from the other nodes.

When C64 PLC execution status or PLC operation status needs to be checked from the other nodes, alternatively check the heart beat signal in the common area that has been written by the C64 side user PLC with TO commands.

6.6 Reference

For the specifications or other programming methods of FL-net, refer to the document of MELSEC Q series below.

FL-net (OPCN-2) Interface Module User's Manual (QJ71FL71-F01-U-SY-J/E)

IX. Connection Function with GOT

IX. Connection Function with GOT

1. Outline

1. Outline

This function is to connect Mitsubishi Graphic Operation Terminal (GOT) with MELDAS C6/C64 and use the GOT as a machine operation panel or a NC operation panel.

You can display not only overall PLC devices but various monitored information of CNC C6/C64 on the GOT. Setting display dedicated for CNC C6/C64 (CNC monitor), and ladder monitor display are also available. The contents of this manual are supporting C6/C64 software Ver. D0.

CAUTION

-  Do not set any of the touch keys on the GOT as a start switch for the C6/C64. If a communication error (including cable disconnection) occurs between the GOT and C6/C64, the communication will be cut off and the GOT operation will be disabled. Even if the start switch is released, it will not be recognized that the start signal has been cut off, so the operation will continue. This could result in serious accidents.

IX. Connection Function with GOT

2. Available Function

2. Available Function

The table below shows the available functions of GOT when the GOT is connected with CNC C6/C64. This table is extracted from GOT-A900 Series Operating Manual (GT Works2 Version1/GT Designer2 Version1 compatible Extended/Option Functions Manual). ○ : Available △ : Partly restricted × : Unavailable

Function			Ref. Section	C6/C64								
				Bus connection	CPU direct connection	Computer link connection	MELSEC NET connection	CC-Link connection			Ethernet connection	
								BT13	BT15	G4		
Utility function			Sec. 4	×	○	×	×	○	△*1	×	○	
Ladder monitor function	Ladder monitor	Monitoring of sequence programs with ladder signals	Sec. 6.3.1	×	○	×	×	○	×	×	○	
	Display switching	Displaying of word device values in decimal and hexadecimal numbers	Sec. 6.3.3	×	○	×	×	○	×	×	○	
		Displaying of device comments										×
	Device changing	Changing of device values	Sec. 6.3.4	×	○	×	×	○	×	×	○	
Print-out	Printing of ladder	Sec. 6.3.5	×	○	×	×	○	×	×	○		
System monitor function	Entry monitor	Monitoring of current values by pre-registering monitor devices	Sec. 9.2	×	○	×	×	○	△*2	×	○	
	Batch monitor	Monitoring of 'n' points of current values subsequent to the designated device	Sec. 9.3	×	○	×	×	○	△*2	×	○	
	T/C monitor	Monitoring of 'm' points of current values, setting values, contacts and coils subsequent to the designated device	Sec. 9.4	×								
	BM monitor	Monitoring of 'x' points of current values subsequent to the designated buffer memory of the designated special unit	Sec. 9.5	×	○	×	×	○	×	×	○	
	Data editing by using test operation	Setting/resetting of bit devices		Sec. 9.6	×	○	×	×	○	×	×	○
		Changing of current values for the buffer memory of word device			×	○	×	×	○	×	×	○
		Changing of current value for T/C (can be used while monitoring T/C)			×	○	×	×	○	×	×	○
		Changing of setting value for T/ C (can be used while monitoring T/C)			×							
	Quick test	Changing of device value by using quick test		Sec. 9.6.2	×	○	×	×	○	○	×	○
	Display switching	Displaying of device comment		Sec. 9.1.2	×	○	×	×	○	×	×	○
Displaying of word device value and buffer memory value in decimal and hexadecimal numbers		×	○		×	×	○	○	×	○		
Special unit monitor function	Monitoring of special unit's buffer memory on the dedicated screen		Ch. 11	×								
Network monitor function	Monitoring of the network status of MELSECNET/B, (II), and /10		Ch. 15	×								
List editing function	List editing of sequence programs		Ch. 19	×								
Motion monitor function	Servo monitor	Monitoring of servo-related items, such as current values and positioning errors on various monitor screens	Ch. 22	×								
	Parameter setting	Changing of servo parameter setting values										
Servo drive unit monitor function	Monitoring of servo drive unit, changing of servo parameter settings and test operation		Ch. 25	This function is available regardless of the connection mode, as RS-232C interface of the GOT is used. (Refer to Sec. 3.7.3 for the precautions for servo drive unit monitor function.)								
CNC monitor function	Monitoring of C6/C64 and changing of the parameters		Ch. 28	×						○		

BT13 : A8GT-J61BT13 is used (intelligent device station).
 BT15 : A8GT-J61BT15 is used (remote device station).
 G4 : A9GT-RS4 or A9GT-50WRS4 is used (via G4).

*1 Clock setting is not available. *2 Link devices can be monitored only when they are allocated to the GOT.

CNC monitor function is available only with A985GOT (-V), which also requires the memory board. For more details, refer to GOT-A900 Series Operating Manual (GT Works2 Version1/GT Designer2 Version1 compatible Extended/Option Functions Manual).

IX. Connection Function with GOT

3. Connection Mode

3. Connection Mode

The table below shows the connectability of GOT by connection mode.

Connection mode	Bus connection	CPU direct connection	Computer link connection	MELSEC NET connection			CC-Link connection			Ethernet connection
				Network system		Data link system	Intelligent device station	Remote device station	Via G4	
				H	10	B, (II)				
Connectable	X	○	X	X	X	X	○ ^{*1}	○	X	○

*1 Compatible with the software version of CC-Link communication unit A8GT-J61BT13 is X or later.

Each unit requires the communication units in every communication mode. But the additional unit on C6/C64 side is not necessary when in CPU direct connection mode.

IX. Connection Function with GOT


3. Connection Mode

3.1 CPU Direct Connection

GOT can be connected with CNC C6/C64 via RS-422 and RS-232C cables, and this connection is the most economical way.

When you use RS-422 cable, you connect this cable with the GPP connector of the F311 cable which is connected to the SIO connector on CNC C64 control unit.

When you use RS-232C cable, you connect this cable with TERMINAL connector on CNC C64 control unit.



< Cable specification >

(1) RS-422 cable

Cable for GOT (MELSEC) AC30R4-25P (3.0m), AC100R4-25P (10.0m), AC300R4-25P (30.0m)

(2) RS-232C cable

CNC C6/C64 side (20-pin half-pitch)		Cable connection and direction of signal	GOT side (9-pin D-SUB)	
Signal name	Pin No.		Pin No.	Signal name
GND	1	↔	1	CD
		→	2	RD (RXD)
SD	6	→	3	SD (TXD)
RD	16	↔	4	DTR (ER)
ER (DTR)	18	→	5	SG (GND)
		→	6	DSR (DR)
		→	7	RS (RTS)
		→	8	CS (CTS)
GND	11	↔	9	-

[CNC connector (recommended)]

Connector : 10120-3000VE (manufactured by Sumitomo 3M Ltd.)

Connector cover : 10320-52F0-008 (manufactured by Sumitomo 3M Ltd.)

[GOT connector]

The following type of connector is used as GOT connector. You should use the matching connector.

D-sub 9-pin (male) inch thread type

17LE-23090-27 (D3CC) (manufactured by DDK Ltd.)

(Note) For more details of GOT, refer to GOT-A900 Series User's Manual (GT Works2 Version1/GT Designer2 Version1 compatible Connection System Manual) and other relevant documents.

IX. Connection Function with GOT

3. Connection Mode


3.2 CC-Link Connection

Remote control can be realized via network since CNC C6/C64 functions as an intelligent device station or remote device station in CC-Link system.

In order to be connected via CC-Link, a CC-Link unit (FCU6-HR865) needs to be mounted on the expansion slot on the control unit.

You need to use CC-Link dedicated cable. Connect the cable to CC-Link system unit (FCU6-HR865) terminal.

And make sure to attach the terminating resistor (attachment) to the end station unit.



(Note 1) We cannot assure the performance when you use any cables other than CC-Link dedicated cable in CC-Link system. For specifications of CC-Link dedicated cables and inquiries, please access the Web page of CC-Link Partner Association (<http://www.cc-link.org/>). (Provided in "Contact List of CPLA Members")

(Note 2) You need to use the attached terminating resistor. The values of the resistors vary depending on the cables to be used. The value is 110 Ω for CC-Link dedicated cable, 130 Ω for CC-Link dedicated high-performance cable.

(Note 3) Connect FG cable from the FG terminal of CC-Link terminal block to the FG terminal at the lower part on C64 control unit.

(Note 4) In order to adjust the rotary switches for station number setting and for baud rate setting on C64 control unit, pull the CC-Link unit out from the control unit.

- With regard to CC-Link specification with CNC C6/C64, refer to "III. CC-LINK Master/Local Unit" in this MANUAL.
- For details of connection instruction, refer to "MELDAS C6/C64 CONNECTION AND MAINTENANCE MANUAL" (BNP-B2255).
- For more details of GOT, refer to "GOT-A900 Series User's Manual (GT Works2 Version1/GT Designer2 Version1 compatible Connection System Manual)" and other relevant documents.

IX. Connection Function with GOT

3. Connection Mode

3.3 Ethernet Connection


After installed in Ethernet system, GOT can operate CNC C6/C64 remotely via network.

In order to be connected via Ethernet, an Ethernet unit (FCU6-EX875) needs to be mounted on the expansion slot of the control unit.

Connect an Ethernet cable (10BASE-T cable) to the modular jack on the Ethernet unit.

Ethernet cable is so susceptible to noise that you should wire power cables and electric supply cables separately. And you need to attach a ferrite core (attachment) on the control unit side.

If you use this function under particularly adverse conditions, or need EMC compatibility, we recommend you to use the shielded cables.



(Note 1) Follow the procedure below to attach ferrite cores.

- (1) Wind the cable around the ferrite core once.
- (2) Fasten the catch as firmly as it can snap.
- (3) Tighten it by a binding band to avoid displacement.

(Note 2) If you use a shielded cable, you will need an additional FG cable to connect it with FG. Shielded cable is usually connected to FG terminal on the control unit. If earth plate is near it, however, you should connect it directly.


(Note 3) If you need EMC compatibility, a ferrite core may need to be attached on GOT side, too.

IX. Connection Function with GOT

3. Connection Mode

3.3.1 Initial setting of Ethernet Connection

The initial setting in the case of the following system configuration is described below.



(1) Setting on NC

Perform the settings of Host IP address on NC side.


The IP address to be set here will be shared with the other Ethernet communication function (including GX Developer connection).

Up to 2 Ethernet units (FCU6-EX875) can be mounted on C6/C64, so it has 2 channels of Ethernet connection.

There are three expansion slots in total: two internal expansion slots (EXT1, EXT2) and one external expansion slot (EXT3).

When you mount 2 Ethernet units, each unit will be controlled by being numbered for identification (as "Unit 1" and "Unit 2"). The mounted status and unit numbers of Ethernet units are as follows.


[When mounted on EXT1 and EXT2] [When mounted on EXT1 and EXT3] [When mounted on EXT2 and EXT3]



[When mounted on EXT1 only]

[When mounted on EXT2 only]

[When mounted on EXT3 only]



IX. Connection Function with GOT

3. Connection Mode

The following table shows the settings relating to Ethernet in accordance with each unit number.

Item	Unit 1	Unit 2
Recommended connection	GOT	Information network
Assigned IP address setting	#1926 IP address	#1931 IP address (2)
Assigned Subnet mask setting	#1927 Subnet mask	#1932 Subnet mask (2)
Assigned port number setting	#1929 Port number	#1933 Port number (2)
Assigned communication speed setting	#1930 Speed 10M/auto	#1934 Speed (2) 10M/auto
Processing priority	High	Low
Others	IP address setting available at off-line	

<Parameter setting>

You will set Ethernet parameters on Basic specification parameter screen.

You can set the parameters from #1926 to #1929 in off-line mode.

(Refer to "IV. Setting the IP Address" in this manual.)

[BASIC SPECIFICATION PARAMETER]	SETUP PARAM 1.18/21
#	
1925	
1926 IP address	192. 168. 1. 2
1927 Subnet mask	255. 255. 255. 0
1928 Gateway address	0. 0. 0. 0
1929 Port number	64758
1930 Speed 10M/auto	0
1931 IP address (2)	192. 168. 2. 2
1932 Subnet mask (2)	255. 255. 255. 0
1933 Port number (2)	64758
1934 Speed (2) 10M/auto	0. 0. 0. 0
1935	
1936	
#() DATA (. . .)	
EMG STOP	
BASIC	AXIS SERVO SPINDLE MENU CHANGE

Parameter number	Parameter name	Setting example
#1926	IP address	192.168.1.2
#1927	Subnet mask	255.255.255.0
#1929	Port number	64758
#1930	Speed 10M/auto	0

(Note 1) If #1926 IP address is not set, the initial setting will be "192.168.1.2".

(Note 2) If you set or change the Ethernet parameters, you need to reboot C64.

(Note 3) Always set Port number to "64758".

(Note 4) Always set #1930 Speed 10M/auto to 0 (10Mbps) during GOT connection.

The following table shows meaning of #1930 Speed 10M/auto and #1934 Speed (2) 10M/auto.


Setting value	0	1
Communication speed Speed 10M/auto	The communication speed is fixed to 10Mbps.	The communication speed is set after 10Mbps or 100Mbps is automatically recognized

IX. Connection Function with GOT

3. Connection Mode

(2) Setting on GT Designer2

Perform the settings of C6/C64 to be monitored in "Ethernet setting" of GT Designer2.



Item	Detail
Host	"*" mark will be shown when you click "Set to Host" button.
N/W No.	Set the network number of the MELDAS C6/C64. If you use the CNC monitor function, set it to "239".
PLC No.	Set the PLC number (station number) of the CNC C6/C64.
Model	Select "AJ71QE71".
IP address	Set the IP address of the MELDAS C6/C64. Set the IP address that is assigned to the connected C6/C64.
Port No.	Set it to "5001".
Communication type	Fixed to UDP/IP. However, communication is made via TCP/IP during the CNC monitoring, and via UDP/IP during the normal monitoring.

IX. Connection Function with GOT

3. Connection Mode

(3) Setting on GOT

Perform the Ethernet settings on GOT unit.

Use Setup of the GOT unit's utility function to perform Ethernet settings.

SET UP	
GOT NET No.	001 (1~239)
GOT PC No.	01 (1~64)
GOT IP ADDRESS	000.000.000.000
GOT PORT No.	05001(1024 to 65534)
ROUTER ADDRESS	000.000.000.000
SUBNET MASK	255.255.255.000
SEND MESSAGE WAIT	000x10ms (0~300)
SEND MESSAGE TIME	03 sec (3~90)
STARTUP TIME	003 sec (0~255)
Page 3/3 ↑ ↓ ← → SELECT/CHANGE	
<div style="display: flex; justify-content: space-around; align-items: center;"> ↑ ↓ ← → ↩ </div>	

Item	Detail	Factory setting
GOT NET No.	Set the network number of the GOT.	1
GOT PC No.	Set the station number of the GOT. Do not set the same number as the PC numbers of the Ethernet unit and C6/C64 to be monitored.	1
GOT IP ADDRESS	Set the IP address of the GOT.	000.000.000.000
GOT PORT No.	Set the port number of the GOT. When connected with C6/C64, set it to "5001".	5001
ROUTER ADDRESS	If the system is connected with the other network by a router, set the router address of the network where the GOT is connected.	000.000.000.000
SUBNET MASK	When the GOT is connected to the Ethernet network controlled by the subnet, set the subnet mask that is commonly set in the network. Without subnet, operation will be conducted with the default value.	255.255.255.000
SEND MESSAGE WAIT	Set the send message wait time in order to reduce loads on the network and the subjected PLC.	0
SEND MESSAGE TIME	Set the timeout interval.	3
START UP TIME	Set how many seconds after GOT's power-on the communication with C6/C64 will be started. Set it to "10".	3

(Note) For more details about settings on GT Designer2 and GOT, refer to "GOT-A900 Series User's Manual (GT Works2 Version1/GT Designer2 Version1 compatible Connection System Manual)" and other relevant documents.

IX. Connection Function with GOT


3. Connection Mode

(4) Initial setting procedure example

The followings show the setting procedure to conduct CNC monitoring with the GOT.

The setup procedure of the configuration below is used as an example.

The procedure of connecting with the default value before changing the IP address in order to set the IP address of C6/C64 is explained here.




[C6/C64 parameter setting (factory setting)]

Parameter No.	Parameter name	Factory setting
#1926	IP address	192.168.1.2
#1927	Subnet mask	0.0.0.0
#1929	Port number	64758
#1930	Speed 10M/auto	0

[GOT parameter setting (factory setting)]

Parameter name	Factory setting
GOT NET No.	1
GOT PC No.	1
GOT IP ADDRESS	000.000.000.000
GOT PORT No.	5001
ROUTER ADDRESS	000.000.000.000
SUBNET MASK	255.255.255.000
TRANSMISSION WAIT TIME	0
TRANSMISSION TIMEOUT	3
START UP TIME	3


[Setting procedure]



IX. Connection Function with GOT


3. Connection Mode

Step (1): Set the following settings in "Ethernet setting" of GT Designer2, and transmit them to the GOT.




Item	Setting value	Remarks
Host	*	
N/W No.	239	When conducting CNC monitoring, set it to "239".
PLC No.	1	
Model	AJ71QE71	
IP address	192.168.1.2	Set the default IP address of C6/C64.
Port No.	5001	
Communication type	UDP	

Step (2): Set the following settings on the GOT unit.




Step (3): With the CNC monitor displayed, change the IP address of C6/C64. The changed IP address will be validated after rebooting.




IX. Connection Function with GOT

3. Connection Mode

Step (4): Set the formal settings in "Ethernet setting" of GT Designer2, and then transmit them to the GOT.



Step (5): Set the formal settings on the GOT unit.



Step (6): Reboot C6/C64 and GOT.

Now, the initial setting is completed.

IX. Connection Function with GOT
4. Device Range Referenced on the GOT

4. Device Range Referenced on the GOT

The following table shows the types and ranges of the devices in the C6/C64 that can be referenced on the GOT.

Application		Device Range	Point
Input		X0 to XAFF	2816 points
Output		Y0 to YE7F	3712 points
Internal relay		M0 to M8191	8192 points
Internal relay (Annunciator)		F0 to F127	128 points
Latch relay		L0 to L255	256 points
Special relay		SM0 to SM127	128 points
Link relay		B0 to B1FFF	8192 points
Special link relay		SB0 to SB1FF	512 points
Special register		SD0 to SD127	128 points
Link register		W0 to W1FFF	8192 points
Special link register		SW0 to SW1FF	512 points
Timer	10ms	T0 to T15	16 points
	100ms	T16 to T95	80 points
	100ms integration	T96 to T103	8 points
	10ms (Fixed timer)	T104 to T143	40 points
	100ms (Fixed timer)	T144 to T239	96 points
	100ms integration (Fixed timer)	T240 to T255	16 points
Counter		C0 to C127	128 points
Data register		D0 to D8191 (Note 1)	8192 points
File register		R0 to R8191	8192 points

(Note 1) D1024 to D8191 can be used with the software version D0 and above.

IX. Connection Function with GOT

5. Related Documents

5. Related Documents

[Documents relating to MELDAS C6/C64]

MELDAS C6/C64 CONNECTION AND MAINTENANCE MANUAL	BNP-B2255
MELDAS C6/C64 PLC PROGRAMMING MANUAL	BNP-B2309
(Ladder Section with MELSEC Tool)	

[Documents relating to GOT]

GOT-A900 Series User's Manual (GT Works2 Version1/GT Designer2 Version1 Compatible Connection System Manual).....	SH (NA)-080255
GOT-A900 Series Operating Manual (GT Works2 Version1/GT Designer2 Version1 Compatible Extended/Option Functions Manual)	SH (NA)-080253

X. GOT Window Function

X. GOT Window Function

1. Outline

1. Outline


This function is an interface used to display various data on the GOT (A900 Series) connected to the MELDAS C6/C64.

The currently running machining program No., the currently running machining program and the coordinates, etc., are read from the GOT with the device read commands.

Commands for the NC are set from the GOT, and the data corresponding to the commands is created on the NC side.

The command area and response area are designated in R7756 to R7760. When the GOT designates the NC data to be gotten in the command area, the NC stores the designated data in the response area. That data can be sequentially read and displayed with the GOT.

Up to ten areas can be set as window areas, and up to ten types of commands can be set simultaneously.



X. GOT Window Function

2. Displaying the NC data

2. Displaying the NC data

The NC internal data can be displayed and set with three methods. Method 2 is explained in this manual.

<Method 1>

The NC screen conventionally displayed on the communication terminal, etc., is displayed on the GOT using the GOT's NC monitor function.

This is a fixed screen which cannot be customized by the user. Only the A985GOT(-V) NC monitor function can be used.

<Method 2>


The data periodically output to the NC's built-in PLC register by the NC system software is displayed on the GOT.

The types and amount of data periodically output by the NC system software are limited.

<Method 3>

Data is prepared (DDB commands) in the register by the NC's built-in PLC, and the GOT reads and writes the NC register.

The degree of freedom is high, but the NC internal data must always be gotten with a ladder.




X. GOT Window Function

3. Displaying the NC data (Method 2): GOT window function

3. Displaying the NC data (Method 2): GOT window function

This function displays the NC internal data prepared in a special register by the NC system.




Display data	Getting method
Main/sub O, N No.	Get with melGetGmodalPack (Command code: 0x0F02)
Currently running program	Get with melGetCurrentPrgPack (Command code: 0x0F01)
Machine value	Get with melGetAxisPosition (Command code: 0x0F03)
Remaining distance	Get with melGetAxisPosition (Command code: 0x0F03)
F command (modal)	Get with melGetGmodalPack (Command code: 0x0F02)
S command (modal)	Get with melGetGmodalPack (Command code: 0x0F02)
T command (modal)	Get with melGetGmodalPack (Command code: 0x0F02)

X. GOT Window Function

4. Designating the window area

4. Designating the window area

Set the window area in R7756 to R7760 with the GOT (or built-in PLC).
Set commands in the set window command area.




(1) Window validity and device type designation (Designate with R7756)

bit	Details		Explanation
0	Window validity		Turn bit0 ON to use the window function.
1			The data in the response area will not be updated when this bit is OFF.
2			
3			Turn the validity bit ON after setting all of the other data.
4			
5			
6			
7			
8	R register usage	} For command	} Designate the device type used with the window function.
9	D register usage		
A	W register usage		
B		} For response	} Turn 1 bit ON. If multiple bits are ON or if they are all OFF, the R register will be used.
C	R register usage		
D	D register usage		
E	W register usage		
F			

X. GOT Window Function

4. Designating the window area

(2) Window command area (Designate with R7757) (3) Window response area (Designate with R7758)



(4) Status (Designate with R7760)

bit	Details
0	Window quantity error
1	Command area Device range error
2	Response area Device range error
3	
4	
5	
6	
7	
8	
9	
A	
B	
C	
D	
E	
F	

The error status from the NC is stored in the status area.

An error will occur if the designated device is not within the user area range, or if the window quantity is not between 1 and 10.

The "response area device range error" will occur if the command area and response area overlap.

Precautions for designating the window area


- (1) Turn the window validity bit ON after setting the window quantity, command head device No. and response head device No.
The window validity bit can be turned ON simultaneously with the device type without problem.
- (2) After changing the window area, turn the window validity bit OFF once and then set the device No., etc.
- (3) After an error such as a window quantity error or device range error occurs, turn the window validity bit OFF once, and make a correct setting.
- (4) The command head device No. and response head device No. must always be an even number (so that 4 bytes is the boundary).

X. GOT Window Function

5. Getting window data

5. Getting window data

The window area must be designated before the GOT can get the NC data. Next, set the required commands, and turn the data change request ON. The NC side receives the data change request, and when the data has been changed, the data change complete signal turns ON. Once the data change request turns ON, the NC will continue to create data until the next data change request turns ON. There are ten data change request signals corresponding to windows 1 to 10.



- (1) Designate the window area.
(Window quantity, command/response device area, device type designation, window validity bit)
- (2) After writing the command (API designation) and argument into the command area from the GOT or built-in ladder, the data change request signal turns ON.
- (3) After the NC receives the data change request and the response area update is completed, the data change complete signal turns ON.
- (4) The GOT receives the data change complete signal and turns the data change request signal OFF.
- (5) The NC continually creates data in respect to the designated command, and stores it in the response area.
- (6) The GOT reads the response area device.

Precautions for getting the window data

- (1) The script function is used to write the commands from the GOT.
- (2) To prevent transient data from being displayed, do not get the data while the data change request is ON.
- (3) If data is to be constantly gotten without changing the command, turn the data change request ON only once. The response area will be constantly updated after that.

X. GOT Window Function
6. Data change request and complete signals

6. Data change request and complete signals

6.1 Data change request signal (GOT → NC)

Offset	Details	Remarks
Command head device +0	Data change request signal	Turns ON when the command data is changed.

Details of bits

bit	Details
0	Window 1 data change request
1	Window 2 data change request
2	Window 3 data change request
3	Window 4 data change request
4	Window 5 data change request
5	Window 6 data change request
6	Window 7 data change request
7	Window 8 data change request
8	Window 9 data change request
9	Window 10 data change request
A	
B	
C	
D	
E	
F	

X. GOT Window Function
6. Data change request and complete signals

6.2 Data change complete signal (NC → GOT)

Offset	Details	Remarks
Response head device +0	Data change complete signal	Turns ON when the data change is completed, and turns OFF when the data change request signal turns OFF.

Details of bits

bit	Details
0	Window 1 data change complete
1	Window 2 data change complete
2	Window 3 data change complete
3	Window 4 data change complete
4	Window 5 data change complete
5	Window 6 data change complete
6	Window 7 data change complete
7	Window 8 data change complete
8	Window 9 data change complete
9	Window 10 data change complete
A	
B	
C	
D	
E	
F	

X. GOT Window Function
7. Window commands/responses

7. Window commands/responses

7.1 List of command codes

Command name	Details	Command code
melGetCurrentPrgPack	Designate and get type of currently running program	0xF01
melGetGmodalPack	Get modal information in batch	0xF02
melGetAxisPosition	Get coordinate values for all axes in batch	0xF03
melGetCurrentAlarmMsg2	Get currently occurring alarm message	0xF04
melGetAlarmHistory	Get alarm history information	0xF05

7.2 Command area

Up to ten window command areas can be used.

Window	Offset	Details	Remarks
-	+0	Data change request signal	
-	+1	Spare	
Window 1	+2	Data size	Number of bytes from command code to end of argument
	+3	Spare	
	+4	Command code	Command code used
	+5	Spare	
	+6 ~ +65	Argument 1 to argument 30	The argument configuration differs according to the command
Window 2	+66	Data size	Number of bytes from command code to end of argument
	+67	Spare	
	+68	Command code	Command code used
	+69	Spare	
	+70 ~ +129	Argument 1 to argument 30	The argument configuration differs according to the command
:	:	:	:
Window 10	+578	Data size	Number of bytes from command code to end of argument
	+579	Spare	
	+580	Command code	Command code used
	+581	Spare	
	+582 ~ +641	Argument 1 to argument 30	The argument configuration differs according to the command

The offset is indicated in word units.

X. GOT Window Function
7. Window commands/responses

7.3 Response area

Up to ten window response areas can be used.

Window	Offset	Details	Remarks
-	+0	Data change complete signal	
-	+1	Spare	
Window 1	+2	Data size	Number of bytes from command code to end of response
	+3	Spare	
	+4	Command code	Command code issued
	+5	Spare	
	+6 +7	Error code	0 : No error Other than 0 : Error occurring
	+8 ~ +129	Response (122 words)	The response configuration differs according to the command
Window 2	+130	Data size	Number of bytes from command code to end of response
	+131	Spare	
	+132	Command code	Command code issued
	+133	Spare	
	+134 +135	Error code	0 : No error Other than 0 : Error occurring
	+136 ~ +257	Response (122 words)	The response configuration differs according to the command
:	:	:	:
Window 10	+1154	Data size	Number of bytes from command code to end of response
	+1155	Spare	
	+1156	Command code	Command code issued
	+1157	Spare	
	+1158 +1159	Error code	0 : No error Other than 0 : Error occurring
	+1160 ~ +1281	Response (122 words)	The response configuration differs according to the command

The offset is indicated in word units.

X. GOT Window Function

8. Details of commands

8. Details of commands

8.1 melGetCurrentPrgPack

melGetCurrentPrgPack	Designates and gets the type of currently running program.
----------------------	--

Usage example

■ Command

Offset	Details	Setting example	Remarks
0	Data size	16	
1	Spare	0	
2	Command code	0x0F01	Designate melGetCurrentPrgPack
3	Spare	0	
4	Argument 1: Designate part system No.	1	1: 1st part system 2: 2nd part system
5			
6	Argument 2: Designate number of blocks to get	3	Setting range: 1 to 10
7			
8	Argument 3: Designate number of characters in one block	16	Setting range: 1 to 240
9			

The offset is indicated in word units.

Designate so that the number of blocks x number of characters in one block is within 240 characters.

■ Response

Offset	Details	Response example	Remarks
0	Data size	60	
1	Spare	0	
2	Command code	0x0F01	Designate melGetCurrentPrgPack
3	Spare	0	
4	Error code	0	0 : No error Other than 0 : Error occurring
5			
6	Status	1	0: Not running 1: Running
7			
8~15	Currently running program	"NO1G90G28X0.Y0.;"	
16~23		"NO2G00X-123.456;"	
24~31		"NO003;"	

The offset is indicated in word units.

The currently running block is always output to the 2nd block. NULL is output for empty blocks.

Thus, if the program is not running, the NULL code is output to the above two blocks.

X. GOT Window Function

8. Details of commands

8.2 melGetGmodalPack

melGetGmodalPack	Gets various modal information in a batch.
------------------	--

Usage example

■ Command

Offset	Details	Setting example	Remarks
0	Data size	16	
1	Spare	0	
2	Command code	0x0F02	Designate melGetGmodalPack
3	Spare	0	
4	Argument 1: Designate part system No.	1	1: 1st part system 2: 2nd part system
5			

The offset is indicated in word units.

X. GOT Window Function

8. Details of commands

■ Response

Offset	Details	Response example	Remarks
0	Data size	190	Number of bytes
1	Spare	0	
2	Command code	0x0F02	Command code issued
3	Spare	0	
4	Error code	0	0 : No error
5			Other than 0 : Error occurring
6~9	S1 modal	"1200"	8-digit S1 modal (ASCII) S1 is output regardless of the part system
10~13	T modal	"13"	8-digit T modal (ASCII)
14~18 (Note1)	F modal	"1200.00"	10-digit FA modal (ASCII)
19~48	G modal	"01 17 91 94" "21 40 49 80" "98 54 64 67" "97 50.143.1"	G modal for each group (ASCII) One group is output with four characters
49	NC status 1	0	0: No alarm message 1: Alarm message found
50~68	NC status 2	"LSK mm INC G40 G54"	When there is no alarm message: ST1 to ST8 are output with ASCII When there is an alarm message: The message is output with up to 33 characters
69~72	Main program No.	"100"	8-digit main program No. (ASCII)
73~76	Main sequence No.	"110"	8-digit main program sequence No. (ASCII)
77~80	Subprogram No.	"9990"	8-digit subprogram No. (ASCII)
81~84	Subprogram sequence No.	"200"	8-digit subprogram sequence No. (ASCII)
85~88	S2 modal	"2000"	8-digit S2 modal (ASCII) S2 is output regardless of the part system
89~92	Current program No.	"9990"	8-digit current program No. (ASCII)
93~96	Currently running program's sequence No.	"200"	8-digit sequence No. of currently running program (ASCII)

The offset is indicated in word units.

(Note 1) The F modal value is a value on which override is not applied.

X. GOT Window Function

8. Details of commands

8.3 melGetAxisPosition

melGetAxisPosition	Gets the coordinate values for all axes in a batch.
--------------------	---

Example of use when getting the machine value (When getting as a character string)

■ Command

Offset	Details	Setting example	Remarks
0	Data size	20	
1	Spare	0	
2	Command code	0x0F03	Designate melGetAxisPosition
3	Spare	0	
4	Argument 1: Designate part system No.	1	1: 1st part system
5			2: 2nd part system
6	Argument 2: Designate the axis to get	3	bit0: 1st axis
7			bit1: 2nd axis ... If the axis is not designated, the values for all axes will be gotten.
8	Argument 3: Designate the type of coordinate value	0	0: Machine value
9			1: Current value 2: Workpiece coordinate value 3: Remaining command 4: Next command
10	Argument 4: Data type	1	0: Interpolation unit (Note 1)
11			1: Character string type (ASCII)

The offset is indicated in word units.

(Note 1) When the command unit is 1 μ m, the interpolation unit is 0.5 μ m.

When the command unit is 0.1 μ m, the interpolation unit is 0.05 μ m.

(Note 2) Only the NC axes are the target axes. The coordinate values for the PLC axes cannot be gotten.

(Note 3) When using the character string type, the diameter designated axis will be displayed as a diameter.

(Note 4) When using the character string type, if the coordinate value exceeds 8 digits, * will be displayed.
(ex.) ***** **

(Note 5) If the number of axes to be gotten exceeds the number of axes actually mounted on the NC, an error will be returned, and the coordinate values, including those for the mounted axes, will not be stored.

X. GOT Window Function

8. Details of commands

■ Response

Offset	Details	Response example	Remarks
0	Data size	44	Number of bytes
1	Spare	0	
2	Command code	0x0F03	Command code issued
3	Spare	0	
4	Error code	0	0 : No error
5			Other than 0 : Error occurring
6~11	1st axis coordinate value	"-12345.678"	8-digit S1 modal (ASCII) S1 is output regardless of the part system
12~17	2nd axis coordinate value	"12345.678"	8-digit T modal (ASCII)
18~23	3rd axis coordinate value	" "	10-digit FA modal (ASCII)

The offset is indicated in word units.

Example of storing "-123.456" in register

	bit15	bit8	bit7	bit0
+0	" "	" "	" "	" "
+1	"-"	" "	" "	" "
+2	"2"	"1"	" "	" "
+3	"."	"3"	" "	" "
+4	"5"	"4"	" "	" "
+5	" "	"6"	" "	" "

X. GOT Window Function

8. Details of commands

Example of use when getting the machine value (When getting as a binary)

■ Command

Offset	Details	Setting example	Remarks
0	Data size	20	
1	Spare	0	
2	Command code	0x0F03	Designate melGetAxisPosition
3	Spare	0	
4	Argument 1: Designate part system No.	1	1: 1st part system
5			2: 2nd part system
6	Argument 2: Designate the axis to get	7	bit0: 1st axis
7			bit1: 2nd axis ... If the axis is not designated, the values for all axes will be gotten.
8	Argument 3: Designate the type of coordinate value	0	0: Machine value
9			1: Current value 2: Workpiece coordinate value 3: Remaining command 4: Next command
10	Argument 4: Data type	0	0: Interpolation unit (Note 1)
11			1: Character string type (ASCII)

The offset is indicated in word units.

(Note 1) When the command unit is 1 μ m, the interpolation unit is 0.5 μ m.

When the command unit is 0.1 μ m, the interpolation unit is 0.05 μ m.

(Note 2) Only the NC axes are the target axes. The coordinate values for the PLC axes cannot be gotten.

(Note 3) If the number of axes to be gotten exceeds the number of axes actually mounted on the NC, an error will be returned, and the coordinate values, including those for the mounted axes, will not be stored.

X. GOT Window Function

8. Details of commands

■ Response

Offset	Details	Response example	Remarks
0	Data size	20	Number of bytes
1	Spare	0	
2	Command code	0x0F03	Command code issued
3	Spare	0	
4	Error code	0	0 : No error
5			Other than 0 : Error occurring
6	1st axis coordinate value	20000	20000-2000=10.000mm
7		(0x4E20)	
8	2nd axis coordinate value	-24690	-24690/2000=-12.345mm
9		(0xFFFF9F8E)	
10	3rd axis coordinate value	1000	1000/2000=0.500mm
11		(0x3E8)	

The offset is indicated in word units.

Example of storing 0xFFFF9F8E (-24690) in register

+0	9F8E
+1	FFFF

X. GOT Window Function

8. Details of commands

8.4 melGetCurrentAlarmMsg2

melGetCurrentAlarmMsg2	Gets the currently occurring alarm message.
------------------------	---

The designated number of up to five currently occurring messages can be gotten in order of priority. The NC alarm/stop code language follows NC parameter "#1043 lang".

Example of use

■ Command

Offset	Details	Setting example	Remarks
0	Data size	16	
1	Spare	0	
2	Command code	0x0F04	Designate melGetCurrentAlarmMsg2
3	Spare	0	
4	Argument 1: Designate part system No.	0	0: All part systems 1: 1st part system 2: 2nd part system ...
5			
6	Argument 2: Number of messages to get	5	1~5
7			
8	Argument 3: Type of alarm to get	0x7	bit0: NC alarm bit1: Stop code bit2: PLC alarm message The alarm messages for which the corresponding bit is ON are gotten.
9			

The offset is indicated in word units.

X. GOT Window Function

8. Details of commands

■ Response

Offset	Details	Response example	Remarks
0	Data size	252	Number of bytes
1	Spare	0	
2	Command code	0x0F04	Command code issued
3	Spare	0	
4	Error code	0	0 : No error
5			Other than 0 : Error occurring
6~7	Number of gotten messages	2	The number of gotten messages (number of occurring alarms) is set.
8~10	Alarm code (1)	0x003300520700	Refer to the Alarm code table
11~31	Alarm message (1)	"S03 Servo error 0052 XYZ \$1"	The message is returned with left justified. A space (0x20) is set in empty areas.
32~34	Alarm code (2)	0x000100000000	
35~55	Alarm message (2)	"EMG Emergency stop EXIN \$1"	
56~58	Alarm code (3)	0x000000000000	0 is set if there is no alarm.
59~79	Alarm message (3)	NULL	NULL(0) is set if there is no alarm.
80~82	Alarm code (4)	0x000000000000	
83~103	Alarm message (4)	NULL	
104~106	Alarm code (5)	0x000000000000	
107~127	Alarm message (5)	NULL	

■ Message format

The NC alarms, stop codes and PLC alarm messages use the following format.

Each message has a fixed length of 21 words (42 characters).

(1) NC alarm/stop code

Message (20 characters) + sp + error No. 1 (4 characters) + sp + error No. 2 (8 characters) + sp + \$1 (2 characters) ^(Note 2) + sp (5 characters)

(2) PLC alarm message

Message (32 characters) + sp + sp + class No. (5 characters) + sp (3 characters)

(Note 1) sp: Space (0x20)


(Note 2) Only when all part systems are designated. When 1st part system or 2nd part system, etc., is designated, this will be sp + sp.

X. GOT Window Function

8. Details of commands

■ Alarm code

The NC alarms, stop code and PLC alarm messages displayed on the NC screen are coded with three words.
(Example) When servo alarm S03 occurs



00000000	00110011	00000000	01010010	00000101	00000000					
PLC axis name	Alarm type	Alarm number			Servo axis name	Spindle name				
		bit								
		7	6	5	4	3	2	1	0	
1st axis		0	0	0	0	0	0	0	1	The bit corresponding to the axis No. at which the alarm occurs turned ON for the servo axis name, spindle axis name and PLC axis name. If several alarms occur simultaneously, several bits will turn ON.
2nd axis		0	0	0	0	0	0	1	0	
3rd axis		0	0	0	0	0	1	0	0	
4th axis		0	0	0	0	1	0	0	0	
5th axis		0	0	0	1	0	0	0	0	
6th axis		0	0	1	0	0	0	0	0	
7th axis		0	1	0	0	0	0	0	0	
8th axis		1	0	0	0	0	0	0	0	

■ Alarm code table

The alarm types and alarm Nos. follow the next table.
 The alarm with priority 1 has the highest priority.

Alarm		Details	Alarm type	Presence of axis name	Priority
NC alarm					
Operation error	M01	OPERATION ERROR	0x11	Some are added.	8
Servo/spindle alarm	S01	SERVO ALARM:PR	0x31	Added.	2
	S02	INIT PARAM ERR	0x32		
	S03	SERVO ALARM:NR	0x33		
	S04	SERVO ALARM:AR	0x36		
	S51	PARAMETER ERROR	0x34	Added.	6
S52	SERVO WARNING	0x35			
MCP alarm	Y02	SYSTEM ALARM	0x41	Not added.	3
	Y03	AMP. UNEQUIPPED	0x42		
	Y51	PARAMETER ERROR	0x45		
	Y90	SP. NON SIGNAL	0x47		
System alarm	Z52	BATTERY FAULT	0x52	Not added.	7
	Z53	TEMP. OVER	0x53		
	Z55	RIO NOT CONNECT	0x54		
	Z59	TIME CONSTANT	0x59		
	Z70	ABS. ILLEGAL	0x55	Added.	1
	Z71	DETECTOR ERROR	0x56		
	Z72	COMPARE ERROR	0x57		
	Z73	ABS. WARNING	0x58		
P990	PREPRO S/W ERR	0x61	Not added.	5	

X. GOT Window Function

8. Details of commands

Alarm		Details		Alarm type	Presence of axis name	Priority
NC alarm (continued)						
Program error	P***	Program error		0x71	Not added.	5
Auxiliary axis (MR-J2-CT) alarm (Note 1)	M00	AUX OPER.ALM		0x81	Added.	8
	M01	AUX OPER.ALM		0x82		
	S01	AUX SERVO ALM		0x83	Added.	2
	S02	AUX SERVO ALM		0x84		
	S03	AUX SERVO ALM		0x85		
	S52	AUX SERVO WRN		0x86		
	Y02	AUX SYSTEM ALM		0x87		
	Y03	AUX AMP UNEQU.		0x88	Some are added.	3
	EMG	AUX EMERGENCY		0x89		
	Z70	AUX POS. ERR		0x8A		
	Z71	AUX DETEC. ERR		0x8B	Added.	1
	Z73	AUX SYSTEM WRN		0x8C		
Emergency stop	EMG	EMERGENC		0x01	Not added.	4
Stop code						
Stop code	T01	CAN'T CYCLE ST		0x21	Not added.	9
	T02	FEED HOLD		0x22		
	T03	BLOCK STOP		0x23		
	T04	COLLATION STOP		0x24		
	T10	FIN WAIT		0x26		
PLC alarm message	(Arbitrary character string)		0x91	Not added.	10	

(Note 1) If multiple alarms occur simultaneously, only the alarm with the highest order of priority in the code table will be output. Note that the auxiliary axis name is output to the servo axis name area.

The messages for emergency stop are coded as shown below.

Alarm		Details	Alarm number
EMG emergency stop	EXIN	External emergency stop	0x0000
	PLC	User PLC emergency stop	0x0001
	SRV	Servo drive unit not ready	0x0002
	STOP	User PLC not running	0x0003
	SPIN	Spindle drive unit not ready	0x0004
	PC_H	PLC high-speed process error	0x0005
	PARA	Door open II fixed device setting illegal	0x0006
	LINK	No communication with external PLC	0x0007
	WAIT	Waiting for external PLC communication	0x0008
	XTEN	External PLC emergency stop	0x0009
	LAD	User PLC illegal code	0x0010

X. GOT Window Function

8. Details of commands

The PLC alarm messages are coded as shown below.

Alarm	Details	Alarm number
PLC alarm message	(Arbitrary character string) + contents of registered D register	For corresponding F device (ex) F64: 64, or When contents of corresponding R register (ex) R118 are the target, and contents of R118 are 64: 64

There are two interfaces for displaying the PLC alarm messages on the NC screen, the "F method" that makes a display request with the temporary memory F, and the "R method" that makes a display request with the file register (R). The method can be selected with the parameters.

Up to four PLC alarm messages can be displayed at once on the Alarm Diagnosis screen.

(1) F method interface

The 128 points from F0 to F127 in the temporary memory are the target.

The priority of the F0 to F127 signals starts with F0. Starting from F0, the messages corresponding to the Fn which is set to 1 are gotten from the message table and displayed.

(2) R method interface

The file registers R118, R119, R120 and R121 are the target.

The values (binary) set in these R registers are the values that indicate which number message in the message table to display.

The messages are cleared by setting the R register contents to 0.

The messages are displayed in order from the message corresponding to R118.

Since the display is cleared when the contents of the R register are set to 0, No. 0 in the message table cannot be used when using the R method.

(3) Parameter for switching between F method and R method

Switch between the methods with the PLC parameter #6450/bit1.

bit1=0: F method bit1=1: R method

X. GOT Window Function

8. Details of commands

8.5 mmeIGetAlarmHistory

melGetAlarmHistory	Gets the alarm history information.
--------------------	-------------------------------------

■ Details of alarm history

- The alarm history information saved in the NC is gotten.
- The NC alarm history information is gotten from the history data displayed on the NC "Operation History" screen.
- The history is sorted in order of latest data and is gotten.
- The history for up to 168 alarms can be stored in the NC.
When 168 alarms are exceeded, the history will be deleted in order from the oldest alarms.
- The stop codes and PLC alarm messages are not stored in the operation history.
- The following NC alarms are not stored in the operation history.
 - M01 Operation error 0004 (External interlock axis found)
 - M01 Operation error 0005 (Internal interlock axis found)
 - M01 Operation error 0109 (Block start interlock)
 - M01 Operation error 0110 (Cutting block start interlock)

■ Alarm history message format

The length of one message is fixed to a total of 60 characters as shown below.
The blank spaces of the message are filled in with space codes.

03/01/01	sp	13:59:02	sp	P153 LF ERROR	sp	sp	...	\$ 1	sp	sp	sp
Year/month/date		Hour:minute:second		Message							
8 characters		1 character	8 characters		1 character	42 characters					

(Note 1) The part system No. (\$1, \$2, etc.) is indicated at the 38th and 39th characters of the message.
For the 1st part system, the part system No. is indicated as sp+sp.

X. GOT Window Function

8. Details of commands

Due to limitations to the response area size, M alarms are gotten from the history for the latest Nth alarms. Up to four alarm histories can be gotten at once. Thus, to get the entire alarm history in the NC, up to 42 retrievals must be used.

Example of use

■ Command

Offset	Details	Setting example	Remarks
0	Data size	12	
1	Spare	0	
2	Command code	0x0F05	Designate melGetAlarmHistory
3	Spare	0	
4	Argument 1: Head history number of history data to be retrieved	10	0: Retrieve from latest history data 1: Retrieve from previous history data 2: Retrieve from second to previous history data
5			
6	Argument 2: Number of histories to retrieve	4	1~4
7			

The offset is indicated in word units.

■ Response

Offset	Details	Response example	Remarks
0	Data size	252	Number of bytes
1	Spare	0	
2	Command code	0x0F05	Command code issued
3	Spare	0	
4	Error code	0	0 : No error
5			Other than 0 : Error occurring
6~7	Number of retrieved histories	3	The number of retrieved histories is set.
8~37	Alarm history (1)	"03/01/01 15:20:26 EMG EMERGENCY EXIN \$3 "	-24690/2000=-12.345mm
38~67	Alarm history (2)	"03/01/01 15:20:26 EMG EMERGENCY EXIN \$2 "	1000/2000=0.500mm
68~97	Alarm history (3)	"03/01/01 15:20:26 EMG EMERGENCY EXIN \$1 "	
98~127	Alarm history (4)	" "	A space is set if there is no alarm history.

XI. Remote Monitor Tool

XI. Remote Monitor Tool

1. Outline

1. Outline

The C64 series remote monitor tool is the software capable of the following functions.

- Remotely monitoring NC screens by using intranet
- Inputting and outputting parameters / machining programs

2. System Configuration

2.1 System Requirements

Remote monitor tool works on the following system requirements.

Items	Details
Processor	Pentium 100MHz or faster
RAM	64MB or more
Hard disk space	50MB or more (apart from the capacity required for OS)
OS	Microsoft Windows95/98 or Microsoft WindowsNT4.0
Interface	10/100M Ethernet
Monitor	Resolution 800 x 600 or more, 256 colors or more
Restriction on the number of Remote Monitor Tools connected	Maximum 8 NC screens per 1 NC can be connected. (Including setup/maintenance tool)
Connectable NC	MELDAS C6/C64/C64T Ver. C or later versions. (Ethernet option card must be mounted in this case.)

2.2 Contents of Software Package

The software package consists of the following items.

- C64 series Remote monitor tool installation disk
- Software license agreement

XI. Remote Monitor Tool


3. Installation of Remote Monitor Tool

3. Installation of Remote Monitor Tool

- (1) Insert an installation disk into a CD-ROM drive. After a while, the setup program of Remote monitor tool starts. (In the case of the personal computer with which reading of CD-ROM is not automatically performed, double-click Setup.exe in a setup disk.) Choose the language used by installation and click "OK" button.




- (2) The screen of "Welcome!" is displayed. Click a "Next" button according to the dialogue in a screen.




XI. Remote Monitor Tool

3. Installation of Remote Monitor Tool

- (3) Next, the "License Agreement" screen is displayed. When you read the contents well and agree with the license agreement, click "Yes". Click "NO" to cancel installation. If clicked "Back", it will return to the screen of "Welcome".



- (4) Next, the "Choose Destination Location" screen is displayed. Here, the directory which installs Remote monitor tool can be chosen. When you install in other directories, click "Browse" and choose a directory. Click "Next", if selection is made, then installation of Remote monitor tool is started.



4. Uninstalling the Remote Monitor Tool

Uninstall the remote monitor tool with following steps.

- (1) Quit the remote monitor tool.
- (2) Click [Start] → [Setting] → [Control panel].
- (3) Double-click on [Add/Remove Program].
- (4) Click on "Remote monitor tool".
- (5) Click on "Add/Remove".
- (6) Follow the onscreen instructions.

XI. Remote Monitor Tool


5. How to Start and Operate

5. How to Start and Operate

How to start and operate the remote monitor tool software is explained in this section.

5.1 Starting Remote Monitor Tool

Click on [Start] → [Program] → [MELDAS C64] → [Remote monitor tool]. Multiple windows of the remote monitor tool can be opened, so the 1st and 2nd NC can be monitored simultaneously.




XI. Remote Monitor Tool

5. How to Start and Operate

5.2 Screen Makeup of Remote Monitor Tool


The window of Remote monitor tool consists of a title bar, menu bar, status bar and NC information display etc.



5.3 Basic Operation of Remote Monitor Tool

5.3.1 Title Bar

Title bar shows the tool name "ReC64Monitor"



Item	Details
Tool name	The tool name is displayed. The tool name is used for being identified in Windows.
IP address of the connected NC	When the tool is in online mode, the IP address of connected NC is displayed.
Iconification of tool	Click this button to minimize the window of Remote monitor tool to the size of an icon and to be contained in the task bar.
Exit	Click this button to exit from Remote monitor tool.

XI. Remote Monitor Tool

5. How to Start and Operate

5.3.2 Menu Bar

Each function including connection destination designation is able to be selected from the menu bar.

(1) File menu

The commands for the basic operation of the tool are allocated on the [File (F)] menu.

Sub menu	Details
<u>C</u> onnect	This connects with the designated NC. When selecting this menu, the dialogue box to designate connection destination shows up.
Translate	This is used when sending and receiving the parameters, machining programs and maintenance data to and from NC. By selecting each menu item, file transferring tool will be activated.
<u>O</u> nline	This is used for selecting online (connecting) mode or offline (disconnecting) mode.
<u>E</u> xit	This exits from Remote monitor tool.

(2) Help menu

An explanation about the operation etc. is allocated on the [Help] menu.

Sub menu	Details
<u>H</u> elp topics	This displays the explanation of how to treat Remote monitor tool.
<u>A</u> bout Remote monitoring tool	This shows the software version of Remote monitor tool.

5.3.3 Connect with Machine Tools (NC)

Select [File] → [Connect] from the menu bar and display the [Connection] dialogue box.


Input the IP address of the NC to connect with and press the button [Connect].

If the communication is started normally, a screen of the connected NC will be displayed.

(The screen of the connected NC is displayed only when "Base specification parameters #21034" is set to "0").

If any communication error occurs, [Communication Error] will be displayed on the status bar. By describing NC list in the Hosts File in advance, the NC to connect with can be selected from the list.

Refer to "8. Supplement" of this chapter for creating the host files.



XI. Remote Monitor Tool

5. How to Start and Operate

5.3.4 Send and Receive a Parameter File

Select [File] → [Translate] → [Parameter] → [Text] from the menu bar.

Or, select [Binary] and display the [Parameter–Text] dialogue box or the [Parameter–Binary] dialogue box.



Receiving a parameter file

When receiving a parameter file from NC, select "ALL.PRM" (text format) or "PARAMET.BIN" (binary format) and press the [Receive] button.

Sending a parameter file

When sending a parameter file to NC, press [Send] button, designate the directory to store the file and a file name of the sending file and then press the [Open] button.

(Note) The parameters can be sent when sending is validated with "ReC64Monitor.ini". Refer to "8. Supplement" of this chapter for details on setting this parameter.



XI. Remote Monitor Tool

5. How to Start and Operate

5.3.5 Send and Receive the Program

Select [File] → [Translate] → [Program] → [Text] from the menu bar.

Or, select [Binary] and display the [Program–Text] dialogue box or the [Program–Binary] dialogue box.

Receiving a machining program file



When receiving a machining program file from NC, select the program from the list, designate directory to store the file and the file name and then press the [Receive] button.

When selecting a machining program file, plural files can be selected by clicking the file names displayed in the list while pressing Ctrl key.

Sending a machining program file

When sending a machining program file to NC, press the [Send] button, select the sending program from the list and press the [Open] button.

(Note) The parameters can be sent when sending is validated with "ReC64Monitor.ini". Refer to "8. Supplement" of this chapter for details on setting this parameter.




XI. Remote Monitor Tool

5. How to Start and Operate

5.3.6 Receiving a Maintenance Data

Select [File] → [Translate] → [Maintenance] from the menu bar, and display [Maintenance] dialogue box.



The maintenance data is used for protecting the user's data or for investigating the cause of the problem. When receiving a maintenance file from NC, select "SRAM.BIN" in the displayed list, designate the directory to store the data and the file name and then press the [Receive] button.

5.3.7 Refer to NC Information

Press the keyboard or click the buttons on the screen with a mouse to work on the NC information

The keyboard keys used for NC information reference are as shown below.


Keyboard keys	Buttons to be clicked
F1	Menu 1
F2	Menu 2
F3	Menu 3
F4	Menu 4
F5	Menu / Operation
F6	Position display
F7	Alarm diagnosis
F8	Tool offset / Param.
F9	Program
→, ←, ↑, ↓	Cursor
Page up, Page Dn	Back / Next
Home	C+B/CAN
Insert	Add
Delete	Delete
Back space	Delete
Tab, Shift + Tab	Tab / Shift + Tab
;	EOB
Enter	INPUT
0 ~ 9	0 ~ 9
!, #, \$, (,), =, -, +, [,], *, /	!, #, \$, (,), =, -, +, [,], *, /
”	”
SPACE	Space

XI. Remote Monitor Tool

5. How to Start and Operate


5.3.8 Search the Topics

Select [Help] → [Help Topics] from the menu bar, and display the help screen. On the "table-of-contents" page, the help system consists of a format of a volume and a page.



5.3.9 Confirm the Remote Monitor Tool Version

Select [Help] → [About Remote monitoring tool] from the menu bar, and display the [Version] dialogue box for version information.




XI. Remote Monitor Tool

5. How to Start and Operate


5.3.10 Using a Tool Bar

Designation of the NC to connect with or other functions can be used without selecting from the menu. Besides, the outline of the function is displayed by placing the cursor on the tool bar.



5.3.11 Using a Status Bar

The status of Remote monitor tool including communication status is displayed on the status bar.



No.	Display	Details
1	ONLINE	This means the status in which Remote monitor tool is communicating with the designated NC. Select the [START / STOP] button on the tool bar or select [Offline] in the menu to change the status to the offline mode.
2	OFFLINE	This means the status in which Remote Monitor Tool is not communicating with the designated NC. Select the [START / STOP] button on the tool bar or select [Online] in the menu to change the status to the online mode.
3	COMMUNICATION ERROR	This means that the communication error between Remote monitor tool and the connected NC has occurred.
4	DISPLAY INVALID	This means the status in which the NC screen cannot be displayed by Remote monitor tool due to the incorrect NC parameter settings. NC screen can be displayed by setting "Base specification parameters #21034" to "0".
5	READY	This status is displayed when the connected NC is ready to start operating.

XI. Remote Monitor Tool

6. Setting NC Parameters

6. Setting NC Parameters

By setting Base specification parameters in NC, the key operation and the display can be restricted.

#	Item	Detail	Setting range	Standard setting value
21033	KeyCtrlLmt	Restriction on the right to operate the keys	0 to 2	0
21034	ReMonDisp	Display restriction	0 to 1	0

XI. Remote Monitor Tool

7. Error Message and Its Remedy

7. Error Message and Its Remedy

The details of the errors that would occur while Remote monitor tool is running and the remedies are listed below.

No.	Message	Details	Remedy
1	Communication error	Communication error is occurring between Remote monitor tool and the designated NC.	Confirm the following items and retry. Confirm: <ul style="list-style-type: none"> • that the designated IP address is correct. • that there is no problem with a connecting cable. • that the ping command in the designated IP address is normal. • that the communication traffic is not crowded.
2	Duplication error	More than 1 dialogue boxes for transferring files are opened.	If more than 1 dialogue boxes for transferring files are opened, close them leaving only 1 dialogue box.
3	Directory open error	The directory information was not acquired successfully in the file transferring dialogue.	Confirm the following items and retry. Confirm: <ul style="list-style-type: none"> • that there is no problem in the file system of the connected NC. • that no communication error is occurring.
4	Directory search error	The directory information was not searched successfully in the file transferring dialogue.	Confirm the following items and retry. Confirm: <ul style="list-style-type: none"> • that there is no problem in the file system of the connected NC. • that no communication error is occurring.
5	Reserved word	"COM1 to COM9, LPT1 to LPT9, AUXCON, PRN, NUL, CLOCK" has already reserved in the system.	Use words other than "COM1 to COM9, LPT1 to LPT9, AUXCON, PRN, NUL, CLOCK"
6	Incorrect file name	"/,;,;,*?"<> " or Tab is used for the file name.	Do not use "/,;,;,*?"<> " nor Tab when naming the title of the file.
7	Select file name	The file to send or receive is not selected.	Retry after selecting the file to send or receive.
8	File reception error	Error has occurred while receiving a parameter file, machining program file or maintenance data.	Confirm the following items and retry. Confirm: <ul style="list-style-type: none"> • that there is no problem in the file system of the connected NC. • that no communication error is occurring.
9	File sending error	Error has occurred while sending a parameter file or machining program file.	Confirm the following items and retry. Confirm: <ul style="list-style-type: none"> • that there is no problem in the file system of the connected NC. • that no communication error is occurring. • that the connected NC is not in the data protect mode. • that the connected NC is running.
10	File designation error	The designated file does not exist.	Confirm that the designated file exists and retry.
11	File deletion error	When overwriting a sending or receiving a file, the file was not deleted successfully.	When overwriting a file on PC side, confirm that the property of the file is not set to "read only". When overwriting a file on NC side, confirm the following items and retry. Confirm: <ul style="list-style-type: none"> • that there is no problem in the file system of the connected NC. • that no communication error is occurring. • that the connected NC is not in the data protect mode. • that the connected NC is running.


XI. Remote Monitor Tool

8. Supplement

8. Supplement

(1) Key operation rights

To operate a screen when another display (NC dedicated display or adjustment and maintenance tool) is connected, press the F5 key or "Key operation rights" button to retrieve the screen operation rights.



(2) Number of simultaneous connections

Up to eight "remote monitor tool + operation panel (adjustment and maintenance tool)" sets can be connected at once. A communication error message will appear if more are connected.

(3) Creating the hosts file

By saving the Hosts file with the following format under the name "C64Hosts" in the C:\Program files\MELDAS C64\Remote monitor tool (default installation directory), a list of the connection destinations can be displayed. Set the name of the connection destination with up to 20 characters, excluding spaces and tabs.

= Comment

IP address [space] connection destination name

Description example

#C64 connection destination list	
#	
192.168.1.2	SP117
192.168.1.3	SP118
192.168.1.4	SP119
192.168.1.5	SP120
192.168.1.6	SP121

(4) Setting the parameter/machining program file transmission validity

To validate transmission of parameter files or machining program files, add the line "DOWNLOAD=1" to the "ReC64Monitor.ini" file located in the "C:\Program files\MELDAS C64\Remote monitor tool (default installation directory)".

[Setting example]

[COMMUNICATION]

DOWNLOAD=1

Revision History

Date of revision	Manual No.	Revision details
Sep. 2003	BNP-B2373*	First edition created.
Apr. 2004	BNP-B2373A	<p>The following changes were made to comply with the software version D.</p> <p>(1) The following chapters were added.</p> <ul style="list-style-type: none"> • "V Ethernet 2-channel Connection" • "VII Ethernet Interface Communication Function Using PLC (Client Function Section)" • "VIII I/O/Intelligent Function Unit Connection Function" <p>(2) The following chapter was deleted.</p> <ul style="list-style-type: none"> • "VIII FL-net interface" • "IX Appendix" → (Moved to Chapter II and Chapter X.) <p>(3) The number of steps was changed in "III CC-Link Master/local Unit".</p> <p>(4) The contents of "IX GOT Connection Function" (previous Chapter VII) were totally reviewed.</p> <p>(5) Mistakes, etc., were corrected.</p>
Dec. 2004	BNP-B2373B	<p>(1) "X. GOT Window Function" was added.</p> <p>(2) The following chapters' explanations were added.</p> <ul style="list-style-type: none"> • "VIII MELSEC Q Series I/O/Intelligent Function Unit Connection Function" • "IX. Connection Function with GOT"

Notice

Every effort has been made to keep up with software and hardware revisions in the contents described in this manual. However, please understand that in some unavoidable cases simultaneous revision is not possible.

Please contact your Mitsubishi Electric dealer with any questions or comments regarding the use of this product.

Duplication Prohibited

This instruction manual may not be reproduced in any form, in part or in whole, without written permission from Mitsubishi Electric Corporation.

© 2003-2004 MITSUBISHI ELECTRIC CORPORATION
ALL RIGHTS RESERVED



MODEL	MC6/C64
MODEL CODE	008-270
Manual No.	BNP-B2373B(ENG)

Specifications subject to change without notice.
Printed in Japan on recycled paper.