



*Changes for the Better*

**MITSUBISHI CNC**

**Setup Manual**

**M700VS Series**



MELDAS is a registered trademark of Mitsubishi Electric Corporation.

Other company and product names that appear in this manual are trademarks or registered trademarks of the respective companies.



# Introduction

This is a setup manual for MITSUBISHI CNC M700VS Series.





This manual is written on the assumption that with all of the MITSUBISHI CNC M700VS Series functions are added, but the actually delivered NC may not have all optional functions.

Refer to the specifications issued by machine tool builder to confirm the functions available for your NC before proceeding to operation.

## Notes on Reading This Manual

- (1) This manual explains general parameters as viewed from the NC.  
For information about each machine tool, refer to manuals issued from the machine tool builder.  
If the descriptions relating to "restrictions" and "allowable conditions" conflict between this manual and the machine tool builder's instruction manual, the later has priority over the former.
- (2) This manual is intended to contain as much descriptions as possible even about special operations.  
The operations to which no reference is made in this manual should be considered "impossible".
- (3) The "special display unit" explained in this manual is the display unit incorporated by the machine tool builder, and is not the MITSUBISHI standard display unit.
- (4) This manual is for the machine tool builders who set up the NC system.

## CAUTION

-  If the descriptions relating to the "restrictions" and "allowable conditions" conflict between this manual and the machine tool builder's instruction manual, the latter has priority over the former.
-  The operations to which no reference is made in this manual should be considered "impossible".
-  This manual is compiled on the assumption that your machine is provided with all optional functions. Refer to the specifications issued by machine tool builder to confirm the functions available for your NC before proceeding to operation.
-  In some NC system versions, there may be cases that different pictures appear on the screen, the machine operates in a different way or some function is not activated.









## Precautions for Safety

Always read the specifications issued by the machine tool builder, this manual, related manuals and attached documents before installation, operation, programming, maintenance or inspection to ensure correct use.





Understand this numerical controller, safety items and cautions before using the unit.

This manual ranks the safety precautions into "DANGER", "WARNING" and "CAUTION".











 <b>DANGER</b>	<b>When the user may be subject to imminent fatalities or major injuries if handling is mistaken.</b>
 <b>WARNING</b>	<b>When the user may be subject to fatalities or major injuries if handling is mistaken.</b>
 <b>CAUTION</b>	<b>When the user may be subject to injuries or when physical damage may occur if handling is mistaken.</b>

Note that even items ranked as "  CAUTION", may lead to major results depending on the situation. In any case, important information that must always be observed is described.

The following signs indicate prohibition and compulsory.

	<b>This sign indicates prohibited behavior (must not do).</b> For example,  indicates "Keep fire away".
	<b>This sign indicates a thing that is compulsory (must do).</b> For example,  indicates "it must be grounded".

The meaning of each pictorial sign is as follows.

 <b>CAUTION</b>	 <b>CAUTION rotated object</b>	 <b>CAUTION HOT</b>	 <b>Danger Electric shock risk</b>	 <b>Danger explosive</b>
 <b>Prohibited</b>	 <b>Disassembly is prohibited</b>	 <b>KEEP FIRE AWAY</b>	 <b>General instruction</b>	 <b>Earth ground</b>

 **DANGER**





Not applicable in this manual.

 **WARNING**


 **Do not cancel the emergency stop before confirming the basic operation.**

## CAUTION





### 1. Items related to product and manual

-  If the descriptions relating to the "restrictions" and "allowable conditions" conflict between this manual and the machine tool builder's instruction manual, the latter has priority over the former.
-  The operations to which no reference is made in this manual should be considered "impossible".
-  This manual is compiled on the assumption that your machine is provided with all optional functions. Confirm the functions available for your machine before proceeding to operation by referring to the specification issued by the machine tool builder.
-  In some NC system versions, there may be cases that different pictures appear on the screen, the machine operates in a different way on some function is not activated.

### 2. Items related to faults and abnormalities

-  If the battery low warning is issued, save the machining programs, tool data and parameters in an input/output device, and then replace the battery. When the battery alarm is issued, the machining programs, tool data and parameters may have been destroyed. Replace the battery and then reload the data.

### 3. Items related to setup
















-  Always set the stroke end and stroke limit. Failure to set this could result in collision with the machine end.
-  Do not adjust the spindle when possible risks associated with adjustment procedures are not thoroughly taken into consideration.
-  Be careful when touching spindle's rotating section, or your hand may be caught in or cut.
-  The analog output R registers are allocated in ascending order of channels and station numbers automatically. Therefore, the analog output destination may change depending on the added option.

[Continued to next page]



## CAUTION

[Continued]

### 4. Items related to maintenance

-  Do not replace the battery while the power is ON.
-  Do not short-circuit, charge, overheat, incinerate or disassemble the battery.
-  Dispose the spent battery according to the local laws.
-  Do not connect or disconnect the cables between units while the power is ON.
-  Do not pull the cables when connecting/disconnecting them.
-  Do not replace the backlight while the power is ON.
-  Dispose the spent backlight according to the local laws.
-  Do not touch the backlight while the power is ON. Failure to observe this could result in electric shocks due to high voltage.
-  Do not touch the backlight while the LCD panel is in use. Failure to observe this could result in burns.
-  Do not apply impact or pressure on the LCD panel or backlight. Failure to observe this could result in breakage as they are made of glass.
-  Incorrect connections could cause devices to damage. Connect the cables to designated connectors.
-  Do not replace the control unit while the power is ON.
-  Do not replace the display unit while the power is ON.
-  Do not replace the keyboard unit while the power is ON.
-  Do not replace the operation panel I/O unit while the power is ON.

### 5. Items related to servo parameters and spindle parameters

-  Do not adjust or change the parameter settings greatly as operation could become unstable.
-  In the explanation on bits, set all bits not used, including blank bits, to "0".



## Disposal



(Note) This symbol mark is for EU countries only.  
This symbol mark is according to the directive 2006/66/EC Article 20 Information for end-users and Annex II.

Your MITSUBISHI ELECTRIC product is designed and manufactured with high quality materials and components which can be recycled and/or reused.

This symbol means that batteries and accumulators, at their end-of-life, should be disposed of separately from your household waste.

If a chemical symbol is printed beneath the symbol shown above, this chemical symbol means that the battery or accumulator contains a heavy metal at a certain concentration. This will be indicated as follows:

Hg: mercury (0,0005%), Cd: cadmium (0,002%), Pb: lead (0,004%)

In the European Union there are separate collection systems for used batteries and accumulators.

Please, dispose of batteries and accumulators correctly at your local community waste collection/recycling centre.

Please, help us to conserve the environment we live in!



## 本製品の取扱いについて

(日本語 /Japanese)

本製品は工業用 ( クラス A) 電磁環境適合機器です。販売者あるいは使用者はこの点に注意し、住商業環境以外での使用をお願いいたします。

## Handling of our product

(English)

This is a class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.

## 본 제품의 취급에 대해서

( 한국어 /Korean)

이 기기는 업무용 (A 급) 전자파적합기기로서 판매자 또는 사용자는 이 점을 주의하시기 바라며 가정외의 지역에서 사용하는 것을 목적으로 합니다 .





# CONTENTS

<b>1 Setup Outline</b>	<b>1</b>
1.1 Device Configuration	2
1.2 Hardware Configuration	3
1.3 Flow of Initial Setup	4
<b>2 Connecting and Setting the Hardware</b>	<b>5</b>
2.1 Connecting and Setting the Drive Unit	6
2.1.1 Connecting with Servo Drive Unit	6
2.1.1.1 Connecting with MDS-D/DH Series	7
2.1.1.2 Connecting with MDS-DM Series	10
2.1.1.3 Connecting with MDS-SVJ3/SPJ3 Series	15
2.1.2 Setting up without Connecting to the Motor/ Drive unit	15
2.2 Setting the Rotary and DIP Switches	16
2.2.1 MDS-D/DH Series	16
2.2.2 MDS-DM Series	18
2.2.3 MDS-D-SVJ3/SPJ3 Series	20
2.3 Connecting the Batteries	21
2.3.1 Control Unit Battery	21
2.3.2 Servo Drive Unit Battery	22
2.4 Connecting and Setting the Remote I/O Unit	24
2.4.1 Outline of the Remote I/O Unit	24
2.4.2 Connection and Station No. Setting on Remote I/O Unit	26
2.4.3 Station No. Setting when Using Multiple Remote I/O Units	28
2.4.4 Device No. Assignment	32
2.5 Initializing the NC Internal Data (SRAM)	34
<b>3 Setting Up with M70/M700 SETUP INSTALLER</b>	<b>35</b>
3.1 Compatible Data and Folder Configuration in the CF Card	37
3.2 Operation Procedure	39
3.2.1 Starting Up M70/M700 SETUP INSTALLER	39
3.2.2 Installing Language Data	39
3.2.3 Installing Custom Data	41
3.2.4 Uninstalling Custom Data	42
3.2.5 Installing Custom Startup Screen	43
3.2.6 Uninstalling Custom Startup Screen	44
3.3 List of Error Messages	45
<b>4 Setting the Parameters and Date/Time</b>	<b>47</b>
4.1 Selecting the NC System Type	48
4.2 Setting on the System Setup Screen	49
4.3 Setting the Parameters for the Machine Specifications	53
4.4 Setting Date and Time	55
<b>5 PLC Program Writing</b>	<b>57</b>
5.1 Setting the Ethernet Communication	58
5.2 Connecting the Control Unit and a Personal Computer	59
5.3 Setting the Communication with GX Developer	60
5.4 Setting the Parameters on GX Developer	62
5.5 Writing a PLC Program with GX Developer	64
5.6 Writing a PLC Program to ROM with GX Developer	65
5.7 Setting the PLC Parameters	67
<b>6 Confirming the Basic Operation</b>	<b>69</b>
6.1 Checking Inputs/Outputs and Alarms	70
6.2 Confirming Manual Operation	71
6.2.1 Using the Manual Pulse Generator	71
6.2.2 Using JOG Feed	71
6.2.3 Servo Simplified Adjustment	72
6.2.3.1 First Measure Against Vibration	72
6.2.3.2 Outline of MS Configurator	73

<b>7 Setting the Position Detection System .....</b>	<b>75</b>
7.1 Adjusting the Absolute Position Detection System .....	76
7.1.1 Marked Alignment Method I .....	77
7.1.2 Marked Point Alignment Method II .....	78
7.1.3 Other Setting Method.....	79
7.1.3.1 Machine End Stopper Method: Automatic Initialization .....	79
7.1.3.2 Machine End Stopper Method: Manual Initialization.....	82
7.1.3.3 Dog-type.....	83
7.1.4 Precautions.....	84
7.1.4.1 Precautions common for the initialization operation.....	84
7.1.4.2 Precautions common for the dogless-type absolute position detector.....	84
7.2 Adjustment of Reference Position Return in Relative Position Detection System .....	86
7.2.1 Dog-type Reference Position Return .....	86
7.2.1.1 Dog-type Reference Position Return Operation .....	86
7.2.1.2 Dog-type Reference Position Return Adjustment Procedures .....	87
<b>8 Setting the Tool Entry Prohibited Range .....</b>	<b>93</b>
8.1 Stroke End (H/W OT) .....	94
8.2 Stored stroke limit (S/W OT) .....	95
8.2.1 Outline.....	95
8.2.2 Detailed Explanation.....	97
8.2.2.1 Stored Stroke Limit I .....	98
8.2.2.2 Stored Stroke Limit II .....	99
8.2.2.3 Stored Stroke Limit IB.....	101
8.2.2.4 Stored Stroke Limit IC.....	102
8.2.2.5 Movable Range during Inclined Axis Control .....	103
8.2.2.6 Stored Stroke Limit for Rotation Axis .....	104
8.2.2.7 Precautions .....	104
<b>9 Confirming the Spindle Operation.....</b>	<b>105</b>
9.1 In Manual Operation (with Manual Numerical Command) .....	106
9.2 In MDI Operation .....	107
9.3 Confirming the Rotation Speed.....	107
<b>10 Setting the Deceleration Check .....</b>	<b>109</b>
10.1 Function.....	110
10.2 Deceleration Check Method.....	111
10.3 Deceleration Check for Opposite Direction Movement Reversal.....	113
10.4 Parameter .....	114
10.5 Precautions .....	116
<b>11 Data Backup and Restoration .....</b>	<b>117</b>
11.1 All Backup .....	118
11.2 All Restoration .....	121
<b>12 Hardware Replacement Methods.....</b>	<b>123</b>
12.1 Durable Parts .....	124
12.1.1 Control Unit Battery .....	124
12.1.2 Display Unit Cooling Fan.....	126
12.1.3 Backlight .....	127
12.1.4 Fuse.....	129
12.1.4.1 Control Unit Protection Fuse .....	129
12.1.4.2 Operation Panel I/O Unit Protection Fuse.....	129
12.1.5 Front Memory Interface Card .....	130
12.1.6 Touch Panel Protective Sheet.....	131
12.1.7 Key Sheet.....	132
12.2 Control Unit .....	133
12.2.1 Installation on FCU7-DU120-11 (8.4-type).....	135
12.2.2 Installation on FCU7-DU140-11/31 (10.4-type).....	136
12.2.3 Installation on FCU7-DU140-31 (10.4-type touch panel).....	137
12.2.4 Calibration Setting and Confirmation .....	138
12.3 Display Unit .....	141
12.4 Keyboard Unit .....	142
12.5 Operation Panel I/O Unit .....	143
12.6 CompactFlash (CF) Card.....	144

12.7 USB Memory .....	145
<b>13 Cables .....</b>	<b>147</b>
13.1 Precautions when Connecting/Disconnecting Cables .....	148
13.2 Precautions for Using Optical Communication Cable.....	151
13.2.1 Optical Communication Cable Outline and Parts.....	151
13.2.2 Precautions for Handling Optical Communication Cable.....	151
13.2.3 Precautions for Laying Optical Communication Cable .....	152
<b>Appendix 1 Explanation of Parameters .....</b>	<b>153</b>
Appendix 1.1 User Parameters .....	154
Appendix 1.2 Base Specifications Parameters .....	220
Appendix 1.3 Axis Specifications Parameters .....	289
Appendix 1.4 Servo Parameters .....	319
Appendix 1.5 Spindle Parameters .....	352
Appendix 1.6 Rotary Axis Configuration Parameters.....	408
Appendix 1.7 Machine Error Compensation Parameters .....	415
Appendix 1.8 PLC Constants .....	417
Appendix 1.9 Macro List.....	420
Appendix 1.10 Position Switches.....	430
Appendix 1.11 Open Parameters .....	444
Appendix 1.12 Device Open Parameters .....	445
Appendix 1.13 SRAM Open Parameters .....	446
Appendix 1.14 CC-Link Parameters .....	447
Appendix 1.15 Anshin-net Parameters 2/ MTB-net Parameters 2 .....	459
Appendix 1.16 PLC Axis Indexing Parameters.....	472
Appendix 1.17 Screen Transition Chart .....	483
Appendix 1.18 Unit.....	484
Appendix 1.19 Inputting the Machine Parameters .....	484
Appendix 1.20 Machine Error Compensation (Function Details) .....	485
Appendix 1.20.1 Outline.....	485
Appendix 1.20.2 Setting Compensation Data .....	488
Appendix 1.20.3 Example in Using a Linear Axis as Base Axis.....	489
Appendix 1.20.4 Example in Using a Rotary Axis as Base Axis.....	493
Appendix 1.21 Position Switch (Function Details) .....	494
Appendix 1.21.1 Outline.....	494
Appendix 1.21.2 Setting and Operation Examples of dog1 and dog2.....	494
Appendix 1.21.3 Canceling the Position Switch.....	496
Appendix 1.22 Bit Selection Parameters #6449 to #6496 .....	497
<b>Appendix 2 Explanation of Alarms.....</b>	<b>499</b>
Appendix 2.1 Operation Errors (M).....	500
Appendix 2.2 Stop Codes (T) .....	516
Appendix 2.3 Servo/Spindle Alarms (S).....	522
Appendix 2.3.1 Servo Errors (S01/S03/S04).....	522
Appendix 2.3.2 Initial Parameter Errors (S02) .....	536
Appendix 2.3.3 Parameter Errors (S51) .....	538
Appendix 2.3.4 Servo Warnings (S52).....	539
Appendix 2.4 MCP Alarms (Y).....	542
Appendix 2.5 System Alarms (Z) .....	553
Appendix 2.6 Absolute Position Detection System Alarms (Z7*).....	561
Appendix 2.7 Distance-coded Reference Scale Errors (Z8*) .....	565
Appendix 2.8 Emergency Stop Alarms (EMG).....	566
Appendix 2.9 Computer Link Errors (L) .....	569
Appendix 2.10 User PLC Alarms (U) .....	570
Appendix 2.11 Network Service Errors (N) .....	573
Appendix 2.12 Program Errors (P) .....	575
Appendix 2.13 Troubleshooting .....	606
Appendix 2.13.1 Troubleshooting for NC.....	606
Appendix 2.13.2 Troubleshooting for drive system.....	607
Appendix 2.13.2.1 Troubleshooting at power ON.....	607
Appendix 2.13.2.2 Troubleshooting for each alarm No. ....	608
Appendix 2.13.2.3 Troubleshooting for each warning No. ....	635
Appendix 2.13.2.4 Parameter numbers during initial parameter error .....	638
Appendix 2.13.2.5 Troubleshooting the spindle system when there is no alarm or warning .....	639






---


## Setup Outline

## 1.1 Device Configuration




## 1.2 Hardware Configuration

The following shows the hardware names used in this manual.



- (A) Cancel key
- (B) Menu changeover key
- (C) CF card interface on front of display unit
- (D) INPUT key



- (A) Rotary switch 1
- (B) Rotary switch 2
- (C) 7-segment LED



## 1.3 Flow of Initial Setup


The following flow chart shows the procedures of the initial setup.

(Note) When setting up with backup files, refer to the section of "Data Backup and Restoration".



### WARNING

Do not cancel the emergency stop before confirming the basic operation.



For other settings, refer to the following sections:

- Setting the Deceleration Check
- Data Backup and Restoration

# 2

---

## **Connecting and Setting the Hardware**

## 2.1 Connecting and Setting the Drive Unit

### 2.1.1 Connecting with Servo Drive Unit

Connect the optical communication cables from the NC to the each drive unit so that they run in a straight line from the NC to the drive unit that is a final axis. Up to 16 axes can be connected per system. Note that the number of connected axes is limited by the NC.

(Note) Refer to "Precautions for Using Optical Communication Cable" when handling and wiring optical communication cable.

**Cable application table**

Cable	Panel internal wiring		Panel external wiring	
	Under 10m	10 to 30m	10m or less	10 to 30m
G396	○	×	×	×
G395	○	×	○	×
G380	○	○	○	○

(Note) Wiring of over 30m can be applied when relaying the optical signal by optical communication repeater unit. Refer to the specification manual of the drive unit for the details of the optical communication repeater unit.

### 2.1.1.1 Connecting with MDS-D/DH Series

#### CAUTION

Connect the NC and the drive units by the optical communication cables. The distance between the NC and the final drive unit must be within 30m and the bending radius within 80mm.

#### POINT

Axis Nos. are determined by the rotary switch for setting the axis No. (Refer to the MDS-D/DH Series Instruction Manual.) The axis No. has no relation to the order for connecting to the NC.

#### (1) When using one power supply unit


Connect the largest-capacity spindle drive unit to the final axis of the NC communication bus in order to control the power supply unit. The spindle drive unit must be installed adjacent to the power supply unit. In the system with servo only, a servo drive unit for controlling unbalance axis must be installed in the same manner in the same way.

##### <Connection>

CN1A: CN1B connector on NC or previous stage's drive unit

CN1B: CN1A connector on next stage's drive unit

CN4: Connector for communication between power supply unit (master side) and drive unit



The optical communication cables from the NC to the final drive unit must be within 30m.


Connection when using one power supply unit

## 2 Connecting and Setting the Hardware

### (2) When using two or more power supply units within a single NC communication bus system

Two or more power supply units may be required within a single NC communication bus system if the spindle drive unit capacity is large. The drive unit receiving power (L+, L-) from each power supply unit must always have NC communication cable connection at the NC side of each power supply unit. In the NC communication bus connection example below, power supply [1] cannot supply power (L+, L-) to the 5th axis servo drive unit.

For basic connection information, refer to the MDS-D/DH Series Instruction Manual.



Connections when using two or more power supply units within a single NC communication bus system


### CAUTION

1. The drive unit receiving power (L+, L-) from each power supply unit must always have NC communication bus connection at the NC side of each power supply unit.
2. If two or more power supply units are connected in the drive system, confirm that the units are not connected with each other through the L+ and L- lines before turning ON the power. Also make sure that the total capacity of the drive units connected to the same power supply unit meets the unit's selected capacity.

**(3) When using one power supply shared unit by two NC communication bus systems**

In systems employing a number of small-capacity drive units, a single power supply unit can be shared by two NC communication bus systems. In this case, a power supply control axis must be set for each axis of each NC communication bus.

For basic connection information, refer to the MDS-D/DH Series Instruction Manual.



Connections when using one power supply shared by two NC communication bus systems

**CAUTION**

If the two NC communication bus systems include a spindle drive unit, connect the power supply unit's CN4 connector to the CN4 connector of the largest capacity spindle drive unit. If there is no spindle drive unit, connect to the unbalance-axis servo drive unit.

## 2.1.1.2 Connecting with MDS-DM Series



Connect the NC and the drive units by the optical communication cables. The distance between the NC and the final drive unit must be within 30m and the bending radius within 80mm.



Axis Nos. are determined by the rotary switch for setting the axis No. (Refer to the MDS-DM Series Instruction Manual.) The axis No. has no relation to the order for connecting to the NC.

### (1) Connecting the MDS-DM-V3

#### (a) When using one power supply unit


Connect the largest-capacity spindle drive unit to the final axis of the NC communication bus in order to control the power supply unit. The spindle drive unit must be installed adjacent to the power supply unit. In the system with servo only, a servo drive unit for controlling unbalance axis must be installed in the same manner in the same way.

#### < Connection >

CN1A : CN1B connector on NC or previous stage's drive unit

CN1B : CN1A connector on next stage's drive unit

CN4 : Connector for communication between power supply unit (master side) and drive unit




The optical communication cables from the NC to the final drive unit must be within 30m.

Connection when using one power supply unit

**(b) When using two or more power supply units within a single NC communication bus system**

Two or more power supply units may be required within a single NC communication bus system if the spindle drive unit capacity is large. The drive unit receiving power (L+, L-) from each power supply unit must always have NC communication cable connection at the NC side of each power supply unit. In the NC communication bus connection example below, power supply [1] cannot supply power (L+, L-) to the 6th axis servo drive unit. For basic connection information, refer to the MDS-DM Series Instruction Manual.



Connections when using two power supply units within a single NC communication bus system

**CAUTION**

1. The drive unit receiving power (L+, L-) from each power supply unit must always have NC communication bus connection at the NC side of each power supply unit.
2. If two or more power supply units are connected in the drive system, confirm that the units are not connected with each other through the L+ and L- lines before turning ON the power. Also make sure that the total capacity of the drive units connected to the same power supply unit meets the unit's selected capacity.




## 2 Connecting and Setting the Hardware

### (c) When using one power supply shared unit by two NC communication bus systems

In systems employing a number of small-capacity drive units, a single power supply unit can be shared by two NC communication bus systems. In this case, a power supply control axis must be set for each axis of each NC communication bus.

For basic connection information, refer to the MDS-DM Series Instruction Manual.




Connections when using one power supply shared by two NC communication bus systems

### CAUTION


If the two NC communication bus systems include a spindle drive unit, connect the power supply unit's CN4 connector to the CN4 connector of the largest capacity spindle drive unit. If there is no spindle drive unit, connect to the unbalance-axis servo drive unit.

## (2) Connecting the MDS-DM-SPV Series

**(a) When using only MDS-DM-SPV Series**




**(b) When using the MDS-D unit together**



The optical communication cables from the NC to the final drive unit must be within 30m.

(c) When using one power supply shared unit by two NC communication bus systems



### 2.1.1.3 Connecting with MDS-SVJ3/SPJ3 Series



Connect the NC and the drive units by the optical communication cables. The bending radius must be within 50mm.




Axis Nos. are determined by the rotary switch for setting the axis No. (Refer to the MDS-SVJ3/SPJ3 Series Instruction Manual.) The axis No. has no relation to the order for connecting to the NC.

#### <Connection>

CN1A: CN1B connector on NC or previous stage's drive unit

CN1B: CN1A connector on next stage's drive unit



The optical communication cable up to 5m can be used in G396 series, and up to 20m in G380 series.

### 2.1.2 Setting up without Connecting to the Motor/ Drive unit

When connecting the motor or drive unit after setting up the system, set the axis data beforehand to enable the operation without the motor or drive unit. The following shows the procedures.

#### Setting up without Connecting to the Motor

The axis detach function can be used for servo axis. The detach function cannot be used for spindle.

- (1) Set the drive unit rotary switch and "#1021 mcp\_no" for the axis that is not connected to the motor.
- (2) Set "1" to the parameter "#1070 axoff" for the axis that is not connected to the motor.
- (3) Do (a) or (b).
  - (a) Set "1" to parameter "#8201 AX. RELEASE" for the axis that is not connected to the motor.
  - (b) Turn ON the control axis detach signal (Y780) for the axis that is not connected to the motor.

#### Setting up without Connecting to the Drive unit

Set the following parameters.

- (1) Set "#1021 mcp\_no" (for the servo axis) or "#3031 smcp\_no" (for the spindle axis) to the axis that is not connected to the drive unit.
- (2) Set the following parameters to the axis that is not connected to the drive unit.
  - For the servo axis: Set "1" to "#2018 no\_srv".
  - For the spindle axis: Set "0" to "#3024 sout".


After connecting to the drive unit, make sure to set "#2018 no\_srv" to "0" and "#3024 sout" to "1".

## 2.2 Setting the Rotary and DIP Switches

### 2.2.1 MDS-D/DH Series

#### (1) Setting the rotary switch

Set the axis number with the rotary switch.



#### MDS-D/DH-V1/V2/SP/SP2 setting

Rotary switch setting	Axis No.
0	1st axis
1	2nd axis
2	3rd axis
3	4th axis
4	5th axis
5	6th axis
6	7th axis
7	8th axis
8	9th axis
9	10th axis
A	11th axis
B	12th axis
C	13th axis
D	14th axis
E	15th axis
F	16th axis

#### MDS-D/DH-CV setting

When not using the external emergency stop: Set SW1 to "0"

When using the external emergency stop: Set SW1 to "4"

\*Any other settings are prohibited.


**(2) Setting the DIP switch**

As a standard setting, turn the all DIP switches OFF.

The switches are OFF when facing bottom as illustrated.

Turning these switches ON sets the corresponding axis to the unused axis.

Carry out the unused axis setting when you use the multi-axes drive unit that has any unused axis.



(A) Used to set L axis to an unused axis


(B) Used to set M axis to an unused axis

## 2.2.2 MDS-DM Series

## &lt;MDS-DM-V3 Series&gt;

## (1) Rotary switch settings

Before turning on the power, the axis No. must be set with the rotary switch. The rotary switch settings will be validated when the drive units are turned ON.



Rotary switch setting	Axis No.
0	1st axis
1	2nd axis
2	3rd axis
3	4th axis
4	5th axis
5	6th axis
6	7th axis
7	8th axis
8	9th axis
9	10th axis
A	11th axis
B	12th axis
C	13th axis
D	14th axis
E	15th axis
F	16th axis


## (2) Setting the DIP switch

As a standard setting, turn the all DIP switches OFF.

The switches are OFF when facing bottom as illustrated.

Turning these switches ON sets the corresponding axis to the unused axis.

Carry out the unused axis setting when you use the multi-axes drive unit that has any unused axis.



(A) Used to set L axis to an unused axis

(B) Used to set M axis to an unused axis

(C) Used to set S axis to an unused axis.

### <MDS-DM-SPV2/SPV3 Series>

The setting of the axis number is fixed as follows in the MDS-DM-SPV2/SPV3 Series.


Setting the MDS-DM-SPVx	Details
1st axis	Spindle axis
2nd axis	L-axis
3rd axis	M-axis
4th axis	S-axis (Only MDS-DM-SPV3)

When using the MDS-DM-SPV2/SPV3, MDS-D and MDS-DM-V3 together, the axis numbers for the MDS-DM-SPV2/SPV3 are fixed as above. Set the axis numbers from 4th axis or 5th axis.



## 2.2.3 MDS-D-SVJ3/SPJ3 Series

Set the axis number with the rotary switch.



Rotary switch setting	Axis No.
0	1st axis
1	2nd axis
2	3rd axis
3	4th axis
4	5th axis
5	6th axis
6	7th axis
7	8th axis
8	9th axis
9	10th axis
A	11th axis
B	12th axis
C	13th axis
D	14th axis
E	15th axis
F	16th axis

## 2.3 Connecting the Batteries

### 2.3.1 Control Unit Battery


**⚠ The battery is not connected when the machine is delivered. Be sure to connect the battery before starting up.**

A lithium battery in the control unit battery holder retains parameter settings, machining programs and the like, which requires to be backed up at the power OFF.

<b>Battery</b>	Q6BAT
<b>Battery cumulative data holding time</b>	45,000 hours (At 0 to 45° C. The life will be shorter if the temperature is high.)
<b>Battery life</b>	Approx. 5 years (from date of battery manufacture)

#### [Installation method]

- (1) Check that the machine power is turned OFF. (If the power is not OFF, turn it OFF.)
- (2) Confirm that the control unit LED, 7-segment display, etc., are all OFF.
- (3) Open the battery cover of the control unit. Pull the right side of the battery cover toward front.
- (4) Fit the new battery into the battery holder.
- (5) Insert the connector connected to the new battery into the BAT connector. Pay attention to the connector orientation: do not insert backwards.
- (6) Close the front cover of the control unit. At this time, confirm that the cover is closed by listening for the "click" sound when the latch catches.



#### [Precautions for handling battery]

- (1) Do not disassemble the battery.
- (2) Do not place the battery in flames or water.
- (3) Do not pressurize and deform the battery.
- (4) This is a primary battery so do not charge it.



#### CAUTION

Do not short-circuit, charge, overheat, incinerate or disassemble the battery.


## 2 Connecting and Setting the Hardware

### 2.3.2 Servo Drive Unit Battery





(Note) The battery connection is not necessary unless the drive unit employs absolute position detection. (Spindle drive unit does not require the battery, because the unit does not employ absolute position detection.)

#### MDS-D/DH-V1/V2 and MDS-DM-V3

Connect the battery connector to the connector of the drive unit.





(Note) There are different types of battery. Refer to the drive unit's specification manual for details.

Type	ER6V-C119B	A6BAT(MR-BAT)	MDS-A-BT- □□	MDS-BTBOX-36
Installation type	Drive unit with battery holder type	Dedicated case type	Unit and battery integration type	Unit and battery integration type
Hazard class	Not applicable	Not applicable (24 or less)	Class9 (excluding MDS-A-BT-2)	Not applicable
Number of connectable axes	Up to 2 axes	Up to 8 axes (When using dedicated case)	2 to 8 axes	Up to 8 axes
Battery change	Possible	Possible	Not possible	Possible
Appearance	(1) 	(2) 	(3) 	(4) 


### MDS-DM-SPV2/SPV3

Connect the battery connector to the connector of the drive unit.



### MDS-D-SVJ3

Connect the battery connector to the connector BAT of the drive unit.




## 2.4 Connecting and Setting the Remote I/O Unit


### 2.4.1 Outline of the Remote I/O Unit

There are eight types of remote I/O unit (FCUA-DX\*\*\*): DX10\*, DX11\*, DX12\* and DX14\* (\* is "0" or "1"). Specifications are different as shown below. Each unit has one or two rotary switch(es) for unit No. setting, which links the device Nos. (with X/Y).

Front




- (A) Left input connector  
 (B) DIO specification switch  
 Currently not used. Always set to "OFF".  
 Front view      View from A direction



- (C),(F) Rotary switch  
 (D) Left output connector  
 (E) Right input connector  
 (G) Right output connector  
 (H) Analog input/output connector

## Bottom



- (A) RIO1 (From controller)  
 (B) RIO2 (To terminating resistor or to next RIO unit)  
 (C) DCIN (24VDC input)

Unit type	Machine control signals that can be handled	Left	Right	Total	Number of occupied stations
<b>DX10* (FCUA-DX10*)</b>	Digital input signal (DI) (Photocoupler insulation)	32 points	-	32 points	1
	Digital output signal (DO) (Non-insulated)	32 points	-	32 points	
<b>DX11* (FCUA-DX11*)</b>	Digital input signal (DI) (Photocoupler insulation)	32 points	32 points	64 points	2
	Digital output signal (DO) (Non-insulated)	32 points	16 points	48 points	
<b>DX12* (FCUA-DX12*)</b>	Digital input signal (DI) (Photocoupler insulation)	32 points	32 points	64 points	2
	Digital output signal (DO) (Non-insulated)	32 points	16 points	48 points	
	Analog output (AO)	-	1 point	1 point	
<b>DX14* (FCUA-DX14*)</b>	Digital input signal (DI) (Photocoupler insulation)	32 points	-	32 points	2
	Digital output signal (DO) (Non-insulated)	32 points	-	32 points	
	Analog input (AI)	-	4 points	4 points	
	Analog output (AO)	-	1 point	1 point	


(Note) "\*" in the table is "0" when the output is sink type, and is "1" when the output is source type. The input is changeable.

### 2.4.2 Connection and Station No. Setting on Remote I/O Unit

When connecting directly to the control unit

Control unit

FCU7-MU531/ FCU7-MU541/ FCU7-MA541



RIO1

CG72

Remote I/O 1ch


FCUA-R211/SH41

Remote I/O 2ch

G214

Remote I/O unit

FCUA-DX1\*\*




Max. 8 channels

Max. input: 256 points (X000 to X0FF)

Max. output: 256 points (Y000 to Y0FF)

FCUA-DX1\*\*



Max. 8 channels

Max. input: 256 points (X100 to X1FF)


Max. output: 256 points (Y100 to Y1FF)

(Note) A remote I/O unit has one or two rotary switch(es) for unit No. setting, which links the device Nos. (with X/ Y). The rotary switch setting is as follows, from "0" to "7".  
When using MITSUBISHI CNC Machine operation panel, RIO station No. "4" to "6" will be occupied.

Station No.	Rotary switch
1	0
2	1
3	2
4	3
5	4
6	5
7	6
8	7

### When connecting to the operation panel I/O unit

Control unit  
FCU7-MU531/ FCU7-MU541/ FCU7-MA541



- (Note) Operation panel I/O unit occupies the specified Nos. of stations. (Station No. 7 and 8 are reserved for manual pulse generator.)  
RIO3 can use either four stations (3rd to 6th) or three stations (4th to 6th) which depends on the operation panel I/O unit type.



## 2 Connecting and Setting the Hardware

### 2.4.3 Station No. Setting when Using Multiple Remote I/O Units


Multiple remote I/O units can be used, as long as the total No. of occupied stations connected with serial links is eight or less. (three/four or less when connected to the operation panel I/O unit).

Unit type	Number of occupied stations
FCUA-DX10*	1
FCUA-DX11*	2
FCUA-DX12*	2
FCUA-DX14*	2

When using multiple remote I/O units, a characteristic station No. must be set for each unit. The FCUA-DX10\* unit has one rotary switch, FCUA-DX11\*, DX12\* and DX14\* unit have two. Each of these switches must be set to a characteristic station No. within a range of 0 to 7 (2 or 3 to 5 when connected to the operation panel I/O unit).


#### When connecting directly to the control unit

##### Setting example 1



Total number of occupied stations: 1

##### Setting example 2




Number of occupied stations: 1

2

Total number of occupied stations: 3

### Setting example 3

FCUA-DX110/111  
or  
FCUA-DX120/121



Number of occupied stations: 2

2

2

2

Total number of occupied stations: 8 (Maximum configuration)

## 2 Connecting and Setting the Hardware

### When connecting to the operation panel I/O unit

Station No. 1, 2, 7, 8 (or 1, 2, 3, 7, 8) are occupied by the operation panel I/O unit. (Station No. 7 and 8 are reserved for manual pulse generator.)


The maximum numbers of stations and I/O points assigned to remote I/O unit(s) via RIO3 are as follows.

Operation panel I/O unit type	Max. number of stations (RIO3 connection)	Max. number of I/O points (RIO3 connection)	Remote I/O Rotary switch Setting range
FCU7-DX710	4 stations (No. 3 to 6)	128 points/128 points	2 to 5
FCU7-DX711	4 stations (No. 3 to 6)	128 points/128 points	2 to 5
FCU7-DX720/730	3 stations (No. 4 to 6)	96 points/96 points	3 to 5
FCU7-DX721/731	3 stations (No. 4 to 6)	96 points/96 points	3 to 5

### Setting example 1

FCU7-DX710/711

FCUA-DX100/101



Number of occupied stations: 1


Total number of occupied stations: 1

### Setting example 2

FCU7-DX710/711

FCUA-DX110/111  
or  
FCUA-DX120/121

FCUA-DX110/111  
or  
FCUA-DX120/121



Number of occupied stations: 2

2


Total number of occupied stations: 4 (Maximum configuration)

**Setting example 3**

FCU7-DX720/721  
/730/731

FCUA-DX100/101

FCUA-DX110/111  
or  
FCUA-DX120/121



**Number of occupied stations: 1**

**2**

**Total number of occupied stations: 3 (Maximum configuration)**

### 2.4.4 Device No. Assignment

The devices used by the PLC are determined as follows after the station Nos. are set with the rotary switches.

Rotary switch No.	Device No. read in	Output device No.	Analog output (AO)
	RIO channel 1	RIO channel 1	RIO channel 1
0	X00 to X1F	Y00 to Y1F(Y0F)	The rotary switches correspond to the file registers R200 to R207 in order of small numbers.
1	X20 to X3F	Y20 to Y3F(Y2F)	
2	X40 to X5F	Y40 to Y5F(Y4F)	
3	X60 to X7F	Y60 to Y7F(Y6F)	
4	X80 to X9F	Y80 to Y9F(Y8F)	
5	XA0 to XBF	YA0 to YBF(YAF)	
6	XC0 to XDF	YC0 to YDF(YCF)	
7	XE0 to XFF	YE0 to YFF(YEF)	

Rotary switch No.	Device No. read in	Output device No.	Analog output (AO)
	RIO channel 2	RIO channel 2	RIO channel 2
0	X100 to X11F	Y100 to Y11F(Y10F)	Not possible (Neither input nor output is possible)
1	X120 to X13F	Y120 to Y13F(Y12F)	
2	X140 to X15F	Y140 to Y15F(Y14F)	
3	X160 to X17F	Y160 to Y17F(Y16F)	
4	X180 to X19F	Y180 to Y19F(Y18F)	
5	X1A0 to X1BF	Y1A0 to Y1BF(Y1AF)	
6	X1C0 to X1DF	Y1C0 to Y1DF(Y1CF)	
7	X1E0 to X1FF	Y1E0 to Y1FF(Y1EF)	


Rotary switch No.	Device No. read in	Output device No.	Analog output (AO)
	RIO channel 3	RIO channel 3	RIO channel 3
0	-	-	Not possible (Neither input nor output is possible)
1	-	-	
2	X240 to X25F	Y240 to Y25F(Y24F)	
3	X260 to X27F	Y260 to Y27F(Y26F)	
4	X280 to X29F	Y280 to Y29F(Y28F)	
5	X2A0 to X2BF	Y2A0 to Y2BF(Y2AF)	
6	-	-	
7	-	-	

The values shown in parentheses are the device range of the card mounted to the right side of the unit.

(Note) When the analog output is equipped to several RIO channels, maximum of four RIO channels will be valid in the following order of priority.

(1) RIO channel 1, (2) RIO channel 2, (3) RIO channel 3

(Ex.) When the analog output is equipped to RIO channel 1 and RIO channel 3.



#3024 sout	R register	Allocation of AO
2	R200 (AO1)	2nd station of RIO 1
3	R201 (AO2)	4th station of RIO 1
4	R202 (AO3)	6th station of RIO 3
5	R203 (AO4)	-


**CAUTION**

The analog output R registers are allocated in ascending order of channels and station numbers automatically. Therefore, the analog output destination may change depending on the added option.


## 2.5 Initializing the NC Internal Data (SRAM)

The initialization does not affect the settings of the option parameters.


- (1) With the NC power OFF, turn the left rotary switch (RSW1) to "0" and the right rotary switch (RSW2) to "C". Then, turn the power ON.



- (2) The LED display will change to "08." -> "00" -> "01" -> ... "08". The process is completed when "0Y" is displayed.



- (3) Turn the NC power OFF.
- (4) Set the right rotary switch (RSW2) to "0".



- (5) Turn the power ON again.

(Note) The initial screen after the initialization is displayed in English. Refer to "Setting on the System Setup Screen" for how to set a language to display.

# 3

---

## **Setting Up with M70/M700 SETUP INSTALLER**



### 3 Setting Up with M70/M700 SETUP INSTALLER

(Note) M70/M700 SETUP INSTALLER is used to install language data other than Japanese and English, as well as custom screens.

If you do not need the installation, go to the next section.

You can install the following data with M70/M700 SETUP INSTALLER.

- (1) Language data
- (2) Custom data
  - Custom screen
  - PLC alarm guidance
- (3) Custom startup screen

A CF card is used for the installation.

The following products' operations have been guaranteed by MITSUBISHI.

<SanDisk CompactFlash cards>

- 64MB SDCFB-64-J60 (JAN: 4523052000294)
- 128MB SDCFB-128-J60 (JAN: 4523052000300)
- 256MB SDCFB-256-J60 (JAN: 4523052000317)
- 512MB SDCFB-512-J60 (JAN: 4523052000324)
- 1.0GB SDCFB-1024-J60 (JAN: 4523052000331)

<Panasonic SD memory cards>

- 1.0GB SD-CF adapter BN-CSDABP3/P + SD memory card (1GB) RP-SDM01GJ1A
- 2.0GB SD-CF adapter BN-CSDABP3/P + SD memory card (2GB) RP-SDM02GJ1A

(Note) The adapter BN-CSDABP3/P does not support SDHC memory card.  
SD-CF adapter which supports SDHC is required when SDHC memory card is used.

The successful operations of these cards are confirmed under certain conditions. Some cards might not work under the end-users' system environment. And some cards might have the same type name but different parts inside: Complete guarantees cannot be given.

Contact the manufacturer or distributor before purchase: There might be some cards which are not currently produced.


### 3.1 Compatible Data and Folder Configuration in the CF Card

(1) M70/M700 SETUP INSTALLER compatible data

Type	Data	Details	Remarks
Language data	lang0_xxx.bin	Language data (for FROM)	Language identification string is shown instead of xxx. (ex. jpn: Japanese, fra: French)
	lang1_xxx.bin	Language data (for expansion FROM)	
Custom data	Custom screen module	Interpreter data and object data	
	config.ini	A setting file to register custom screens	
	customdef.ini	A setting file to register custom screens on the menus and function buttons located to the default screen	
	customload.txt	A setting file to register a name and a load order of the object data	
	PLC alarm guidance data	HTML/JPEG files to be displayed in the PLC alarm guidance	
Custom startup screen	startupscreen.bmp	A bitmap file to be displayed on the initial screen when the power is turned ON	Color: 256 colors (8 bit) Size: 640 * 440


(2) Folder configuration in the CF card

The following shows the folder configuration of the M70/M700 SETUP INSTALLER compatible data which is stored in the CF card.



## 3.2 Operation Procedure

### 3.2.1 Starting Up M70/M700 SETUP INSTALLER


- (1) Insert the M70/M700 SETUP INSTALLER CF card into the card interface on front of display unit.
  - (2) Turn the power ON while pressing the cancel key .
- The M70 SETUP INSTALLER Mode Select screen will appear in about 15 seconds after the startup screen appears.



- (Note1) Keep pressing the cancel key until the Mode Select screen appears.  
(Note2) Use the latest version of M70/M700 SETUP INSTALLER.

### 3.2.2 Installing Language Data

- (1) Select [Lang Pack] on the Mode Select screen to switch to the Language Pack Install screen.  
The language selection menus are displayed. The language currently installed is shown in the "Installed language" field.



- (Note) Pressing the menu changeover key  (Next menu>>) displays the next language selection menus.

- (2) Select the language to install with the menu key.  
The language selected is shown in the "Now Selected Language" field.

M70/M700 SETUP INSTALLER BND-1212W000-AA

Language Pack Install

Installed Language

1st Japanese

2nd

Now Selected Language

1st Chinese-traditional

2nd

\* English is the default selection.

<< Cancel Next menu >>

Japan German French Italian Spanish Chinese tradit Korean Clear Install

(Note 1) To change the selected language, press [Clear] before selecting again.

(Note 2) The 2nd language can be selected when the expansion FROM is provided. (Cursor moves to the "2nd" field after the 1st language has been selected.)

- (3) Select [Install].
- (4) A confirmation message appears. Select [Yes] to start the installation.

Do you wish to install?

<< Cancel Next menu >>

Yes No

- (5) A message appears when the installation has been completed.

Installation completed


<< Cancel Next menu >>

Yes No

(Note 1) Selecting [No] displays the language selection menus.


(Note 2) The language data installation takes about 105 seconds. Do not turn the power OFF during the installation.

- (6) To close M70/M700 SETUP INSTALLER, turn the power OFF and ON.


To return to the Mode Select screen, press the cancel key  (<< Cancel).

### 3.2.3 Installing Custom Data


- (1) Select [Custom Data] on the Mode Select screen to switch to the Custom Data Install screen.
- (2) Select [Install].



- (3) A confirmation message appears. Select [Yes] to start the installation.




- (4) A message appears when the installation has been completed.



(Note 1) Selecting [No] displays the previous menus.


(Note 2) Do not turn the power OFF during the installation.

- (5) To close M70/M700 SETUP INSTALLER, turn the power OFF and ON.


To return to the Mode Select screen, press the cancel key  (<< Cancel).

### 3.2.4 Uninstalling Custom Data

- (1) Select [Uninst] on the Custom Data Install screen.




- (2) A confirmation message appears. Select [Yes] to start the uninstallation.




(Note 1) Selecting [No] displays the previous menus.

(Note 2) Do not turn the power OFF during the uninstallation.

- (3) A message appears when the uninstallation has been completed.




- (4) To close M70/M700 SETUP INSTALLER, turn the power OFF and ON.


To return to the Mode Select screen, press the cancel key  (<< Cancel).

### 3.2.5 Installing Custom Startup Screen


- (1) Select [Custom StartUp] on the Mode Select screen to switch to the Custom Startup Screen Install screen.
- (2) Select [Install].



- (3) A confirmation message appears. Select [Yes] to start the installation.




- (4) A message appears when the installation has been completed.



(Note 1) Selecting [No] displays the previous menus.

(Note 2) Do not turn the power OFF during the installation.


- (5) To close M70/M700 SETUP INSTALLER, turn the power OFF and ON.

To return to the Mode Select screen, press the cancel key  (<< Cancel).




### 3.2.6 Uninstalling Custom Startup Screen


- (1) Select [Uninst] on the Custom Startup Screen Install screen.



- (2) A confirmation message appears. Select [Yes] to start the uninstallation.




- (3) A message appears when the uninstallation has been completed.



(Note 1) Selecting [No] displays the previous menus.

(Note 2) Do not turn the power OFF during the uninstallation.

- (4) To close M70/M700 SETUP INSTALLER, turn the power OFF and ON.

To return to the Mode Select screen, press the cancel key  (<< Cancel).

### 3.3 List of Error Messages

Message	Details
The 1st language is not selected.	The first language has not been selected at the installation of language pack. Specify the first language again.
The same language is selected.	The same language has been selected as both first and second language at the installation of language pack. Specify the language again.
The selected language does not exist.(1st)	The language data, selected as the 1st language at the installation of language pack, does not exist. Ensure that the language data has been stored in the CF card, and that version of the data is appropriate.
The selected language does not exist.(2nd)	The language data, selected as the 2nd language at the installation of language pack, does not exist. Ensure that the language data has been stored in the CF card, and that version of the data is appropriate.
The custom data does not exist.	The "custom" folder does not exist in the CF card. Check the stored data in the CF card.
The file "startupscreen.bmp" does not exist.	The "startupscreen.bmp" file does not exist in the CF card. Check the stored data in the CF card.



# 4

---


## Setting the Parameters and Date/Time

**WARNING** Confirm the emergency stop state before carrying out the steps in this chapter.


## 4.1 Selecting the NC System Type

When employing the lathe system, set the parameter as follows.

- (1) On the Mainte screen, select [Mainte] and then [Psswd input].  
Enter "MPARA" in the setting area and press the INPUT key.  
(Note 1) To enter the character "A", press the shift key and then "A" key. Do not press both keys at the same time.  
(Note 2) The entered password is displayed as "\*\*\*\*\*". See below.



- (2) Press the cancel key to return to the Mainte screen. Then select [Param].
- (3) Select [Param number]. Enter "1007" in the setting area and press the INPUT key.  
The screen changes to the base system parameters screen. The cursor moves to the "#1007 System type select" field.
- (4) Enter "1" in the setting area and press the INPUT key. (0: Machining center system 1: Lathe system)



- (5) Turn the power OFF and ON.

## 4.2 Setting on the System Setup Screen

Set the following items on the system setup screen.

- Displayed language and the number of spindle connections
- Number of axes and command type for each part system
- Servo I/F connection channel and rotary switch setting for each spindle, as well as types of the motor and the power supply connected to each spindle drive
- Servo I/F connection channel and rotary switch setting for each servo axis, as well as types of the motor, encoder, and the power supply connected to each servo drive

(1) Enter the password on the Mainte screen.

(a) On the Mainte screen, select [Mainte] and then [Psswd input].

(b) Enter "MPARA" in the setting area and press the INPUT key.

(Note 1) To enter the character "A", press the shift key and then "A" key. Do not press both keys at the same time.

(2) Select a displayed language.

(a) Press the cancel key to return to the Mainte screen. Select [Mainte] and then [System Setup].

(b) Set the No. of the language to display in "language displayed".

Common setting

Language displayed	0
Number of spindles	0
Setting by system	\$1 \$2 PLC
Number of axes	1 0 0
Command type	1 1 1
Setting by spindle	
Ch / Rotary SW No.	
Motor type	
Power Supply type	
Setting by servo	AX1
Ch / Rotary SW No.	00
Motor type	0
Detector type	0
Power Supply type	0

<Language disp>

Related param:  
#1043 lang

Setting value:  
0:English  
1:Japanese  
11:German  
12:French  
13:Italian  
14:Spanish  
15:trad Chinese  
16:Korean

Menu[Next guide]->

END Y03 Drive unit unequipped 14:03

Param setting Next guide Next SV axis

## 4 Setting the Parameters and Date/Time

- (3) Carry out the spindle and servo axis settings. Set the following items.

### Common setting

Number of spindles: Set the number of spindles connected to the NC. This setting is registered at "#1039 spinno (Number of spindles)".

### Setting by system

Number of axes:

Set the number of axes for each part system and PLC. This setting is registered at "#1002 axisno (Number of axes)".

(Note) A setting error occurs if a value "1" or higher is set for any of the 2nd to 4th part systems while the setting for the previous part system is "0".

Command type

Set the command type for each part system. This setting is registered at "#1037 cmdtyp (Command type)".

(Note) Although this can be set individually for each part system, it will be shared by the entire part system if specified for the machining center.

### Setting by spindle area

Ch / Rotary SW No.

Set the servo I/F connection channel and the rotary switch No. (2-digit value) for each spindle drive unit. This setting is registered at "#3031 smcp\_no (Drive unit I/F channel No. (spindle))".

1st digit: Servo I/F connection channel

2nd digit: Rotary switch No.

Motor type:

Set the motor types that are connected to each spindle. Input the values as indicated at the guidance display area. The input values are not converted to motor types.

Power Supply type:

Set the power supply types that are connected to each spindle drive unit.

Input the values as indicated at the guidance display area. The input values are then converted to, and displayed as, power supply types. "0" means "No connection".

### Setting by servo

Ch / Rotary SW No.

Set the servo I/F connection channel and the rotary switch No. (2-digit value) for each servo drive unit. This setting is registered at "#1021 mcp\_no (Drive unit I/F channel No. (servo))".

1st digit: Servo I/F connection channel

2nd digit: Rotary switch No.

Motor type:

Set the motor types that are connected to each servo axis.

Input the values as indicated at the guidance display area. The input values are then converted to, and displayed as, motor types.

Detector type:

Set the encoder types that are connected to each servomotor.


Input the values as indicated at the guidance display area. The input values are then converted to, and displayed as, encoder types.

Power Supply type:

Set the power supply types that are connected to each servo drive unit.

Input the values as indicated at the guidance display area. The input values are then converted to, and displayed as, power supply types. "0" means "No connection".

### Setting example (with three servo axes and a spindle)





## 4 Setting the Parameters and Date/Time

- (5) Write the parameter settings and format the system.
  - (a) Select [Param setting].
  - (b) The message "Set up parameter? (Y/N)" appears. Press "Y".

- (c) The message "Param set ended. Format NC memory? (Y/N)" appears. Press "Y".

- (d) The message "Format complete" appears when the format is completed.

- (6) Turn the power OFF and ON.

(Note) When MDS-D-SVJ3/SPJ3 Series is used, the regenerative resistor type must be set with the servo parameter "#2236 SV036" and the spindle parameter "#13032 SP032" in addition to the settings above.

## 4.3 Setting the Parameters for the Machine Specifications

- (1) On the Mainte screen, select [Mainte] and then [Psswd input]. Enter "MPARA" in the setting area and press the INPUT key.  
(Note 1) To enter the character "A", press the shift key and then "A" key. Do not press both keys at the same time.
- (2) Press the cancel key to return to the Mainte screen. Then select [Param].  
Set the parameters according to the machine specifications. Setting of the following parameters is necessary.

### Base system parameters

"#1025 l\_plane (Initial plane selection)"  
 "#1026 base\_I (Base axis I)"  
 "#1027 base\_J (Base axis J)"  
 "#1028 base\_K (Base axis K)"  
 "#1029 aux\_I (Flat axis I)"  
 "#1030 aux\_J (Flat axisJ)"  
 "#1031 aux\_K (Flat axis K)"

### Base axis specification parameter

"#1013 axname (Axis name)"

### Base common parameters

"#1038 plcsl (Ladder selection ... Set "0")"  
 "#1041 l\_inch (Initial state (inch))"  
 "#1042 pcinch (PLC axis command (inch))"  
 "#1239 set11/bit1 (Handle I/F selection)"  
 "#1240 set12/bit0 (Handle input pulse)"

### Axis specification parameter

"#2001 rapid (Rapid traverse rate)"  
 "#2002 clamp (Cutting feedrate for clamp function)"  
 "#2003 smgst (Acceleration and deceleration modes)"  
 "#2004 G0tL (G0 time constant)"  
 "#2007 G0tL (G1 time constant)"

### Servo parameter


"#2201 SV001 (PC1 Motor side gear ratio)"  
 "#2202 SV002 (PC2 Machine side gear ratio)"  
 "#2218 SV018 (PIT Ball screw pitch)"

### Spindle specification parameter

"#3001 slimt1 (Limit rotation speed (Gear: 00))"  
 "#3002 slimt2 (Limit rotation speed (Gear: 01))"  
 "#3003 slimt3 (Limit rotation speed (Gear: 10))"  
 "#3004 slimt4 (Limit rotation speed (Gear: 11))"  
 "#3005 smax1 (Maximum rotation speed (Gear: 00))"  
 "#3006 smax2 (Maximum rotation speed (Gear: 01))"  
 "#3007 smax3 (Maximum rotation speed (Gear: 10))"  
 "#3008 smax4 (Maximum rotation speed (Gear: 11))"  
 "#3023 smini (Minimum rotation speed)"  
 "#3109 zdetspd (Z phase detection speed)"

## 4 Setting the Parameters and Date/Time

- (Note 1) These parameters are not set on the system setup screen. Use the parameter screen to set them.
- (Note 2) Refer to the section of "Explanation of Parameters" for the details of the parameters.  
You can also refer to the parameter guidance display.
- (Note 3) Parameters "#3001 slimt1 (Limit rotation speed (Gear: 00))" to "#3004 slimt4 (Limit rotation speed (Gear: 11))" are set with the spindle rotation speed which can be attained at the spindle motor's maximum rotation speed. This value is obtained by multiplying the gear ratio on the value of "#13026 SP026 TSP (Maximum motor speed)". Parameters "#3005 smax1 (Maximum rotation speed (Gear: 00))" to "#3008 smax4 (Maximum rotation speed (Gear: 11))" are set when the rotation speed is to be limited according to the machine specifications, such as the spindle gear specifications. Up to four value can be set for gear changeover.




## 4.4 Setting Date and Time

(1) Select [Time] on the Monitr screen.

(2) Select [Time setting] on the integrated time screen.

The time setting mode is entered. The cursor appears at the "#1 Date" position in the Run-out time display.



(3) Set the date and time to "#1 Date" and "#2 Time" respectively.



# 5


---

## PLC Program Writing


In this manual, PLC program writing is executed by connecting a personal computer, which has GX Developer installed, to the control unit. You can also save the PLC program in a CF card and write the data to NC using the external file operations on PLC onboard. (M700V Series allows using a USB memory.) Refer to the PLC programming Manual for details.

## 5.1 Setting the Ethernet Communication


- (1) Click "Start" on the personal computer. Right-click on "My network" and select "Property".
- (2) Right-click on "Local Area Connection" in My network window, and select "Properties".




- (3) Click "Internet Protocol(TCP/IP)" on the "General" tab, and then click "Properties".



- (4) Take a note of the displayed IP address and subnet mask.




- (5) Set the following addresses.  
 IP address: 192.168.200.2  
 Subnet mask: 255.255.255.0



- (6) Click "OK" and close all the windows.

## 5.2 Connecting the Control Unit and a Personal Computer

Connect a personal computer, which has GX Developer installed, to the control unit.




- (Note 1) GX Developer Version8 is required.  
 (Note 2) Use a cross LAN cable for the communication.  
 (Note 3) Carry out the Ethernet communication setting (IP address and so on) on the personal computer before connecting it to NC.




## 5.3 Setting the Communication with GX Developer


- (1) Start GX Developer on the personal computer. Open a created project.
- (2) Select [Transfer setup...] from the [Online] menu.




- (3) On the "Transfer Setup" screen, click "Ethernet board" in the "PC side I/F" field and double-click "Ethernet module" in the "PLC side I/F" field.



- (4) Select "QJ71E71" for "PLC", input "192.168.200.1" for IP address, then click "OK".




- (5) Click "Other station(Single network)" in the "Other station" field on the "Transfer Setup" screen.
  - (6) Click "Connection test" to execute the test.
- After confirming the message "Successfully connected", click "OK".  
Click "OK" and close the "Transfer Setup" screen.




## 5.4 Setting the Parameters on GX Developer

- (1) Double-click on [Parameter] --> [PLC parameter] in the project list on GX Developer. The "QnA Parameter" dialog box appears.



- (2) On the "Device" tab, confirm the followings are set.  
 Inside relay M: 10K  
 Retentive timer ST: 64 (Do not attach "K")



Confirm the other parameter settings.

(Note) There are two methods of ladder programming; independent program method and multi-program method, which makes differences in parameter settings. An incorrect parameter setting in the ladder programming may cause a write error.

For details of the parameter settings, refer to the PLC Programming Manual.


- (3) Check the "Allow" check box in the "Remote reset" field on the "PLC system" tab. Click "End".

The screenshot shows the 'QnA Parameter' dialog box with the 'PLC system' tab selected. The 'Remote reset' section has the 'Allow' checkbox checked. The 'End' button at the bottom right is highlighted with a red circle.


Parameter	Value	Range
Low speed	100	ms (10ms--1000ms)
High speed	10	ms (1ms--100ms)
Common pointer No. P		After (0--4095)
General data processing	1	module/time (1--6)
Points occupied by empty slot	16	Points
Interrupt counter start No. C		(0--976)
I28 fixed scan interval	100	ms (5ms--1000ms)
I29 fixed scan interval	40	ms (5ms--1000ms)
I30 fixed scan interval	20	ms (5ms--1000ms)
I31 fixed scan interval	10	ms (5ms--1000ms)

## 5.5 Writing a PLC Program with GX Developer

- (1) Select [Write to PLC...] from the [Online] menu.



- (2) Check all the check boxes in the "Write to PLC" dialog box, and then click "Execute".




- (3) GX Developer starts the PLC program writing. Confirmation dialog boxes appear during the writing. Select "Yes" on all of them.

(Note 1) After the writing, select "Verify with PLC..." from the "Online" menu to check any error.


(Note 2) Do not turn the NC power OFF after the writing. Keep the power ON until the program is written to ROM.

## 5.6 Writing a PLC Program to ROM with GX Developer


- (1) Select [Remote operation...] from the [Online] menu.



- (2) Select "STOP" from the pull-down menu in the "Operation" field in the "Remote operation" dialog box. Click "Execute".



- (3) Select [Remote operation] again. Select "PAUSE" from the pull-down menu in the "Operation" field and click "Execute". (Executing "PAUSE" starts the writing to NC ROM.)



- (4) The message "Completed." appears when the writing to ROM is completed.



(Note) The program has been written to ROM although the on-board screen still shows the message "ROM-Write incomplete".  
The message will disappear when the screen has been changed.

- (Note) You can also save the PLC program in a CF card and write the data to NC using the external file operations on PLC onboard. Refer to the PLC programming Manual for details.

## 5.7 Setting the PLC Parameters

Select [Bit select] on the Mainte screen and set the bit selection parameters from #6449 to #6452.  
See the following table for details of the parameters.

	Symbol name	7	6	5	4	3	2	1	0
0	#6449 R7824 L	Control unit thermal alarm on	Setting and display unit thermal mgmt on ■	-		Counter C retention	Integrated timer ST retention	PLC counter program on	PLC timer program on
1	#6450 R7824 H	-	External alarm message display ■	Alarm/operator change ■	Full screen display of message ■	-	Operator message on	1 R method	0 F method
2	#6451 R7825 L	-	-	GX Developer serial communication			Onboard editing not possible ■	Onboard simple operation mode on	Onboard on
3	#6452 R7825 H	-	Branch destination label check valid		Serial handy terminal comm. on	-	-	Extended PLC instruction mode valid	-

(Note) Functions marked with ■ may not be available for some machine types.





# 6


---

## Confirming the Basic Operation

## 6.1 Checking Inputs/Outputs and Alarms


### (1) Checking the input signals

- Select [I/F dia] on the Diagn screen.
- Confirm that signals turn ON/OFF properly on the IF Diagnosis screen.



### (2) Checking the alarm display

- Select [Alarm message] on the Diagn screen.
- Check any other alarm than "Emergency stop EXIN" displayed on the Alarm screen.



## 6.2 Confirming Manual Operation

### 6.2.1 Using the Manual Pulse Generator

- (1) Select the handle mode.
- (2) Set the handle feed magnification to a minimum value.
- (3) Cancel the emergency stop. Confirm the READY lamp is ON on the keyboard.  
(Note) If any abnormal noise or vibration occurs, execute an emergency stop and take a measure against vibration. (Refer to "First Measure Against Vibration".)
- (4) Select an axis and turn the manual pulse generator by one scale. Confirm the direction and the amount of the movement on the current position display.  
If the display is not correct, check parameters, PLC programs and devices' connections.
- (5) Turn the manual pulse generator and confirm the direction and the amount of the machine's movement.  
If the display is not correct, check parameters.  
(Related parameters: "#1018 ccw (Motor CCW)", "#2201 PC1 (Motor side gear ratio)", "#2202 PC2 (Machine side gear ratio)", "#2218 PIT (Ball screw pitch)" and so on)  
(Note) Take care of the machine's movement range during the operation.
- (6) Check the rest of the axes for each with the same operation as above.

### 6.2.2 Using JOG Feed

- (1) Select JOG mode.
- (2) Set the manual feed rate to 100mm/min.
- (3) Cancel the emergency stop. Confirm the READY lamp is ON on the keyboard.  
(Note) If any abnormal noise or vibration occurs, execute an emergency stop and take a measure against vibration. (Refer to "First Measure Against Vibration".)
- (4) Select an axis, press the JOG feed button and move the axis to safe area. Confirm the direction and the amount of the movement on the current position display.  
If the display is not correct, check parameters, PLC programs and devices' connections.
- (5) Confirm the direction and the amount of machine's movement.  
If the display is not correct, check parameters.  
(Related parameters: "#1018 ccw (Motor CCW)", "#2201 PC1 (Motor side gear ratio)", "#2202 PC2 (Machine side gear ratio)", "#2218 PIT (Ball screw pitch)" and so on)  
(Note) Take care of the machine's movement range during the operation.
- (6) Check the rest of the axes for each with the same operation as above.

## 6 Confirming the Basic Operation

### 6.2.3 Servo Simplified Adjustment

#### 6.2.3.1 First Measure Against Vibration

Setting the filter can reduce the vibration.

- (1) Select [Drv mon] and then [Servo unit] on the Diagn screen. See the displayed value in "AFLT frequency".

SYS1	MEMORY	Monitr	Setup	Edit	Diagn	Mainte
	X1	Z1	C1	Y1		
Gain (1/s)	0	0	0	0		
Droop (i)	0	0	0	0		
Speed (r/min)	0	0	0	0		
Feedrate (mm/s)	0	0	0	0		
Load current (%)	0	0	0	0		
Max current 1 (%)	0	0	0	0		
Max current 2 (%)	0	0	0	0		
Max current 3 (%)	0	0	0	0		
Overload (%)	0	0	0	0		
Regen load (%)	0	0	0	0		
Est disturb torq(%)	0	0	0	0		
Max disturb torq(%)	0	0	0	0		
Load inertia R (%)	0	0	0	0		
AFLT frequency (Hz)	0	0	0	0		
AFLT gain (dB)	0	0	0	0		
LED display	00	00	00	00		
Alarm	00 00 00 00	00 00 00 00	00 00 00 00	00 00 00 00		
S/W Key	\$1RDY	\$2RDY				17:57
Servo unit	Spindle unit	Power unit		Synchro error	Alarm his clr	Next axis

(Note) The screen above is when NC parameters have default values.

- (2) Select [Param] and then [Servo param] on the Mainte screen. Set the AFLT frequency value you saw at (1) to "#2238 SV038 FHZ1 (Notch filter frequency 1)".


SYS1	MEMORY	Monitr	Setup	Edit	Diagn	Mainte
No.	Name	X1	Z1	C1	Y1	
2231	SV031(OVS1)	0	0	0	0	
2232	SV032(TOF)	0	0	0	0	
2233	SV033(SF2)	0000	0000	0000	0000	
2234	SV034(SF3)	0000	0000	0000	0000	
2235	SV035(SF4)	0000	0000	0000	0000	
2236	SV036(PTYP)	0000	0000	0000	0000	
2237	SV037(I)	0	0	0	0	
2238	SV038(FHZ1)	0	0	0	0	
2239	SV039(LMCD)	0	0	0	0	
2240	SV040(LMCT/Icy)	0	0	0	0	
2241	SV041(LMC2)	0	0	0	0	
2242	SV042(OVS2)	0	0	0	0	
2243	SV043(OBS1)	0	0	0	0	
2244	SV044(OBS2)	0	0	0	0	
2245	SV045(TRUB/Ib1)	0	0	0	0	
S/W Key	\$1RDY	\$2RDY				17:59
Abs pos param	Servo param	Spindle spec	Spindle param	Param number	Area copy	Area paste
						Next axis

(Note) The screen above is when NC parameters have default values.

If the vibration is not reduced by the measure, refer to the manuals of the drive unit you are using.

### 6.2.3.2 Outline of MS Configurator

With MS Configurator, the attribute of the servo motor system is measured and the bode diagram is output by activating the motor with vibration signals and measuring/analyzing the machine characteristics. And the servo waveform measurement function is supported, too.



#### <Function>

#### Waveform measurement function

- Frequency response measurement : Measures the frequency response (speed command - speed FB) of speed loop for the designated axis. The result will be presented as Bode diagram.
- Frequency response measurement of machine : Measures the frequency response (torque command - speed FB) of machine system for the designated axis. The result will be presented as Bode diagram.
- Measurement function (with program creation function) : Measures the Chronological data measurement, Arc shape error measurement, Synchronous tapping error measurement, Measuring arbitrary path.

#### Automatic adjustment function

- Initial notch filter setup : Automatically adjusts the notch filter when the initial resonance is large.
- Velocity loop gain adjustment : Automatically adjusts the notch filter and the speed loop gain.
- Time constant adjustment : Automatically adjusts the acceleration/deceleration time constant.
- Position loop gain adjustment : Automatically adjusts the position loop gain.
- Lostmotion adjustment : Automatically adjusts the quadrant protrusion amount of the designated axis.
- Lostmotion 3 adjustment : Automatically adjusts the lost motion type 3 for the quadrant protrusion amount of the designated axis.

#### Environment setup

- Communication path setup : Sets the path to communicate with NC. The model of connected NC is selected.
- Program creation : Creates machining programs for adjustment.

#### Assistance setup function

- Parameter setup : Saves/changes the servo parameters.

For details, refer to "MS Configurator instruction manual" (IB-1500154).





---

## **Setting the Position Detection System**



There are two kinds of position detection system: one is "relative position detection", which establishes the reference position (zero point) at every CNC power-ON; the other is "absolute position detection", which allows to start the operation without establishing the reference position (zero point) again after the CNC power-ON.

## 7.1 Adjusting the Absolute Position Detection System

There are four types of the absolute position zero point initialization set: "marked point alignment method", "marked point alignment method II", "machine end stopper method", and "dog-type".

Set the parameter "#2049 type (Absolute position detection method)" for the type and method of absolute position zero point initialization set.

The required components differ depending on the detection method.

	Marked point alignment method I	Marked point alignment method II	Machine end stopper method	Dog type
Required component	None	None	Machine end stopper	Dog, dog-sensor
#2049 type	2	4	1	3
Basic position	The first grid point which is returned from where the mark is aligned.	The position where the marks are aligned.	The position where the table is pushed against the machine end stopper. Or the first grid pointed which is returned from where the table is pushed against the machine end stopper.	The first grid point after the dog OFF.
Reference	7.1.1 Marked Point Alignment Method I	7.1.2 Marked Point Alignment Method II	7.1.3.1 Machine End Stopper Method: Automatic Initialization 7.1.3.2 Machine End Stopper Method: Manual Initialization	7.1.3.3 Dog-type

Each method has the following characteristics

### (1) Marked point alignment method I

Align the table side's mark and the machine side's mark.

The first grid point which is returned from the marks are aligned is determined as the basic position.

Because the first grid point which is returned from the marks are aligned is determined as the basic position, the reproducibility is kept even the position information is lost due to running out of battery etc.

### (2) Marked point alignment method II

Align the table side's mark and the machine side's mark.

The position where the marks are aligned is determined as the basic position.

Because the position where the marks are aligned is determined as the basic position, the reproducibility is low if the position information is lost due to running out of battery etc.

### (3) Machine end stopper method

[When #2059 zerbas = 0]

Push the table against the machine end stopper.

The position where the table is pushed against the machine end stopper is determined as the basic position.

[When #2059 zerbas = 1]

Push the table against the machine end stopper.

The first grid point which is returned from where the table is pushed against the machine end stopper is determined as the basic position.

There are two types of the machine end stopper method: automatic initialization and manual initialization.

When the automatic initialization is applied, the axis travels automatically after the JOG is started.

When the manual initialization is applied, the axis travels by handle mode or JOG mode while confirming each operation.

## (4) Dog method

This method requires a dog sensor.

Move the table until the dog is kicked, and the first grid point after the dog OFF is determined as the basic position.

The parameters for the approach speed and grid mask amount etc. need to be adjusted.


### 7.1.1 Marked Alignment Method I

- (1) Select [Param] -> [Abs.Posit.Param.] in the maintenance screen.

Set the following parameters in the "Abs.Posit.Param." screen.

Parameter	Setting value
#2049 type (absolute position detection type)	2 (marked point alignment method isselected)
#2050 absdir (basic Z - direction)	0/1
#2059 zerbas (zero point parameter)	1

- (2) Turn the power OFF and ON.
- (3) Select [Mainte] -> [To abs pos]. The absolute position setting screen will appear.
- (4) Select [Axis select]. Enter the axis name (the name set in "#1022 axname2 (2nd axis name)", and hold down INPUT key.
- (5) Select HANDLE (handle axis) or "JOG" mode.
- (6) Set "1" to "#0 Absolute posn set".
- (7) Enter an arbitrary value to "#2 Zero-P".
- (8) Move the axis toward the mechanical basic position and align it to the marked point. (a in the diagram)
- (9) Set "1" to "#1 Origin-P".
- (10) Move the axis in the direction designated with the parameter "#2050 absdir".
- (11) The axis reached the first grid point. (c in the diagram)  
When the absolute position is established, [Complete] will appear in [State].  
Select [Next axis] menu, and perform the absolute position initial set up for all axes.
- (12) Turn the power OFF and ON.




- (Note 1) To change just the basic machine coordinate zero point, set "#0 Absolute posn set" and "#2 Zero-P", and then turn the power OFF and ON.
- (Note 2) If aligning axis on the marked point is attempted without passing the grip point once after turning the power ON, the operation message "Not passed on grid" will appear. Return to a point before the last grid, and then repeat from step of aligning the axis on the marked point.
- (Note 3) If the first grid point is covered by the grid mask (#2028 grmask) as a result of return to the electric basic position, the axis stops at the next grid point.  
Note that zero-point shift amount (#2027 G28sft) is invalid.
- (Note 4) Reconfirm the "absdir" setting if the machine does not move in the direction of "#2050 absdir". The machine will move only in the positive direction when set to "0", and the negative direction when set to "1".

### 7.1.2 Marked Point Alignment Method II

This is a method to align to the marked point (matchmark or marking line) on the machine.

- (1) Select [Param] on the Mainte screen, then select [Abs pos param].  
On the absolute position parameter screen, set "#2049 type (Absolute position detection method)" to "4" for the axis for which the zero point is to be initialized.
- (2) Turn the power OFF and ON.
- (3) Select [Mainte] and then [To abs pos]. The absolute position setting screen appears.
- (4) Select [Axis select]. Enter the axis name (in "#1022 axname2 (2nd axis name)") and press the INPUT key.
- (5) Select the handle (handle axis) or JOG mode.
- (6) Input "1" to "#0 Absolute posn set" on the absolute position setting screen.
- (7) Input a value to "#2 Zero-P".
- (8) Move the axis toward the machine basic position and align it to the marked point. ((a) in the following diagram)



- (9) Input "1" to "#1 Origin-P" on the absolute position setting screen.
  - (10) When the absolute position has been completed, "State" area on the absolute position setting screen shows "Complete".  
Select [Next axis] and execute the absolute position initialization for all the axes.
  - (11) Turn the power OFF and ON.
- (Note 1) To change just the basic machine coordinate zero point, set "#0 Absolute posn set" and "#2 Zero-P", and then turn the power OFF and ON.
- (Note 2) If aligning to the marked point is attempted without passing the grid point even once after turning the power ON, the operation message "Not Passed on grid" will appear. Return to a point before the last grid, and then repeat from the step of aligning the axis on the marked point.
- (Note 3) If the first grid point is covered by the grid mask ("#2028 grmask") as a result of return to the electric basic position, the axis stops at the next grid point. Note that the zero point shift ("#2027 G28sft") is invalid.
- (Note 4) This method is not interfered by the setting of "#2059 zerbas", and the basic position is always where the marked point alignment is attempted.

### 7.1.3 Other Setting Method

#### 7.1.3.1 Machine End Stopper Method: Automatic Initialization

- (1) Select [Param] -> [Abs.Posit.Param.] in the maintenance screen.

Set the following parameters in the "Abs.Posit.Param." screen.

Parameter	Setting value
#2049 type (absolute position detection type)	1 (machine end stopper method isselected)
#2054 clpush (current limit)	0 to 100
#2055 pushf (push speed)	1 to 999
#2056 aproch (approach point)	0 to 999.999
#2059 zerbass (zero point return parameter)	1 (on the grid point immediately beforethe stopper)

The parameters other than "#2049 type" can be set in the "Zero point set" screen.

- (2) Turn the power OFF and ON.
- (3) Select [Mainte] -> [To Abs pos.]. The absolute position setting screen will appear.
- (4) Select [Axis select]. Enter the axis name (the name set in "#1022 axname2 (2nd axis name)", and hold down INPUT key.
- (5) Select [Auto init set] mode.
- (6) Set "1" to "#0 Absolute posn set".
- (7) Enter the value in "#2 Zero-P".

## 7 Setting the Position Detection System

- (8) Start JOG operation.

The axis moves automatically as follow.

- 1) The axis moves toward the machine end stopper at the push speed. (a in the diagram).
- 2) The axis pushes against the machine end stopper. After the current reached its limit continually during given time period, the axis returns toward the approach point at the "push speed". (b in the diagram)
- 3) After arrived at the approach point, the axis moves toward the machine end stopper at the "push speed". (c in the diagram)
- 4) The axis pushes against the machine end stopper. After the current reached its limit continually during the given time period, the axis returns toward the grid point immediately before the stopper at the "push speed". (d in the diagram)

If "#2059 zerbas" is set to "0" (absolute position origin point = mechanical basic position), the axis will stop automatically at this point without moving in the opposite direction, and "Complete" appears in the [State] and "0.000" in the [Machine end].

[State] will change as follow:


[Stopper1] -> [Zero-P. Rel.] -> [Stopper2] -> [Ret. Ref. P.]

- (9) When the axis has reached the grid point immediately before the stopper (e in the diagram) and the absolute position is established, "Complete" will appear in "State".

The distance between the machine end stopper and the grid point immediately before the stopper will appear in [Machine end].

Select [Next axis] menu, and perform the absolute position initial set up for all axes.


- (10) Turn the power OFF and ON.



- (Note 1) To change just the basic machine coordinate zero point, set "#0 Absolute posn set" and "#2 Zero-P", and then turn the power OFF and ON.
- (Note 2) If pressing against the machine end is attempted without passing the grip point once after turning the power ON, the operation message "Not passed on grid" will appear. Return to a point before the last grid, and then repeat from step of pressing against the machine end stopper.
- (Note 3) If the first grid point is covered by the grid mask (#2028 grmask) as a result of return to the electric basic position, the axis stops at the next grid point.  
Note that zero-point shift amount (#2027 G28sft) is invalid.
- (Note 4) Acceleration/deceleration during movement at the specified push speed is performed in smoothing-off (stepfeed) mode.
- (Note 5) If "0" is specified for "#2056 aproch" of the absolute position parameters, the machine zero point is regarded as the approach point.
- (Note 6) Automatic initialization is interrupted if one of the following events occurs. If it is interrupted, [State] indicates "Jog Start" (after selecting the "Auto init set" mode if it is caused by mode change), so restart operation from the step of JOG-start.
- An absolute position detection alarm occurs.
  - Operation preparation signal turns OFF.
  - The mode is changed.
  - The system is reset.
- If [State] is "Complete" before automatic initialization is started, "State" returns to "Complete" when power is turned OFF and ON again without restarting the operation.
- (Note 7) Automatic initialization cannot be started in the following cases. The operation message "Can't start" will appear if starting is attempted.
- When "#0 Absolute posn set" is not set.
  - When the "#2 Zero-P" setting is inappropriate.
  - When "#2055 pushf" is not set.
  - When "Z71 Abs encoder failure 0005" has occurred.

In the above cases, if the "#2 Zero-P" setting is inappropriate, this means that the relation of "#2 Zero-P" and "#2037 G53ofs" is inappropriate. That is, if "#2 Zero-P" is smaller than the "#2037 G53ofs", the machine end stopper will be located between the basic machine coordinate system zero point and reference position; this disables automatic initialization. (Refer to the following left figure.)

If "#2 Zero-P" is set to "0", the machine end stopper direction is unpredictable; this also disables automatic initialization. (Refer to the following right figure.)



## 7 Setting the Position Detection System


### 7.1.3.2 Machine End Stopper Method: Manual Initialization

- (1) Select [Param] -> [Abs.Posit.Param.] in the maintenance screen.  
Set the following parameters in the "Abs.Posit.Param." screen.

Parameter	Setting value
#2049 type (absolute position detection type)	1 (machine end stopper method is selected)
#2054 clpush (current limit)	0 to 100
#2059 zerbas (zero point return parameter)	1 (on the grid point immediately before the stopper)

The parameters other than "#2049 type" can be set in the "Zero point set" screen.

- (2) Turn the power OFF and ON.
- (3) Select [Mainte] -> [To abs pos]. The absolute position setting screen will appear.
- (4) Select [Axis select]. Enter the axis name (the name set in "#1022 axname2 (2nd axis name)", and hold down INPUT key.
- (5) Select HANDLE (handle axis) or "JOG" mode.
- (6) Set "1" to "#0 Absolute posn set".
- (7) Enter an arbitrary value to "#2 Zero-P".
- (8) Move the axis toward the machine end stopper. (a in the diagram)
- (9) Press the axis against the machine end stopper. (b in the diagram)  
The current limit is reached continually during the given time period. (c in the diagram)  
The display for [State] changes from [Stopper] to [Release].
- (10) Move the axis in the counter direction. (d in the diagram)  
[Ret. Ref. P.] will appear in [State].  
If "#2059 zerbas" is set to "0" (absolute position origin point = mechanical basic position), the axis will stop automatically at this point without moving in the opposite direction, and "Complete" appears in the [State] and "0.000" in the [Machine end].
- (11) When the axis has reached the grid point immediately before the stopper (e in the diagram) and the absolute position is established, "Complete" will appear in "State".  
Select [Next axis] menu, and perform the absolute position initial set up for all axes.
- (12) Turn the power OFF and ON.



- (Note 1) To change just the basic machine coordinate zero point, set "#0 Absolute posn set" and "#2 Zero-P", and then turn the power OFF and ON.
- (Note 2) If pressing against the machine end is attempted without passing the grip point once after turning the power ON, the operation message "Not passed on grid" will appear. Return to a point before the last grid, and then repeat from step of pressing against the machine end stopper.
- (Note 3) If the first grid point is covered by the grid mask (#2028 grmask) as a result of return to the electric basic position, the axis stops at the next grid point.  
Note that zero-point shift amount (#2027 G28sft) is invalid.

### 7.1.3.3 Dog-type

- (1) Select [Param] -> [Abs.Posit.Param.] in the maintenance screen.  
Set "3" for the axis for which the absolute position initialization is performed to "#2049 type (absolute position detection type)".
  - (2) Turn the power OFF and ON.
  - (3) Select [Mainte] -> [To abs pos]. The absolute position setting screen will appear.
  - (4) Select [Axis select]. Enter the axis name (the name set in "#1022 axname2 (2nd axis name)", and hold down INPUT key.
  - (5) Execute the manual or automatic dog-type reference position return.
  - (6) When the reference position return is completed and the absolute position is established, "Complete" will appear in "State".  
Select [Next axis] menu, and perform the absolute position initial set up for all axes.
  - (7) Turn the power OFF and ON.
- (Note 1) If the dog-type reference position return is interrupted by resetting, the previous state ("Complete" or "Illegality") will display in the [State] column.
- (Note 2) With dog-type reference position return, reference position return can be executed again even if the [State] is "Complete".



## 7.1.4 Precautions




### 7.1.4.1 Precautions common for the initialization operation

- (1) The "#0 Absolute posn set" parameter (axis for which zero point is to be initialized) can be set simultaneously for all axes or individually for each axis.
- (2) The "#0 Absolute posn set" parameter cannot be turned OFF with the keys. It is turned OFF when the power is turned ON again.
- (3) "#2 ZERO-P" can be set at any time as long as "#0 Absolute posn set" is set to "1".
- (4) The grid point must be passed at least once after turning the power ON before initializing the zero point. If the grid point has not been passed, the operation message "Not passed on grid" will appear at the "Machine posn".
- (5) When the absolute position is established, the required data will be stored in the memory.

### 7.1.4.2 Precautions common for the dogless-type absolute position detector


- (1) Example of setting "#2 Zero-P" parameter

For the "#2 Zero-P" parameter, set the coordinate value of the absolute position origin point (mechanical basic position or electrical basic position) looking from the basic machine coordinate system zero point.

<p>(Example 1) To set the zero point at 50.0mm before absolute position origin point on + end</p>	
<p>(Example 2) To set the zero point at 400.0mm before the machine basic position or absolute position origin point on - end.</p>	
<p>(Example 3) To set the basic machine coordinate system zero point on the grid point, calculate the "#2 Zero-P" parameter setting value as shown below using the value displayed at "Machine end". "Machine end" shows the distance from the mechanical basic position to the previous grid point. (Note that when setting the electrical basic position coordinate value in "#2 Zero-P", the "Machine end" value does not need to be considered.)</p>	
<p>To set the third grid point as the zero point when the "Machine end" display is -5.3 at the + end basic position. (Example of 10.0mm grid interval.)</p>	

## (2) Setting the reference position

The reference position can be set as shown below by setting the "#2037 G53ofs".



## 7.2 Adjustment of Reference Position Return in Relative Position Detection System


### 7.2.1 Dog-type Reference Position Return

#### 7.2.1.1 Dog-type Reference Position Return Operation

In the dog-type reference position return, the axis moves as follows:

- (1) Starts moving at G28 rapid traverse rate.
- (2) Decelerates to stop when the near-point dog is detected during the movement. Then, resumes moving at G28 approach speed.
- (3) Stops at the first grid point after leaving the near-point dog.

This grid point, where the axis stopped at (3), is called the electrical zero point. Normally, this electrical zero point is regarded as the reference position.



The first reference position return after turning the power ON is carried out with the dog-type reference position return. The second and following returns are carried out with either the dog-type reference position return or the high-speed reference position return, depending on the parameter.

High-speed reference position return is a function that directly positions to the reference position saved in the memory without decelerating at the near-point dog.

- (Note) If reference position return has never been executed after turning the power ON and a movement command other than G28 is executed, the program error (P430) will occur.

### 7.2.1.2 Dog-type Reference Position Return Adjustment Procedures


Adjust the dog-type reference position return with the following steps.

- (1) Select [Param] menu from the maintenance screen, and then select zero point parameter screen by feeding the page.  
The zero point parameter screen appears.
- (2) Set "0" for the following parameters on the [ZERO-RTN PARAM] screen.  
Reference position shift amount (#2027 G28sft)  
Grid mask amount (#2028 grmask)
- (3) Turn the power OFF and ON, and then execute reference position return.  
(Note) Use the switches on the machine operation panel to command "reference position return mode" and operate the axis movement. The GOT project and the panel switches are made by the machine tool builder.
- (4) Select [Drv mon] screen from the diagnosis screen, and display the drive monitor screen. Feed the page and check "Grid space" and "Grid amnt".


## 7 Setting the Position Detection System

(5) Determine the grid mask amount according to the state as shown below.

- When  $\frac{\text{Grid space}}{2}$  is smaller than the grid amount




- When  $\frac{\text{Grid space}}{2}$  is larger than the grid amount



(6) Set the determined grid mask amount for "#2028 grmask" of the [ZERO-RTN PARAM] screen.

- (7) Turn the power OFF and ON, and then execute reference position return.
- (8) Confirm the grid space and grid amount values on DRIVE MONITOR screen.  
If the grid amount value is approximately half of the grid space, the grid mask amount has been set correctly. If the value is not approximately half, repeat the procedure from step (1).
- (9) Set the reference position shift amount (#2027 G28sft).  
To designate the electrical zero point as reference position, set "0" to "#2027 G28sft".
- (10) Turn the power OFF and ON, and then execute the reference position return.  
(Note) The axis moves at the speed of "#2025 G28rap G28 rapid traverse rate".  
The parameter "#2025 G28rap G28 rapid traverse rate" is usually set the maximum speed, which makes the high-speed movement in the 2nd reference position return and later. Take extra care for the safe axis movement.
- (11) Set the machine coordinate system offset amount (#2037 G53ofs).

#### [Terms and parameters related to the dog-type reference position return]



#### Electrical zero point

The first grid point after the dog OFF.

If the grid point is at the position where the near-point dog is kicked OFF, the position of electrical zero point may be at the grid point where the dog is kicked OFF or at the next grid point because of the delay of the limit switch operation. This causes a deviation of reference position by the amount of the grid space.

Setting the grid mask amount ("#2028 grmask") prevents this deviation.

#### Reference position

The base for position and coordinate.

The axis is positioned to this position by the manual reference position return command or G28 command in the machining program.

The position is determined by shifting from the electrical zero point by the amount of "#2027 G28sft Reference position shift amount".

## 7 Setting the Position Detection System

### Grid point

The position detector has a Z-phase that generates one pulse per rotation. The 0-point position of this Z-phase is the grid point.

Thus, there is a grid point per rotation of the position detector, and the machine has many grid points at a regular pitch. The grid point can be set at intervals of grid space by setting the grid space (#2029 grspc). Thus, multiple grid points can be set per detector rotation.

### Grid amount

The grid amount is the distance from where the near-point detection limit switch leaves the near-point dog to the grid point (electrical zero point) as the dog-type reference position return is executed.

The grid amount can be confirmed on the DRIVE MONITOR screen.

After setting the grid mask, the grid amount shows the distance from the grid mask OFF to the grid point.

### G28 rapid traverse rate (#2025 G28rap)

Set the feedrate for dog-type reference position return in manual operation and the automatic operation.

The rapid traverse rate (#2001 rapid) is applied for the feedrate during the high-speed reference position return.

### G28 approach speed (#2026 G28crp)

Set the approach speed to the reference position after decelerating to a stop by the near-dog detection. Since the approach speed is accelerated and decelerated in steps (no-acceleration/deceleration), the mechanical shock, etc. could occur if the speed is too large. The G28 approach speed should be set between 100 and 300 mm/min., or within 500 mm/min. at the fastest.

### Reference position shift amount (#2027 G28sft)

When shifting the reference position from the electrical zero point, set the shift amount.

The shifting direction can be set only in the reference position return direction.

If the reference position shift amount is "0", the grid point (electrical zero point) will be the reference position.

### Grid mask amount (#2028 grmask)

The first grid point after the dog OFF is regarded as the electrical zero point.

If the grid point is at the position where the near-point dog is kicked OFF, the position of electrical zero point may be at the grid point where the dog is kicked OFF or at the next grid point because of the delay of the limit switch operation. This causes a deviation of reference position by the amount of the grid space. Thus, the position that the dog is kicked OFF needs to be at the approximate center of the grid space.

Adjustments are made by setting the grid mask amount or changing the near-point dog.

Setting the grid mask has the same effect as lengthening the near-point dog. Refer to the previous procedures for setting the grid mask amount.

### Grid space (#2029 grspc)

Set the distance between grids.

Set either the ball screw pitch value (#2218 PIT) or the movement amount per motor rotation as the normal grid space.

To make the grid space smaller, set a divisor of the grid space.

### <Calculation method for movement amount per motor rotation>


- (1) When linear feed mechanism is a ball screw:  
The movement amount per motor rotation = the motor side gear ration / the machine side gear ratio x the ball screw pitch
- (2) When linear feed mechanism is a rack and pinion:  
The movement amount per motor rotation = the motor side gear ration / the machine side gear ratio x number of pinion gear teeth x the rack pitch
- (3) For the rotary axis:  
The movement angle per motor rotation = the motor side gear ration / the machine side gear ratio x 360

**Reference position return direction (#2030 dir (-))**

The direction of the (axis) movement, after the dog-type reference position return is executed and the limit switch kicks the dog and decelerate to stop, is set to either positive "0" or negative "1".

Set "0" if the reference position is in the positive direction from the near-point dog.

Set "1" if the reference position is in the negative direction from the near-point dog.

**Axis with no reference position (#2031 noref)**

Set "0" for the axis to carry out dog-type reference position return and the axis for absolute position detection.

Set "1" for the axis without carrying out reference position return during the relative position detection.

**Machine coordinate system offset (#2037 G53ofs)**

Set the amount to shift the basic machine coordinate system zero point position from the reference position.

When "0" is set, the reference position will be the position of the basic machine coordinate system zero point.

In "G53ofs" parameter, set the position of the reference position looking from the basic machine coordinate system zero point with the coordinates of basic machine coordinate system. By the reference position return after the power is turned ON, the machine position will be set and the basic machine coordinate system will be established.

**Selection of grid display type (#1229 set01/bit6)**


Select the grid display type on DRIVE MONITOR screen during dog-type reference position return.

0: Distance from dog OFF to electric zero point (including the grid mask amount)

1: Distance from dog OFF to electric zero point (excluding the grid mask amount)







---

## **Setting the Tool Entry Prohibited Range**

## 8 Setting the Tool Entry Prohibited Range

Following functions are available for setting a tool entry prohibited range to detect over travels (OT).

- (1) Stroke end (H/W OT)  
The limit switch signal will detect the stroke end and limit the movement of the axis.
- (2) Stored stroke limit (S/W OT)  
Prohibited ranges are set with parameters.



When stroke end (H/W OT) is set, the axis will move the distance required to decelerate and stop after H/W OT is activated.

When stored stroke limit (S/W OT) is set, the axis will stop before the prohibited range of S/W OT including the deceleration distance.

For safety, set the stroke end (H/W OT) and also, the stored stroke limit (S/W OT).



### WARNING

**Stroke end (H/W OT) and stored stroke limit (S/W OT) must always be set. If not, the tool may hit the machine end.**

### 8.1 Stroke End (H/W OT)

The axis movement is controlled by the limit switch which detects the stroke end.

Signal device No. is allocated by the following parameters.

Parameter "#2074" and "#2075" will be valid only when "#1226 aux10/bit" is set to "1".

#1226 aux10/bit5: Set to "1" (assigning the signal is valid).

#2074 H/W OT+: Set the input device for assigning the OT (+) signal. (Setting range 0000 to 02FF (Hexadecimal))

#2075 H/W OT-: Set the input device for assigning the OT (-) signal. (Setting range 0000 to 02FF (Hexadecimal))

(Note 1) When "OT IGNORED" (R248) signal is set to ON, the stroke end signal associated with a specific control axis can be ignored.

(Note 2) When parameter "#1226 aux10/bit5" is set to "1", do not set the same device No. to #2073 to #2075.

Setting the same device No. may cause the emergency stop. However, the device number will not be checked for the axis which is set the signal to ignore (R248,R272).


## 8.2 Stored stroke limit (S/W OT)


### 8.2.1 Outline


Three tool entry prohibited ranges can be set with stored stroke limit I, stored stroke limit II, IIB and stored stroke limit IB. Part of the prohibited range on the outside of stored stroke limit I can turn into a moveable range with stored stroke limit IC.

Set the parameters to select the entry prohibited range, stored stroke limit II or IIB.

(II: Prohibits entering outside the range IIB: Prohibits entering inside the range)



 : Moveable range

 : Prohibited range

(A): Prohibited range by stored stroke limit I

(B): Prohibited range by stored stroke limit IIB

(C): Prohibited range by stored stroke limit IB

(D): Moveable range by stored stroke limit IC

If the axis is moving over the set range, an alarm will appear and the axis will decelerate to a stop.

If the prohibited range is entered and an alarm occurs, movement will be possible only in the direction opposite the entry direction.

## 8 Setting the Tool Entry Prohibited Range

### Valid Conditions of Stored Stroke Limit

When using the relative position detection system, the stored stroke limit is invalid until the reference position return is completed after the power is turned ON.

The stored stroke limit can be validated even if the reference position return is not yet completed, by setting "#2049 type (Absolute position detection method)" to "9".

(Note) If the absolute position detection is valid when using the absolute position detection system, the stored stroke limit will be validated immediately after the power is turned ON.

### Stored Stroke Limit Coordinates

The stored stroke limit check is carried out in the basic machine coordinate system established by the reference position return.

When the stored stroke limit has been validated while the reference position return has not been completed, the stored stroke limit check is executed with the basic machine coordinate system at the time of last power-OFF as temporary one.

When the 1st dog-type reference position return is completed after the power is turned ON, the proper coordinate system is established.

(Note) While the reference position return has not been completed, only the manual and handle feed mode allow the axis movement. Automatic operation is validated after the reference position return is completed.



**CAUTION**

**Always set the stored stroke limit. Failure to set this could result in collision with the machine end.**

### 8.2.2 Detailed Explanation

The stored stroke limit sets a prohibited range with the parameters or program command. The minimum and maximum values of the prohibited range are set as the coordinate value (radius value) on the machine coordinate system for each axis.

- The stroke check will not be executed when both maximum and minimum value are set to the same value.
- This function is valid after the reference position return if the system does not apply the absolute position detection system.
- Before the machine enters the prohibited range, an error "M01 Operation error 0007" (S/W stroke end) will occur, and the machine movement will stop. The alarm can be reset by moving the erroneous axis in the opposite direction.
- During automatic operation, if an alarm occurs with even one axis, all axes will decelerate to a stop.
- During manual operation, only the axis that caused the alarm will decelerate to a stop.
- The axis will always stop at a position before the prohibited range.
- The distance between the prohibited range and stop position will depend on the feedrate, etc.

The stored stroke limits I, II, IIB, IB and IC are handled as follows.


Type	Prohibited range	Description	Range setting parameters	Validating conditions
I	Outside	- Set by the machine tool builder. - When used with II, the confined range designated by the two functions becomes the movement valid range.	"#2013 OT - (Soft limit I -)" "#2014 OT + (Soft limit I +)"	- Reference position return is completed. - #2013 and #2014 are not set to the same value.
II	Outside	- Set by the user. - Select II or IIB with the parameters.	- "#8210 OT-INSIDE" = "0" - Used with I.	- Reference position return is completed. - #8204 and #8205 are not set to the same value.
IIB	Inside	- "#8210 OT-INSIDE" = "1"	"#8204 OT-CHECK-N" "#8205 OT-CHECK-P"	- "#8202 OT-CHECK OFF" = "0"
IB	Inside	- Set by the machine tool builder.	"#2061 OT_1B- (Soft limit IB-)" "#2062 OT_1B+ (Soft limit IB +)"	- Reference position return is completed. - #2061 and #2062 are not set to the same value.
IC	Outside	- Set by the machine tool builder.	"#2061 OT_1B- (Soft limit IB-)" "#2062 OT_1B+ (Soft limit IB +)"	- Reference position return is completed. - #2061 and #2062 are not set to the same value. - "#2063 OT_1Btype (Soft limit IB type)" = "2"


## 8 Setting the Tool Entry Prohibited Range


### 8.2.2.1 Stored Stroke Limit I

This is a stroke limit function used by the machine tool builder. The boundary is set with the parameters ("#2013 OT - (Soft limit I -)" and "#2014 OT + (Soft limit I +)"). The outside of the set boundary is the prohibited range. The outside of the set boundary is the prohibited range.

When used with the stored stroke limit II function, the confined range designated by the two functions becomes the moveable range.



 : Moveable range

 : Prohibited range

(A): Set value for (-) side

(B): Set value for (+) side

Point 1: "#2014 OT+ (Soft limit I +)" and

Point 2: "#2013 OT- (Soft limit I -)" are set with the coordinate values in the basic machine coordinate system.

(Note 1) This function will be invalid if the same value excluding "0" is set for both "#2013 OT -" and "#2014 OT +".


(Note 2) When using the peripheral axis, inside of the specified range will be prohibited if the "#2013 OT -" value is larger than that of "#2014 OT +".

### 8.2.2.2 Stored Stroke Limit II

The boundary is set with the axis parameters "#8204 OT-CHECK-N" and "#8205 OT-CHECK-P" or with program commands. Either the inside or the outside of the set boundary is the prohibited range. Whether the inside or outside of the range is prohibited is determined by "#8210 OT-INSIDE". When the inside is selected, this function is called stored stroke limit IIB.



When using program commands, entry of the tool into the prohibited range is prohibited with G22, and entry into the prohibited range is enabled with G23. The stored stroke limit II can be invalidated for each axis with setting "#8202 OT-CHECK OFF" to "1".

#### Prohibited range



#### (1) Stored stroke limit II (When prohibited range is on outside)

When used with the stored stroke limit I function, the narrow range designated by the two types becomes the movement valid range.



(A): Set value for (-) side

(B): Set value for (+) side

(C): Prohibited range by stored stroke limit II

Point 3: "#8205 OT-CHECK-P" and

Point 4: "#8204 OT-CHECK-N" are set with the coordinate values in the basic machine coordinate system.


Points 1 and 2 are the prohibited range set with stored stroke limit I.





## 8 Setting the Tool Entry Prohibited Range

### (2) Stored stroke limit IIB (When prohibited range is on inside)

A range except for that of the stored stroke limit I becomes the movement prohibited range.



 : Moveable range

 : Prohibited range

(A): Set value for (-) side

(B): Set value for (+) side

(C): Prohibited range by stored stroke limit IIB


Point 3: "#8205 OT-CHECK-P" and


Point 4: "#8204 OT-CHECK-N" are set with the coordinate values in the basic machine coordinate system.


Points 1 and 2 are the prohibited range set with stored stroke limit I.

### 8.2.2.3 Stored Stroke Limit IB

The boundary is set for each axis with the axis parameters "#2061 OT\_1B-" and "#2062 OT\_1B+". The inside of the set boundary is the prohibited range.



 : Moveable range

 : Prohibited range

Point 5: "#2062 OT\_1B+ (Soft limit IB+)" and

Point 6: "#2061 OT\_1B- (Soft limit IB-)" are set with the coordinate values in the basic machine coordinate system.

(A): Set value for (-) side

(B): Set value for (+) side

(C): Prohibited range by stored stroke limit II

(D): Prohibited range by stored stroke limit IB

Points 1 and 2 are the prohibited range set with stored stroke limit I.


Points 3 and 4 are the prohibited range set with stored stroke limit IIB.


## 8 Setting the Tool Entry Prohibited Range


### 8.2.2.4 Stored Stroke Limit IC

The boundary is set for each axis with the axis parameters "#2061 OT\_1B-" and "#2062 OT\_1B+". The inside of the set boundary is the machine movement valid range.

This is valid when the axis parameter "#2063 OT\_1Btype (Soft limit IB type)" is set to "2". Cannot be used with soft limit IB.



 : Moveable range

 : Prohibited range

Point 3: "#2062 OT\_1B+ (Soft limit IB+)" and


Point 4: "#2061 OT\_1B- (Soft limit IB-)" are set with the coordinate values in the basic machine coordinate system.


Points 1 and 2 are the prohibited range set with stored stroke limit I.


### 8.2.2.5 Movable Range during Inclined Axis Control

By setting "#2063 OT\_1Btype" to "3", the inclined axis control axis can be checked with the program coordinates using the stored stroke limit IB/IC range setting ("#2061" and "#2062"). The stored stroke limit IB and IC cannot be used together at this time.

By using this function with stored stroke limit I, the check can be carried out simultaneously with the actual axis and program coordinate value. In this case, the range that does not fit into either of the following two prohibited ranges will be the movable range.



 : Moveable range

 : Prohibited range

Point 3: "#2062 OT\_1B+ (Soft limit IB+)" and

Point 4: "#2061 OT\_1B- (Soft limit IB-)" are set with the coordinate values in the basic machine coordinate system.

Points 1 and 2 are the prohibited range set with stored stroke limit I.

### 8.2.2.6 Stored Stroke Limit for Rotation Axis

Stored stroke limits I and II are used as the stored stroke limit for the rotation axis. The area between the maximum and minimum values of the prohibited range's parameters, which does not contain the 0 point of the basic machine coordinate system, is the entry prohibited range.

The prohibited range parameters for the rotation axis can be set to establish "maximum value < minimum value" ("#2014 OT+" < "#2013 OT-", "#8205 OT-CHECK-P" < "#8204 OT-CHECK-N"). This will be handled in the same manner as if "maximum value > minimum value" ("#2014 OT+" > "#2013 OT-", "#8205 OT-CHECK-P" > "#8204 OT-CHECK-N").

(Example) Stored stroke limit I (maximum value and minimum value of prohibited range parameter)


#2013 OT -: -70.000°

#2014 OT +: 60.000°

Stored stroke limit II (maximum value and minimum value of prohibited range parameter)

#8204 OT-CHECK-N: 30.000°

#8205 OT-CHECK-P: 80.000°



(A): Moveable range

(B): Prohibited range by stored stroke limit I

(C): Prohibited range by stored stroke limit II

### 8.2.2.7 Precautions

- (1) If the maximum value and minimum value of the stored stroke limit's prohibited range are set to the same value, the following will occur.
  - (a) When the maximum value and minimum value are set to "0", if the outside is the prohibited range, the entire range will be prohibited. If the inside is the prohibited range, the entire range will be the moveable range.
  - (b) If data other than 0 is set for the maximum value and minimum value, the entire range will be the moveable range.
- (2) The stored stroke limit IC is valid when the axis parameter #2063 is changed. If changed during automatic operation, the function will be validated after the smoothing for all axes reaches 0.
- (3) Make sure that the lower limit value of the stored stroke limit IC setting value is "smaller than the upper limit value".
- (4) To set the inside of the specified range as a prohibited range, set the parameters as follow:  
 EX. There are 2 methods to set 10° to 70° as a prohibited range.  
 (Method 1) #2013 OT-: 70° #2014 OT+: 370°  
 (Method 2) #2013 OT-: 370° #2014 OT+: 70°

---

## Confirming the Spindle Operation

## 9 Confirming the Spindle Operation


Confirm that the spindle operates properly in manual/MDI operation. Confirm the spindle rotation speed as well.

### CAUTION

1. Do not adjust the spindle when possible risks associated with adjustment procedures are not thoroughly taken into consideration.
2. Be careful when touching spindle's rotating section, or your hand may be caught in or cut.

### 9.1 In Manual Operation (with Manual Numerical Command)


- (1) Select [MST] on the Monitr screen. Enter a spindle rotation speed (ex. 100r/min) in "S" field.



- (2) Enter "3" in "M" field to rotate the spindle.
- (3) Check the rotation speed of the spindle motor while the spindle is rotating. Refer to the section of "Confirming the Rotation Speed".
- (4) After checking the rotation speed, set "5" in "M" field or press the spindle stop button to stop the spindle rotation.

## 9.2 In MDI Operation

- (1) Select MDI mode.
- (2) Select [MDI] on the Setup screen. Enter a program to issue an S command.



Program example (to rotate the spindle at 100r/min for 5 seconds)


```
S100 M03 ;
G04 X5.0 ;
M05 ;
```

Press the INPUT key after entering the program.

- (3) Press the automatic start button.
- (4) Check the rotation speed of the spindle motor while the spindle is rotating. Refer to the section of "Confirming the Rotation Speed".

## 9.3 Confirming the Rotation Speed

- (1) Select [Drv mon] and then [Spindle unit] on the Diagn screen.
- (2) Check the rotation speed of the spindle motor. (To obtain the spindle rotation speed, apply the gear ratio to the motor's rotation speed.)



(Note) If the vibration is not reduced by the measure, refer to the manuals of the servo drive unit.





## Setting the Deceleration Check

## 10.1 Function

The purpose of the deceleration check is to reduce the machine shock that occurs when the control axis feedrate is suddenly changed, and prevent corner roundness. The check is carried out at block joints.

(1) Deceleration check during rapid traverse

The deceleration check is always carried out at the block joints (before executing the next block) during rapid traverse.

(2) Deceleration check during cutting feed

The deceleration check is carried out at the block joints (before executing the next block) during cutting feed when any one of the following conditions is valid.

- (a) When the error detect switch is ON.
- (b) When G09 (exact stop check) is commanded in the same block.
- (c) When G61 (exact stop check mode) has been selected.

(3) Designating deceleration check

The deceleration check by designating a parameter includes "deceleration check specification type 1" and "deceleration check specification type 2". The setting is selected with the parameter "#1306 InpsTyp".

(a) Deceleration check specification type 1 ("#1306 InpsTyp" = 0)

The G0 and G1 deceleration check method can be selected with the base specification parameter deceleration check method 1 "#1193 inpos" and deceleration check method 2 "#1223 aux07/bit1".

Parameter	Rapid traverse command	Parameter	Other than rapid traverse command (G1: other than G0 command)	
Inpos (#1193)	G0 -> XX (G0+G9 -> XX)	AUX07/BIT-1 (#1223/BIT-1)	G1+G9 -> XX	G1 -> XX
0	Command deceleration check	0	Command deceleration check	No deceleration check
1	In-position check	1	In-position check	

(Note 1) XX expresses all commands.

(Note 2) "#1223 aux07" is the part system common parameter.

(b) Deceleration check specification type 2 ("#1306 InpsTyp" = 1)

Rapid traverse and cutting feed in-position are designated with the parameter "#1193 inpos".

Parameter	Command block		
	G0	G1+G9	G1
0	Command deceleration check	Command deceleration check	No deceleration check
1	In-position check	In-position check	No deceleration check

(Note 1) "#1193 inpos" is the parameter per part system.


(Note 2) "G0" means the rapid traverse, and "G1" means the cutting feed.

## 10.2 Deceleration Check Method


### (1) Command deceleration check

After interpolation for one block has been completed, the completion of the command system deceleration is confirmed before execution of the next block. The time required for the deceleration check is determined according to the acceleration/deceleration mode and acceleration/deceleration time constant.


#### (a) For linear acceleration/deceleration



#### (b) For exponential acceleration/deceleration



#### (c) For exponential acceleration and linear deceleration



The deceleration check time required during rapid traverse is the longest rapid traverse deceleration check time of all axes. This check time is determined by the rapid traverse acceleration/deceleration mode and rapid traverse acceleration/deceleration time constant of simultaneously commanded axes.


The deceleration check time required during cutting feed is determined in the same manner. It is the longest cutting feed deceleration check time of all axes. This check time is determined by the cutting feed acceleration/deceleration mode and cutting feed acceleration/deceleration time constant of simultaneously commanded axes.

## 10 Setting the Deceleration Check

### (2) In-position check

When the in-position check is valid, the command deceleration check is carried out. After that, it is confirmed that the servo system positional error is less than the parameter setting value, and the next block is executed.

The in-position check width can be designated with the servo parameter in-position width (SV024). Note that G0 and G1 can be designated independently with the axis specification parameter G0 in-position check width (G0inps) and G1 in-position check width (G1inps). If both the servo parameter and axis specification parameter are set, the larger value will have the priority.







If the SV024 setting value is larger, in-position check will end when the SV024 setting value is established.

## 10.3 Deceleration Check for Opposite Direction Movement Reversal

Deceleration check cannot be designated for G1 → G0 or G1 → G1, but it can be designated in the following manner only when the movement reverses to the opposite direction in successive blocks. Deceleration check can also be executed if even one axis is moving in the opposite direction while several axes are interpolating.





- (1) Designating deceleration check for G1 → G0 opposite direction movement reversal

If the axis movement reverses to the opposite direction in a G1 to G0 successive block, the deceleration check for the movement in the opposite direction can be changed with the base specification parameter G1 → G0 deceleration check (#1502 G0lpfg).

	Same direction	Opposite direction
<b>G0lpfg: 0</b>		 The acceleration is excessive due to the G1 and G0 composite speed.
<b>G0lpfg: 1</b>		 Commanded deceleration

- (2) Designating deceleration check for G1 → G1 opposite direction movement reversal

If the axis movement reverses to the opposite direction in a G1 to G1 successive block, the deceleration check for the movement in the opposite direction can be changed with the base specification parameter G1 → G1 deceleration check (#1503 G1lpfg).

	Same direction	Opposite direction
<b>G0lpfg: 0</b>		 The acceleration is excessive due to the G1 and G1 composite speed
<b>G0lpfg: 1</b>		 Commanded deceleration

(1) Designating de

- (1) Designating deceleration check  
Base specification parameter

#	Item		Details	Setting range
1193	inpos	The definitions are changed with the setting of "#1306 InpsTyp Deceleration check specification type".		
		When Deceleration check method 1 is selected	Select the deceleration check method for G0. 0: Command deceleration check 1: In-position check	0 / 1
		When Deceleration check method 2 is selected	Select the deceleration confirmation method for the positioning or cutting command. 0: G0, G1+G9 Command deceleration check 1: G0, G1+G9 In-position check	0 / 1
1223	aux07/bit1	Deceleration check method 2	Select the deceleration check method in G1+G9. 0: Command deceleration check in G1+G9 1: In-position check in G1+G9 The deceleration check is not performed for the commands except G1+G9. When "#1306 InpsTyp deceleration check specification type" is set to "1" (Deceleration check specification type 2), this parameter will be invalid.	0 / 1
1306	InpsTyp	Deceleration check specification type	Select the parameter specification type for the G0 or G1 deceleration check. 0: Deceleration check specification type 1 G0 is specified with "#1193 inpos", and G1+G9 with "#1223 aux07/bit1". 1: Deceleration check specification type 2 G0 or G1+G9 is specified with "#1193 inpos".	0 / 1

- (2) Deceleration check during opposite direction travel  
Base specification parameter

#	Item		Details	Setting range
1502	G0lpfg	G1 -> G0 deceleration check	Select whether to perform a deceleration check when the travel direction is changed from G1 to G0. 0: Not perform 1: Perform	0 / 1
1503	G1lpfg	G1 -> G1 deceleration check	Select whether to perform a deceleration check when the travel direction is changed from G1 to G1. 0: Not perform 1: Perform	0 / 1

## (3) Designation of in-position check width

## (a) Servo parameter

#	Item		Details	Setting range
2224	SV024 INP	In-position detection width	Set the in-position detection width. Set the accuracy required for the machine. The lower the setting is, the higher the positioning accuracy gets; however, the cycle time (setting time) becomes longer. The standard setting value is "50".	0 to 32767 ( $\mu$ m)

## (b) Axis specification parameter

#	Item		Details	Setting range
2077	G0inps	G0 in-position width	Set the in-position width for G0. Between SV024 and this parameter, the parameter with a larger value will be applied. When "0" is set, this parameter will be invalid: only SV024 will be available.	0.000 to 99.999 (mm)
2078	G1inps	G1 in-position width	Set the in-position width for G1. Between SV024 and this parameter, the parameter with a larger value will be applied. When "0" is set, this parameter will be invalid: only SV024 will be available.	0.000 to 99.999 (mm)



## 10.5 Precautions

(1) Designating deceleration check

When in-position check is valid, set the in-position width in the servo parameters.

(2) Deceleration check for opposite direction movement reversal

- When deceleration check is valid (G0lpfg=1), deceleration check will be executed when the axis reverses its movement to the opposite direction at the G1 -> G0 successive block regardless of whether G0 non-interpolation is ON or OFF.
- When deceleration check is valid (G0lpfg=1), deceleration check will be executed when the axis reverses its movement to the opposite direction at the G1 -> G0 successive block even in the fixed cycle.
- In the G1 -> G28, G1 -> G29 or G1 -> G30 successive blocks, deceleration check will always be executed when the G1 movement is completed, when movement to the intermediate point is completed and when movement to the return point is completed. Note that if the base specification parameter's simple zero point return "#1222 aux06/bit7" is valid, the base specification parameter G1 -> G0 deceleration check (G0lpfg) will be followed when the G1 movement is completed and when movement to the intermediate point is completed. (Deceleration check will always be executed when movement to the return point is completed even in this case.)

(3) Designating in-position width

- The in-position width (programmable in-position check width) designated in the machining program has a priority over the in-position width set in the parameters (SV024, G0inps, G1inps).
- When error detect is ON, in-position check will be forcibly carried out.

(4) Deceleration check in G1 -> G0, G1 -> G1 opposite direction movement reversal during high-speed machining mode

When the axis movement reverses to the opposite direction in a G1 -> G1 successive block during the high-speed machining mode, the commanded deceleration will not take place even if G1lpfg is set to 1. Note that the G0lpfg setting will be followed if the axis direction reverses to the opposite direction in a G1 -> G0 successive block.

(5) Deceleration check in movement including spindle/C-axis

- The deceleration check for spindle/C-axis movement command is as described in the table below. That is because a vibration and so on occurs in the machine when the position loop gain (#13002 PGN) is changed during the axis movement.

Parameter	Rapid traverse command	Parameter	Other than rapid traverse command (G1: other than G0 command)	
Inpos (#1193)	G0 -> XX (G0+G9 -> XX)	AUX07/BIT-1 (#1223/BIT-1)	G1-> G0 (G0+G9 -> XX)	G1-> G1
0	Command deceleration check	0	In-position check (Applicable only to SV024)	No deceleration check
1	In-position check	1		

(Note 1) When G1 command is issued, the in-position check is performed regardless of the deceleration check parameter.

(Note 2) XX expresses all commands.

(6) Deceleration check in polar coordinate interpolation / milling interpolation / cylindrical start / cancel command

- The deceleration check in polar coordinate interpolation / milling interpolation / cylindrical start / cancel command are as follows.

Parameter: #1223 aux07 BIT1	Deceleration check method
0	Command deceleration check
1	In-position check

# 11

---

## Data Backup and Restoration

## 11 Data Backup and Restoration

The following two functions are available for the data backup and restoration: all backup function for files in batch and input/output function for separate files.

The following devices are available in all backup and restoration.

M700VW Series: DS, Memory card (CF card or USB memory), and hard disk (HD)

M700VS Series: Memory card (CF card) and USB memory

Files to be backed up/ restored are as follows.


Screen display	File name	Data type
System data	SRAM.BIN	SRAM data (binary files) Programs, parameters, R registers and so on
Ladder	USERPLC.LAD	User PLC program
APLC data	APLC.BIN	C language module created by user
Custom data (For M700VS only)	CUSTOM.BIN	Custom screen data (binary files) (Custom screen modules, setting files (Config.ini/ customdef.ini/customload.txt) and PLC alarm messages)

This manual explains the procedures of all backup using a CF card.



For the input/output function for separate files, refer to the Instruction Manual.

### 11.1 All Backup


- (1) Carry out the emergency stop.
- (2) Insert a CF card into the interface on front of display unit.  
(Note) When M700VW Series is used, an adapter is required to insert a CF card into the interface on front of display unit.
- (3) Enter the password on the Mainte screen.  
(a) On the Mainte screen, select [Mainte] and then [Psswd input].  
(b) Enter "MPARA" in the setting area and press the INPUT key.
- (4) Press the cancel key to return to the Mainte screen. Select [Mainte] and then [All backup].



- (5) The all backup screen appears. "Device" shows the backup destination.  
To change the destination, click [Device select] and select the device.




- (6) Select [Backup].



## 11 Data Backup and Restoration

- (7) The menu is highlighted. The operation message "Select directory to backup" appears. Select the backup destination ("Manual" or "Master data") in the backup list. Then press the INPUT key.



- (Note) "Backup list" shows the list of backup destination directories and backup dates/times (year, month, date and hour). The date field is blank when the backup has never been executed.

Auto1 to 3: Files automatically backed up

Manual: Files manually backed up

Master data: Files manually backed up, basically for shipping

"Auto1 to 3" cannot be selected at all backup.

- (8) The operation message "OK? (Y/N)" appears. Press Y or INPUT key to start the backup.

- (Note) If any data exists in the backup directory (backup date is shown), the overwriting confirmation message appears when Y or INPUT key has been pressed. Press Y or INPUT key to start the backup.

- (9) The operation message "Performing Backup" appears.

- (10) When the backup is completed without error, the operation message "Backup complete" appears.



Open the interface door on front of display unit and eject the CF card.

(Note) Press the eject lever twice to eject the CF card.

- (11) Cancel the emergency stop.


## 11.2 All Restoration

- (1) Carry out the emergency stop.
- (2) Insert the CF card containing the backed up data into the interface on front of display unit.  
(Note) When M700VW Series is used, an adapter is required to insert a CF card into the interface on front of display unit.
- (3) Select [Mainte] and then [All backup]. Select [Device select].
- (4) The all backup screen appears. "Device" shows the restoration source.  
To change the destination, click [Device select] and select the device.




# 11 Data Backup and Restoration

- (5) Select [Restore].



- (6) The menu is highlighted. The operation message "Select directory to restore" appears. Move the cursor to select the area. Press the INPUT key.



- (7) The operation message "OK? (Y/N)" appears. Press Y or INPUT key to start the restore.
- (8) The operation message "Restoring" appears.
- (9) When the restore is completed without error, the operation message "Restore complete" appears.  
Open the interface door on front of display unit and eject the CF card.  
(Note) Press the eject lever twice to eject the CF card.
- (10) Cancel the emergency stop.
- (Note) Restored data writes over the previous absolute position data. Carry out the absolute position detection again after restoration.

## Hardware Replacement Methods



## 12.1 Durable Parts

### [List of durable parts]

Durable parts	Part type
Control unit battery	Q6BAT
Backlight for FCU7-DU120-11	84LHS06
Backlight for FCU7-DU140-11/31	104LHS52
Touch Panel Protective Sheet for FCU7-DU140-31	N939B036G51
Key sheet for FCU7-KB024/44	N330B532G51
Key sheet for FCU7-KB029	N330A565G51
Display unit cooling fan	MMF-06G24DS-RP2

### [List of replacements]

Replacements	Part type
Protection fuse	LM40
Front memory interface card CF-700	HN793

### 12.1.1 Control Unit Battery

A lithium battery in the control unit battery holder retains parameter settings, machining programs and the like, which requires to be backed up at the power OFF.

Battery	Q6BAT
Battery cumulative data holding time	45,000 hours (At 0 to 45° C. The life will be shorter if the temperature is high.)
Battery life	Approx. 5 years (from date of battery manufacture)


(Note) Replace the battery within one month after the alarm "Z52 Battery drop 0001" appears on the NC screen.  
The internal data may have been damaged if the alarm "Z52 Battery drop 0003" appears.

### [Replacement procedures]

Always replace the battery with the control unit (machine) power turned OFF.

Complete the replacement within 30 minutes after turning the power OFF. (If the battery is not connected within 30 minutes, the data being backed up might be destroyed.)

- (1) Check that the machine power is turned OFF. (If the power is not OFF, turn it OFF.)
- (2) Confirm that the control unit LED, 7-segment display, etc., are all OFF.
- (3) Open the battery cover of the control unit. Pull the right side of the battery cover toward front.
- (4) Disconnect the battery connector from the control unit BAT connector.
- (5) Remove the battery from the battery holder.
- (6) Fit the new battery into the battery holder.
- (7) Insert the new battery connector into the control unit BAT connector. Pay attention to the connector orientation: do not insert backwards.
- (8) Close the front cover of the control unit. At this time, confirm that the cover is closed by listening for the "click" sound when the latch catches.



#### [Precautions for handling battery]

- (1) Always replace the battery with the same type.
- (2) Do not disassemble the battery.
- (3) Do not place the battery in flames or water.
- (4) Do not pressurize and deform the battery.
- (5) This is a primary battery so do not charge it.
- (6) Dispose the spent battery as industrial waste in accordance with the local law.

#### **WARNING**

If the battery low warning is issued, save the machining programs, tool data and parameters in an input/output device, and then replace the battery. When the battery alarm is issued, the machining programs, tool data and parameters may have been destroyed. Replace the battery and then reload the data.

#### **CAUTION**

1. Do not short-circuit, charge, overheat, incinerate or disassemble the battery.
2. Dispose the spent battery according to the local laws.

## 12.1.2 Display Unit Cooling Fan


Type	MMF-06G24DS-RP2
Life	50,000 hours (When the rotary speed decreased 20% less than the initial values)

(Note) The life is estimated on the assumption that it is used under 60°C environment. Keep in mind that the value above is not a guaranteed value.

### [Replacement procedures]

Always replace the display unit cooling fan with the machine power turned OFF.

- (1) Check that the machine power is turned OFF. (If the power is not OFF, turn it OFF.)
- (2) Open the electric cabinet door.
- (3) Remove the fan covers for the cooling fan housing that are installed to the PCB on the back of the display unit.  
(Remove the fan covers by pushing up the tabs.)
- (4) Pull the cooling fan out from the cooling fan housing.
- (5) Disconnect the cooling fan connector from the PCB.
- (6) Replace the cooling fan with new one. Insert the new cooling fan connector into the PCB.
- (7) Mount the cooling fan onto the cooling fan housing.
- (8) Put the cooling fan wires neatly into the cooling fan housing.
- (9) Install the fan covers.
- (10) Confirm that all the cables are correctly connected and close the electric cabinet door.



### CAUTION

1. Do not replace the cooling fan while the power is ON.
2. Dispose the spent cooling fan according to the local laws.

### 12.1.3 Backlight

Display unit type	Screen size	TFT-LCD type	Backlight type	Inverter type
FCU7-DU120-11	8.4-type	NL6448BC21-09	84LHS06	84PW031
FCU7-DU140-11 FCU7-DU140-31	10.4-type	NL6448BC33-74N	104LHS52	104PW161

Backlight life ... 50,000 hours (Duration of time until luminance drops to 50% of the initial value.)

The life is estimated on the assumption that it is used under 25 °C environment. Keep in mind that the value above is not a guaranteed value.

#### [Replacement procedures]

Always replace the backlight for LCD panel with the control unit (machine) power turned OFF.

- (1) Check that the machine power is turned OFF. (If the power is not OFF, turn it OFF.)
- (2) Disconnect the backlight connector from the backlight inverter (one for top).
- (3) Disconnect the MENUKEY connector.
- (4) Remove the escutcheon fixing screws (at 4 places) and take the escutcheon off.
- (5) Pull out the backlight installed on the left side of the LCD panel. (The backlights have locking claws on the front. Hold these claws down while pulling the backlight out.)
- (6) Insert the new backlight into the upper and lower sections at the left end of the LCD panel. (Press in until the locking claws click.)
- (7) Mount the escutcheon with 4 fixing screws (one each for 4 sections).
- (8) Connect the backlight connector to the backlight inverter.
- (9) Confirm that all the cables are correctly connected and close the electric cabinet door.
- (10) Connect the MENUKEY connector.

#### [Precautions for using LCD panel]


- (1) Response time, brightness and color may differ depending on the ambient temperature.
- (2) Brightness nonuniformity, flickers and streaks may be observed on LCD display depending on the display contents.
- (3) Because cold cathode-tube is used for LCD display, optical characteristics (brightness nonuniformity and display) change according to the operation time. (Especially in low temperature.)
- (4) Screen display color may differ depending on the angle to view it.



#### CAUTION

1. Do not replace the backlight while the power is ON.
2. Dispose the spent backlight according to the local laws.
3. Do not touch the backlight while the power is ON. Failure to observe this could result in electric shocks due to high voltage.
4. Do not touch the backlight while the LCD panel is in use. Failure to observe this could result in burns.
5. Do not apply impact or pressure on the LCD panel or backlight. Failure to observe this could result in breakage as they are made of glass.

[8.4-type/10.4-type display unit]




## 12.1.4 Fuse

### 12.1.4.1 Control Unit Protection Fuse

Disconnection of the protection fuse will be caused by misconnections such as a reverse connection of 24VDC power supply connector between +24V terminal and the ground.

Hold the upper part of the protection fuse and pull it when replacing it.




Replacements	Part type
Protection fuse	LM40

### 12.1.4.2 Operation Panel I/O Unit Protection Fuse

Disconnection of the protection fuse will be caused by misconnections of digital inputs/outputs.

Hold the upper part of the protection fuse and pull it when replacing it.



Replacements	Part type
Protection fuse	LM40

### 12.1.5 Front Memory Interface Card

Replace the front memory interface card on which the connector CF has been broken due to a wrong insertion or repetitive insertions/removals of the CF card.

**[Replacement procedures]**

- (1) Remove the control unit as described in the section of "Control Unit".
- (2) Remove the two screws which fix the front memory interface card.
- (3) Remove the damaged front memory interface card, and install a new one with the two screws.
- (4) Mount the control unit on the display unit.


Replacements	Part type
Front memory interface card CF-700	HN793

### 12.1.6 Touch Panel Protective Sheet


Type of 10.4-type touch panel protective sheet : N939B036G51

Type of 15-type touch panel protective sheet for M700VW Series: N939B060G61


- (1) Remove the old protective sheet and clean the surface of the display unit.  
(Note) Peel off the protective sheet slowly.



- (2) Remove the release paper on the back of the new protective sheet.  
Fit the position of the sheet as shown in the figure and stick the sheet to the display unit.




- (3) Remove the protective film on the surface of the protective sheet.





### 12.1.7 Key Sheet

The key sheet covering the sheet-key type keyboard can be replaced.  
Remove the old key sheet as shown below, then place the new one.



Key sheet for FCU7-KB024/44	N330B532G51
Key sheet for FCU7-KB029	N330A565G51

(Note1) Clean the surface before placing the new key sheet.


(Note 2) The figure in the above is an example of FCU7-KB024/44. The keysheet for FCU7-KB029 can be removed in a similar way.

## 12.2 Control Unit

### [Replacement procedures]

Always replace the control unit with the machine power turned OFF.


- (1) Check that the machine power is turned OFF. (If the power is not OFF, turn it OFF.)
- (2) Disconnect all the external cables from the control unit.
- (3) Disconnect all the internal cables from the control unit. (MENUKEY, INV and LCD connectors)  
(Note) Open the battery cover to disconnect the LCD connector.
- (4) Remove the screws fixing the control unit, and remove the control unit from the control unit installation fitting.  
(Loosen the two lower fixing screws first, and then remove one upper fixing screw while supporting the control unit with a hand. Then lift the control unit upward and take it off. The two lower fixing screws do not need to be removed.)
- (5) Install a new control unit onto the control unit installation fitting with fixing screws.
- (6) Connect all the cables back to the control unit. (Always connect the cables to the designated connectors.)
- (7) Confirm that all the cables are correctly connected and close the electric cabinet door.




### CAUTION

1. Incorrect connections could cause devices to damage. Connect the cables to designated connectors.
2. Do not replace the control unit while the power is ON.
3. Do not connect or disconnect the cables between units while the power is ON.

(Note) Wire the control unit optical cable as shown below. Refer to the Connection Manual when handling and wiring optical communication cable.




### 12.2.1 Installation on FCU7-DU120-11 (8.4-type)




(Note) After mounting a new control unit, check the screen's brightness with a slide switch LCDSEL.

### 12.2.2 Installation on FCU7-DU140-11/31 (10.4-type)



(Note) After mounting a new control unit, check the screen's brightness with a slide switch LCDSEL.  
Calibrate the touch panel when using it, referring to the section of "Calibration Setting and Confirmation".

### 12.2.3 Installation on FCU7-DU140-31 (10.4-type touch panel)




(Note) Calibrate the touch panel, referring to the section of "Calibration Setting and Confirmation".


### 12.2.4 Calibration Setting and Confirmation

The touch panel calibration is saved in the control unit. When only the control unit has been replaced, the calibration must be carried out again.

- (Note) Use a round-tip stick to set the position properly. Take care not to scratch the protective sheet covering the panel.
- (1) Turn the right rotary switch (RSW2), which is on the back of the touch panel display unit, to "F". Then turn the power ON. After the system starts up, display the calibration setting screen.




- (2) On the calibration setting screen, keep pressing the center of the upper-left cross with a red circle for more than one second. Then lift the stick off the screen.




When the data has been achieved, the upper-left cross turns green and the red circle moves to the bottom-right.

- (3) Keep pressing the center of the bottom-right cross with a red circle for more than one second. Then lift the stick off.



When the data has been achieved, the bottom-right cross turns green.

When the two points have been measured, a completion message will appear.




- (4) Check whether the calibration settings have been successfully measured.

Press the rightmost menu key . The calibration setting confirmation screen will appear.

Touch the target (a white square) shown on the confirmation screen.

Touching the target moves it to the next point. The target will move in the following order.





- (5) After touching ten points, the display will show the result.




When the result shows "OK":


The calibration settings have been successfully measured.

Turn the right rotary switch (RSW2) back to "0", then turn the power ON again.

When the result shows "NG":

Press the leftmost menu key  and carry out the confirmation again.

If "NG" still shows after reconfirmations, carry out the calibration again from the step (1).


- (Note) Pressing the rightmost menu key  after the result has showed "OK" displays the maintenance screen. When the screen appears, turn the right rotary switch (RSW2) back to "0" and turn the power ON again.

## 12.3 Display Unit

### [Replacement procedures]

Always replace the display unit with the control unit (machine) power turned OFF.

- (1) Check that the machine power is turned OFF. (If the power is not OFF, turn it OFF.)
- (2) Open the electric cabinet door.
- (3) Disconnect all the cables connected to the display unit.
- (4) Remove the screws fixing the display unit (at 4 places) and take the display unit off.
- (5) Install a new display unit with fixing screws.
- (6) Connect all the cables back to the display unit. (Always connect the cables to the designated connectors.)
- (7) Confirm that all the cables are correctly connected and close the electric cabinet door.



### CAUTION


1. Incorrect connections could cause devices to damage. Connect the cables to designated connectors.
2. Do not replace the display unit while the power is ON.
3. Do not connect or disconnect the cables between units while the power is ON.

## 12.4 Keyboard Unit

### [Replacement procedures]

Always replace the keyboard unit with the control unit (machine) power turned OFF.

- (1) Check that the machine power is turned OFF. (If the power is not OFF, turn it OFF.)
- (2) Open the electric cabinet door.
- (3) Disconnect all the cables connected to the keyboard unit.
- (4) Remove the screws fixing the keyboard unit and take the keyboard unit off.
- (5) Install a new keyboard unit with fixing screws.
- (6) Connect all the cables connected to the keyboard unit. (Always connect the cables to the designated connectors.)
- (7) Confirm that all the cables are correctly connected and close the electric cabinet door.



### CAUTION

1. Incorrect connections could cause devices to damage. Connect the cables to designated connectors.
2. Do not replace the keyboard unit while the power is ON.
3. Do not connect or disconnect the cables between units while the power is ON.

## 12.5 Operation Panel I/O Unit


### [Replacement procedures]

Always replace the operation panel I/O unit with the control unit (machine) power turned OFF.

- (1) Check that the machine power is turned OFF. (If the power is not OFF, turn it OFF.)
- (2) Open the electric cabinet door.
- (3) Disconnect all the cables connected to the operation panel I/O unit.
- (4) Remove the screws fixing the operation panel I/O unit, and take the unit off.
- (5) Install a new operation panel I/O unit with fixing screws. (Fix so that the NCKB connector slot is placed at the lower part.)
- (6) Connect all the cables back to the operation panel I/O unit. (Always connect the cables to the designated connectors.)

NCKB cable can be easily inserted by fitting the  $\Delta$  1st pin position with the connector.

- (7) Confirm that all the cables are correctly connected and close the electric cabinet door.



### CAUTION

1. Incorrect connections could cause devices to damage. Connect the cables to designated connectors.
2. Do not replace the operation panel I/O unit while the power is ON.
3. Do not connect or disconnect the cables between units while the power is ON.


## 12.6 CompactFlash (CF) Card

### [Card insertion procedures]

- (1) Open the card interface door on the display unit right end.
- (2) Insert the CF card. (Insert it so that the top surface faces to the observer's right or display side.)

### [Card ejecting procedures]

- (1) Open the card interface door on the display unit right end.
- (2) Press the eject lever twice to eject the CF card.




(Note 1) Do not eject a CF card during the data reading/writing.

(Note 2) There may be a compatibility problem with non-recommended CF cards, which may lead illegal operations.

## 12.7 USB Memory

The USB memory slot is above the CF card interface.

Open the door located on the display unit right end and insert/remove the USB memory.



(Note) Do not remove a USB memory during the data reading/writing.



# 13

## Cables




## 13.1 Precautions when Connecting/Disconnecting Cables

If the cable is connected/disconnected without turning the power OFF, the normal unit or peripheral devices could be damaged, and risks could be imposed.

Disconnect each cable with the following procedures.


- (a) For the following type of connector, press the tabs with a thumb and forefinger in the direction of the arrow, and pull the connector off.




### CAUTION

1. Do not connect or disconnect the cables between units while the power is ON.
2. Do not pull the cables when connecting/disconnecting them.


- (b) For a flat cable type connector with latches, open the latches in the directions of the arrows, and pull the connector off.



- (c) For a flat cable type connector without latches, hold the connector with a thumb and forefinger, and pull the connector off.




- (d) For the screw fixed type connector, loosen the two fixing screws, and pull the connector off.




### CAUTION

1. Do not connect or disconnect the cables between units while the power is ON.
2. Do not pull the cables when connecting/disconnecting them.

(e) For the optical cable connector, pull off while holding down the lock button.



(f) For the Ethernet connector, pull off while holding down the locked latch.



**CAUTION**


1. Do not connect or disconnect the cables between units while the power is ON.
2. Do not pull the cables when connecting/disconnecting them.

## 13.2 Precautions for Using Optical Communication Cable

An optical communication cable is used for communication between the control unit and the drive unit. Special precautions, differing from the conventional cable, are required when laying and handling the optical communication cable.

(Note) If the cable you use is not Mitsubishi's, malfunctions resulted from connection problems or aged deterioration are not covered under the warranty.

### 13.2.1 Optical Communication Cable Outline and Parts




To ensure the system performance and reliability, purchase the optical communication cable from Mitsubishi. A machining drawing is given in the Connection Manual as reference, but the purchased optical communication cable cannot be cut or connected by the machine tool builder.

### 13.2.2 Precautions for Handling Optical Communication Cable

- (1) A protective cap is attached to the optical module and optical communication cable mounted on the PCB when the system is delivered. Leaving this protective cap unattached could result in connection faults from the adherence of dirt and dust. Do not remove the protective cap when not connecting the cable. If dirty, wipe off lightly with a piece of dry gauze, etc. (Do not use solvents such as alcohol as the optical fiber material could melt.)
- (2) Hold the connector section when connecting or disconnecting the optical connector. Holding the fiber cord will result in force exceeding the tolerable tension on the fiber cord and connector connection section, and could cause the fiber cord to dislocate from the optical connector thereby inhibiting use.
- (3) The optical connector cannot be connected in reversed. Check the connector orientation when connecting the optical communication cable to the optical module. Align the connector lock lever with the lock holes on the PCB's optical module, and press the connector straight in. Confirm that the lock lever connects with the optical module and that a "click" is heard.
- (4) When disconnecting the optical communication cable from the PCB, press the lock release buttons on the lock lever, and pull out the cable while holding the connector section. The connector could be damaged if the cable is pulled without pressing down on the lock release buttons.
- (5) Do not apply excessive force onto the optical communication cable by stepping on it or dropping tools, etc., on it.

### 13.2.3 Precautions for Laying Optical Communication Cable

- (1) Do not apply a force exceeding the cable's tolerable tension. Binding the cables too tight with tie-wraps could result in an increased loss or a disconnection. Use a cushioning material such as a sponge or rubber when bundling the cables and fix so that the cables do not move.
- (2) Do not connect the cables with a radius less than the tolerable bending radius. Excessive stress could be applied near the connector connection section and cause the optical characteristics to drop. The cable bending radius should be 10 times or more than the outer diameter at the reinforced sheath, and 20 times or more than the outer diameter at the fiber cord section.
- (3) Do not apply torsion to the optical communication cable. Laying a twisted cable could cause the optical characteristics to drop.
- (4) When laying the cables in a conduit, avoid applying stress on the fiber cord and connector connection section. Use the tensile end such as a pulling eye or cable grip, etc.
- (5) Fix the reinforced sheath with a cable clamp so that the mass of the optical communication cable is not directly applied on the fiber cord and connector connection section.
- (6) Never bundle the cables with vinyl tape. The plasticizing material in the vinyl tape could cause the POF cable to break.
- (7) Loop the excessive cable with twice or more than the minimum bending radius.



Recommended clamp material: CKN-13SP KITAGAWA INDUSTRIES.

# Appendix 1

---

## Explanation of Parameters

## Appendix 1.1 User Parameters

The parameters with "(PR)" requires the CNC to be turned OFF after the settings. Turn the power OFF and ON to enable the parameter settings.

### 【#8001】 WRK COUNT M

Set the M code for counting the number of the workpiece repeated machining.  
The number of the M-codes set by this parameter is counted.  
The No. will not be counted when set to "0".

---Setting range---  
0 to 999

### 【#8002】 WRK COUNT

Set the initial value of the number of workpiece machining. The number of current workpiece machining is displayed.

---Setting range---  
0 to 999999

### 【#8003】 WRK COUNT LIMIT

Set the maximum number of workpiece machining.  
A signal will be output to PLC when the number of machining times is counted to this limit.

---Setting range---  
0 to 999999

### 【#8004】 SPEED

Set the feedrate during automatic tool length measurement.

---Setting range---  
1 to 1000000 (mm/min)

### 【#8005】 ZONE r

Set the distance between the measurement point and deceleration start point.

---Setting range---  
0 to 99999.999 (mm)

### 【#8006】 ZONE d

Set the tolerable range of the measurement point.  
An alarm will occur when the sensor signal turns ON before the range, set by this parameter, has not been reached from the measurement point, or when the signal does not turn ON after the range is passed.

---Setting range---  
0 to 99999.999 (mm)

### 【#8007】 OVERRIDE

Set the override value for automatic corner override.

---Setting range---  
0 to 100 (%)

### 【#8008】 MAX ANGLE

Set the maximum corner opening angle where deceleration should start automatically.  
When the angle is larger than this value, deceleration will not start.

---Setting range---  
0 to 180 (°)

#### 【#8009】 DSC. ZONE

Set the position where deceleration starts at the corner.  
Designate at which length point before the corner deceleration should start.

---Setting range---  
0 to 99999.999 (mm)

#### 【#8010】 ABS. MAX. (for L system only)

Set the maximum value when inputting the tool wear compensation amount.  
A value exceeding this setting value cannot be set.  
Absolute value of the input value is set.  
(If a negative value is input, it is treated and set as a positive value.)  
If "0" is input, this parameter will be disabled.

---Setting range---  
0 to 999.999 (mm)  
(Input setting increment applies)

#### 【#8011】 INC. MAX. (for L system only)

Set the maximum value for when inputting the tool wear compensation amount in the incremental mode.  
A value exceeding this setting value cannot be set.  
Absolute value of the input value is set.  
(If a negative value is input, it is treated and set as a positive value.)  
If "0" is input, this parameter will be disabled.

---Setting range---  
0 to 999.999 (mm)  
(Input setting increment applies)

#### 【#8012】 G73 n (for M system only)

Set the return amount for G73 (step cycle).

---Setting range---  
0 to 99999.999 (mm)

#### 【#8013】 G83 n

Set the return amount for G83 (deep hole drilling cycle).

---Setting range---  
0 to 99999.999 (mm)

#### 【#8014】 CDZ-VALE (for L system only)

Set the screw cut up amount for G76 and G78 (thread cutting cycle).

---Setting range---  
0 to 127 (0.1 lead)

#### 【#8015】 CDZ-ANGLE (for L system only)

Set the screw cut up angle for G76 and G78 (thread cutting cycle).

---Setting range---  
0 to 89 (°)

#### 【#8016】 G71 MINIMUM (for L system only)

Set the minimum value of the last cutting amount by the rough cutting cycle (G71, G72).  
The cutting amount of the last cutting will be the remainder. When the remainder is smaller than this parameter setting, the last cycle will not be executed.

---Setting range---  
0 to 999.999 (mm)



**【#8017】 G71 DELTA-D (for L system only)**

Set the change amount of the rough cutting cycle.

The rough cutting cycle (G71, G72) cutting amount repeats  $d + \Delta d$ ,  $d$ ,  $d - \Delta d$  using the value (d) commanded with D as a reference. Set the change amount  $\Delta d$ .

---Setting range---

0 to 999.999 (mm)

**【#8018】 G84/G74 n (for M system only)**

Not used. Set to "0".

**【#8019】 R COMP**

Set a compensation coefficient for reducing a control error in the reduction of a corner roundness and arc radius.

The larger the set value is, the smaller the theoretical error will be. However, since the speed at the corner goes down, the cycle time will be extended.

Coefficient = 100 - set value


(Note) This function will be enabled when "#8021 COMP\_CHANGE" is set to "0".

---Setting range---

0 to 99 (%)

**Theoretical radius decrease error amount**

Displays the theoretical radius decrease error amount,  $\Delta R$ (mm), from the automatic calculation by NC.



Theoretical radius decrease amount in arc

**R5mm arc deceleration speed**


Displays a deceleration speed(mm/min) along an arc of 5(mm) radius.

**R1mm arc deceleration speed**

Displays a deceleration speed(mm/min) along an arc of 1(mm) radius.

## 【#8020】 DCC ANGLE

Set the minimum value of an angle (external angle) that should be assumed to be a corner. When an inter-block angle (external angle) in high-accuracy mode is larger than the set value, it will be determined as a corner and the speed will go down to sharpen the edge.



(Note) If "0" is set, it will be handled as "5" degrees.


### ---Setting range---

0 to 89 (°)

0: 5 degree (Equals to setting "5")

## Theoretical corner dull amount

Displays the corner dull amount  $\Delta c(\text{mm})$  in respect to the corner's angle (external angle)  $\theta$  (°).



Theoretical roundness amount at corner

ca(mm): Error ( $\Delta$ ) caused by the soft acceleration/deceleration 2

cs(mm): Error ( $\Delta$ ) caused by the servo system

## Corner deceleration speed

Display corner deceleration speed  $c$  (mm/min) for the corner of the angle (external angle) with  $\theta$  (°).

## Theoretical dull amount at 90 degree

Display corner dull amount when the angle is 90 degree.

## Corner deceleration speed at 90 degree

Display corner deceleration speed when the angle is 90 degree.

## 【#8021】 COMP\_CHANGE

Select whether to share or separate the compensation coefficient at the corner/curve during the high-accuracy control mode.

0: Share ("#8019 R COMP" is applied.)

1: Separate

- Corner : #8022 CORNER COMP

- Curve : #8023 CURVE COMP

(Note) Set "1" when using SSS control.

## 【#8022】 CORNER COMP

Set the compensation coefficient to further reduce or increase the roundness at the corner during the high-accuracy control mode.

Coefficient = 100 - setting value

(Note) This is valid when "#8021 COMP CHANGE" is set to "1".

Reference to "#8020 Corner decreasing speed" for theoretical corner roundness amount, corner decreasing speed, theoretical 90 degree dull amount, 90 degree corner decreasing speed.

### ---Setting range---

-1000 to 99 (%)

### 【#8023】 CURVE COMP

Set the compensation coefficient to further reduce or increase the radius reduction amount at the curve (arc, involute, spline) during the high-accuracy control mode.

Coefficient = 100 - setting value

(Note) This is valid when "#8021 COMP CHANGE" is set to "1".

For theoretical radius reduction error amount, R5mm arc deceleration speed and R1mm arc deceleration speed, refer to "#8019 R COMP".

#### ---Setting range---

-1000 to 99 (%)

### 【#8025】 SPLINE ON (for M system only)

Select whether to enable the spline function.

0: Disable

1: Enable

Spline interpolation is valid during G61.2 modal, regardless of this setting.

### 【#8026】 CANCEL ANG. (for M system only)

Set the angle where the spline interpolation is temporarily canceled.

When the angle made by blocks exceeds this parameter setting value, spline interpolation will be canceled temporarily. In consideration of the pick feed, set a value a little smaller than the pick feed angle.

#### ---Setting range---

0 to 180 (°)

0: 180 (°)

### 【#8027】 Toler-1 (for M system only)

Set the maximum chord error (tolerance) in a block that includes an inflection point. Set the tolerance applicable when the applicable block is developed to fine segments by CAM. (normally about 10

μm)

When "0.000" is set, the applicable block will be linear.

#### ---Setting range---

0.000 to 100.000 (mm)

### 【#8028】 Toler-2 (for M system only)

Set the maximum chord error (tolerance) in a block that includes no inflection point. Set the tolerance applicable when the applicable block is developed to fine segments by CAM. (normally about 10

μm)

When "0.000" is set, the applicable block will be linear.

#### ---Setting range---

0.000 to 100.000 (mm)

### 【#8029】 FairingL (for M system only)

Set the length of the block subject to fairing.

(Enabled when "#8033 Fairing ON" is set to "1".)

#### ---Setting range---

0 to 100.000 (mm)

### 【#8030】 MINUTE LENG (for M system only)

Set the fine-segment length where the spline interpolation is temporarily canceled.

When the length of one block exceeds this parameter setting value, spline interpolation is canceled temporarily and linear interpolation is performed. Set a value a little smaller than one block length of the program.

If "-1" is set, spline interpolation will be performed regardless of block length.

#### ---Setting range---

-1 to 127 (mm)

0: 1 (mm)

#### 【#8033】 Fairing ON (for M system only)

Select whether to use the fairing function.

0: Not use

1: Use

Fairing function is enabled during G61.2 modal, regardless of this setting.

#### 【#8034】 AccClamp ON (for M system only)

Select the method for clamping the cutting speed.

0: Clamp with parameter "#2002 clamp" or the corner deceleration function.

1: Clamp the cutting speed with acceleration judgment.

(Enabled when "#8033 Fairing ON" is set to "1".)

#### 【#8036】 CordecJudge (for M system only)

Select the condition to decide a corner.

0: A corner is decided from the angle of the neighboring block.

1: A corner is decided from the angle of the neighboring block, excluding minute blocks.

(Enabled when "#8033 Fairing ON" is set to "1".)

#### 【#8037】 CorJudgeL (for M system only)

Set the length of the block to be excluded when deciding a corner.

(Enabled when "#8036 CordecJudge" is set to "1".)

##### ---Setting range---

0 to 99999.999 (mm)

#### 【#8041】 C-rot.R

Set the length from the center of the normal line control axis to the tool tip. This is used to calculate the turning speed at the block joint.

This is enabled during the normal line control type II.

##### ---Setting range---

0.000 to 99999.999 (mm)

#### 【#8042】 C-ins.R

Set the radius of the arc to be automatically inserted into the corner during normal line control.

This is enabled during the normal line control type I.

##### ---Setting range---

0.000 to 99999.999 (mm)

#### 【#8043】 Tool HDL FD OFS

Set the length from the tool holder to the tool tip.

##### ---Setting range---

0.000 to 99999.999 (mm)

#### 【#8044】 UNIT\*10

Set the command increment scale.

The scale will be "1" when "0" is set.

##### ---Setting range---

0 to 10000 (fold)

0: One fold

#### 【#8051】 G71 THICK

Set the amount of cut-in by the rough cutting cycle (G71, G72)

##### ---Setting range---

0 to 99999.999 (mm)

#### 【#8052】 G71 PULL UP

Set the amount of pull-up when returning to the cutting start point for the rough cutting cycle (G71, G72).

---Setting range---  
0 to 99999.999 (mm)

#### 【#8053】 G73 U

Set the X-axis cutting margin of the forming rough cutting cycle (G73).

---Setting range---  
-99999.999 to 99999.999 (mm)

#### 【#8054】 G73 W

Set the Z-axis cutting margin of the forming rough cutting cycle (G73).

---Setting range---  
-99999.999 to 99999.999 (mm)

#### 【#8055】 G73 R

Set how many times cutting will be performed in the forming rough cutting cycle (G73).

---Setting range---  
0 to 99999 (times)

#### 【#8056】 G74 RETRACT

Set the amount of retract (amount of cut-up) of the cutting-off cycle (G74, G75).

---Setting range---  
0 to 999.999 (mm)

#### 【#8057】 G76 LAST-D

Set the amount of final cut-in by the compound type thread cutting (G76).

---Setting range---  
0 to 999.999 (mm)

#### 【#8058】 G76 TIMES

Set how many times the amount of final cut-in cycle (G76 finish margin) will be divided in the compound type thread cutting (G76).

---Setting range---  
0 to 99 (times)

#### 【#8059】 G76 ANGLE

Set the angle (thread angle) of the tool nose in the compound type thread cutting (G76).

---Setting range---  
0 to 99 (°)

#### 【#8060】 G71 ERR

Set the tolerable error range to avoid a program error (a shape change at pocket machining) against minute inversion when the finished shape's Z axis (or X axis at G72 command) does not move monotonously.

---Setting range---  
0.000 to 0.010 (mm)

### 【#8071】 3-D CMP (for M system only)

Set the value of the denominator constants for 3-dimensional tool radius compensation.

Set the value of "p" in the following formula.

$V_x = i \times r/p$ ,  $V_y = j \times r/p$ ,  $V_z = k \times r/p$

$V_x$ ,  $V_y$ ,  $V_z$  : X, Y, and Z axes or vectors of horizontal axes

i, j, k : Program command value

r : Offset

$p = \sqrt{(i^2 + j^2 + k^2)}$  when the set value is "0".

---Setting range---

0 to 99999.999

### 【#8072】 SCALING P (for M system only)

Set the scale factor for reduction or magnification in the machining program specified by G50 or G51 command.

This parameter will be valid when the program specifies no scale factor.

---Setting range---

-99.999999 to 99.999999

### 【#8075】 SpiralEndErr (for M system only)

Set the tolerable error range (absolute value) when the end point position, commanded by the spiral or conical interpolation command with the command format type 2, differs from the end point position obtained from the speed and increment/decrement amount.

---Setting range---

0 to 99999.999 (mm)

### 【#8078】 Screen Saver Timer

Set the period of time before turn-OFF of the display unit backlight.

When "0" is set, the backlight is not turned OFF.

---Setting range---

0 to 60 (min)

0: The backlight is not turned OFF

### 【#8081】 Gcode Rotat (for L system only)

Set the rotation angle for the program coordinate rotation command.

This parameter is enabled when "1" is set in "#1270 ext06/bit5 (Coordinate rotation angle without command)".

This parameter is set as absolute value command regardless of the "#8082 G68.1 R INC" setting. If the rotation angle is designated by an address R in G68.1 command, the designation by program will be applied.

---Setting range---

-360.000 to +360.000 (°)

### 【#8082】 G68.1 R INC (for L system only)

Select absolute or increment command to use for the rotation angle command R at L-system coordinate rotation.

0: Use absolute value command in G90 modal, incremental value command in G91 modal

1: Always use incremental value command

(Note) If G91 does not exist in the G code system, the command type is decided by this parameter only.

### 【#8083】 G83S modeM (for M system only)

Set the M command code for changing to the small diameter deep hole drilling cycle mode.

---Setting range---

1 to 99999999

### **【#8084】 G83S Clearance (for M system only)**

Set the clearance amount for the small diameter deep hole drilling cycle (G83).

**---Setting range---**  
 0 to 999.999 (mm)

### **【#8085】 G83S Forward F (for M system only)**

Set the feedrate from the R point to the cutting start position in the small diameter deep hole drilling cycle (G83).

**---Setting range---**  
 0 to 99999 (mm/min)

### **【#8086】 G83S Back F (for M system only)**

Set the speed for returning from the hole bottom during the small diameter deep hole drilling cycle (G83).

**---Setting range---**  
 0 to 99999 (mm/min)

### **【#8090】 SSS ON (for M system only)**

Set whether to enable the SSS control with G05 P10000.  
 0: Disable  
 1: Enable

### **【#8091】 StdLength (for M system only)**

Set the maximum value of the range for recognizing the shape.  
 To eliminate the effect of steps or errors, etc., set a large value. To enable sufficient deceleration, set a small value.  
 If "0.000" is set, the standard value (1.000mm) will be applied.

**---Setting range---**  
 0 to 100.000 (mm)

### **【#8092】 ClampCoeff (for M system only)**

Set the clamp speed at the curved section configured of fine segments.  
 Coefficient =  $\sqrt{\text{setting value}}$

**---Setting range---**  
 1 to 100

### **【#8093】 StepLeng (for M system only)**

Set the width of the step at which the speed is not to be decelerated. (Approximately the same as the CAM path difference [Tolerance].)  
 If "0" is set, the standard value (5  $\mu$  m) will be applied.  
 If a minus value is set, the speed will decelerate at all minute steps.

**---Setting range---**  
 -1.000 to 0.100 (mm)

### **【#8094】 DccWaitAdd (for M system only)**

Set the time to wait for deceleration when the speed FB does not drop to the clamp speed.

**---Setting range---**  
 0 to 100 (ms)

### **【#8101】 MACRO SINGLE**

Select how to control the blocks where the user macro command continues.  
 0: Do not stop while macro blocks continue.  
 1: Stop every block during signal block operation.

#### 【#8102】 COLL. ALM OFF

Select the interference (bite) control to the workpiece from the tool diameter during tool radius compensation and nose R compensation.

- 0: An alarm will be output and operation stops when an interference is judged.
- 1: Changes the path to avoid interference.

#### 【#8103】 COLL. CHK OFF

Select the interference (bite) control to the workpiece from the tool diameter during tool radius compensation and nose R compensation.

- 0: Performs interference check.
- 1: Does not perform interference check.

#### 【#8105】 EDIT LOCK B

Select the edit lock for program Nos. 8000 to 9999 in the memory.

- 0: Enable the editing.
- 1: Prohibit the editing of above programs.

When "1" is set, the file cannot be opened.

#### 【#8106】 G46 NO REV-ERR (for L system only)

Select the control for the compensation direction reversal in G46 (nose R compensation).

- 0: An alarm will be output and operation will stop when the compensation direction is reversed (G41 -> G42' G42 -> G41).
- 1: An alarm won't occur when the compensation direction is reversed, and the current compensation direction will be maintained.

#### 【#8107】 R COMPENSATION

Select whether to move to the inside because of a delay in servo response to a command during arc cutting mode.

- 0: Move to the inside, making the arc smaller than the command value.
- 1: Compensate the movement to the inside.

#### 【#8108】 R COMP Select

Select the arc radius error compensation target.

- 0: Perform compensation over all axes.
- 1: Perform compensation axis by axis.

(Note) This parameter is effective only when "#8107 R COMPENSATION" is "1".

#### 【#8109】 HOST LINK

Select whether to enable computer link B instead of the RS-232C port.

- 0: Disable (Enable normal RS-232C communication.)
- 1: Enable (Disable normal RS-232C communication.)

#### 【#8110】 G71/G72 POCKET

Select whether to enable the pocket machining when there is a dimple (pocket) in the rough cutting cycle (G71, G72) finishing program.

- 0: OFF
- 1: ON

#### 【#8111】 Milling Radius

Select the diameter and radius of the linear axis for milling (cylindrical/pole coordinate) interpolation.

- 0: All axes radius command
- 1: Each axis setting (follows "#1019 dia")

(Note) This parameter is valid only in the milling (cylindrical/polar coordinate) interpolation mode.

#### 【#8112】 DECIMAL PNT-P

Select whether to enable the decimal point command for G04 address P.

- 0: Disable
- 1: Enable



### 【#8113】 Milling Init G16

Set which plane to execute for milling machining after the power is turned ON or reset.

#8113:0, #8114:0 ---> G17 plane  
 #8113:0, #8114:1 ---> G19 plane  
 #8113:1, #8114:0 ---> G16 plane  
 #8113:1, #8114:1 ---> G16 plane

0: Not G16 plane  
 1: G16 plane

(Note) This parameter is valid for the G code system 2 or 3 ("#1037 cmdtyp"="3" or "4").

### 【#8114】 Milling Init G19

Set which plane to execute for milling machining after the power is turned ON or reset.

#8113:0, #8114:0 ---> G17 plane  
 #8113:0, #8114:1 ---> G19 plane  
 #8113:1, #8114:0 ---> G16 plane  
 #8113:1, #8114:1 ---> G16 plane

0: Not G19 plane  
 1: G19 plane

(Note) This parameter is valid for the G code system 2 or 3 ("#1037 cmdtyp"="3" or "4").

### 【#8116】 Coord rot para invd

Select whether to enable the coordinate rotation by the parameters.

0: Enable  
 1: Disable

### 【#8117】 OFS Diam DESIGN

Select tool radius or tool diameter compensation amount to be specified.

0: Tool radius compensation amount  
 1: Tool diameter compensation amount

### 【#8119】 Comp. unit switch

Select the setting unit of compensation amount that has no decimal point.

0: 1mm (or 1inch) unit  
 1: The minimum command unit (follows "#1003 iunit")

### 【#8120】 FONT SELECTION

Select the font when Simplified Chinese is selected for "#1043 lang".

0: MITSUBISHI CNC GOTHIC font  
 1: Standard Windows font

(Note) This parameter is available for M700VW only.

### 【#8121】 Screen Capture

Select whether to enable the screen capture function.

0: Disable  
 1: Enable

(Note1) By setting this parameter to "1", and by keeping pushing the [SHIFT] key, screen capture will be executed.

(Note2) This parameter is valid with 700VS/70 Series.

### 【#8122】 Keep G43 MDL M-REF

Select whether to keep the tool length offset by high speed manual reference position return during tool length offset.

0: Will not be kept (Cancel)  
 1: Kept

#### 【#8123】 H-spd retract ON

Select whether to enable the drilling cycle at high-speed retract in fixed cycle for drilling.  
0: Disable  
1: Enable

#### 【#8124】 Mirr img at reset

Select the operation type of the mirror image by parameter setting and the mirror image by external input.  
0: The current mirror image is canceled, and new mirror image will start with the machine position at reset as the mirror center.  
1: The mirror center is kept to continue the mirror image.

#### 【#8125】 Check Scode in G84

Select how to operate when there is no S command in synchronous tapping block.  
0: Use the spindle function modal value as S-command value.  
1: Output a program error.

#### 【#8126】 Disable op tone

Select whether to disable keyboard/touch panel operation tones.  
0: Enable the operation tones  
1: Disable the operation tones  
(Note) This setting is valid only for M700VS/M70V/M70 Series.

#### 【#8145】 Validate F1 digit

Select whether to execute the F command with a 1-digit code command or with a direct numerical command.  
0: Direct numerical command (command feedrate during feed per minute or rotation)  
1: 1-digit code command (with the feedrate specified by the parameters "#1185 spd\_F1" to "#1189 spd\_F5")

#### 【#8154(PR)】

Not used. Set to "0".

#### 【#8155】 Sub-pro interrupt

Select the method for the user macro interrupt.  
0: The user macro interrupt of macro type  
1: The user macro interrupt of sub-program type

#### 【#8156】 Fine thread cut E

Select the address E type when cutting an inch screw.  
0: Specify the number of threads per inch for inch screw cutting.  
1: Specify the precision lead for inch screw cutting.

#### 【#8157】 Radius comp type B (M system) / Nose R comp type B (L system)

For M system

Select the method of the arithmetic processing for the intersection point when the start-up or cancel commands are operated during radius compensation.

- 0: The processing does not handle the start-up or cancel command block: handle the offset vector in the direction vertical to that of the command instead.
- 1: The processing is executed for the intersection point between the command block and the next block.

For L system

Select the method of the arithmetic processing for the intersection point when the start-up or cancel commands are operated during nose R or radius compensation.

- 0: The processing does not handle the start-up or cancel command block: handle the offset vector in the direction vertical to that of the command instead.
- 1: The processing is executed for the intersection point between the command block and the next block.

## Appendix 1 Explanation of Parameters

### 【#8158】 Init const sur spd

Select the initial state after power-ON.  
 0: Constant surface speed control cancel mode.  
 1: Constant surface speed control mode.

### 【#8159】 Synchronous tap

Select whether to use the floating tap chuck in G74 and G84 tap cycles.  
 0: With a floating tapping chuck  
 1: Without a floating tapping chuck

### 【#8160】 Start point alarm

Select an operation when the operation start point cannot be found while moving to the next block of G117.  
 0: The auxiliary function is enabled after the block for the movement has finished.  
 1: The program error (P33) occurs.

### 【#8173】 Hold intr amount

Select whether to clear or hold the interruption amount after the "NC reset 1 (or 2)" signal is ON when the manual ABS switch is OFF.  
 0: Clear (Reset the coordinate deviation due to the interruption)  
 1: Hold

### 【#8201】 AX. RELEASE

Select the function to remove the control axis from the control target.  
 0: Control as normal.  
 1: Remove from control target.

### 【#8202】 OT-CHECK OFF

Select whether to enable the stored stroke limit II function set in #8204 and #8205.  
 0: Enable  
 1: Disable

### 【#8203】 OT-CHECK-CANCEL

When the simple absolute position method ("#2049 type" is "9") is selected, the stored stroke limits I, II (or IIB) and IB can be disabled until the first reference position return is executed after the power is turned ON.  
 0: Enable (according to #8202)  
 1: Temporarily cancel

(Note) "#8203 OT-CHECK-CANCEL" affects all the stored stroke limits.

### 【#8204】 OT-CHECK-N

Set the coordinates of the (-) direction in the movable range of the stored stroke limit II or the lower limit coordinates of the prohibited range of stored stroke limit IIB.  
 If the sign and value are the same as #8205, the stored stroke limit II (or IIB) will be invalid.  
 If the stored stroke limit IIB function is selected, the prohibited range will be between two points even when #8204 and #8205 are set in reverse. When II is selected, the entire range will be prohibited if #8204 and #8205 are set in reverse.

---Setting range---  
 -99999.999 to 99999.999 (mm)

### 【#8205】 OT-CHECK-P

Set the coordinates of the (+) direction in the movable range of the stored stroke limit II or the upper limit coordinates of the prohibited range of stored stroke limit IIB.

---Setting range---  
 -99999.999 to 99999.999 (mm)

**【#8206】 TOOL CHG. P**

Set the coordinates of the tool change position for G30. n (tool change position return).  
Set with coordinates in the basic machine coordinate system.

**---Setting range---**

-99999.999 to 99999.999 (mm)

**【#8207】 G76/87 IGNR (for M system only)**

Select whether to enable the shift operation at G76 (fine boring) and G87 (back boring).

0: Enable  
1: Disable

**【#8208】 G76/87 (-) (for M system only)**

Select the shift direction at G76 and G87.

0: Shift to (+) direction  
1: Shift to (-) direction

**【#8209】 G60 SHIFT (for M system only)**

Set the last positioning direction and distance for a G60 (unidirectional positioning) command.

**---Setting range---**

-99999.999 to 99999.999 (mm)

**【#8210】 OT INSIDE**

Select whether the stored stroke limit function set by #8204 and #8205 prevents the machine from moving to the inside or outside of the specified range.

0: Inhibits outside area (Select stored stroke limit II.)  
1: Inhibits inside area (Select stored stroke limit II B.)

**【#8211】 MIRR. IMAGE**

Select whether to enable the parameter mirror image function.

0: Disable  
1: Enable

## [#8213(PR)] Rotation axis type

Select the rotation type (short-cut valid/invalid) or linear type (workpiece coordinate linear type/all coordinate linear type).

This parameter is enabled only when "#1017 rot" is set to "1". (Note)

- 0: Short-cut invalid
- 1: Short-cut valid
- 2: Workpiece coordinate linear type
- 3: All coordinate linear type

(Note) The movement method is as follows by the specified rotation axis type.

<Workpiece coordinate value>

- 0,1 : Display range 0° to 359.999°
- 2,3 : Display range 0° to ±99999.999°

<Machine coordinate value/relative position>

- 0,1,2 : Display range 0° to 359.999°
- 3 : Display range 0° to ±99999.999°

<ABS command>

- 0 : The incremental amount from the end point to the current position is divided by 360, and the axis moves by the remainder amount according to the sign.
- 1 : Moves with a short-cut to the end point.
- 2,3 : In the same manner as the normal linear axis, moves according to the sign by the amount obtained by subtracting the current position from the end point.

<INC command>

- 0,1,2,3 : Moves in the direction of the commanded sign by the commanded incremental amount starting at the current position.

<Reference position return>

- 0,1,2 : The movement to the middle point applies to the ABS command or the INC command. Returns with movement within 360 degrees from the middle point to reference position.
- 3 : The movement to the middle point applies to the ABS command or the INC command. Moves and returns in the reference position direction for the difference from the current position to the reference position.

## [#8215] TLM std length

Set the TLM standard length.

TLM standard length is the distance from a tool replacement point (reference position) to the measurement basic point (surface) which is used to measure the tool length.

---Setting range---

-99999.999 to 99999.999 (mm)

## [#8216] Type in G28 return

Select the performance after establishing the reference position in reference position return command.

- 0: Moves to the reference position.
- 1: Won't move to the reference position.

## [#8217] Check start point

Set a drawing start position in graphic check of each axis.

---Setting range---

-99999.999 to 99999.999 (mm)

## [#8300] P0 (for L system only)

Set the reference X-coordinates of the chuck and the tail stock barrier.

Set the center coordinate (radius value) of workpiece by the basic machine coordinate system.

---Setting range---

-99999.999 to 99999.999 (mm)

#### **【#8301】 P1 (for L system only)**

Set the area of the chuck and tail stock barrier.  
Set the coordinate from the center of workpiece (P0) for X-axis. (radius value)  
Set the coordinate value by basic machine coordinate system for Z-axis.

---Setting range---  
-99999.999 to 99999.999 (mm)

#### **【#8302】 P2 (for L system only)**

Set the area of the chuck and tail stock barrier.  
Set the coordinate from the center of workpiece (P0) for X-axis. (radius value)  
Set the coordinate value by basic machine coordinate system for Z-axis.

---Setting range---  
-99999.999 to 99999.999 (mm)

#### **【#8303】 P3 (for L system only)**

Set the area of the chuck and tail stock barrier.  
Set the coordinate from the center of workpiece (P0) for X-axis. (radius value)  
Set the coordinate value by basic machine coordinate system for Z-axis.

---Setting range---  
-99999.999 to 99999.999 (mm)

#### **【#8304】 P4 (for L system only)**

Set the area of the chuck and tail stock barrier.  
Set the coordinate from the center of workpiece (P0) for X-axis. (radius value)  
Set the coordinate value by basic machine coordinate system for Z-axis.

---Setting range---  
-99999.999 to 99999.999 (mm)

#### **【#8305】 P5 (for L system only)**

Set the area of the chuck and tail stock barrier.  
Set the coordinate from the center of workpiece (P0) for X-axis. (radius value)  
Set the coordinate value by basic machine coordinate system for Z-axis.

---Setting range---  
-99999.999 to 99999.999 (mm)

#### **【#8306】 P6 (for L system only)**

Set the area of the chuck and tail stock barrier.  
Set the coordinate from the center of workpiece (P0) for X-axis. (radius value)  
Set the coordinate value by basic machine coordinate system for Z-axis.

---Setting range---  
-99999.999 to 99999.999 (mm)

#### **【#8310】 Barrier ON (for L system only)**

Select whether to enable the chuck and tailstock barrier.  
0: Disable (Setting from special display unit will be enabled)  
1: Enable

#### **【#8311】 P7 (for L system only)**

Set the area of the left spindle section.  
Set the coordinate from the center of workpiece (P0) for X-axis. (radius value)  
Set the coordinate value by basic machine coordinate system for Z-axis.

---Setting range---  
-99999.999 to 99999.999 (mm)

**【#8312】 P8 (for L system only)**

Set the area of the left spindle section.  
Set the coordinate from the center of workpiece (P0) for X-axis. (radius value)  
Set the coordinate value by basic machine coordinate system for Z-axis.

**---Setting range---**

-99999.999 to 99999.999 (mm)

**【#8313】 P9 (for L system only)**

Set the area of the right spindle section.  
X axis: Set the coordinate from the workpiece center (P0). (radius value)  
Z axis: Set the coordinates in the basic machine coordinate system.

**---Setting range---**

-99999.999 to 99999.999 (mm)

**【#8314】 P10 (for L system only)**

Set the area of the right spindle section.  
Set the coordinate from the center of workpiece (P0) for X-axis. (radius value)  
Set the coordinate value by basic machine coordinate system for Z-axis.

**---Setting range---**

-99999.999 to 99999.999 (mm)

**【#8315】 Barrier Type (L) (for L system only)**

Select the shape of the left chuck and tailstock barrier.

- 0: No area
- 1: Chuck
- 2: Tailstock

**【#8316】 Barrier Type (R) (for L system only)**

Select the shape of the right chuck and tailstock barrier.

- 0: No area
- 1: Chuck
- 2: Tailstock

**【#8317】 ELIV. AX. Name (for L system only)**

Set the name of the delivery axis when the right chuck and tailstock barrier is movable.  
When using the multi-part system method and the delivery axis is an axis in the other part system, designate the axis including the part system as 1A, 1B or 2A, 2B. If the part system is not designated as A and B, the set part system will be used.

**---Setting range---**

A/B/.. (axis name)

1A/1B/..

2A/2B/.. (with part system designated)

0: Cancel

**【#8318】 Stock Angle (L) (for L system only)**

Set the angle for the left tailstock end section.  
The angle will be interpreted as 90° if there is no setting (when "0" is set).

**---Setting range---**

0 to 180 (°)

0: 90° (default)

#### 【#8319】 Stock Angle (R) (for L system only)

Set the angle for the right tailstock end section.  
The angle will be interpreted as 90° if there is no setting (when "0" is set).

---Setting range---  
0 to 180 (°)  
0: 90° (default)

#### 【#8621】 Coord rot plane (H)

Set the plane (horizontal axis) for coordinate rotation control.  
Usually, set the name of the 1st axis.  
When this parameter is not set, the coordinate rotation function will not work.

---Setting range---  
Axis name

#### 【#8622】 Coord rot plane (V)

Set the plane (vertical axis) for coordinate rotation control.  
Usually, set the name of the 2nd axis.  
When this parameter is not set, the coordinate rotation function will not work.

---Setting range---  
Axis name

#### 【#8623】 Coord rot centr (H)

Set the center coordinates (horizontal axis) for coordinate rotation control.

---Setting range---  
-999999.999 to 999999.999 (mm)

#### 【#8624】 Coord rot centr (V)

Set the center coordinates (vertical axis) for coordinate rotation control.

---Setting range---  
-999999.999 to 999999.999 (mm)

#### 【#8625】 Coord rot vctr (H)

Set the vector components (horizontal axis) for coordinate rotation control.  
When this parameter is set, the coordinate rotation control angle (#8627) will be automatically calculated.

---Setting range---  
-999999.999 to 999999.999 (mm)

#### 【#8626】 Coord rot vctr (V)

Set the vector components (vertical axis) for coordinate rotation control.  
When this parameter is set, the coordinate rotation control angle (#8627) will be automatically calculated.

---Setting range---  
-999999.999 to 999999.999 (mm)

#### 【#8627】 Coord rot angle

Set the rotation angle for coordinate rotation control.  
When this parameter is set, the coordinate rotation vector (#8625, #8626) will be "0".

---Setting range---  
-360.000 to 360.000 (°)



## [#8701] Tool length

Set the length to the touch tool tip.

### ---Setting range---

-99999.999 to 99999.999 (mm)

## [#8702] Tool Dia

Set the diameter of the sphere at the touch tool tip.

### ---Setting range---

-99999.999 to 99999.999 (mm)

## [#8703] OFFSET X

This sets the deviation amount (X direction) from the touch tool center to the spindle center.

### ---Setting range---

-99999.999 to 99999.999 (mm)

## [#8704] OFFSET Y

Set the deviation amount (Y direction) from the touch tool center to the spindle center.

### ---Setting range---

-99999.999 to 99999.999 (mm)

## [#8705] RETURN

Set the one-time return distance for contacting again.

### ---Setting range---

0 to 99999.999 (mm)

## [#8706] FEED

Set the feedrate when contacting again.

### ---Setting range---

1 to 60000 (mm/min)

## [#8707] Skip past amout (H)

Set the difference (horizontal axis direction) between the skip read value and actual skip position.

### ---Setting range---

-99999.999 to 99999.999 (mm)

## [#8708] Skip past amout (V)

Set the difference (vertical axis direction) between the skip read value and actual skip position.

### ---Setting range---

-99999.999 to 99999.999 (mm)

## [#8709] EXT work sign rvs

Select when using the external workpiece coordinate system with Z shift.

Select whether to reverse the sign.

0: External workpiece offset (Z shift) without sign reversal

1: External workpiece offset (Z shift) with sign reversal

## [#8710] EXT work ofs invld

Set whether to enable external workpiece offset subtraction when setting the workpiece coordinate offset.

0: Not subtract the external workpiece offset. (Conventional specification)

1: Subtract the external workpiece offset.

### 【#8711】 TLM L meas axis

Set the tool length measurement axis.  
Set the "#1022 axname2" axis name.

#### ---Setting range---

Axis name

(Note) If the axis name is illegal or not set, the 3rd axis name will be set as default.

### 【#8712】 TLM D meas axis

Set the tool diameter measurement axis.  
Set the "#1022 axname2" axis name.

#### ---Setting range---

Axis name

(Note) If the axis name is illegal or not set, the 1st axis name will be set as default.

### 【#8713】 Skip coord. Switch (For M system only)

Select the coordinate system for reading skip coordinate value.  
Select whether to read the skip coordinate in the workpiece coordinate system or in the feature coordinate system during inclined surface machining command.  
Select whether to read the skip coordinate in the workpiece coordinate system or in the workpiece installation coordinate system during workpiece installation error compensation.  
0: Workpiece coordinate system  
1: Feature coordinate system/Workpiece installation coordinate system

### 【#8880】 Subpro stor D0: dev

Select the storage destination (device) for the subprogram.  
M:Memory, G:HD(Note), F:FD(Note), R:Memory card, D:Data server(Note)  
(Note) This is available only with M700/M700VW Series.

When D0 is designated at a subprogram call, the subprogram to be called will be searched from the device selected with this parameter.

(Example) M98 P (program No.), D0  
-> Device: "#8880 Subpro stor D0: dev" device  
Directory: "#8881 Subpro stor D0: dir" directory  
The device and directory above will be searched.

(Note 1) When the called subprogram is not found in the selected storage destination, a program error will occur.

(Note 2) When D0 to D4 is not designated at a subprogram call, the subprogram will be searched from the memory.

### 【#8881】 Subpro stor D0: dir

Select the storage destination (directory) for the subprogram.  
When D0 is designated at a subprogram call, the subprogram to be called will be searched from the directory selected with this parameter.  
Refer to "#8880 Subpro stor D0: dev".

#### ---Setting range---

Directory 48 characters

## 【#8882】 Subpro stor D1: dev

Select the storage destination (device) for the subprogram.  
 M:Memory, G:HD(Note), F:FD(Note), R:Memory card, D:Data server(Note)  
 (Note) This is available only with M700/M700VW Series.

When D1 is designated at a subprogram call, the subprogram to be called will be searched from the device selected with this parameter.

(Example) M98 P (program No.), D1  
 -> Device: "#8882 Subpro stor D1: dev" device  
 Directory: "#8883 Subpro stor D1: dir" directory  
 The device and directory above will be searched.

(Note 1) When the called subprogram is not found in the selected storage destination, a program error will occur.

(Note 2) When D0 to D4 is not designated at a subprogram call, the subprogram will be searched from the memory.

## 【#8883】 Subpro stor D1: dir

Select the storage destination (directory) for the subprogram.  
 When D1 is designated at a subprogram call, the subprogram to be called will be searched from the directory selected with this parameter.  
 Refer to "#8882 Subpro stor D1: dev".

### ---Setting range---

Directory 48 characters

## 【#8884】 Subpro stor D2: dev

Select the storage destination (device) for the subprogram.  
 M:Memory, G:HD(Note), F:FD(Note), R:Memory card, D:Data server(Note)  
 (Note) This is available only with M700/M700VW Series.

When D2 is designated at a subprogram call, the subprogram to be called will be searched from the device selected with this parameter.

(Example) M98 P (program No.), D2  
 -> Device: "#8884 Subpro stor D2: dev" device  
 Directory: "#8885 Subpro stor D2: dir" directory  
 The device and directory above will be searched.

(Note 1) When the called subprogram is not found in the selected storage destination, a program error will occur.

(Note 2) When D0 to D4 is not designated at a subprogram call, the subprogram will be searched from the memory.

## 【#8885】 Subpro stor D2: dir

Select the storage destination (directory) for the subprogram.  
 When D2 is designated at a subprogram call, the subprogram to be called will be searched from the directory selected with this parameter.  
 Refer to "#8884 Subpro stor D2: dev".

### ---Setting range---

Directory 48 characters

### 【#8886】 Subbro stor D3: dev

Select the storage destination (device) for the subprogram.  
M:Memory, G:HD(Note), F:FD(Note), R:Memory card, D:Data server(Note)  
(Note) This is available only with M700/M700VW Series.

When D3 is designated at a subprogram call, the subprogram to be called will be searched from the device selected with this parameter.

(Example) M98 P (program No.), D3  
-> Device: "#8886 Subpro stor D3: dev" device  
Directory: "#8887 Subpro stor D3: dir" directory  
The device and directory above will be searched.

(Note 1) When the called subprogram is not found in the selected storage destination, a program error will occur.

(Note 2) When D0 to D4 is not designated at a subprogram call, the subprogram will be searched from the memory.

### 【#8887】 Subpro stor D3: dir

Select the storage destination (directory) for the subprogram.  
When D3 is designated at a subprogram call, the subprogram to be called will be searched from the directory selected with this parameter.  
Refer to "#8886 Subpro stor D3: dev".

---Setting range---  
Directory 48 characters

### 【#8888】 Subbro stor D4: dev

Select the storage destination (device) for the subprogram.  
M:Memory, G:HD(Note), F:FD(Note), R:Memory card, D:Data server(Note)  
(Note) This is available only with M700/M700VW Series.

When D4 is designated at a subprogram call, the subprogram to be called will be searched from the device selected with this parameter.

(Example) M98 P (program No.), D4  
-> Device: "#8888 Subpro stor D4: dev" device  
Directory: "#8889 Subpro stor D4: dir" directory  
The device and directory above will be searched.

(Note 1) When the called subprogram is not found in the selected storage destination, a program error will occur.

(Note 2) When D0 to D4 is not designated at a subprogram call, the subprogram will be searched from the memory.

### 【#8889】 Subpro stor D4: dir

Select the storage destination (directory) for the subprogram.  
When D4 is designated at a subprogram calling, the subprogram to be called will be searched from the directory selected with this parameter.  
Refer to "#8888 Subpro stor D4: dev".

---Setting range---  
Directory 48 characters

### 【#8890-8894】 Subpro srch odr D0 to D4

Specify the search order of D0 to D4 (devices and directories storing subprograms) when D0 to D4 are omitted from subprogram call.  
Search is performed in the order from 1 to 5. When 0 is set, the device is excluded from search.  
If the same value is set for more than one device, search is carried out in the order from the one with a smaller parameter number.  
If 0 is set for all the devices, the memory is searched.

---Setting range---  
0 to 5

### 【#8901】 Counter type 1

Set the type of counter displayed at the upper left of the AUTO/MDI display on the Monitor screen.

- 1: Current position
- 2: Workpiece coordinate position
- 3: Machine position
- 4: Program position
- 8: Remain command
- 9: Manual interrupt amount
- 10: Next command
- 11: Restart position
- 12: Remain distance
- 16: Tip workpiece coordinate position
- 18: Tool axis movement
- 19: Tip machine position
- 20: Relative position
- 21: Table coordinate position
- 22: Workpiece installation position
- 23: Inclined surface coordinate

---Setting range---

1 to 23

### 【#8902】 Counter type 2

Set the type of counter displayed at the lower left of the AUTO/MDI display on the Monitor screen.

- 1: Current position
- 2: Workpiece coordinate position
- 3: Machine position
- 4: Program position
- 8: Remain command
- 9: Manual interrupt amount
- 10: Next command
- 11: Restart position
- 12: Remain distance
- 16: Tip workpiece coordinate position
- 18: Tool axis movement
- 19: Tip machine position
- 20: Relative position
- 21: Table coordinate position
- 22: Workpiece installation position
- 23: Inclined surface coordinate

---Setting range---

1 to 23

### 【#8903】 Counter type 3

Set the type of counter displayed at the upper right of the AUTO/MDI display on the Monitor screen.

- 1: Current position
- 2: Workpiece coordinate position
- 3: Machine position
- 4: Program position
- 8: Remain command
- 9: Manual interrupt amount
- 10: Next command
- 11: Restart position
- 12: Remain distance
- 16: Tip workpiece coordinate position
- 18: Tool axis movement
- 19: Tip machine position
- 20: Relative position
- 21: Table coordinate position
- 22: Workpiece installation position
- 23: Inclined surface coordinate

---Setting range---

1 to 23

#### **【#8904】 Counter type 4**

Set the type of counter displayed at the lower right of the AUTO/MDI display on the Monitor screen.

- 1: Current position
- 2: Workpiece coordinate position
- 3: Machine position
- 4: Program position
- 8: Remain command
- 9: Manual interrupt amount
- 10: Next command
- 11: Restart position
- 12: Remain distance
- 16: Tip workpiece coordinate position
- 18: Tool axis movement
- 19: Tip machine position
- 20: Relative position
- 21: Table coordinate position
- 22: Workpiece installation position
- 23: Inclined surface coordinate

**---Setting range---**

1 to 23

#### **【#8905】 Counter type 5**

Set the type of counter displayed at the left of the Manual display on the Monitor screen.

- 1: Current position
- 2: Workpiece coordinate position
- 3: Machine position
- 4: Program position
- 8: Remain command
- 9: Manual interrupt amount
- 10: Next command
- 11: Restart position
- 12: Remain distance
- 16: Tip workpiece coordinate position
- 18: Tool axis movement
- 19: Tip machine position
- 20: Relative position
- 21: Table coordinate position
- 22: Workpiece installation position
- 23: Inclined surface coordinate

**---Setting range---**

1 to 23

#### **【#8906】 Counter type 6**

Set the type of counter displayed at the right of the Manual display on the Monitor screen.

- 1: Current position
- 2: Workpiece coordinate position
- 3: Machine position
- 4: Program position
- 8: Remain command
- 9: Manual interrupt amount
- 10: Next command
- 11: Restart position
- 12: Remain distance
- 16: Tip workpiece coordinate position
- 18: Tool axis movement
- 19: Tip machine position
- 20: Relative position
- 21: Table coordinate position
- 22: Workpiece installation position
- 23: Inclined surface coordinate

**---Setting range---**

1 to 23

### 【#8909(PR)】 Aut/Manual switch

Select the counter display method on Monitor screen.

- 0: "AUTO/MDI" and "Manual" display is switched by the mode selection switch.
- 1: Display AUTO/MDI counter only.
- 2: Display Manual counter only.
- 3: Display the enlarged counter of "#8901 Counter type 1".

(Note) This parameter is disabled when "#11019 2-system display (2-part system simultaneous display)" is set to "1" or "2".

### 【#8910】 Edit undo

Set whether to enable the Undo function during program edit on the Monitor screen or Edit screen.

- 0: Disable
- 1: Enable

(Note) This parameter is valid only with M700VW/M700VS/M700/M70V Series.

### 【#8913】 Touch panel sense

Set the sensibility of the touch panel.

The smaller the setting value is, the more sensitive the panel will be.

(1: sensitive, 4: insensitive)

When set to 0, the sensibility will be the same as when the standard setting of 2 is applied.

(Note) This parameter is available for M700VS/M70V/M70 Series.

---Setting range---

0 to 4

### 【#8914】 Auto Top search

Select the operation method for restart search type 2.

- 0: It is necessary to set the top search position arbitrarily.
- 1: The restart search is executed from O No. that is designated as head.

### 【#8915】 Auto backup day 1

When the NC power is ON after the designated date was passed over, the automatic backup is executed.

When "-1" is set to "Auto backup day 1", the automatic backup is executed every turning NC power ON.

When "0" is set to all on "Auto backup day 1" to "4", the automatic backup is not executed.

It is possible to specify the designated date up to 4 days for a month.

---Setting range---

-1 to 31("-1" can be set for "Auto backup day 1" only.)

### 【#8916】 Auto backup day 2

When the NC power is ON after the designated date was passed over, the automatic backup is executed.

When "-1" is set to "Auto backup day 1", the automatic backup is executed every turning NC power ON.

When "0" is set to all on "Auto backup day 1" to "4", the automatic backup is not executed.

It is possible to specify the designated date up to 4 days for a month.

---Setting range---

-1 to 31("-1" can be set for "Auto backup day 1" only.)

### 【#8917】 Auto backup day 3

When the NC power is ON after the designated date was passed over, the automatic backup is executed.

When "-1" is set to "Auto backup day 1", the automatic backup is executed every turning NC power ON.

When "0" is set to all on "Auto backup day 1" to "4", the automatic backup is not executed.

It is possible to specify the designated date up to 4 days for a month.

---Setting range---

-1 to 31("-1" can be set for "Auto backup day 1" only.)

#### 【#8918】 Auto backup day 4

When the NC power is ON after the designated date was passed over, the automatic backup is executed.  
When "-1" is set to "Auto backup day 1", the automatic backup is executed every turning NC power ON.  
When "0" is set to all on "Auto backup day 1" to "4", the automatic backup is not executed.  
It is possible to specify the designated date up to 4 days for a month.

##### ---Setting range---

-1 to 31 ("-1" can be set for "Auto backup day 1" only.)

#### 【#8919】 Auto backup device

Select the automatic backup target device.

[M700/M700VW Series]

- 0: DS
- 1: HD
- 2: Memory card

[M700VS/M70V Series]

- 0: Memory card
- 3: USB memory

[M70 Series]

- 0: Memory card

(Note) The setting range differs according to the model.

#### 【#8920】 3D tool ofs select

Select the method to calculate the drawing position when drawing a solid.

With 3D drawing, the drawing position (tool tip position) is calculated with the method designated with this parameter, and the image is drawn.

- 0: For tool radius compensation, use the tool compensation amount set in tool compensation screen. For tool length, use the value in tool set window. (for tool length measurement type I)
- 1: Use the tool compensation amount set in tool compensation screen for both tool radius and tool length compensation. (for tool length measurement type II)
- 2: Use the value set in tool set window for both tool radius and tool length compensation. (for tool length measurement type I)
- 3: Use the value set in tool set window for both tool radius and tool length compensation. (for tool length measurement type II)

#### 【#8921】 Mass Edit select

Select the editing mode for the machining programs saved in HD, FD, and memory card.

When the program size is 1.0MB (When "#8910 Edit Undo" is invalid, 2.0MB) or more, mass-editing will be applied.

- 0: Regular editing mode
- 1: Mass-editing mode

#### 【#8922】 T-reg-dup check

Set whether to enable the duplication check in registering tools to magazine pots, and in setting tool Nos. for spindle/standby.

- 0: Duplication check valid for all valid magazines
- 1: Duplication check invalid
- 2: Duplication check valid only for the selected magazine

#### 【#8923(PR)】 Hide Edit-IO menu

Set whether to enable the edit-in/out menu. When disabled, the edit-input/output menu won't appear. However, the maintenance-in/out menu is always enabled regardless of this parameter setting.

- 0: Enable
- 1: Disable

#### 【#8924】 MEAS. CONFIRM MSG

Select whether to display a confirming message when attempting to write compensation data for tool measurement, or coordinate system data for workpiece measurement.

- 0: Not display a confirming message
- 1: Display a confirming message



### 【#8925】 SP on 1st part sys

Set a spindle No. to be displayed on the 1st part system window when 2-part system simultaneous display is valid. On the 15-type display, 1-part system display can be also specified.

High-order: Select an upper side spindle No.

Low-order: Select a lower side spindle No.

(Note 1) When "00" is set in 2-part system simultaneous display, spindles will be displayed in a default order (the 1st spindle on the upper side, the 2nd spindle on the lower side). When "00" is set in 1-part system display of the 15-type display, all spindles will be displayed.

(Note 2) If you designate a bigger number than the setting of "#1039 spinno", or either the high-order or low-order setting is "0", the 1st spindle will be displayed.

(Note 3) If the low-order is set to "F", the spindle speed command value and the actual rotation number which are specified in the high-order will be displayed.

#### ---Setting range---

High-order: 0 to 6

Low-order: 0 to 6, F

### 【#8926】 SP on 2nd part sys

Set a spindle No. to be displayed on the 2nd part system window when 2-part system simultaneous display is valid. On the 15-type display, 1-part system display can be also specified.

High-order: Select an upper side spindle No.

Low-order: Select a lower side spindle No.

(Note 1) When "00" is set in 2-part system simultaneous display, spindles will be displayed in a default order (the 1st spindle on the upper side, the 2nd spindle on the lower side). When "00" is set in 1-part system display of the 15-type display, all spindles will be displayed.

(Note 2) If you designate a bigger number than the setting of "#1039 spinno", or either the high-order or low-order setting is "0", the 1st spindle will be displayed.

(Note 3) If the low-order is set to "F", the spindle speed command value and the actual rotation number which are specified in the high-order will be displayed.

#### ---Setting range---

High-order: 0 to 6

Low-order: 0 to 6, F

### 【#8927】 SP on 3rd part sys

Set a spindle No. to be displayed on the 3rd part system window when 2-part system simultaneous display is valid. On the 15-type display, 1-part system display can be also specified.

High-order: Select an upper side spindle No.

Low-order: Select a lower side spindle No.

(Note 1) When "00" is set in 2-part system simultaneous display, spindles will be displayed in a default order (the 1st spindle on the upper side, the 2nd spindle on the lower side). When "00" is set in 1-part system display of the 15-type display, all spindles will be displayed.

(Note 2) If you designate a bigger number than the setting of "#1039 spinno", or either the high-order or low-order setting is "0", the 1st spindle will be displayed.

(Note 3) If the low-order is set to "F", the spindle speed command value and the actual rotation number which are specified in the high-order will be displayed.

#### ---Setting range---

High-order: 0 to 6

Low-order: 0 to 6, F

### 【#8928】 SP on 4th part sys

Set a spindle No. to be displayed on the 4th part system window when 2-part system simultaneous display is valid. On the 15-type display, 1-part system display can be also specified.

High-order: Select an upper side spindle No.

Low-order: Select a lower side spindle No.

(Note 1) When "00" is set in 2-part system simultaneous display, spindles will be displayed in a default order (the 1st spindle on the upper side, the 2nd spindle on the lower side). When "00" is set in 1-part system display of the 15-type display, all spindles will be displayed.

(Note 2) If you designate a bigger number than the setting of "#1039 spinno", or either the high-order or low-order setting is "0", the 1st spindle will be displayed.

(Note 3) If the low-order is set to "F", the spindle speed command value and the actual rotation number which are specified in the high-order will be displayed.

#### ---Setting range---

High-order: 0 to 6

Low-order: 0 to 6, F

### 【#8929】 Disable=INPUT:comp

Select whether to enable [=INPUT] menu in [T-ofs] (tool compensation amount setting) or [Coord] (workpiece coordinate system offset setting) menu on [Setup] screen.

0: Enable

1: Disable

### 【#8930】 Disable=INPUT:var

Select whether to enable [=INPUT] menu in [Com var] (common variables) menu on [Monitr] screen.

0: Enable

1: Disable

### 【#8931】 Display/Set limit

Select the restriction of the connected NC's screen display/settings on/from the remote control tool.

0: Permit the screen display/settings

1: Permit the screen display only

2: Restrict the connection

### 【#8932(PR)】 Hide measure scrn

Select whether to display the tool measurement screen and workpiece measurement screen.

0: Display

1: Not display

### 【#8933】 Disable lngth comp

Set whether to disable the setting of tool shape compensation amount.

0: Not disable

1: Disable

The shape compensation amount covers the following data according to the tool compensation type.

- Compensation type A ("1" in "#1037 cmdtyp(command type)")  
... Compensation amount (the sum of shape compensation and wear compensation amount)
- Compensation type B ("2" in "#1037 cmdtyp(command type)")  
... Length dimension and radius dimension
- Compensation type C ("3" in "#1037 cmdtyp(command type)")  
... Tool length and tool nose R

## 【#8934】 Disable wear comp

Select whether to disable the setting of tool wear compensation amount.  
0: Not disable  
1: Disable

The wear compensation amount covers the following data according to the tool compensation type.

- Compensation type A ("1" in "#1037 cmdtyp(command type 1)")  
... This parameter is disabled.
- Compensation type B ("2" in "#1037 cmdtyp(command type)")  
... Length wear and radius wear
- Compensation type C ("3" in "#1037 cmdtyp(command type)")  
... Tool wear and tool nose wear

## 【#8935】 W COORD CONFIRM

Select whether to display confirmation message when setting workpiece coordinate system offset in [Simple setting] menu.  
0: Not display  
1: Display

## 【#8936】 Delete leading 0

In creating a file, or in transferring a file, if the file name of the new file, or the file name of the transfer destination consists only of numerical figures, 0 of the file name head will be deleted from the name.  
0: Designated file name (0 remains in the file name)  
1: 0 will be deleted from the file name

## 【#8937】 File sort volume

Set the maximum number of files to sort in the memory card and DS lists.  
If the setting is large, update of the list may take longer.  
With M70V/M70 Series, the maximum number will be 64 regardless of the setting of this parameter.

### ---Setting range---

64 to 1000(M700/M700VW Series)  
64 to 250(M700VS Series)  
Standard: 64

## 【#8938】 Edit-Not show Prg

Select whether to enable the automatic display on the Edit screen, when selected, of the programs searched by operation/check search or the MDI programs in MDI mode.  
0: Enable the automatic display  
1: Disable the automatic display

## 【#8939】 Undo confirm msg

Display a confirming message when operating the [Undo] menu.  
0: Not display a confirming message  
1: Display a confirming message

## 【#8940】 Set select display

Select what to display in the selectable display area.

- 0: Common variable
- 1: Local variable
- 2: Workpiece coordinate system offset
- 3: All spindles' rotation speed
- 4: Expanded counters
- 5: Tool center coordinate display
- 6: Custom release window

(Note 1) This parameter is available for 15-type display unit only.

(Note 2) Tool center coordinate display is available only when any of the 5-axis related options is enabled.

### 【#8941(PR)】 ABS/INC for T-ofs

Enable switching the method to set tool compensation data (absolute/incremental value) with INPUT key.

- 0: Fix it to the absolute value input.
- 1: Enable to switch between absolute and incremental value input.

### 【#8942(PR)】 \$1 color

Set the color to be shown on the top-left of screen for the 1st part system. This enables switching the color patterns for each part system.

When set to the values 1 to 4, the part system name is shown in the form of button image.

When set to 0, the settings between #8943 and #8945 is disabled and the screen is shown by the default color pattern for all the part systems.

- 0: Purple (no button image) (default)
- 1: Purple
- 2: Pink
- 3: Light blue
- 4: Orange

### 【#8943(PR)】 \$2 color

Set the color to be shown on the top-left of screen for the 2nd part system. This enables switching the color patterns for each part system. When set to the values 1 to 4, the part system name is shown in the form of button image.

Note) Enabled when #8942 (\$1 color) is set to the values 1 to 4.

- 1: Purple (default)
- 2: Pink
- 3: Light blue
- 4: Orange

### 【#8944(PR)】 \$3 color

Set the color to be shown on the top-left of screen for the 3rd part system. This enables switching the color patterns for each part system. When set to the values 1 to 4, the part system name is shown in the form of button image.

Note) Enabled when #8942 (\$1 color) is set to the values 1 to 4.

- 1: Purple (default)
- 2: Pink
- 3: Light blue
- 4: Orange

### 【#8945(PR)】 \$4 color

Set the color to be shown on the top-left of screen for the 4th part system. This enables switching the color patterns for each part system. When set to the values 1 to 4, the part system name is shown in the form of button image.

Note) Enabled when #8942 (\$1 color) is set to the values 1 to 4.

- 1: Purple (default)
- 2: Pink
- 3: Light blue
- 4: Orange

### 【#8951】 No Tab counter sw.

Disable Tab key to change the counter type.

- 0: Enable Tab key to change counter typ  
(The value of #8905 also changes)
- 1: Disable Tab key to change counter type

### 【#8952】 Edit-win \$ switch

Select whether to enable switching of program displayed in the edit window on Monitor screen according to the displayed part system when part system switch is performed.

- 0: Not switch
- 1: Switch

### 【#8953】 2\$ disp switch typ

Select how to switch the part system to display when the 2-part system simultaneous display is enabled.

- 0: Switch by incrementing the No. of part system to display by one.
- 1: Switch by skipping the system displayed in the non-active area. When a window is being popped up, however, this skip is not performed and the system is switched by incrementing the No. by one.

### 【#8956(PR)】 User key type

Select the definition type of the user-defined keys.

There are two user-defined keys.

Type 1 :

It is the same as the conventional specification. A line feed between "[]" is not dealt as ";".

It is dealt as an upper case/lower case letter depending on the CapsLock status.

A symbolic character may be converted into a specific character.

Type 2:

A line break inside square brackets "[]" is dealt as ";".

Regardless of the CapsLock status, the defined character is input.

A symbolic character is also input as defined.

0 : Type 1 (Conventional specification)

1 : Type 2

(Note) This parameter is valid for M700VW series.

### 【#9001】 DATA IN PORT

Select the port for inputting the data such as machine program and parameters.

1: ch1

2: ch2

### 【#9002】 DATA IN DEV.

Select the device No. for inputting the data. (The device Nos. correspond to the input/output device parameters.)

---Setting range---

0 to 4

### 【#9003】 DATA OUT PORT

Select the port for outputting the data such as machine program and parameters.

1: ch1

2: ch2

### 【#9004】 DATA OUT DEV.

Select the device No. for outputting the data. (The device Nos. correspond to the input/output device parameters.)

---Setting range---

0 to 4

### 【#9005】 TAPE MODE PORT

Select the input port for running with the tape mode.

1: ch1

2: ch2

### 【#9006】 TAPE MODE DEV.

Select the device No. to be run with the tape mode. (The device Nos. correspond to the input/output device parameters.)

---Setting range---

0 to 4

#### 【#9007】 MACRO PRINT PORT

Select the output port used for the user macro DPRINT command.

- 1: ch1
- 2: ch2
- 9: Memory card

#### 【#9008】 MACRO PRINT DEV.

Select the device No. used for the DPRINT command. (The device Nos. correspond to the input/output device parameters.)

---Setting range---  
0 to 4

#### 【#9009】 PLC IN/OUT PORT

Select the port for inputting/outputting various data with PLC.

- 1: ch1
- 2: ch2

#### 【#9010】 PLC IN/OUT DEV.

Select the device No. used for the PLC input/output. (The device Nos. correspond to the input/output device parameters.)

---Setting range---  
0 to 4

#### 【#9011】 REMOTE PRG IN PORT

Select the port for inputting remote programs.

- 1: ch1
- 2: ch2

#### 【#9012】 REMOTE PRG IN DEV.

Select the device No. used to input remote programs. The device Nos. correspond to the input/output device parameters.

---Setting range---  
0 to 4

#### 【#9013】 EXT UNIT PORT

Select the port for communication with an external unit.

- 1: ch1
- 2: ch2

#### 【#9014】 EXT UNIT DEV.

Select the unit No. used for communication with an external unit(The unit Nos. correspond to the input/output device parameters.)

---Setting range---  
0 to 4

#### 【#9017】 HANDY TERMINAL PORT

Select the port for communication with a handy terminal.

- 1: ch1
- 2: ch2

#### 【#9018】 HANDY TERMINAL DEV.

Select the device No. used for communication with a handy terminal. (The device Nos. correspond to the input/output device parameters.)

---Setting range---  
0 to 4

## Appendix 1 Explanation of Parameters

### 【#9051】 Data I/O port

Select whether to use display side serial port or NC side serial port for data input/output function.

- 0: Display side serial port
- 1: Display side serial port
- 2: NC side serial port

(Note) The setting range differs according to the model.

### 【#9052】 Tape mode port

Select whether to use display side serial port or NC side serial port for tape mode.

- 0: NC side serial port
- 1: Display side serial port
- 2: NC side serial port

(Note) The setting range differs according to the model.

### 【#9053】 M2 macro converter

Select whether to enable the macro converter when inputting M2/M0 formatted program via RS-232C (serial connection).

When enabling the converter, select whether to convert the comment part enclosed with brackets ().

- 0: Disable
- 1: Enable; convert the comment part enclosed with brackets ().
- 2: Enable; not convert the comment part enclosed with brackets ().

### 【#9054】 MACRO PRINT FILE

Set the file name to save the output data to a memory card with the DRPNT command for the user macro.

If this parameter is not set, the data will be output under the following name.

dprt\$-MMDDhhmmssff

\$ is the part system No. in which DPRNT is commanded, MMDDhhmmssff is the current date.

(MM: month, DD: day, hh: hour, mm: minute, ss: second, ff: millisecond)

(Note) This parameter is enabled when "#9007 Macro print directory" is set to "9".

#### ---Setting range---

Program name or file name (32 characters)

### 【#9101】 DEV0 DEVICE NAME

Set the device name corresponding to the device No.

Set a simple name for quick identification.

#### ---Setting range---

Use alphabet characters, numerals and symbols to set a name within 3 characters.

### 【#9102】 DEV0 BAUD RATE

Select the serial communication speed.

- 0: 19200 (bps)
- 1: 9600
- 2: 4800
- 3: 2400
- 4: 1200
- 5: 600
- 6: 300
- 7: 110

### 【#9103】 DEV0 STOP BIT


Select the stop bit length used in the start-stop system.

Refer to "#9104 DEV0 PARITY CHECK". At the output of data, the number of characters is always adjusted for the parity check.

- 1: 1 (bit)
- 2: 1.5
- 3: 2

#### 【#9104】 DEV0 PARITY CHECK

Select whether to add the parity check bit to the data.



Set this parameter in accordance with the I/O device specifications.

- 0: Not add a parity bit in I/O mode
- 1: Add a parity bit in I/O mode

#### 【#9105】 DEV0 EVEN PARITY

Select odd or even when parity is added to the data. This parameter is ignored when no parity is added.

- 0: Odd parity
- 1: Even parity

#### 【#9106】 DEV0 CHR. LENGTH

Set the length of the data bit.

Refer to "9104 DEV0 PARITY CHECK".

- 0: 5 (bit)
- 1: 6
- 2: 7 (NC connection not supported)
- 3: 8

#### 【#9107】 DEV0 TERMINATR TYP

Select the code to terminate data reading.

- 0, 3: EOR
  - 1, 2: EOB or EOR
- [When M700/700VW display side serial port is selected]
- 0: No terminator
  - 1: EOR
  - 2: EOB
  - 3: EOB or EOR

#### 【#9108】 DEV0 HAND SHAKE

Select the transmission control method.

No handshaking will be used when a value except 1 to 3 is set.

- 1: RTS/CTS method
- 2: No handshaking
- 3: DC code method

#### 【#9109】 DEV0 DC CODE PRTY

Select the DC code type when the DC code method is selected.

- 0: Not add parity to DC code (DC3 = 13H)
- 1: Add parity to DC code (DC3 = 93H)

#### 【#9111】 DEV0 DC2/4 OUTPUT

Select the DC code handling when outputting data to the output device.

- DC2 / DC4
- 0: None / None
- 1: Yes / None
- 2: None / Yes
- 3: Yes / Yes

#### 【#9112】 DEV0 CR OUTPUT

Select whether to add the (CR) code just before the EOB (L/F) code during output.

- 0: Not add
- 1: Add



#### 【#9113】 DEV0 EIA OUTPUT

Select ISO or EIA code for data output.  
In data input mode, the ISO and EIA codes are identified automatically.  
0: ISO code output  
1: EIA code output

#### 【#9114】 DEV0 FEED CHR.

Set the length of the tape feed to be output at the start and end of the data during tape output.

---Setting range---  
0 to 999 (characters)

#### 【#9115】 DEV0 PARITY V

Select whether to perform the parity check for the number of characters in a block at the input of data.  
At the output of data, the number of characters is always adjusted to for the parity check.  
0: Not perform parity V check  
1: Perform parity V check

#### 【#9116】 DEV0 TIME-OUT (sec)

Set the time out time to detect an interruption in communication.  
Time out check will not be executed when set to "0".

---Setting range---  
0 to 30 (s)

#### 【#9117】 DEV0 DR OFF

Select whether to enable the DR data check in data I/O mode.  
0: Enable  
1: Disable

#### 【#9118】 DEV0 DATA ASCII

Select the code of the output data.  
0: ISO/EIA code (Depends on whether #9113, #9213, #9313, #9413 or #9513 EIA output parameter is set up.)  
1: ASCII code

#### 【#9119】 DEV0 INPUT TYPE

Select the mode for input (verification).  
0: Standard input (Data from the very first EOB is handled as significant information.)  
1: EOBs following the first EOB of the input data are skipped until data other than EOB is input

#### 【#9120】 DEV0 OUT BUFFER

Select the buffer size of the output data which is output to output device using NC side serial port.  
If the output device has a data receiving error (overrun error), decrease the buffer size with this parameter.  
If the buffer size is decreased, output time will prolong according to the size.  
0: 250 bytes (default)  
1: 1 byte  
2: 4 bytes  
3: 8 bytes  
4: 16 bytes  
5: 64 bytes

#### 【#9121】 DEV0 EIA CODE [

Set the code in hexadecimal, which does not duplicate the existing EIA codes, for the special code "[".  
When output with EIA code, data can be output using the alternate code in which the special ISO code, not included in EIA, is specified.

---Setting range---  
0 to FF (hexadecimal)

#### 【#9122】 DEV0 EIA CODE ]

Set the code in hexadecimal, which does not duplicate the existing EIA codes, for the special code "]" .  
When output with EIA code, data can be output using the alternate code in which the special ISO code, not included in EIA, is specified.

---Setting range---  
0 to FF (hexadecimal)

#### 【#9123】 DEV0 EIA CODE #

Set the code in hexadecimal, which does not duplicate the existing EIA codes, for the special code "#" .  
When output with EIA code, data can be output using the alternate code in which the special ISO code, not included in EIA, is specified.

---Setting range---  
0 to FF (hexadecimal)

#### 【#9124】 DEV0 EIA CODE \*

Set the code in hexadecimal, which does not duplicate the existing EIA codes, for the special code "\*" .  
When output with EIA code, data can be output using the alternate code in which the special ISO code, not included in EIA, is specified.

---Setting range---  
0 to FF (hexadecimal)

#### 【#9125】 DEV0 EIA CODE =

Set the code in hexadecimal, which does not duplicate the existing EIA codes, for the special code "=" .  
When output with EIA code, data can be output using the alternate code in which the special ISO code, not included in EIA, is specified.

---Setting range---  
0 to FF (hexadecimal)

#### 【#9126】 DEV0 EIA CODE :

Set the code in hexadecimal, which does not duplicate the existing EIA codes, for the special code ":" .  
When output with EIA code, data can be output using the alternate code in which the special ISO code, not included in EIA, is specified.

---Setting range---  
0 to FF (hexadecimal)

#### 【#9127】 DEV0 EIA CODE \$

Set the code in hexadecimal, which does not duplicate the existing EIA codes, for the special code "\$" .  
When output with EIA code, data can be output using the alternate code in which the special ISO code, not included in EIA, is specified.

---Setting range---  
0 to FF (hexadecimal)

#### 【#9128】 DEV0 EIA CODE !

Set the code in hexadecimal, which does not duplicate the existing EIA codes, for the special code "!" .  
When output with EIA code, data can be output using the alternate code in which the special ISO code, not included in EIA, is specified.

---Setting range---  
0 to FF (hexadecimal)

**[#9201] DEV1 DEVICE NAME**

Set the device name corresponding to the device No.  
 Set a simple name for quick identification.

**---Setting range---**

Use alphabet characters, numerals and symbols to set a name within 3 characters.

**[#9202] DEV1 BAUD RATE**

Select the serial communication speed.

- 0: 19200 (bps)
- 1: 9600
- 2: 4800
- 3: 2400
- 4: 1200
- 5: 600
- 6: 300
- 7: 110

**[#9203] DEV1 STOP BIT**


Select the stop bit length used in the start-stop system.

Refer to "#9204 DEV1 PARITY CHECK". At the output of data, the number of characters is always adjusted to for the parity check.

- 1: 1 (bit)
- 2: 1.5
- 3: 2

**[#9204] DEV1 PARITY CHECK**

Select whether to add a parity check bit to the data.



Set this parameter in accordance with the I/O device specifications.

- 0: Not add a parity bit in I/O mode
- 1: Add a parity bit in I/O mode

**[#9205] DEV1 EVEN PARITY**

Select whether even or odd parity will be used when parity is used. This parameter is ignored when no parity is added.

- 0: Odd parity
- 1: Even parity

**[#9206] DEV1 CHR. LENGTH**

Select the length of the data bit.

Refer to "#9204 DEV1 PARITY CHECK".

- 0: 5 (bit)
- 1: 6
- 2: 7 (NC connection not supported)
- 3: 8

**[#9207] DEV1 TERMINATR TYP**

Select the code to terminate data reading.

- 0, 3: EOR
- 1, 2: EOB or EOR
- [When M700/700VW display side serial port is selected]
- 0: No terminator
- 1: EOR
- 2: EOB
- 3: EOB or EOR

#### 【#9208】 DEV1 HAND SHAKE

Select the transmission control method.  
No handshaking will be used when a value except 1 to 3 is set.  
1: RTS/CTS method  
2: No handshaking  
3: DC code method

#### 【#9209】 DEV1 DC CODE PRY

Select the DC code type when the DC code method is selected.  
0: Not add parity to DC code (DC3 = 13H)  
1: Add parity to DC code (DC3 = 93H)

#### 【#9211】 DEV1 DC2/4 OUTPUT

Select the DC code handling when outputting data to the output device.  
DC2 / DC4  
0: None / None  
1: Yes / None  
2: None / Yes  
3: Yes / Yes

#### 【#9212】 DEV1 CR OUTPUT

Select whether to add the (CR) code just before the EOB (L/F) code during output.  
0: Not add  
1: Add

#### 【#9213】 DEV1 EIA OUTPUT

Select ISO or EIA code for data output.  
In data input mode, the ISO and EIA codes are identified automatically.  
0: ISO code output  
1: EIA code output

#### 【#9214】 DEV1 FEED CHR.

Set the length of the tape feed to be output at the start and end of the data during tape output.  
  
---Setting range---  
0 to 999 (characters)

#### 【#9215】 DEV1 PARITY V

Select whether to perform the parity check for the number of characters in a block at the input of data.  
At the output of data, the number of characters is always adjusted to for the parity check.  
0: Not perform parity V check  
1: Perform parity V check

#### 【#9216】 DEV1 TIME-OUT (sec)

Set the time out time to detect an interruption in communication.  
Time out check will not be executed when set to "0".  
  
---Setting range---  
0 to 30 (s)

#### 【#9217】 DEV1 DR OFF

Select whether to enable the DR data check in data I/O mode.  
0: Enable  
1: Disable

#### 【#9218】 DEV1 DATA ASCII

Select the code of the output data.  
0: ISO/EIA code (Depends on whether #9113, #9213, #9313, #9413 or #9513 EIA output parameter is set up.)  
1: ASCII code

## 【#9219】 DEV1 INPUT TYPE

Select the mode for input (verification).

- 0: Standard input (Data from the very first EOB is handled as significant information.)
- 1: EOBs following the first EOB of the input data are skipped until data other than EOB is input

## 【#9220】 DEV1 OUT BUFFER

Select the buffer size of the output data which is output to output device using NC side serial port. If the output device has a transmission error (overrun error), decrease the buffer size with this parameter.

If the buffer size is decreased, output time will prolong according to the size.

- 0: 250 bytes (default)
- 1: 1 byte
- 2: 4 byte
- 3: 8 byte
- 4: 16 byte
- 5: 64 byte

## 【#9221】 DEV1 EIA CODE [

Set the code in hexadecimal, which does not duplicate the existing EIA codes, for the special code "[".

When output with EIA code, data can be output using the alternate code in which the special ISO code, not included in EIA, is specified.

---Setting range---

0 to FF (hexadecimal)

## 【#9222】 DEV1 EIA CODE ]

Set the code in hexadecimal, which does not duplicate the existing EIA codes, for the special code "]".

When output with EIA code, data can be output using the alternate code in which the special ISO code, not included in EIA, is specified.

---Setting range---

0 to FF (hexadecimal)

## 【#9223】 DEV1 EIA CODE #

Set the code in hexadecimal, which does not duplicate the existing EIA codes, for the special code "#".

When output with EIA code, data can be output using the alternate code in which the special ISO code, not included in EIA, is specified. .

---Setting range---

0 to FF (hexadecimal)

## 【#9224】 DEV1 EIA CODE \*

Set the code in hexadecimal, which does not duplicate the existing EIA codes, for the special code "\*".

When output with EIA code, data can be output using the alternate code in which the special ISO code, not included in EIA, is specified.

---Setting range---

0 to FF (hexadecimal)

## 【#9225】 DEV1 EIA CODE =

Set the code in hexadecimal, which does not duplicate the existing EIA codes, for the special code "=".

When output with EIA code, data can be output using the alternate code in which the special ISO code, not included in EIA, is specified.

---Setting range---

0 to FF (hexadecimal)

#### 【#9226】 DEV1 EIA CODE :

Set the code in hexadecimal, which does not duplicate the existing EIA codes, for the special code ":".  
When output with EIA code, data can be output using the alternate code in which the special ISO code, not included in EIA, is specified.

---Setting range---  
0 to FF (hexadecimal)

#### 【#9227】 DEV1 EIA CODE \$

Set the code in hexadecimal, which does not duplicate the existing EIA codes, for the special code "\$".  
When output with EIA code, data can be output using the alternate code in which the special ISO code, not included in EIA, is specified.

---Setting range---  
0 to FF (hexadecimal)

#### 【#9228】 DEV1 EIA CODE !

Set the code in hexadecimal, which does not duplicate the existing EIA codes, for the special code "!".  
When output with EIA code, data can be output using the alternate code in which the special ISO code, not included in EIA, is specified.

---Setting range---  
0 to FF (hexadecimal)

#### 【#9301】 DEV2 DEVICE NAME

Set the device name corresponding to the device No.  
Set a simple name for quick identification.

---Setting range---  
Use alphabet characters, numerals and symbols to set a name within 3 characters.

#### 【#9302】 DEV2 BAUD RATE


Select the serial communication speed.  
0: 19200 (bps)  
1: 9600  
2: 4800  
3: 2400  
4: 1200  
5: 600  
6: 300  
7: 110

#### 【#9303】 DEV2 STOP BIT

Select the stop bit length used in the start-stop system.  
Refer to "#9304 DEV2 PARITY CHECK". At the output of data, the number of characters is always adjusted to for the parity check.  
1: 1 (bit)  
2: 1.5  
3: 2

#### 【#9304】 DEV2 PARITY CHECK

Select whether to add a parity check bit to the data.



Set this parameter in accordance with the I/O device specifications.  
0: Not add a parity bit in I/O mode  
1: Add a parity bit in I/O mode

#### 【#9305】 DEV2 EVEN PARITY

Select whether even or odd parity will be used when parity is used. This parameter is ignored when no parity is added.

- 0: Odd parity
- 1: Even parity

#### 【#9306】 DEV2 CHR. LENGTH

Select the length of the data bit.  
Refer to "#9304 DEV2 PARITY CHECK".

- 0: 5 (bit)
- 1: 6
- 2: 7 (NC connection not supported)
- 3: 8

#### 【#9307】 DEV2 TERMINATR TYP

Select the code to terminate data reading.

- 0, 3: EOR
  - 1, 2: EOB or EOR
- [When M700/700VW display side serial port is selected]
- 0: No terminator
  - 1: EOR
  - 2: EOB
  - 3: EOB or EOR

#### 【#9308】 DEV2 HAND SHAKE

Select the transmission control method.

No handshaking will be used when a value except 1 to 3 is set.

- 1: RTS/CTS method
- 2: No handshaking
- 3: DC code method

#### 【#9309】 DEV2 DC CODE PRY

Select the DC code type when the DC code method is selected.

- 0: Not add parity to DC code (DC3 = 13H)
- 1: Add parity to DC code (DC3 = 93H)

#### 【#9311】 DEV2 DC2/4 OUTPUT

Select the DC code handling when outputting data to the output device.

- DC2 / DC4
- 0: None / None
- 1: Yes / None
- 2: None / Yes
- 3: Yes / Yes

#### 【#9312】 DEV2 CR OUTPUT

Select whether to add the (CR) code just before the EOB (L/F) code during output.

- 0: Not add
- 1: Add

#### 【#9313】 DEV2 EIA OUTPUT

Select ISO or EIA code for data output.

In data input mode, the ISO and EIA codes are identified automatically.

- 0: ISO code output
- 1: EIA code output

#### 【#9314】 DEV2 FEED CHR.

Set the length of the tape feed to be output at the start and end of the data during tape output.

---Setting range---

- 0 to 999 (characters)

#### 【#9315】 DEV2 PARITY V

Select whether to perform the parity check for the number of characters in a block at the input of data.

At the output of data, the number of characters is always adjusted to for the parity check.

0: Not perform parity V check

1: Perform parity V check

#### 【#9316】 DEV2 TIME-OUT (sec)

Set the time out time to detect an interruption in communication.

Time out check will not be executed when set to "0".

---Setting range---

0 to 30 (s)

#### 【#9317】 DEV2 DR OFF

Select whether to enable the DR data check in data I/O mode.

0: Enable

1: Disable

#### 【#9318】 DEV2 DATA ASCII

Select the code of the output data.

0: ISO/EIA code (Depends on whether #9113, #9213, #9313, #9413 or #9513 EIA output parameter is set up.)

1: ASCII code

#### 【#9319】 DEV2 INPUT TYPE

Select the mode for input (verification).

0: Standard input (Data from the very first EOB is handled as significant information.)

1: EOBs following the first EOB of the input data are skipped until data other than EOB is input

#### 【#9320】 DEV2 OUT BUFFER

Select the buffer size of the output data which is output to output device using NC side serial port. If the output device has a transmission error (overrun error), decrease the buffer size with this parameter.

If the buffer size is decreased, output time will prolong according to the size.

0: 250 bytes (default)

1: 1 byte

2: 4 byte

3: 8 byte

4: 16 byte

5: 64 byte

#### 【#9321】 DEV2 EIA CODE [

Set the code in hexadecimal, which does not duplicate the existing EIA codes, for the special code "[ ".

When output with EIA code, data can be output using the alternate code in which the special ISO code, not included in EIA, is specified.

---Setting range---

0 to FF (hexadecimal)

#### 【#9322】 DEV2 EIA CODE ]

Set the code in hexadecimal, which does not duplicate the existing EIA codes, for the special code "]".

When output with EIA code, data can be output using the alternate code in which the special ISO code, not included in EIA, is specified.

---Setting range---

0 to FF (hexadecimal)



#### 【#9323】 DEV2 EIA CODE #

Set the code in hexadecimal, which does not duplicate the existing EIA codes, for the special code "#".  
When output with EIA code, data can be output using the alternate code in which the special ISO code, not included in EIA, is specified.

**---Setting range---**  
0 to FF (hexadecimal)

#### 【#9324】 DEV2 EIA CODE \*

Set the code in hexadecimal, which does not duplicate the existing EIA codes, for the special code "\*".  
When output with EIA code, data can be output using the alternate code in which the special ISO code, not included in EIA, is specified.

**---Setting range---**  
0 to FF (hexadecimal)

#### 【#9325】 DEV2 EIA CODE =

Set the code in hexadecimal, which does not duplicate the existing EIA codes, for the special code "=".  
When output with EIA code, data can be output using the alternate code in which the special ISO code, not included in EIA, is specified.

**---Setting range---**  
0 to FF (hexadecimal)

#### 【#9326】 DEV2 EIA CODE :

Set the code in hexadecimal, which does not duplicate the existing EIA codes, for the special code ":".  
When output with EIA code, data can be output using the alternate code in which the special ISO code, not included in EIA, is specified.

**---Setting range---**  
0 to FF (hexadecimal)

#### 【#9327】 DEV2 EIA CODE \$

Set the code in hexadecimal, which does not duplicate the existing EIA codes, for the special code "\$".  
When output with EIA code, data can be output using the alternate code in which the special ISO code, not included in EIA, is specified.

**---Setting range---**  
0 to FF (hexadecimal)

#### 【#9328】 DEV2 EIA CODE !

Set the code in hexadecimal, which does not duplicate the existing EIA codes, for the special code "!".  
When output with EIA code, data can be output using the alternate code in which the special ISO code, not included in EIA, is specified.

**---Setting range---**  
0 to FF (hexadecimal)

#### 【#9401】 DEV3 DEVICE NAME

Set the device name corresponding to the device No.  
Set a simple name for quick identification.

**---Setting range---**  
Use alphabet characters, numerals and symbols to set a name within 3 characters.

#### 【#9402】 DEV3 BAUD RATE

Select the serial communication speed.

- 0: 19200 (bps)
- 1: 9600
- 2: 4800
- 3: 2400
- 4: 1200
- 5: 600
- 6: 300
- 7: 110

#### 【#9403】 DEV3 STOP BIT


Select the stop bit length used in the start-stop system.

Refer to "#9404 DEV3 PARITY CHECK". At the output of data, the number of characters is always adjusted to for the parity check.

- 1: 1 (bit)
- 2: 1.5
- 3: 2

#### 【#9404】 DEV3 PARITY CHECK

Select whether to add a parity check bit to the data.



Set this parameter in accordance with the I/O device specifications.

- 0: Not add a parity bit in I/O mode
- 1: Add a parity bit in I/O mode

#### 【#9405】 DEV3 EVEN PARITY

Select whether even or odd parity will be used when parity is used. This parameter is ignored when no parity is added.

- 0: Odd parity
- 1: Even parity

#### 【#9406】 DEV3 CHR. LENGTH

Select the length of the data bit.

Refer to "#9404 DEV3 PARITY CHECK".

- 0: 5 (bit)
- 1: 6
- 2: 7 (NC connection not supported)
- 3: 8

#### 【#9407】 DEV3 TERMINATR TYP

Select the code to terminate data reading.

- 0, 3: EOR
  - 1, 2: EOB or EOR
- [When M700/700VW display side serial port is selected]
- 0: No terminator
  - 1: EOR
  - 2: EOB
  - 3: EOB or EOR

#### 【#9408】 DEV3 HAND SHAKE

Select the transmission control method.

No handshaking will be used when a value except 1 to 3 is set.

- 1: RTS/CTS method
- 2: No handshaking
- 3: DC code method

#### 【#9409】 DEV3 DC CODE PRY

Select the DC code type when the DC code method is selected.  
 0: Not add parity to DC code (DC3 = 13H)  
 1: Add parity to DC code (DC3 = 93H)

#### 【#9411】 DEV3 DC2/4 OUTPUT

Select the DC code handling when outputting data to the output device.  
 DC2 / DC4  
 0: None / None  
 1: Yes / None  
 2: None / Yes  
 3: Yes / Yes

#### 【#9412】 DEV3 CR OUTPUT

Select whether to add the (CR) code just before the EOB (L/F) code during output.  
 0: Not add  
 1: Add

#### 【#9413】 DEV3 EIA OUTPUT

Select ISO or EIA code for data output.  
 In data input mode, the ISO and EIA codes are identified automatically.  
 0: ISO code output  
 1: EIA code output

#### 【#9414】 DEV3 FEED CHR.

Set the length of the tape feed to be output at the start and end of the data during tape output.

---Setting range---  
 0 to 999 (characters)

#### 【#9415】 DEV3 PARITY V

Select whether to perform the parity check for the number of characters in a block at the input of data.  
 At the output of data, the number of characters is always adjusted to for the parity check.  
 0: Not perform parity V check  
 1: Perform parity V check

#### 【#9416】 DEV3 TIME-OUT (sec)

Set the time out time to detect an interruption in communication.  
 Time out check will not be executed when set to "0".

---Setting range---  
 0 to 30 (s)

#### 【#9417】 DEV3 DR OFF

Select whether to enable the DR data check in data I/O mode.  
 0: Enable  
 1: Disable

#### 【#9418】 DEV3 DATA ASCII

Select the code of the output data.  
 0: ISO/EIA code (Depends on whether #9113, #9213, #9313, #9413 or #9513 EIA output parameter is set up.)  
 1: ASCII code

#### 【#9419】 DEV3 INPUT TYPE

Select the mode for input (verification).  
 0: Standard input (Data from the very first EOB is handled as significant information.)  
 1: EOBs following the first EOB of the input data are skipped until data other than EOB is input.

#### 【#9420】 DEV3 OUT BUFFER

Select the buffer size of the output data which is output to output device using NC side serial port. If the output device has a data receiving error (overrun error), decrease the buffer size with this parameter.

If the buffer size is decreased, output time will prolong according to the size.

- 0: 250 bytes (default)
- 1: 1 byte
- 2: 4 bytes
- 3: 8 bytes
- 4: 16 bytes
- 5: 64 bytes

#### 【#9421】 DEV3 EIA CODE [

Set the code in hexadecimal, which does not duplicate the existing EIA codes, for the special code "[".

When output with EIA code, data can be output using the alternate code in which the special ISO code, not included in EIA, is specified.

---Setting range---

0 to FF (hexadecimal)

#### 【#9422】 DEV3 EIA CODE ]

Set the code in hexadecimal, which does not duplicate the existing EIA codes, for the special code "]".

When output with EIA code, data can be output using the alternate code in which the special ISO code, not included in EIA, is specified.

---Setting range---

0 to FF (hexadecimal)

#### 【#9423】 DEV3 EIA CODE #

Set the code in hexadecimal, which does not duplicate the existing EIA codes, for the special code "#".

When output with EIA code, data can be output using the alternate code in which the special ISO code, not included in EIA, is specified.

---Setting range---

0 to FF (hexadecimal)

#### 【#9424】 DEV3 EIA CODE \*

Set the code in hexadecimal, which does not duplicate the existing EIA codes, for the special code "\*".

When output with EIA code, data can be output using the alternate code in which the special ISO code, not included in EIA, is specified.

---Setting range---

0 to FF (hexadecimal)

#### 【#9425】 DEV3 EIA CODE =

Set the code in hexadecimal, which does not duplicate the existing EIA codes, for the special code "=".

When output with EIA code, data can be output using the alternate code in which the special ISO code, not included in EIA, is specified.

---Setting range---

0 to FF (hexadecimal)

#### 【#9426】 DEV3 EIA CODE :

Set the code in hexadecimal, which does not duplicate the existing EIA codes, for the special code ":".

When output with EIA code, data can be output using the alternate code in which the special ISO code, not included in EIA, is specified.

---Setting range---

0 to FF (hexadecimal)

#### 【#9427】 DEV3 EIA CODE \$

Set the code in hexadecimal, which does not duplicate the existing EIA codes, for the special code "\$".

When output with EIA code, data can be output using the alternate code in which the special ISO code, not included in EIA, is specified.

---Setting range---

0 to FF (hexadecimal)

#### 【#9428】 DEV3 EIA CODE !

Set the code in hexadecimal, which does not duplicate the existing EIA codes, for the special code "!".

When output with EIA code, data can be output using the alternate code in which the special ISO code, not included in EIA, is specified.

---Setting range---

0 to FF (hexadecimal)

#### 【#9501】 DEV4 DEVICE NAME

Set the device name corresponding to the device No.

Set a simple name for quick identification.

---Setting range---

Use alphabet characters, numerals and symbols to set a name within 3 characters.

#### 【#9502】 DEV4 BAUD RATE

Select the serial communication speed.

0: 19200 (bps)

1: 9600

2: 4800

3: 2400

4: 1200

5: 600

6: 300

7: 110

#### 【#9503】 DEV4 STOP BIT

Select the stop bit length used in the start-stop system.

Refer to "#9504 DEV4 PARITY CHECK". At the output of data, the number of characters is always adjusted to for the parity check.


1: 1 (bit)

2: 1.5

3: 2

#### 【#9504】 DEV4 PARITY CHECK

Select whether to add a parity check bit to the data.



Set this parameter in accordance with the I/O device specifications.

0: Not add a parity bit in I/O mode

1: Add a parity bit in I/O mode

#### 【#9505】 DEV4 EVEN PARITY

Select whether even or odd parity will be used when parity is used. This parameter is ignored when no parity is added.

0: Odd parity

1: Even parity

#### 【#9506】 DEV4 CHR. LENGTH

Select the length of the data bit.  
Refer to "#9504 DEV4 PARITY CHECK".  
0: 5 (bit)  
1: 6  
2: 7 (NC connection not supported)  
3: 8

#### 【#9507】 DEV4 TERMINATR TYP

Select the code to terminate data reading.  
0, 3: EOR  
1, 2: EOB or EOR  
[When M700/700VW display side serial port is selected]  
0: No terminator  
1: EOR  
2: EOB  
3: EOB or EOR

#### 【#9508】 DEV4 HAND SHAKE

Select the transmission control method.  
No handshaking will be used when a value except 1 to 3 is set.  
1: RTS/CTS method  
2: No handshaking  
3: DC code method

#### 【#9509】 DEV4 DC CODE PRY

Select the DC code type when the DC code method is selected.  
0: Not add parity to DC code (DC3 = 13H)  
1: Add parity to DC code (DC3 = 93H)

#### 【#9511】 DEV4 DC2/4 OUTPUT

Select the DC code handling when outputting data to the output device.  
DC2 / DC4  
0: None / None  
1: Yes / None  
2: None / Yes  
3: Yes / Yes

#### 【#9512】 DEV4 CR OUTPUT

Select whether to add the (CR) code just before the EOB (L/F) code during output.  
0: Not add  
1: Add

#### 【#9513】 DEV4 EIA OUTPUT

Select ISO or EIA code for data output.  
In data input mode, the ISO and EIA codes are identified automatically.  
0: ISO code output  
1: EIA code output

#### 【#9514】 DEV4 FEED CHR.

Set the length of the tape feed to be output at the start and end of the data during tape output.

---Setting range---  
0 to 999 (characters)

#### 【#9515】 DEV4 PARITY V

Select whether to perform the parity check for the number of characters in a block at the input of data.  
At the output of data, the number of characters is always adjusted to for the parity check.  
0: Not perform parity V check  
1: Perform parity V check

## [#9516] DEV4 TIME-OUT (sec)

Set the time out time to detect an interruption in communication.  
Time out check will not be executed when set to "0".

**---Setting range---**  
0 to 30 (s)

## [#9517] DEV4 DR OFF

Select whether to enable the DR data check in data I/O mode.  
0: Enable  
1: Disable

## [#9518] DEV4 DATA ASCII

Select the code of the output data.  
0: ISO/EIA code (Depends on whether #9113, #9213, #9313, #9413 or #9513 EIA output parameter is set up.)  
1: ASCII code

## [#9519] DEV4 INPUT TYPE

Select the mode for input (verification).  
0: Standard input (Data from the very first EOB is handled as significant information.)  
1: EOBs following the first EOB of the input data are skipped until data other than EOB is input.

## [#9520] DEV4 OUT BUFFER

Select the buffer size of the output data which is output to output device using NC side serial port.  
If the output device has a transmission error (overrun error), decrease the buffer size with this parameter.  
If the buffer size is decreased, output time will prolong according to the size.  
0: 250 bytes (default)  
1: 1 byte  
2: 4 byte  
3: 8 byte  
4: 16 byte  
5: 64 byte

## [#9521] DEV4 EIA CODE [

Set the code in hexadecimal, which does not duplicate the existing EIA codes, for the special code "[ ".  
When output with EIA code, data can be output using the alternate code in which the special ISO code, not included in EIA, is specified.

**---Setting range---**  
0 to FF (hexadecimal)

## [#9522] DEV4 EIA CODE ]

Set the code in hexadecimal, which does not duplicate the existing EIA codes, for the special code "] ".  
When output with EIA code, data can be output using the alternate code in which the special ISO code, not included in EIA, is specified.

**---Setting range---**  
0 to FF (hexadecimal)

## [#9523] DEV4 EIA CODE #

Set the code in hexadecimal, which does not duplicate the existing EIA codes, for the special code "#".  
When output with EIA code, data can be output using the alternate code in which the special ISO code, not included in EIA, is specified.

**---Setting range---**  
0 to FF (hexadecimal)

#### 【#9524】 DEV4 EIA CODE \*

Set the code in hexadecimal, which does not duplicate the existing EIA codes, for the special code "\*".

When output with EIA code, data can be output using the alternate code in which the special ISO code, not included in EIA, is specified.

**---Setting range---**

0 to FF (hexadecimal)

#### 【#9525】 DEV4 EIA CODE =

Set the code in hexadecimal, which does not duplicate the existing EIA codes, for the special code "=".

When output with EIA code, data can be output using the alternate code in which the special ISO code, not included in EIA, is specified.

**---Setting range---**

0 to FF (hexadecimal)

#### 【#9526】 DEV4 EIA CODE :

Set the code in hexadecimal, which does not duplicate the existing EIA codes, for the special code ":".

When output with EIA code, data can be output using the alternate code in which the special ISO code, not included in EIA, is specified.

**---Setting range---**

0 to FF (hexadecimal)

#### 【#9527】 DEV4 EIA CODE \$

Set the code in hexadecimal, which does not duplicate the existing EIA codes, for the special code "\$".

When output with EIA code, data can be output using the alternate code in which the special ISO code, not included in EIA, is specified.

**---Setting range---**

0 to FF (hexadecimal)

#### 【#9528】 DEV4 EIA CODE !

Set the code in hexadecimal, which does not duplicate the existing EIA codes, for the special code "!".

When output with EIA code, data can be output using the alternate code in which the special ISO code, not included in EIA, is specified.

**---Setting range---**

0 to FF (hexadecimal)

#### 【#9601】 BAUD RATE

Select the rate at which data is transferred.

- 0: 19200 (bps)
- 1: 9600
- 2: 4800
- 3: 2400
- 4: 1200
- 5: 600
- 6: 300
- 7: 110
- 8: 38400

#### 【#9602】 STOP BIT

Select the stop bit length used in the start-stop system.

Refer to "#9603 PARITY EFFECTIVE". At the output of data, the number of characters is always adjusted to for the parity check.


- 1: 1 (bit)
- 2: 1.5
- 3: 2



**【#9603】 PARITY EFFECTIVE**

Select whether to add the parity bit to the data.

The parameter is set when using a parity bit separately from the data bit.



Set this parameter according to the specifications of input/output device.

- 0: Not add a parity bit at the input/output
- 1: Add a parity bit at the input/output

**【#9604】 EVEN PARITY**

Select odd or even when parity is added to the data. This parameter is ignored when no parity is added.

- 0: Odd parity
- 1: Even parity

**【#9605】 CHR. LENGTH**

Select the length of the data bit.

Refer to "#9603 PARITY EFFECTIVE".

- 0: 5 (bit)
- 1: 6
- 2: 7 (NC connection not supported)
- 3: 8

**【#9606】 HAND SHAKE**

Select the transmission control method.

"3" (DC code method) should be set for computer link B.

- 0: No control
- 1: RTS/CTS method
- 2: No handshaking
- 3: DC code method

**【#9607】 TIME-OUT SET**

Set the time-out time at which an interruption of data transfer during data input/output should be detected.

"0" means infinite time-out.

---Setting range---

0 to 999 (1/10s)

**【#9608】 DATA CODE**

Set the code to be used for the data description.

Refer to "#9603 PARITY EFFECTIVE".

- 0: ASCII code
- 1: ISO code

**【#9609】 LINK PARAM. 1****bit1: DC1 output after NAK or SYN**

Select whether to output the DC1 code after the NAK or SYN code is output.

- 0: Not output the DC1 code.
- 1: Output the DC1 code.

**bit7: Enable/disable resetting**

Select whether to enable the resetting in the computer link.

- 0: Enable
- 1: Disable

## 【#9610】 LINK PARAM. 2

### Bit 2: Specify the control code parity (even parity for the control code).

Select whether to add an even parity to the control code, in accordance with the I/O device specifications.

- 0: Not add a parity bit to the control code
- 1: Add a parity bit to the control code

### Bit 3: Parity V

Select whether to enable checking of parity V in one block at the input of the data.

- 0: Disable
- 1: Enable

## 【#9611】 Link PARAM. 3

Not used. Set to "0".

## 【#9612】 Link PARAM. 4

Not used. Set to "0".

## 【#9613】 Link PARAM. 5

Not used. Set to "0".

## 【#9614】 START CODE

Select the code used to command the first transfer of file data.

This parameter is used for a specific user. Normally set "0".

- 0: DC1 (11H)
- 1: BEL (07H)

## 【#9615】 CTRL. CODE OUT

### bit 0: NAK output

Select whether to send the NAK code to the host if a communication error occurs in computer link B.

- 0: Not output the NAK code
- 1: Output the NAK code.

### bit 1: SYN output

Select whether to send the SYN code to the host if NC resetting or an emergency stop occurs in computer link B.

- 0: Not output the SYN code.
- 1: Output the SYN code.

### bit 3: DC3 output

Select whether to send the DC3 code to the host when the communication ends in computer link B.

- 0: Not output the DC3 code.
- 1: Output the DC3 code.

## 【#9616】 CTRL. INTERVAL

Not used. Set to "0".

## 【#9617】 WAIT TIME

Not used. Set to "0".

## 【#9618】 PACKET LENGTH

Not used. Set to "0".

## 【#9619】 BUFFER SIZE

Not used. Set to "0".

## 【#9620】 START SIZE

Not used. Set to "0".

**【#9621】 DC1 OUT SIZE**

Not used. Set to "0".

**【#9622】 POLLING TIMER**

Not used. Set to "0".

**【#9623】 TRANS. WAIT TMR**

Not used. Set to "0".

**【#9624】 RETRY COUNTER**

Not used. Set to "0".

**【#9701(PR)】 IP addr auto set**

The IP address is automatically assigned from the server.

0: Manual setting

1: Automatic setting

(Note) When the automatic setting is selected, "#11005 PC IP address, PC Subnet, PC Gateway" will be invalid.

**【#9706】 Host No.**

Select the No. of the host to be used from host 1 to host 4.

---Setting range---

1 to 4 : Host No.

**【#9711】 Host1 host name**

Set the host computer name.

This parameter allows the NC to easily recognize the host computer on the network. Set the host computer's name (name registered in C:\windows\hosts) or the IP address.

<Setting example>

For host name: mspc160

For IP address: 150.40.0.111

(Note) Set the host computer's TCP/IP address if communication is not carried out correctly.

---Setting range---

15 characters (alphanumeric) or less

**【#9712】 Host1 user name**

Set the user name when logging into the host computer.

---Setting range---

15 characters (alphanumeric) or less

**【#9713】 Host1 password**

Set the password when logging into the host computer.

---Setting range---

15 characters (alphanumeric) or less

**【#9714】 Host1 directory**

Set the directory name of the host computer.

The directory released to the client (NC unit) with the host computer's server is handled as root directory by the NC unit.

---Setting range---

31 characters (alphanumeric) or less

### **【#9715】 Host1 host type**

Select the type of the host computer.

- 0: UNIX/PC automatic judgment
- 1: UNIX
- 2: PC (DOS)

(Note) When "0" is set, the settings for the following parameters will be invalid.

- #9716 Wrd pos: name
- #9717 Wrd pos: size
- #9718 Wrd pos: Dir
- #9719 Wrd pos: cmnt
- #9720 Wrd num: cmnt

### **【#9716】 Host 1 Wrd pos: name**

Set the file name display position (nth word from left) of the list displayed when the ftp command "dir" is executed.

(Note) One word designates a character string divided by one or more spaces.

**---Setting range---**

- 0 to 100
- 0: Default value

### **【#9717】 Host 1 Wrd pos: size**

Set the size display position (nth word from left) of the list displayed when the ftp command "dir" is executed.

(Note) One word designates a character string divided by one or more spaces.

**---Setting range---**

- 0 to 100
- 0: Default value

### **【#9718】 Host 1 Wrd pos: Dir**

Set the <DIR> display position (nth word from left) of the list displayed when the ftp command "dir" is executed.

(Note) One word designates a character string divided by one or more spaces.

**---Setting range---**

- 0 to 100
- 0: Default value

### **【#9719】 Host 1 Wrd pos: cmnt**

Set the comment (date, time, etc.) display position (nth word from left) of the list displayed when the ftp command "dir" is executed.

(Note) One word designates a character string divided by one or more spaces.

**---Setting range---**

- 0 to 100
- 0: Default value

### **【#9720】 Host 1 Wrd num: cmnt**

Set the number of words to be displayed as a comment.

(Note) One word designates a character string divided by one or more spaces.

**---Setting range---**

- 0 to 100
- 0: Default value

### **【#9721】 Host 1 no total siz**

Set whether to display the total number of characters registered in the machining programs of host1 when displaying the file list.  
 If there are many files in the directory to be referred to, the list can be updated quickly by setting "1".  
 0: Display  
 1: Not display

### **【#9731】 Host2 host name**

Set the host computer name.  
 This parameter allows the NC to easily recognize the host computer on the network. Set the host computer's name (name registered in C:\windows\hosts) or the IP address.  
 <Setting example>  
 For host name: mspc160  
 For IP address: 150.40.0.111  
 (Note) Set the host computer's TCP/IP address if communication is not carried out correctly.

---Setting range---  
 15 characters (alphanumeric) or less

### **【#9732】 Host2 user name**

Set the user name when logging into the host computer.

---Setting range---  
 15 characters (alphanumeric) or less

### **【#9733】 Host2 password**

Set the password when logging into the host computer.

---Setting range---  
 15 characters (alphanumeric) or less

### **【#9734】 Host2 directory**

Set the directory name of the host computer.  
 The directory released to the client (NC unit) with the host computer's server is handled as the root directory by the NC unit.

---Setting range---  
 31 characters (alphanumeric) or less

### **【#9735】 Host2 host type**

Select the type of the host computer.  
 0: UNIX/PC automatic judgment  
 1: UNIX  
 2: PC (DOS)

(Note) When "0" is set, the settings for the following parameters will be invalid.

- #9736 Wrd pos: name
- #9737 Wrd pos: size
- #9738 Wrd pos: Dir
- #9739 Wrd pos: cmnt
- #9740 Wrd num: cmnt

### **【#9736】 Host 2 Wrd pos: name**

Set the file name display position (nth word from left) of the list displayed when the ftp command "dir" is executed.

(Note) One word designates a character string divided by one or more spaces.

---Setting range---  
 0 to 100  
 0: Default value

#### **【#9737】 Host 2 Wrd pos: size**

Set the size display position (nth word from left) of the list displayed when the ftp command "dir" is executed.

(Note) One word designates a character string divided by one or more spaces.

**---Setting range---**

0 to 100

0: Default value

#### **【#9738】 Host 2 Wrd pos: Dir**

Set the <DIR> display position (nth word from left) of the list displayed when the ftp command "dir" is executed.

(Note) One word designates a character string divided by one or more spaces.

**---Setting range---**

0 to 100

0: Default value

#### **【#9739】 Host 2 Wrd pos: cmnt**

Set the comment (date, time, etc.) display position (nth word from left) of the list displayed when the ftp command "dir" is executed.

(Note) One word designates a character string divided by one or more spaces.

**---Setting range---**

0 to 100

0: Default value

#### **【#9740】 Host 2 Wrd num: cmnt**

Set the number of words to be displayed as a comment.

(Note) One word designates a character string divided by one or more spaces.

**---Setting range---**

0 to 100

0: Default value

#### **【#9741】 Host 2 no total siz**

Set whether to display the total number of characters registered in the machining programs of host1 when displaying the file list.

If there are many files in the directory to be referred to, the list can be updated quickly by setting "1".

0: Display

1: Not display

#### **【#9751】 Host3 host name**

Set the host computer name.

This parameter allows the NC to easily recognize the host computer on the network. Set the host computer's name (name registered in C:\windows\hosts) or the IP address.

<Setting example>

For host name: mspc160

For IP address: 150.40.0.111

(Note) Set the host computer's TCP/IP address if communication is not carried out correctly.

**---Setting range---**

15 characters (alphanumeric) or less

#### **【#9752】 Host3 user name**

Set the user name when logging into the host computer.

**---Setting range---**

15 characters (alphanumeric) or less

## 【#9753】 Host3 password

Set the password when logging into the host computer.

### ---Setting range---

15 characters (alphanumeric) or less

## 【#9754】 Host3 directory

Set the directory name of the host computer.

The directory released to the client (NC unit) with the host computer's server is handled as the root directory by the NC unit.

### ---Setting range---

31 characters (alphanumeric) or less

## 【#9755】 Host3 host type

Select the type of the host computer.

0: UNIX/PC automatic judgment

1: UNIX

2: PC (DOS)

(Note) When "0" is set, the settings for the following parameters will be invalid.

- #9756 Wrd pos: name

- #9757 Wrd pos: size

- #9758 Wrd pos: Dir

- #9759 Wrd pos: cmnt

- #9760 Wrd num: cmnt

## 【#9756】 Host 3 Wrd pos: name

Set the file name display position (nth word from left) of the list displayed when the ftp command "dir" is executed.

(Note) One word designates a character string divided by one or more spaces.

### ---Setting range---

0 to 100

0: Default value

## 【#9757】 Host 3 Wrd pos: size

Set the size display position (nth word from left) of the list displayed when the ftp command "dir" is executed.

(Note) One word designates a character string divided by one or more spaces.

### ---Setting range---

0 to 100

0: Default value

## 【#9758】 Host 3 Wrd pos: Dir

Set the <DIR> display position (nth word from left) of the list displayed when the ftp command "dir" is executed.

(Note) One word designates a character string divided by one or more spaces.

### ---Setting range---

0 to 100

0: Default value

#### **【#9759】 Host 3 Wrd pos: cmnt**

Set the comment (date, time, etc.) display position (nth word from left) of the list displayed when the ftp command "dir" is executed.

(Note) One word designates a character string divided by one or more spaces.

**---Setting range---**

0 to 100

0: Default value

#### **【#9760】 Host 3 Wrd num: cmnt**

Set the number of words to be displayed as a comment.

(Note) One word designates a character string divided by one or more spaces.

**---Setting range---**

0 to 100

0: Default value

#### **【#9761】 Host 3 no total siz**

Set whether to display the total number of characters registered in the machining programs of host1 when displaying the file list.

If there are many files in the directory to be referred to, the list can be updated quickly by setting "1".

0: Display

1: Not display

#### **【#9771】 Host4 host name**

Set the host computer name.

This parameter allows the NC to easily recognize the host computer on the network. Set the host computer's name (name registered in C:\windows\hosts) or the IP address.

<Setting example>

For host name: mspc160

For IP address: 150.40.0.111

(Note) Set the host computer's TCP/IP address if communication is not carried out correctly.

**---Setting range---**

15 characters (alphanumeric) or less

#### **【#9772】 Host4 user name**

Set the user name when logging into the host computer.

**---Setting range---**

15 characters (alphanumeric) or less

#### **【#9773】 Host4 password**

Set the password when logging into the host computer.

**---Setting range---**

15 characters (alphanumeric) or less

#### **【#9774】 Host4 directory**

Set the directory name of the host computer.

The directory released to the client (NC unit) with the host computer's server is handled as the root directory by the NC unit.

**---Setting range---**

31 characters (alphanumeric) or less



## 【#9775】 Host4 host type

Select the type of the host computer.

- 0: UNIX/PC automatic judgment
- 1: UNIX
- 2: PC (DOS)

(Note) When "0" is set, the settings for the following parameters will be invalid.

- #9776 Wrd pos: name
- #9777 Wrd pos: size
- #9778 Wrd pos: Dir
- #9779 Wrd pos: cmnt
- #9780 Wrd num: cmnt

## 【#9776】 Host 4 Wrd pos: name

Set the file name display position (nth word from left) of the list displayed when the ftp command "dir" is executed.

(Note) One word designates a character string divided by one or more spaces.

### ---Setting range---

- 0 to 100
- 0: Default value

## 【#9777】 Host 4 Wrd pos: size

Set the size display position (nth word from left) of the list displayed when the ftp command "dir" is executed.

(Note) One word designates a character string divided by one or more spaces.

### ---Setting range---

- 0 to 100
- 0: Default value

## 【#9778】 Host 4 Wrd pos: Dir

Set the <DIR> display position (nth word from left) of the list displayed when the ftp command "dir" is executed.

(Note) One word designates a character string divided by one or more spaces.

### ---Setting range---

- 0 to 100
- 0: Default value

## 【#9779】 Host 4 Wrd pos: cmnt

Set the comment (date, time, etc.) display position (nth word from left) of the list displayed when the ftp command "dir" is executed.

(Note) One word designates a character string divided by one or more spaces.

### ---Setting range---

- 0 to 100
- 0: Default value

## 【#9780】 Host 4 Wrd num: cmnt

Set the number of words to be displayed as a comment.

(Note) One word designates a character string divided by one or more spaces.

### ---Setting range---

- 0 to 100
- 0: Default value

**【#9781】 Host 4 no total siz**

Set whether to display the total number of characters registered in the machining programs of host1 when displaying the file list.

If there are many files in the directory to be referred to, the list can be updated quickly by setting "1".

0: Display

1: Not display

# **【#10501 - 10530(PR)】 Monitr main menu 1 to 30**

Set the menu Nos. to display the menu on Monitor screen's main menu using menu customization function.

The menu position of each parameter and the menu when "0" is set are as follows.

- #10501: First from left in the page 1 (when "0" is set: Search)
- #10502: Second from left in the page 1 (when "0" is set: Research)
- #10503: Third from left in the page 1 (when "0" is set: Edit)
- #10504: Fourth from left in the page 1 (when "0" is set: Trace)
- #10505: Fifth from left in the page 1 (when "0" is set: Check)
- #10506: Sixth from left in the page 1 (when "0" is set: Cnt exp)
- #10507: Seventh from left in the page 1 (when "0" is set: Offset)
- #10508: Eighth from left in the page 1 (when "0" is set: Coord)
- #10509: Ninth from left in the page 1 (when "0" is set: Cnt set)
- #10510: Tenth from left in the page 1 (when "0" is set: MST)
- #10511: First from left in the page 2 (when "0" is set: Modal)
- #10512: Second from left in the page 2 (when "0" is set: Tree)
- #10513: Third from left in the page 2 (when "0" is set: Time)
- #10514: Fourth from left in the page 2 (when "0" is set: Com var)
- #10515: Fifth from left in the page 2 (when "0" is set: Loc var)
- #10516: Sixth from left in the page 2 (when "0" is set: P corr)
- #10517: Seventh from left in the page 2 (when "0" is set: PLC SW)
- #10518: Eighth from left in the page 2 (when "0" is set: G92 set)
- #10519: Ninth from left in the page 2 (when "0" is set: Col stp)
- #10520: Tenth from left in the page 2 (when "0" is set: LD MTR)
- #10521: First from left in the page 3 (when "0" is set: Sp-stby)
- #10522: Second from left in the page 3 (when "0" is set: TipDisp)
- #10523: Third from left in the page 3 (when "0" is set: All sp)
- #10524: Fourth from left in the page 3 (when "0" is set: MST)
- #10525: Fifth from left in the page 3 (when "0" is set: Not display)
- #10526: Sixth from left in the page 3 (when "0" is set: Not display)
- #10527: Seventh from left in the page 3 (when "0" is set: Not display)
- #10528: Eighth from left in the page 3 (when "0" is set: Not display)
- #10529: Ninth from left in the page 3 (when "0" is set: Not display)
- #10530: Tenth from left in the page 3 (when "0" is set: Not display)

- Menu No. --
- 1: Not display
  - 0: Default
  - 1: Search
  - 2: Research
  - 3: Edit
  - 4: Trace
  - 5: Check
  - 6: Cnt exp
  - 7: Offset
  - 8: Coord
  - 9: Cnt set
  - 10: MST
  - 11: Modal
  - 12: Tree
  - 13: Time
  - 14: Com var
  - 15: Loc var
  - 16: P corr
  - 17: PLC SW
  - 18: G92 set
  - 19: Col stp
  - 20: LD MTR
  - 21: Sp-stby
  - 22: TipDisp
  - 23: All sp
  - 24: MST

(Note) If the menu No. for "Not display" is set for the main menu, that menu will not be displayed.

**【#10551 - 10580(PR)】 Setup main menu 1 to 30**

Set the menu Nos. to display the menu on Setup screen's main menu using menu customization function.

The menu position of each parameter and the menu when "0" is set are as follows.

#10551: First from left in the page 1 (when "0" is set: T-ofs)  
 #10552: Second from left in the page 1 (when "0" is set: T-meas)  
 #10553: Third from left in the page 1 (when "0" is set: T-reg)  
 #10554: Fourth from left in the page 1 (when "0" is set: T-life)  
 #10555: Fifth from left in the page 1 (when "0" is set: Coord)  
 #10556: Sixth from left in the page 1 (when "0" is set: W-meas)  
 #10557: Seventh from left in the page 1 (when "0" is set: User)  
 #10558: Eighth from left in the page 1 (when "0" is set: MDI)  
 #10559: Ninth from left in the page 1 (when "0" is set: Cnt set)  
 #10560: Tenth from left in the page 1 (when "0" is set: MST)  
 #10561: First from left in the page 2 (when "0" is set: T-list)  
 #10562: Second from left in the page 2 (when "0" is set: Pallet)  
 #10563: Third from left in the page 2 (when "0" is set: Not display)  
 #10564: Fourth from left in the page 2 (when "0" is set: Not display)  
 #10565: Fifth from left in the page 2 (when "0" is set: Not display)  
 #10566: Sixth from left in the page 2 (when "0" is set: Not display)  
 #10567: Seventh from left in the page 2 (when "0" is set: Not display)  
 #10568: Eighth from left in the page 2 (when "0" is set: Not display)  
 #10569: Ninth from left in the page 2 (when "0" is set: Not display)  
 #10570: Tenth from left in the page 2 (when "0" is set: Not display)  
 #10571: First from left in the page 3 (when "0" is set: Not display)  
 #10572: Second from left in the page 3 (when "0" is set: Not display)  
 #10573: Third from left in the page 3 (when "0" is set: Not display)  
 #10574: Fourth from left in the page 3 (when "0" is set: Not display)  
 #10575: Fifth from left in the page 3 (when "0" is set: Not display)  
 #10576: Sixth from left in the page 3 (when "0" is set: Not display)  
 #10577: Seventh from left in the page 3 (when "0" is set: Not display)  
 #10578: Eighth from left in the page 3 (when "0" is set: Not display)  
 #10579: Ninth from left in the page 3 (when "0" is set: Not display)  
 #10580: Tenth from left in the page 3 (when "0" is set: Not display)

-- Menu No. --  
 -1: Not display  
 0: Default  
 1: T-ofs  
 2: T-meas  
 3: T-reg  
 4: T-life  
 5: Coord  
 6: W-meas  
 7: User  
 8: MDI  
 9: Cnt set  
 10: MST  
 11: T-list  
 12: Pallet

(Note) If the menu No. for "Not display" is set for the main menu, that menu will not be displayed.

## Appendix 1 Explanation of Parameters

### 【#10601 - 10630(PR)】 Edit main menu 1 to 30

Set the menu Nos. to display the menu on Edit screen's main menu using menu customization function.

The menu position of each parameter and the menu when "0" is set are as follows.

- #10601: First from left in the page 1 (when "0" is set: Edit)
- #10602: Second from left in the page 1 (when "0" is set: Check)
- #10603: Third from left in the page 1 (when "0" is set: NAVI)
- #10604: Fourth from left in the page 1 (when "0" is set: Not display)
- #10605: Fifth from left in the page 1 (when "0" is set: I/O)
- #10606: Sixth from left in the page 1 (when "0" is set: Not display)
- #10607: Seventh from left in the page 1 (when "0" is set: Not display)
- #10608: Eighth from left in the page 1 (when "0" is set: Not display)
- #10609: Ninth from left in the page 1 (when "0" is set: Not display)
- #10610: Tenth from left in the page 1 (when "0" is set: Not display)
- #10611: First from left in the page 2 (when "0" is set: Not display)
- #10612: Second from left in the page 2 (when "0" is set: Not display)
- #10613: Third from left in the page 2 (when "0" is set: Not display)
- #10614: Fourth from left in the page 2 (when "0" is set: Not display)
- #10615: Fifth from left in the page 2 (when "0" is set: Not display)
- #10616: Sixth from left in the page 2 (when "0" is set: Not display)
- #10617: Seventh from left in the page 2 (when "0" is set: Not display)
- #10618: Eighth from left in the page 2 (when "0" is set: Not display)
- #10619: Ninth from left in the page 2 (when "0" is set: Not display)
- #10620: Tenth from left in the page 2 (when "0" is set: Not display)
- #10621: First from left in the page 3 (when "0" is set: Not display)
- #10622: Second from left in the page 3 (when "0" is set: Not display)
- #10623: Third from left in the page 3 (when "0" is set: Not display)
- #10624: Fourth from left in the page 3 (when "0" is set: Not display)
- #10625: Fifth from left in the page 3 (when "0" is set: Not display)
- #10626: Sixth from left in the page 3 (when "0" is set: Not display)
- #10627: Seventh from left in the page 3 (when "0" is set: Not display)
- #10628: Eighth from left in the page 3 (when "0" is set: Not display)
- #10629: Ninth from left in the page 3 (when "0" is set: Not display)
- #10630: Tenth from left in the page 3 (when "0" is set: Not display)

- Menu No. --
- 1: Not display
- 0: Default
- 1: Edit
- 2: Check
- 3: NAVI
- 5: I/O

(Note) If the menu No. for "Not display" is set for the main menu, that menu will not be displayed.

### 【#10801】 Notice tel num 1

Set the call-back telephone No. used for one-touch call and operator notification.  
Begin with the No. from an area code for domestic call.  
Begin with a communication company No. for international call.  
Hyphens "-" can be used as a delimiting character.

---Setting range---  
Within 28 characters

### 【#10802】 Comment 1

Set a comment, such as a party's name, for the notification party telephone No.1.

---Setting range---  
Within 20 alphanumerical characters  
(excluding spaces)

#### 【#10803】 Notice tel num 2

Set the call-back telephone No. used for one-touch call and operator notification.  
Begin with the No. from an area code for domestic call.  
Begin with a communication company No. for international call.  
Hyphens "-" can be used as a delimiting character.

**---Setting range---**

Within 28 characters

#### 【#10804】 Comment 2

Set a comment, such as a party's name, for the notification party telephone No.2.

**---Setting range---**

Within 20 alphanumerical characters  
(excluding spaces)

#### 【#10805】 Notice tel num 3

Set the call-back telephone No. used for one-touch call and operator notification.  
Begin with the No. from an area code for domestic call.  
Begin with a communication company No. for international call.  
Hyphens "-" can be used as a delimiting character.

**---Setting range---**

Within 28 characters

#### 【#10806】 Comment 3

Set a comment, such as a party's name, for the notification party telephone No.3.

**---Setting range---**

Within 20 alphanumerical characters  
(excluding spaces)

#### 【#10807】 Password

Set the password for sharing of machining data.

**---Setting range---**

4 characters (one-byte alphanumeric characters, without space)

#### 【#10808】 Customer number

Set the user No. for sharing of machining data.

**---Setting range---**

Within 8 characters (one-byte alphanumeric characters, without space)

#### 【#10812】 Anshin-net valid

Select whether to enable the Anshin-net function.

0: Disable  
1: Enable

#### 【#10813】 MTBnet enable

Select whether to enable the machine tool builder network system.

0: Disable  
1: Enable  
Standard setting: 0

(Note) Values other than "0" and "1" are invalid.

# 【#10814】 OP-notice condition

Select the condition of an NC for delivering an operator notification.

- 0: When the "automatic operation is starting" signal turns off. (Notifies the alarm if an alarm occurs, and if not, notifies the completion of machining.)
- 1: If the designated "#10971 Complete condition" changes into "#10972 Complete CND num", or the "automatic operation is starting" signal turns off due to an alarm.(Notifies the alarm if an alarm occurs at the change of device condition, and if not, notifies the completion of machining.)
- 2: When the "automatic operation is starting" signal turns off due to an alarm.

# 【#10815】 OP-notice mode

Select whether to cancel the mode after delivering an operator notification.

- 0: Cancel
- 1: Not cancel. Cancel the mode by screen operation.

# 【#19001】 Syn.tap(,S)cancel

- 0: Retain the spindle speed (,S) in synchronous tap return
- 1: Cancel the spindle speed (,S) in synchronous tap return with G80

# 【#19002】 Zero-point mark

Select the position for displaying the zero point mark in the graphic trace and 2D check.

- 0: Machine coordinates zero point (same as conventional method)
- 1: Workpiece coordinate zero point

# 【#19003】 PRG coord rot type

Select the start point of the initial travel command after program coordinate rotation command.

- 0: Calculate the end position using the current position on the local coordinate system before rotating, without rotating the start point in accordance with the coordinates rotation.
- 1: Calculate the end position, assuming that the start point rotates in accordance with the coordinates rotation.

# 【#19004】 Tap feedrate limit

Set the upper limit of the cutting feed rate in synchronous tapping.

---Setting range---  
0 to 1000(mm/rev)

(Note)Setting "0" disables this parameter.

When the commanded cutting feed rate in synchronous tapping exceeds this setting, a program error (P184) will occur.

# 【#19005】 manual Fcmd2 clamp

Set a clamp speed coefficient (%) for manual speed command 2.

The feed rate is clamped at the command feed rate or rapid traverse rate for automatic operation, which was multiplied by this parameter's value.

(Note)This setting is valid only for manual speed command 2.

---Setting range---  
0 to 1000 (%)  
0: 100% (Default value)

# 【#19006(PR)】 EOR Disable

Set whether to handle an EOR(%) in machining program as the end of program in automatic operation, graphic check, program transfer to NC memory, program editing, and buffer correction. Tape operation, Computer Link B, and serial input/output are not included.

- 0: An EOR(%) is handled as the end of machining program.
- 1: An EOR(%) is not handled as the end of machining program. The program will be read to the end of file.

# 【#19401】 G33.n chamfer spd

Set the chamfering speed in C axis interpolation type thread cutting.

---Setting range---  
1 to 1000000 (mm/min)

#### 【#19405】 Rotary ax drawing

Specify this parameter to draw a path of C axis (rotary axis) according to its rotation in the graphic trace and 2D graphic trace.

When "#1013 axname" is set to "C", the axis is handled as a rotary axis.

By setting this parameter to "C", a rotation path around the Z axis on actual workpiece can be expressed.

When the Graphic check rotary axis drawing option or Graphic trace rotary axis drawing option is disabled, this parameter is ignored.

C : Enable this function

0 : Disable this function

(Setting is cleared when "0" is set)

#### 【#19425】 ManualB Std R1

Set a radius used as standard for the rotary axis speed.

When the setting value of #19425 is larger than that of "#19427 ManualB Std R2", #19425 setting will be used as surface speed control standard radius 2: #19427 setting will be used as surface speed control standard radius 1.

**---Setting range---**

0 to 99999.999 (mm)

#### 【#19426】 ManualB Std F1

This sets the rotary axis speed for surface speed control standard radius 1 (ManualB Std R1).

When the setting value of #19426 is larger than that of "#19428 ManualB Std F2", #19426 setting will be used as surface speed control standard speed 2: #19427 setting will be used as surface speed control standard speed 1.

**---Setting range---**

1 to 1000000 (°/min)

#### 【#19427】 ManualB Std R2

Set a radius used as standard for the rotary axis speed.

When the same value is set as "#19425 ManualB Std R1", the surface speed control standard speed 1 (ManualB Std F1) will be selected as the rotary axis speed if the radius is less than that value. The surface speed control standard speed 2 (ManualB Std F2) is selected if larger than the set value.

**---Setting range---**

0 to 99999.999 (mm)

#### 【#19428】 ManualB Std F2

Set the rotary axis speed for surface speed control standard radius 2 (ManualB Std R2).

**---Setting range---**

1 to 1000000 (°/min)



## Appendix 1.2 Base Specifications Parameters

The parameters with "(PR)" requires the CNC to be turned OFF after the settings. Turn the power OFF and ON to enable the parameter settings.

### 【#1001(PR)】 SYS\_ON System validation setup

Select the existence of PLC axes and part systems.  
0: Not exist  
1: Exist

### 【#1002(PR)】 axisno Number of axes

Set the number of control axes and PLC axes.  
A total of 16 axes can be set.  
Control axis: 0 to 8  
PLC axis: 0 to 6

When set to "0", the number of control axes in the part system will be "0". Do not set the number of control axes of the first part system to "0".

(Note) The setting range differs according to the model.

### 【#1003(PR)】 iunit Input setup unit

Select the input setting value for each part system and the PLC axis.  
Increments in parameters will follow this selection.  
B : 1  $\mu$  m  
C : 0.1  $\mu$  m  
D : 0.01  $\mu$  m (10nm)  
E : 0.001  $\mu$  m (1nm)

### 【#1004(PR)】 ctrl\_unit Control unit

Select the control increment for each part system and PLC axis.  
Select the increment for the NC internal position data, communication data between the NC and drive unit, and the servo travel data. Although the standard value is "D", set the optimum value according to the series and specification.  
B : 1  $\mu$  m  
C : 0.1  $\mu$  m  
D : 0.01  $\mu$  m (10nm)  
E : 0.001  $\mu$  m (1nm)

### 【#1005(PR)】 plcunit PLC unit

Select the PLC interface setting and display increment.  
The PLC interface setting and display increment will follow this specification. Note that the PLC axis will follow "#1003 iunit".  
B : 1  $\mu$  m  
C : 0.1  $\mu$  m  
D : 0.01  $\mu$  m (10nm)  
E : 0.001  $\mu$  m (1nm)

### 【#1006(PR)】 mcmpunit Machine error compensation unit

Select the machine error compensation setting and display increment.  
The parameters related to machine error compensation (backlash, pitch error compensation, etc.) and PLC interface (external machine coordinate system compensation) will follow this selection.  
B : 1  $\mu$  m  
C : 0.1  $\mu$  m  
D : 0.01  $\mu$  m (10nm)  
E : 0.001  $\mu$  m (1nm)

### 【#1007(PR)】 System type select System type select

Select the NC system type.  
0: Machining center system (M system)  
1: Lathe system (L system)

(Note 1) If the setting value is out of range, M system will be selected.

(Note 2) This parameter is valid only for M700VS/M70V/M70 Series. (M700/M700VW series doesn't support this parameter.)

### 【#1010(PR)】 srvunit Output unit (servo)

Select the output increment to servo. Although the standard value is "D", set the optimum value according to the series and specification.

B : 1  $\mu$  m  
C : 0.1  $\mu$  m  
D : 0.01  $\mu$  m (10nm)  
E : 0.001  $\mu$  m (1nm)

### 【#1013(PR)】 axname Axis name

Set each axis' name with an alphabetic character.  
Use the characters X, Y, Z, U, V, W, A, B or C.

(Note 1) Do not set the same name twice in one part system.

The same name which is used in another part system can be set.

(Note 2) The PLC name does not need to be set. (Numbers 1 to 6 are shown as the axis names.)

---Setting range---

X,Y,Z,U,V,W,A,B,C

### 【#1014(PR)】 incax Increment command axis name

Set the axis name when commanding an incremental value for the axis travel amount.  
Available alphabets are the same as in "#1013 axname".

(Note 1) Set an alphabet that is different from that of "#1013 axname".

(Note 2) Setting is not required if absolute/incremental specification with axis names is not performed ("#1076 AbsInc" = "0").

---Setting range---

X, Y, Z, U, V, W, A, B, C

### 【#1015(PR)】 cunit Program command unit

Set the minimum increment of program travel command.

cunit Travel amount for travel command 1

0: Follow "#1003 iunit"  
1: 0.0001 mm (0.1  $\mu$  m)  
10: 0.001 mm (1  $\mu$  m)  
100: 0.01 mm (10  $\mu$  m)  
1000: 0.1 mm (100  $\mu$  m)  
10000: 1.0 mm

If there is a decimal point in travel command, the decimal point position will be handled as 1mm regardless of this setting.

### 【#1017(PR)】 rot Rotational axis

Select whether the axis is a rotary axis or linear axis.

When rotary axis is set, the axis will be controlled with the rotary axis's coordinate system. Set the rotary axis type with "#8213 Rotation axis type".

0: Linear axis  
1: Rotary axis

### 【#1018(PR)】 ccw Motor CCW

Select the direction of the motor rotation to the command direction.

0: Clockwise (looking from motor shaft) with the forward rotation command  
1: Counterclockwise (looking from motor shaft) with the forward rotation command

## Appendix 1 Explanation of Parameters

### 【#1019(PR)】 dia Diameter specification axis

Select the command method of program travel amount.

When the travel amount is commanded with the diameter dimensions, the travel distance will be 5mm when the command is 10mm of travel distance.

The travel amount per pulse will also be halved during manual pulse feed.

If diameter is selected, tool length, the wear compensation amount, and the workpiece coordinate offset will be displayed in diameter value. Other parameters concerning length will always be displayed in radius value.

0: Command with travel amount

1: Command with diameter dimension

### 【#1020(PR)】 sp\_ax Spindle Interpolation


Select "1" when using the spindle for the contour control of NC axis (C-axis).

0: Servo axis is used for contour control.

1: Spindle is used for contour control.

### 【#1021(PR)】 mcp\_no Drive unit I/F channel No. (servo)

Using a 4-digit number, set the drive unit interface channel No. and which axis in that channel is to be used when connecting a servo drive unit.



### 【#1022(PR)】 axname2 2nd axis name

Set the name of the axis displayed on the screen with two characters. (X1, Z2, etc.)

Always use an alphabetic character (A to Z) for the first character.

#### ---Setting range---

A to Z and 1 to 9 (Two digits)

(Setting will be cleared when "0" is set)

### 【#1023(PR)】 crsadr Command address during mixed control (cross axis control)

Set the axis name for issuing a command to this axis during mixed control (cross axis control).

#### ---Setting range---

A to Z

(Setting will be cleared when "0" is set)

### 【#1024(PR)】 crsinc Incremental command address during mixed control (cross axis control)

Set the axis name for issuing an incremental command to this axis during mixed control (cross axis control).

#### ---Setting range---

A to Z

(Setting will be cleared when "0" is set)

### 【#1025】 l\_plane Initial plane selection

Select the plane to be selected when the power is turned ON or reset.

0: X-Y plane (G17 command state)

1: X-Y plane (G17 command state)

2: Z-X plane (G18 command state)

3: Y-Z plane (G19 command state)

### 【#1026】 base\_I Base axis I

Set the names of the basic axes that compose the plane.  
Set the axis name set in "#1013 axname".  
If all three items ("base\_I", "base\_J" and "base\_K") do not need to be set, such as for 2-axis specifications, input "0", and the parameter will be blank.  
Normally, when X, Y and Z are specified respectively for base\_I, \_J, \_K, the following relation will be established:  
G17: X-Y  
G18: Z-X  
G19: Y-Z  
Specify the desired axis name to set an axis address other than above.

#### ---Setting range---

Axis names such as X, Y or Z

### 【#1027】 base\_J Base axis J

Set the names of the basic axes that compose the plane.  
Set the axis name set in "#1013 axname".  
If all three items ("base\_I", "base\_J" and "base\_K") do not need to be set, such as for 2-axis specifications, input "0", and the parameter will be blank.  
Normally, when X, Y and Z are specified respectively for base\_I, \_J, \_K, the following relation will be established:  
G17: X-Y  
G18: Z-X  
G19: Y-Z  
Specify the desired axis name to set an axis address other than above.

#### ---Setting range---

Axis names such as X, Y or Z

### 【#1028】 base\_K Base axis K

Set the names of the basic axes that compose the plane.  
Set the axis name set in "#1013 axname".  
If all three items ("base\_I", "base\_J" and "base\_K") do not need to be set, such as for 2-axis specifications, input "0", and the parameter will be blank.  
Normally, when X, Y and Z are specified respectively for base\_I, \_J, \_K, the following relation will be established:  
G17: X-Y  
G18: Z-X  
G19: Y-Z  
Specify the desired axis name to set an axis address other than above.

#### ---Setting range---

Axis names such as X, Y or Z

### 【#1029】 aux\_I Flat axis I

Set the axis name when there is an axis parallel to "#1026 base\_I".

#### ---Setting range---

Axis names such as X, Y or Z

### 【#1030】 aux\_J Flat axis J

Set the axis name when there is an axis parallel to "#1027 base\_J".

#### ---Setting range---

Axis names such as X, Y or Z

### 【#1031】 aux\_K Flat axis K

Set the axis name when there is an axis parallel to "#1028 base\_K".

#### ---Setting range---

Axis names such as X, Y or Z

## Appendix 1 Explanation of Parameters

### 【#1037(PR)】 cmdtyp Command type

Set the G code list and compensation type for programs.

- 1 : List1(for M)      Type A (one compensation amount for one compensation No.)
- 2 : List1(for M)      Type B (shape and wear compensation amounts for one comp. No.)
- 3 : List2(for L)      Type C (shape and wear compensation amounts for one comp. No.)
- 4 : List3(for L)      Ditto
- 5 : List4(for special L)      Ditto
- 6 : List5(for special L)      Ditto
- 7 : List6(for special L)      Ditto
- 8 : List7(for special L)      Ditto
- 9 : List8(for M)      M2 form at type A      Type A  
(one compensation amount for one compensation No.)
- 10 : List8(for M)      M2 form at type B      Type B  
(shape and wear compensation amounts for one compensation No.)

There are some items in the specifications that can be used or cannot be used according to the value set in this parameter.

The file structure may also change depending on the compensation data type.

### 【#1038】 plcsl Ladder selection

Not used. Set to "0".

### 【#1039(PR)】 spinno Number of spindles

Select the number of spindles.

- 0: No spindle
- 1 to 6: One to six spindles

(Note) The setting range differs according to the model.

### 【#1040(PR)】 M\_inch Constant input (inch)

Select the unit system for setting and display regarding machine parameter and PLC interface's position, length and speed.

- 0: Metric system
- 1: Inch system

### 【#1041(PR)】 I\_inch Initial state (inch)

Select the unit system for the program travel amount when the power is turned ON or reset and for position display.

- 0: Metric system
- 1: Inch system

(Note) The units of the following data are converted by "#1041 I\_inch".

- Command unit at power ON and reset (Inch/metric command mode)  
But under the following conditions, the unit will follow G20/G21 command modal even at reset.  
When reset modal is retained ("#1151 rstint"="0")  
When G code group 06 reset modal is retained ("#1210 RstGmd/bit5" ON)
- Unit system for position display (counter, user parameter, tool, work offset)
- User parameter I/O unit
- Parameter unit of user parameters concerning length and speed
- Arc error parameter (#1084 RadErr)
- PLC interface unit related to function manual arc feed

### 【#1042(PR)】 pcinch PLC axis command (inch)

Select the unit system for the commands to the PLC axis.

- 0: Metric system
- 1: Inch system

### 【#1043】 lang Select language displayed

Select the display language.  
 0: English (Standard)  
 1: Japanese (Standard)  
 11: German (Option)  
 12: French (Option)  
 13: Italian (Option)  
 14: Spanish (Option)  
 15: Traditional Chinese (Option)  
 16: Korean (Option)  
 17: Portuguese (Option)  
 18: Dutch (Option)  
 19: Swedish (Option)  
 20: Hungarian (Option)  
 21: Polish (Option)  
 22: Simplified Chinese (Option)  
 23: Russian (Option)  
 24: Turkish (Option)  
 25: Czech (Option)

(Note) A language which can be displayed is different according to each series.

### 【#1044(PR)】 auxno MR-J2-CT Connections

Set the number of MR-J2-CTs connected.

(Note) The number of MR-J2-CTs possible to connect and setting range are different according to the model.  
 Check the specifications of each series.

### 【#1050(PR)】 MemPrg

Not used. Set to "0".

### 【#1051(PR)】 MemTol Tool compensation memory common for part systems

0: Tool compensation memory separate for part systems  
 1: Tool compensation memory common for part systems

### 【#1052(PR)】 MemVal No. of common variables shared in part system designation

0: Common variables common for part systems (number fixed)  
 #100 - : Per part system  
 #500 - : Common for part systems  
 1: Common variables common for part systems (number designation)  
 #100 - : Designate with V1comN  
 #500 - : Designate with V0comN

(Note) When this parameter is changed, the file system will be changed after the power is turned ON.  
 So always execute format.  
 The new format will be enabled after turning the power ON again.

Setting order

(1) MemVal changeover -> (2) Turn power ON again -> (3) Format -> (4) Turn power ON again

### 【#1061(PR)】 intabs Manual ABS updating

Select whether to update the absolute position data during automatic handle interrupt.  
 This parameter is enabled only when "#1145 l\_abs" is set to "1".  
 0: Do not update (coordinate system shifted the amount of the interruption)  
 1: Update (same coordinates as when interrupt did not occur will be applied)

#### 【#1062】 T\_cmp Tool compensation function

Select whether the tool length compensation and wear compensation are enabled during T command execution.

0 : Tool length compensation enable	Wear compensation enable
1 : Tool length compensation enable	Wear compensation disable
2 : Tool length compensation disable	Wear compensation enable
3 : Tool length compensation disable	Wear compensation disable

#### 【#1063】 mandog Manual dog-type

Select the manual reference position return method for the second return (after the coordinate system is established) and later.

The initial reference position return after the power ON is performed with dog-type return, and the coordinate system will be established.

(This setting is not required when the absolute position detection is used.)

- 0: High speed return
- 1: Dog-type

#### 【#1064(PR)】 svof Error correction

Select whether to correct the error when the servo is OFF.

- 0: Not correct the error
- 1: Correct the error

#### 【#1068(PR)】 slavno Secondary axis number

Set the axis number of the secondary axis in synchronous control.

The axis number is an NC number excluding the spindle and PLC axis.

Two or more secondary axes cannot be set for one primary axis.

This parameter cannot be set for a secondary axis.

When using the multi-part system, the relation of the primary axis and secondary axis cannot extend over part systems.

- 0: No secondary axis
- 1 to 16: First to sixteenth axis

#### 【#1069】 no\_dsp Axis with no counter display

Select whether to display the axis counter or not.

This setting is enabled on the counter display screen (relative position counter, etc.).

- 0: Display
- 1: Not display

#### 【#1070】 axoff Axis removal

Select whether to enable or disable axis removal control.

- 0: Disable
- 1: Enable

#### 【#1072】 chop\_ax Chopping axis

Select the chopping axis.

- 0: Non-chopping axis
- 1: Chopping axis

#### 【#1073】 I\_Absm Initial absolute setting

Select the mode (absolute or incremental) at turning ON the power or reset.

- 0: Incremental setting
- 1: Absolute setting

#### 【#1074】 I\_Sync Initial synchronous feed

Select the feedrate mode at turning ON the power or reset.

- 0: Asynchronous feed (feed per minute)
- 1: Synchronous feed (feed per revolution)

#### 【#1075】 I\_G00 Initial G00

Select the linear command mode at turning ON the power or reset.

- 0: Linear interpolation (G01 command state)
- 1: Positioning (G00 command state)

**【#1076】 AbsInc ABS/INC address (for L system only)**

Select the command method for the absolute and incremental commands.

- 0: Use G command for the absolute and incremental commands.
- 1: Use axis name for the absolute and incremental commands.

(The axis name in "#1013 axname" will be the absolute command, "#1014 incax" will be the incremental command.)

When "1" is selected, using two axis names, one each for the absolute and incremental commands, allows to issue the absolute and incremental commands appropriately to an axis.

**【#1077】 radius Incremental command for diameter specification axis**

Select whether the incremental command of the diameter specification axis ("#1019 dia" is set to "1") uses the diameter value or radius value.

- 0: Diameter value
- 1: Radius value

**【#1078】 Decpt2 Decimal point type 2**

Select the increment of position commands that do not have a decimal point.

- 0: Minimum input command unit (follows "#1015 cunit")
- 1: 1mm (or 1inch) unit (For the dwell time, 1s unit is used.)

**【#1079】 F1digit Validate F1 digit**

Select the F command method.

- 0: Direct numerical command (command feedrate during feed per minute or rotation)
- 1: 1-digit code command (feedrate set with "#1185 spd\_F1" to "#1189 spd\_F5")

**【#1080】 Dril\_Z Specify boring axis (for M system only)**

Select a fixed cycle hole drilling axis.

- 0: Use an axis vertical to the selected plane as hole drilling axis.
- 1: Use the Z axis as the hole drilling axis regardless of the selected plane.

**【#1081】 Gmac\_P Give priority to G code parameter**

Select the G code priority relationship during the macro call with G command.

- 0: Priority is on G code used in the system
- 1: Priority is on registered G code for call

**【#1082】 Geomet Geometric**

Select the type of geometric to use.

- 0: Not use
- 1: Use only geometric I
- 2: Use geometric I and IB

With geometric, specific address codes are used for exclusive meanings. Thus, if A or C is used for the axis name or 2nd miscellaneous command code, the A used for the axis name may function as the geometric's angle designation. Pay special attention to axis names, etc., when using this function.

**【#1084】 RadErr Arc error**

Set the tolerable error range when the end point deviates from the center coordinate in the circular command.

---Setting range---  
0 to 1.000 (mm)

**【#1085】 G00Drn G00 dry run**

Select whether to apply dry run (feed at manual setting speed instead of command feedrate) to the G00 command.

- 0: Not apply to G00. (move at rapid traverse rate)
- 1: Apply to G00. (move at manual setting speed)



**【#1086】 G0Intp G00 non-interpolation**

Select the G00 travel path type.

- 0: Move linearly toward the end point. (interpolation type)
- 1: Move to the end point of each axis at the rapid traverse feedrate for each axis. (non-interpolation)

(Note) If this parameter is set to "1", neither of the following functions will be available: rapid traverse constant inclination acceleration/deceleration and rapid traverse constant inclination multi-step acceleration/deceleration.

**【#1087】 G96\_G0 Constant surface speed control by rapid traverse feed command**

Select how to handle the surface speed for the G00 command when using the constant surface speed control function.

- 0: Calculate the surface speed constantly even during G00 movement
- 1: Calculate the surface speed at the block end point in the G00 command

**【#1088】 G30SL Disable G30 soft limit**

Select how to handle the soft limit during G30 (2nd reference position return).

- 0: Enable
- 1: Disable

**【#1091】 Mpoint Ignore middle point**

Select how to handle the middle point during G28 and G30 reference position return.

- 0: Pass the middle point designated in the program and move to the reference position.
- 1: Ignore the middle point designated in the program and move straight to the reference position.

**【#1092】 Tchg\_A Replace tools for additional axis**

Select the movement of the additional axis at the tool change position return command.

- 0: The additional axis will not move
- 1: After the standard axis returns, the additional axis will also return to the tool change position

**【#1093】 Wmvfin Synchronization between part systems method**

Select the timing of synchronization between part systems when using the multi-part system.

When the travel command is found in the synchronization command (I, M) block:

- 0: Synchronize before executing travel command
- 1: Synchronize after executing travel command

**【#1094】 TI\_SBK Select life count for single block (for L system only)**

Select whether to count the data units to be used for single block operation when using the tool life management II function (L system).

- 0: Not count
- 1: Count

**【#1095】 T0tfof TF output**

Select how to handle TF for T00 command.

- 0: TF will be output
- 1: TF wont be output

**【#1096(PR)】 T\_Ltyp Tool life management type**

Select the tool life management type.

- 1: Life management I  
In this type, how long and how many times the program commanded tool is used are accumulated to monitor the usage state.
- 2: Life management II  
This method is the same as tool life management I, but with the spare tool selection function. A spare tool is selected from a group of tool commands commanded in the program. Tool compensation (tool length compensation and tool radius compensation) is carried out for the selected tool.
- 3: Life management III (for M system only)  
The usage time, frequency of use or the wear amount of the tool which is designated by the program is accumulated, and the tool usage state is monitored.  
It is not managed by the group number.  
(Note) When "3" is set for the L system, the Life management I is selected.

**【#1097】 Tldigt Tool wear compensation number 1-digit command**

- Select the number of digits of the tool wear compensation No. in the T command.
- 0: The 2 high-order digits are the tool No., and the 2 low-order digits are the wear compensation No.
  - 1: The 3 high-order digits are the tool No., and the 1 low-order digit is the wear compensation No.

This parameter will be fixed to "0" when tool life management II is selected.

**【#1098】 Tlno. Tool length offset number**

- Select the number of digits of the tool length compensation No. in the T command.
- 0: The 2 or 3 high-order digits are the tool No.  
The 2 or 1 low-order digits are the tool length compensation and wear compensation Nos.
  - 1: The 2 or 3 high-order digits are the tool No. and tool length compensation Nos.  
The 2 or 1 low-order digits are the wear compensation No.

**【#1099】 Treset Cancel tool compensation amount**

- Select how to handle the tool compensation vector when resetting the system.
- 0: Clear the tool length and wear compensation vectors when resetting
  - 1: Hold the tool length and wear compensation vectors when resetting

When the values are cleared, the compensation will not be applied. So the axis will be shifted by the compensation amount in the next compensation operation.

When the values are kept, the compensation will be applied, so the axis will shift the differential amount of the compensation amount in the next compensation operation.

**【#1100】 Tmove Tool compensation**

- Select when to perform tool length compensation and wear compensation.
- 0: Compensate when T command is executed.
  - 1: Superimpose and compensate with the travel command in the block where the T command is located. If there is no travel command in the same block, compensation will be executed after the travel command is superimposed in the next travel command block.
  - 2: Compensate the wear amount when the T command is executed. Superimpose and compensate the tool length compensation amount with the travel command in the same block. If there is no travel command in the same block, compensation will be executed after the travel command is superimposed in the next travel command block.

**【#1101】 Tabsmv Tool compensation method**

- Select the type of travel command when "#1100 Tmove" is set to "1" or "2".
- 0: Compensate regardless of the travel command type
  - 1: Compensate only at the travel command in the absolute command

**【#1102】 tlm Manual tool length measuring system (for L system only)**

- Select the measurement method for manual tool measurement I.
- 0: Align tool with basic point
  - 1: Input measurement results

(Note) Interpreted as "0" when other than "0" or "1" is set.

**【#1103】 T\_Life Validate life management**

- Select whether to use the tool life management.
- 0: Not use
  - 1: Use

**【#1104】 T\_Com2 Tool command method 2**

- Select how to handle the tool command in the program when "#1103 T\_Life" is set to "1".
- 0: Handle the command as group No.
  - 1: Handle the command as tool No.

(Note) In the case of the tool life management III, the program tool command will be handled as the tool No. regardless of the setting.

**【#1105】 T\_Sel2 Tool selection method 2**

Select the tool selection method when "#1103 T\_Life" is set to "1".

0: Select in order of registered No. from the tools used in the same group.

1: Select the tool with the longest remaining life from the tools used or unused in the same group.

**【#1106】 Tcount Life management (for L system only)**

Select the input method when address N is omitted in inputting the data (G10 L3 command) for tool life management function II.

0: Time specified input

1: Number of times specified input

**【#1107】 TlIfsc Split life management display screen (for L system only)**

Set the number of groups to be displayed on the tool life management II (L system) screen.

0: Displayed group count 1, maximum number of registered tools: 16

1: Displayed group count 2, maximum number of registered tools: 8

2: Displayed group count 4, maximum number of registered tools: 4

**【#1108】 TirectM Life management re-count M code (for L system only)**

Set the M code for tool life management II (L system) re-count.

---Setting range---

0 to 99

**【#1109】 subs\_M Validate alternate M code**

Select the user macro interrupt with the substitute M code.

0: Disable alternate M code

1: Enable alternate M code

**【#1110】 M96\_M M96 alternate M code**

Set an M code to replace M96 when "#1109 subs\_M" is set to "1".

---Setting range---

3 to 97 (excluding 30)

**【#1111】 M97\_M M97 alternate M code**

Specify an M code to replace M97 when #1109 subs\_M is set to 1.

---Setting range---

3 to 97 (excluding 30)

**【#1112(PR)】 S\_TRG Validate status trigger method**

Select the enable conditions for the user macro interrupt signal (UIT).

0: Enable when interrupt signal (UIT) turns ON

1: Enable when interrupt signal (UIT) is ON

**【#1113(PR)】 INT\_2 Validate interrupt method type 2**

Select the performance after user macro interrupt signal (UIT) input.

0: Execute interrupt program without waiting for block being executed to end

1: Execute interrupt program after completing block being executed

**【#1114】 mcrint Macro argument initialization**

Select whether to clear statements other than specified arguments by macro call.

Also select whether to clear local variables by power-ON and resetting.

0: Clear the non-specified arguments by macro call.

1: Hold non-specified arguments by macro call

2: Hold non-specified arguments by macro call, and clear local variables by power-ON and resetting

#### **【#1115】 thwait Waiting for thread cutting**

Set the queue number during screw thread cutting when chamfering is disabled.

##### **---Setting range---**

0 to 99 (Approx. 4 ms)  
Standard setting value: 4

#### **【#1116】 G30SLM Invalidate soft limit (manual operation)**

Enable this function when disabling the soft limit check function at the second to fourth reference position return.

0: Enable soft limit function  
1: Disable soft limit function

#### **【#1117(PR)】 H\_sens**

Select the handle response mode during handle feed.

0: Standard  
1: High-speed

#### **【#1118】 mirr\_A Select how to set up the length of tools on cutter tables (opposed tables) (for L system only)**

Select one of the following two methods:

- Set the current length of tools on each facing turret.
  - Set a value, assuming that the tools on each facing turret are in the same direction as that of those on the base turret.
- 0: Current length of the tools on each facing turret  
1: Value, assuming that the tools on each facing turret are in the same direction as that of those on the base turret

#### **【#1119】 Tmiron Select the mirror image of each facing turret with T command (for L system only)**

Select whether to enable the mirror image of each facing turret with the T command.

0: Disable  
1: Enable

#### **【#1120(PR)】 TofVal Change macro variable**

Select whether to change the macro variable (tool offset) numbers for shape compensation and wear compensation.

0: Not change (Conventional specification)  
1: Change the shape and wear compensation variable numbers each for X, Z, and R

#### **【#1121】 edlk\_c Edit lock C**

Select the edit lock for program Nos. 9000 to 9999 in memory.

0: Editing possible  
1: Editing prohibited. The file cannot be opened.

(Note) If “#1122” is set to “1” or “2”, “1” will be set in “#1121” when the power is turned ON.

#### **【#1122(PR)】 pglk\_c Program display lock C**

Select whether to prohibit the program display and search for program Nos. 9000 to 9999 in memory.

0: Program display and search is possible  
1: Program display is impossible. Search is possible.  
2: Program display and search is impossible

(Note) If “#1122” is set to “1” or “2”, “1” will be set in “#1121” when the power is turned ON.

#### **【#1123】 origin Origin set prohibit**

Select whether to use the origin set function.

0: Use  
1: Not use

**【#1124】 ofsfix Fix tool compensation No.**

Select how to handle the compensation No. when the input key is pressed on the tool compensation screen.

- 0: Increment the compensation No. by 1 (Same as general parameters)
- 1: # compensation No. does not change

When setting in sequence, "0" is handler. When changing and setting repeatedly while adjusting one compensation value, "1" is handler

**【#1125】 real\_f Actual feedrate display**

Select the feedrate display on the monitor screen.

- 0: Command speed
- 1: Actual travel feedrate

**【#1126】 PB\_G90 Playback G90**

Select the method to command the playback travel amount in the playback editing.

- 0: Incremental value
- 1: Absolute value

**【#1127】 DPRINT DPRINT alignment**

Select the alignment for printing out with the DPRINT function.

- 0: No alignment, output s printed with left justification
- 1: Align the minimum digit and output

**【#1128】 RstVCI Clear variables by resetting**

Select how to handle the common variables when resetting.

- 0: Common variables won't change after resetting.
- 1: The following common variables will be cleared by resetting:
  - #100 to #149 when 100 sets of variables are provided.
  - #100 to #199 when 200 sets or more of variables are provided.

**【#1129】 PwrVCI Clear variables by power-ON**

Select how to handle the common variables when the power is turned ON.

- 0: The common variables are in the same state as before turning the power OFF.
- 1: The following common variables will be cleared when the power is turned ON:
  - #100 to #149 when 100 sets of variables are provided.
  - #100 to #199 when 200 sets or more of variables are provided.

**【#1130】 set\_t Display selected tool number**

Select the tool command value display on the POSITION screen.

- 0: Display T-modal value of program command
- 1: Display Tool No. sent from PLC

**【#1132】 brightness**

Select the brightness of display unit.

- 1: High brightness (in bright state)
- 0: Medium brightness
- 1: Low brightness (in dim state)

(Note) This setting is valid only for M700VW/M700VS/M70V/M70 Series.

Set this to "0" for M700 series display as it has no brightness control function.

**【#1133】 ofsmem**

Not used. Set to "0".

**【#1134】 LCDneg**

Not used. Set to "0".

**【#1135】 unt\_nm Unit name**

Set the unit name.  
Set with 4 or less characters consisting of both alphabets and numbers.  
If "0" is set, the unit name won't be displayed.

**---Setting range---**

4 or less characters consisting of both alphabets and numbers

**【#1136】 optype**

Not used. Set to "0".

**【#1137】 Cntsel**

Not used. Set to "0".

**【#1138】 Pnosel**

Not used. Set to "0".

**【#1139】 edtype**

Not used. Set to "0".

**【#1140】 Mn100 M code number**

Set the first number of M code that corresponds to the setup Nos. from 100 to 199.

**---Setting range---**

0 to 99999999

**【#1141】 Mn200 M code number**

Set the first number of M code that corresponds to the setup Nos. from 200 to 299.

**---Setting range---**

0 to 99999999

**【#1142】 Mn300 M code number**

Set the first number of M code that corresponds to the setup Nos. from 300 to 399.

**---Setting range---**

0 to 99999999

**【#1143】 Mn400 M code number**

Set the first number of M code that corresponds to the setup Nos. from 400 to 499.

**---Setting range---**

0 to 99999999

**【#1144】 mdlkof MDI setup lock**

Select whether to enable MDI setting in non-MDI mode.  
0: Disable MDI setting  
1: Enable MDI setting

**【#1145】 l\_abs Manual ABS parameter**

Select how to handle the absolute position data during automatic handle interrupt.  
0: Absolute position data will be renewed if manual ABS switch is ON. If it is OFF, data won't be renewed.  
1: Follow the "intabs" state when "#1061 intabs" is enabled

**【#1146】 Sclamp Spindle rotation speed clamp function**

Select how to handle the spindle rotation speed clamp function with the G92S command.  
 0: G92S command is handled as a clamp command only in the G96 state (during constant surface speed control).  
 G92S will be handled as normal S command in G97 state (constant surface speed OFF).  
 1: The S command in the same block as G92 is constantly handled as a clamp command

**【#1147】 smin\_V Minimum spindle rotation speed clamp type**

Specify the type of spindle min. rotation speed clamp value.  
 0: Rotation speed setting  
 1: Output voltage coefficient setting

Set "#3023 smini" according to this type setting.

**【#1148】 I\_G61 Initial high precision**

Set the high accuracy control mode for the modal state when the power is turned ON.  
 0: G64 (cutting mode) at power ON  
 1: G61.1 (high-accuracy control mode) at power ON

**【#1149】 cireft Arc deceleration speed change**

Select whether to decelerate at the arc entrance or exit.  
 0: Not decelerate  
 1: Decelerate

**【#1151】 rstint Reset initial**

Select whether to initialize (power ON state) the modals by resetting.  
 0: Not initialize modal state  
 1: Initialize modal state

**【#1153】 FixbDc Hole bottom deceleration check**

Select whether to perform a deceleration check or in-position check at the hole bottom in a hole drilling cycle. This parameter is enabled only for a hole drilling cycle in which no dwell command can be issued at the hole bottom.  
 0: Perform no deceleration check and in-position check  
 1: Perform deceleration check  
 2: Perform in-position check

**【#1154(PR)】 pdoor**

Not used. Set to "0".

**【#1155】 DOOR\_m**

Not used. Set to "100".

---Setting range---  
 100

**【#1156】 DOOR\_s**

Not used. Set to "100".

---Setting range---  
 100

**【#1157】 F0atr**

Not used. Set to "0".

**【#1158】 F0atno**

Not used. Set to "0".

#### **【#1163(PR)】 No rio RIO connection detection invalid**

Select whether to enable or disable RIO connection detection.

- 0: Enable
- 1: Disable

If your I/O consists of only cards such as CC-LINK, setting this parameter to "1" will avoid the RIO communication cutoff alarm.

#### **【#1164(PR)】 ATS Automatic tuning function**

Select whether to enable or disable the automatic tuning function.

- 0: Disable
- 1: Enable

(Note) Enable this parameter when using MS Configurator.

#### **【#1166】 fixpro Fixed cycle editing**

Select a type of program dealt on the edit/program list/data in/out screen, general program, fixed cycle, or machine tool builder macro program.

- 0: General programs can be edited, etc.
- 1: Fixed cycles can be edited, etc.

Password No.: The machine tool builder macro programs can be edited, etc.

---Setting range---

0 to 99999999

#### **【#1167】 e2rom**

Not used. Set to "0".

#### **【#1168】 test Simulation test**

Select the test mode for the control unit.

In the test mode, test is performed with a hypothetical reference position return complete even though the real reference position return hasn't been completed. This is limited to test operation of the control unit itself, and must not be used when the machine is connected.

- 0: Normal operation mode
- 1: Test mode

#### **【#1169】 part system name Part system name**

Set the name of each part system.

This must be set only when using multi-part system.

This name will be displayed on the screen only when the part systems must be identified.

Use a max. of four alphabetic characters or numerals.

---Setting range---

A max. of four alphabetic characters or numerals.

#### **【#1170】 M2name Second miscellaneous code**

Set this address code when using the 2nd miscellaneous command. Set an address with A, B or C that is not used for "#1013 axname" or "#1014 incax".

---Setting range---

A, B, C

#### **【#1171】 taprov Tap return override**

Set the tap return override value for the synchronous tapping.

When "0" is set, it will be regarded as 100%.

---Setting range---

0 to 100 (%)

#### **【#1172】 tapovr Tap return override**

Set the override value when leaving the tap end point in the synchronous tapping cycle.

When "0" is set, 100 % is applied for the operation.

---Setting range---

0 to 999 (%)



### 【#1173】 dwlskp G04 skip condition

Set the skip signal for ending the G04 (dwell) command.

PLC interface input signal

Skip3 Skip2 Skip1

0 :	-	-	-
1 :	-	-	*
2 :	-	*	-
3 :	-	*	*
4 :	*	-	-
5 :	*	-	*
6 :	*	*	-
7 :	*	*	*

(\* : Enable - : Disable)

### 【#1174】 skip\_F G31 skip speed

Set the feedrate when there is no F command in the program at G31 (skip) command.

---Setting range---

1 to 999999 (mm/min)

### 【#1175】 skip1 G31.1 skip condition

Designate the skip signal in multi-step skip G31.1.

The setting method is same as "#1173".

### 【#1176】 skip1f G31.2 skip speed

Set the skip feedrate in multi-step skip G31.1.

---Setting range---

1 to 999999 (mm/min)

### 【#1177】 skip2 G31.2 skip condition

Set the skip signal in multi-step skip G31.2.

The setting method is same as "#1173".

### 【#1178】 skip2f G31.2 skip speed

Set the skip signal in multi-step skip G31.2.

---Setting range---

1 to 999999 (mm/min)

### 【#1179】 skip3 G31.3 skip condition

Set the skip signal in multi-step skip G31.3

The setting method is same as "#1173".

### 【#1180】 skip3f G31.3 skip speed

Set the skip signal in multi-step skip G31.3.

---Setting range---

1 to 999999 (mm/min)

### 【#1181】 G96\_ax Constant surface speed axis

Select the axis to be targeted for constant surface speed control.

0: Program setting will be disabled, and the axis will always be fixed to the 1st axis

1: 1st axis

2: 2nd axis

3: 3rd axis

:

8: 8th axis

However, when set to other than "0", the priority will be on the program setting.

**【#1182】 thr\_F Thread cutting speed**

Set the screw cut up speed when not using chamfering in the thread cutting cycle.  
0: Cutting feed clamp feedrate  
1 to 60000 mm/min: Setting feedrate

---Setting range---  
0 to 60000 (mm/min)

**【#1183】 clmp\_M M code for clamp**

Set the M code for C axis clamp in hole drilling cycle.

---Setting range---  
0 to 99999999

**【#1184】 clmp\_D Dwelling time after outputting M code for unclamp**

Set the dwell time after outputting the M code for C axis unclamp in hole drilling cycle.

---Setting range---  
0.000 to 99999.999 (s)

**【#1185】 spd\_F1 F1 digit feedrate F1**

Set the feedrate for the F command in the F 1-digit command ("#1079 F1digit" is set to "1").  
Feedrate when F1 is issued (mm/min)  
When "#1246 set08/bit6" is set to "1" and F 1-digit feed is commanded, the feedrate can be increased/decreased by operating the manual handle.

---Setting range---  
0 to 1000000 (mm/min)

**【#1186】 spd\_F2 F1 digit feedrate F2**

Set the feedrate for the F command in the F 1-digit command ("#1079 F1digit" is set to "1").  
Feedrate when F2 is issued (mm/min)  
When "#1246 set08/bit6" is set to "1" and F 1-digit feed is commanded, the feedrate can be increased/decreased by operating the manual handle.

---Setting range---  
0 to 1000000 (mm/min)

**【#1187】 spd\_F3 F1 digit feedrate F3**

Set the feedrate for the F command in the F 1-digit command ("#1079 F1digit" is set to "1").  
Feedrate when F3 is issued (mm/min)  
When "#1246 set08/bit6" is set to "1" and F 1-digit feed is commanded, the feedrate can be increased/decreased by operating the manual handle.

---Setting range---  
0 to 1000000 (mm/min)

**【#1188】 spd\_F4 F1 digit feedrate F4**

Set the feedrate for the F command in the F 1-digit command ("#1079 F1digit" is set to "1").  
Feedrate when F4 is issued (mm/min)  
When "#1246 set08/bit6" is set to "1" and F 1-digit feed is commanded, the feedrate can be increased/decreased by operating the manual handle.

---Setting range---  
0 to 1000000 (mm/min)

**【#1189】 spd\_F5 F1 digit feedrate F5**

Set the feedrate for the F command in the F 1-digit command ("#1079 F1digit" is set to "1").  
Feedrate when F5 is issued (mm/min)  
When "#1246 set08/bit6" is set to "1" and F 1-digit feed is commanded, the feedrate can be increased/decreased by operating the manual handle.

---Setting range---  
0 to 1000000 (mm/min)

## Appendix 1 Explanation of Parameters

### 【#1190(PR)】 s\_xcnt Validate inclined axis control (for L system only)

Select whether to enable or disable inclined axis control.  
 0: Disable inclined axis control  
 1: Enable inclined axis control

### 【#1191(PR)】 s\_angl Inclination angle (for L system only)

Set the inclination angle (  $\theta$  ).  
 (Note) When set to "0", the angle determined by three-side setting will be applied.

---Setting range---  
 -80.000 to 80.000 (°)

### 【#1192(PR)】 s\_zrmv Compensation at reference position return (for L system only)

Select whether to perform compensation for the base axis corresponding to the inclined axis at reference position return.  
 0: Perform compensation  
 1: Not perform compensation

### 【#1193】 inpos Deceleration check method 1/ Validate in-position check

The definitions are changed with the setting of "#1306 InpsTyp Deceleration check specification type".  
 <When Deceleration check method 1 is selected>  
 Select the deceleration check method for G0.  
 0: Command deceleration check  
 1: In-position check  
 <When Deceleration check method 2 is selected>  
 Select the deceleration confirmation method for the positioning or cutting command.  
 0: G0, G1+G9 Command deceleration check  
 1: G0, G1+G9 In-position check

### 【#1194】 H\_acdc Time constant 0 for handle feed

Select the time constant for manual handle feed.  
 0: Use time constant for G01  
 1: Time constant 0 (step)

### 【#1195】 Mmac Macro call for M command

Select whether to enable or disable M command macro call of user macro.  
 0: Disable  
 1: Enable

### 【#1196】 Smac Macro call for S command

Select whether to enable or disable S command macro call of user macro.  
 0: Disable  
 1: Enable

### 【#1197】 Tmac Macro call for T command

Select whether to enable or disable T command macro call of user macro.  
 0: Disable  
 1: Enable

### 【#1198】 M2mac Macro call with 2nd miscellaneous code

Select whether to enable or disable 2nd miscellaneous command macro call of user macro.  
 0: Disable  
 1: Enable

### 【#1199】 Sselect Select initial spindle control

Select the initial condition of spindle control after power is turned ON.  
 0: 1st spindle control mode (G43.1)  
 1: Selected spindle control mode (G44.1)  
 2: All spindle simultaneously control mode (G47.1)

(Note) Spindle No. when G44.1 is commanded is selected with "#1534 SnG44.1".

**【#1200(PR)】 G0\_acc Validate acceleration and deceleration with inclination angle constant G0**

Select the acceleration and deceleration type when a rapid traverse command is issued.  
0: Acceleration and deceleration with constant time (conventional type)  
1: Acceleration and deceleration with a constant angle of inclination

(Note) When rapid traverse constant inclination multi-step acceleration/deceleration is valid, this parameter will be invalid.

**【#1201(PR)】 G1\_acc Validate acceleration and deceleration with inclination constant G1**

Select the acceleration and deceleration type when a linear interpolation command is issued.  
0: Acceleration and deceleration with constant time (conventional type)  
1: Acceleration and deceleration with a constant angle of inclination

**【#1202】 mirofs Distance between facing turrets (for L system only)**

Set the distance between tools (edges) (between facing turrets).

---Setting range---  
0 to 99999.999 (mm)

**【#1203】 TmirS1 Select turrets as facing turrets with T command (for L system only)**

Select the turrets, which correspond to the tool Nos. 1 to 32, as facing turrets for T code mirror image.

---Setting range---  
0 to FFFFFFFF

**【#1204】 TmirS2 Select turrets as facing turrets with T command (for L system only)**

Select the turrets, which correspond to the tool Nos. 33 to 64, as facing turrets for T code mirror image.

---Setting range---  
0 to FFFFFFFF

**【#1205】 G0bdcc Acceleration and deceleration before G0 interpolation**

0: Post-interpolation acceleration/deceleration is applied to G00.  
1: Pre-interpolation acceleration/deceleration is applied to G00 even in the high accuracy control mode.  
2: Rapid traverse constant inclination multi-step acceleration/deceleration is enabled.

(Note) "1" cannot be set for the 2nd part system and the following.


**【#1206】 G1bF Maximum speed**

Set a cutting feedrate when applying pre-interpolation acceleration/deceleration.  
When high-accuracy control time constant expansion is valid, set the maximum of cutting feed clamp speed of each axis.

---Setting range---  
1 to 999999 (mm/min)

### 【#1207】 G1btL Time constant

Set a cutting feed time constant when applying pre-interpolation acceleration/deceleration.  
When set to "0", the time constant will be clamped at 1ms.



#### ---Setting range---

Without high-accuracy control time constant expansion: 0 to 5000 (ms)

With high-accuracy control time constant expansion: 0 to 30000 (ms)

### Cutting feed Acc Cutting feed acceleration

Displays cutting feed acceleration.

### 【#1208】 RCK Arc radius error compensation factor

Set a coefficient for arc radius error compensation.

An arc radius error compensation amount can be increased or decreased between -60.0 and +20.0%.

#### ---Setting range---

-60.0 to +20.0 (%)

### 【#1209】 cirdcc Arc deceleration speed

Set the deceleration speed at the arc entrance or exit.

#### ---Setting range---

1 to 999999 (mm/min)

# **【#1210】 RstGmd Modal G code reset**

Select whether to initialize G code group modals and H and D codes, which corresponds to bits as follows, when the system is reset.

0: Initialize.

1: Not initialize.

<Description of bits for M system>

1F	1E	1D	1C	1B	1A	19	18	17	16	15	14	13	12	11	10
0	0	0	0	0	0	*	*	0	0	0	0	*	*	*	*

F	E	D	C	B	A	9	8	7	6	5	4	3	2	1	0
0	*	0	*	*	0	*	0	*	*	*	*	0	*	*	*

bit 1F: (Not used)

bit 1E: (Not used)

bit 1D: (Not used)

bit 1C: (Not used)

bit 1B: (Not used)

bit 1A: (Not used)

bit 19: Spindle clamp rotation speed initialization

bit 18: H, D codes initialization

bit 17: (Not used)

bit 16: (Not used)

bit 15: (Not used)

bit 14: (Not used)

bit 13: Group 20 2nd spindle control modal initialization

bit 12: Group 19 G command mirror modal initialization

bit 11: Group 18 Polar coordinate command modal initialization

bit 10: Group 17 Constant surface speed control command modal initialization

bit F: (Not used)

bit E: Group 15 Normal line control modal initialization

bit D: (Not used)

bit C: Group 13 Cutting modal initialization

bit B: Group 12 Workpiece coordinate system modal initialization

bit A: (Not used)

bit 9: Group 10 Fixed cycle return command modal initialization

bit 8: (Not used)

bit 7: Group 8 Length compensation modal initialization

bit 6: Group 7 Radius compensation modal initialization

## Appendix 1 Explanation of Parameters

**bit 5: Group 6 Inch/metric modal initialization**

**bit 4: Group 5 Feed G modal initialization**

**bit 3: (Not used)**

**bit 2: Group 3 Absolute/incremental command modal initialization**

**bit 1: Group 2 Plane selection modal initialization**

**bit 0: Group 1 Move G modal initialization**

The H code indicates the tool length offset number, and the D code indicates the tool radius compensation number.

When bit 18 is set to ON, the H and D codes and group 8 G modal are retained.

When bit 7 is set to ON, the H code and group 8 G modal are retained.

<Description of bits for L system>

1F	1E	1D	1C	1B	1A	19	18	17	16	15	14	13	12	11	10
0	0	0	0	0	0	*	0	0	0	0	*	*	0	*	*

F	E	D	C	B	A	9	8	7	6	5	4	3	2	1	0
0	0	0	*	*	0	*	0	0	*	*	*	*	*	*	*

**bit 1F: (Not used)**

**bit 1E: (Not used)**

**bit 1D: (Not used)**

**bit 1C: (Not used)**

**bit 1B: (Not used)**

**bit 1A: (Not used)**

**bit 19: Spindle clamp rotation speed initialization**

**bit 18: (Not used)**

**bit 17: (Not used)**

**bit 16: (Not used)**

**bit 15: (Not used)**

**bit 14: Group 15 Facing turret mirror image initialization**

**bit 13: Group 20 2nd spindle control modal initialization**

**bit 12: (Not used)**

**bit 11: Group 18 Balance cut initialization**

**bit 10: Group 17 Constant surface speed control command modal initialization**

**bit F: (Not used)**

**bit E: (Not used)**

**bit D: (Not used)**

**bit C: Group 13 Cutting modal initialization**

**bit B: Group 12 Workpiece coordinate system modal initialization**

**bit A: (Not used)**

**bit 9: Group 10 Fixed cycle return command modal initialization**

**bit 8: (Not used)**

**bit 7: (Not used)**

**bit 6: Group 7 Nose R compensation modal initialization**

**bit 5: Group 6 Inch/metric modal initialization**

**bit 4: Group 5 Feed G modal initialization**

**bit 3: Group 4 Barrier check modal initialization**

**bit 2: Group 3 Absolute/incremental command modal initialization**

**bit 1: Group 2 Plane selection modal initialization**

**bit 0: Group 1 Move G modal initialization**

**【#1213(PR)】 proaxy Side 1 of inclination angle (for L system only)**

Set the length within the orthogonal coordinate of the inclined axis, a side of the triangle formed with the inclination angle.

---Setting range---  
-9999.999 to 9999.999

**【#1214(PR)】 macaxy Side 2 of inclination angle (for L system only)**

Set the actual length of the base axis corresponding to the inclined axis, a side of the triangle formed with the inclination angle.

---Setting range---  
-9999.999 to 9999.999

**【#1215(PR)】 macaxx Side 3 of inclination angle (for L system only)**

Set the actual length of the inclined axis, a side of the triangle formed with the inclination angle.

---Setting range---  
-9999.999 to 9999.999

**【#1216】 extdcc External deceleration level**

Set the upper limit value of the feedrate when the external deceleration signals are enabled.

---Setting range---  
1 to 999999 (mm/min)

**【#1217】 aux01**

Not used. Set to "0".



**【#1218】 aux02**

**bit3: Parameter input/output format**

Select the parameter input/output format.

- 0: Type I
- 1: Type II (related to "#1218 aux02/bit5")

**bit4: External workpiece coordinate offset tool number selection**

Select the R register that contains the tool number used for automatic calculation when measuring the coordinate offset of an external workpiece.

- 0: Follow the setting of "#1130 set\_t".
- 1: Use the tool number indicated by user PLC.

**bit5: Parameter I/O II spindle specification address**

Select the spindle specification address of parameter I/O type II.

- 0: C
- 1: T

This parameter is also applied to the spindle specification address for input and verification.

(Note) This parameter is valid only for parameter I/O type II (when "#1218 aux02/bit3" is set to "1").

**bit6: Set No. valid when program input**

Select which program No. is applied when inputting programs in "#1 MAIN PROGRAM" on Data I/O screen.

- 0: The No. in the input data
- 1: The No. set in the data setting area

**bit7: Input by program overwrite**

(1) Select the operation when the program to be input in "#1 MAIN PROGRAM" on Data I/O screen, has already been registered.

- 0: An operation error (E65) occurs.
- 1: Input by overwrite.

(2) Select the operation in the high-speed program server mode, when the name of the file to be transmitted with (IC -> host) transmission already exists in the host.

- 0: Prohibit overwrite
- 1: Enable overwrite

**【#1219】 aux03**

**bit1: Stop high-speed PC monitoring function**

Set "1" to disable the function that triggers the emergency stop when the PC high-speed processing time is extended.  
Disable the monitoring function only as a temporary measure.

**bit5: Dog-type intermediate point**

Select whether to move to the intermediate point during automatic dog-type reference position return.


- 0: Not move.
- 1: Move.

**bit7: Time constant setting changeover for soft acceleration/deceleration**

0: Accelerating time is  $G0tL(G1tL)$ .

When the G00 pre-interpolation acceleration/deceleration and the soft acceleration/deceleration are used together, the inclination of soft acceleration/deceleration will be steeper by setting a time to the soft acceleration/deceleration 2nd step time constant (#2005 G0t1).  
Consequently, the acceleration for G28/G30 will be larger than that for G00.


- (1) Total accelerating time is "G0tL".
- (2) The time for curve part is "G0t1".
- (3) The time for linear part is obtained by " $G0tL - (2 \times G0t1)$ ".



1: Accelerating time is obtained by  $G0tL + G0t1$  ( $G1tL + G1t1$ ).

When the G00 pre-interpolation acceleration/deceleration and the soft acceleration/deceleration are used together, you can attain the G28/G30 acceleration that is equal to G00, by setting the same value to G00 soft acceleration/deceleration filter (#1569 SfiltG0) as well as to the soft acceleration/deceleration 2nd step time constant (#2005 G0t1).

- (1) Total accelerating time is obtained by " $G0tL + G0t1$ ".
- (2) The time for curve part is "G0t1".
- (3) The time for linear part is obtained by " $G0tL - G0t1$ ".



**【#1220】 aux04 (for L system only)**

**bit 0: Tool life check timing selection**

Select the criterion to judge the tool life end when the use count is incremented in tool life management II.

- 0: Determine the tool life end when the incremented use count has exceeded the life count.  
(Default)  
(Use count > life count)
- 1: Determine the tool life end when the incremented use count has reached the life count.  
(Use count  $\geq$  life count)

**【#1221】 aux05**

**bit0: Workpiece coordinate/ Absolute coordinate display switching**

Select the coordinate to display when workpiece coordinate position counter is selected for the Monitor screen counter display.

- 0: Workpiece coordinate
- 1: Absolute coordinate

**【#1222】 aux06**

**bit4: Minimum cut-in amount selection**

Select the minimum cut-in amount command value for the compound thread cutting cycle (G76 command).

- 0: The minimum cut-in amount (Q) will be "0".
- 1: The minimum cut-in amount (Q) will be set in the CNC internal data.

**bit5: Fixed cycle for compound lathe command format check selection**

Select the operation when the 1st block of the fixed cycle for compound lathe is omitted while the conventional format is selected ("#1265 ext01/bit0" is set to "0").

- 0: Program error (P33) will occur.
- 1: Parameter setting value will be used.

**bit7: Reference position return deceleration check method**

Select the deceleration check method to be used during automatic reference position return.

- 0: In-position check
- 1: Commanded deceleration check

## 【#1223】 aux07

### bit1: Deceleration check method 2

Select the deceleration check method in G1+G9.

- 0: Command deceleration check in G1+G9
- 1: In-position check in G1+G9

The deceleration check is not performed for the commands except G1+G9.

When "#1306 InpsTyp deceleration check specification type" is set to "1" (Deceleration check specification type 2), this parameter will be invalid.

### bit2: Synchronous tap R-point in-position check

Select whether to enable the synchronous tap I-point -> R-point in-position check.

- 0: Disable
- 1: Enable

(Note) This parameter is valid only when "1" (Enable in-position check) is set for "#1223 aux07/bit3 Synchronous tap in-position check improvement".

### bit3: Synchronous tap in-position check improvement

Select whether to enable the synchronous tap in-position check improvement.

- 0: Disable
- 1: Enable

Related parameters:

- #1223/bit2 Synchronous tap R-point in-position check
- #1223/bit4 Synchronous tap hole bottom in-position check
- #1223/bit5 Synchronous tap R-point in-position check 2

### bit4: Synchronous tap hole bottom in-position check

Select whether to enable the synchronous tap hole bottom in-position check.

- 0: Disable
- 1: Enable

(Note) This parameter is valid only when "1" (Enable in-position check) is set for "#1223 aux07/bit3 Synchronous tap in-position check improvement".

### bit5: Synchronous tap R-point in-position check 2

Select whether to enable the synchronous tap R-point in-position check.

- 0: Disable
- 1: Enable

(Note) This parameter is valid only when "1" (Enable in-position check) is set for "#1223 aux07/bit3 Synchronous tap in-position check improvement".

### bit6: Cancel synchronous tap (, S) return

- 0: Retain the spindle speed (, S) in synchronous tap return
- 1: Cancel the spindle speed (, S) in synchronous tap return with G80

### bit7: Synchronous tap method

Select the synchronous tapping method.

- 0: Synchronous tapping with multi-step acceleration and rapid return
- 1: Conventional type synchronous tapping

## 【#1224】 aux08

### bit0: Sampling data output

Select whether to enable the sampling data output.

- 0: Disable
- 1: Enable

**【#1225】 aux09**

**bit7: Enable/disable spindle rotation speed clamp**

Select whether to enable the spindle rotation speed clamp by the G92 S or Q command for the spindle command rotation speed (R7000) set with the user ladder.

- 0: Enable
- 1: Disable

**【#1226】 aux10**

**bit0: Tool compensation data for external workpiece coordinate offset measurement**

Select the tool compensation data to be used for external workpiece coordinate offset measurement.

- 0: Tool length data and tool nose wear data
- 1: Tool length data

**bit1: Optional block skip type**

Select whether to enable the optional block skip in the middle of a block.

- 0: Enable only at the beginning of a block.
- 1: Enable in the middle of a block, as well as at the beginning of the block.

**bit2: Single block stop timing**

Select the timing at which the single block signal is activated.

- 0: When the signal goes ON while automatic operation is starting, the block will stop after finished.
- 1: When the signal is ON at the end of the block, the block will stop.

**bit3: C-axis reference position return type**

Select the C-axis reference position return type.

- 0: Basic position return is performed by the G28 reference position return command or by activating the manual reference position return. The basic point dog is used.
- 1: When the first C-axis command is issued after the C-axis mode is entered in automatic mode, reference position return is performed before the execution of the block. The reference position return is also performed by the G28 reference position return command or by activating the manual reference position return. The Z phase of the encoder is used.

**bit4: S command during constant surface speed**

Select whether to output a strobe signal when the S command is issued in constant surface speed mode.

- 0: Not output any strobe signal in constant surface speed mode.
- 1: Output strobe signals in constant surface speed mode.

**bit5: Arbitrary allocation of dog signal**

Select whether to enable the arbitrary allocation parameter for the origin dog and H/W OT.

- 0: Disable (Fixed device is used.)
- 1: Enable (Device is specified by the parameter.)

**bit7: Shorten JOG stop time**

Select whether to shorten the JOG stop time.

- 0: Not shorten (Conventional specification)
- 1: Shorten

**【#1227】 aux11**

**bit0: Select PLC signal or spindle feedrate attained**

Set up this option when disabling the cutting start interlock by spindle feedrate attained.

- 0: Cutting start interlock by PLC signal
- 1: Cutting start interlock by spindle feedrate attained

**bit1: Select H or D code**

Set up this option to validate the data that is set up on the tool life management screen when issuing the H99 or D99 command.

- 0: The H and D codes validate the data that is set up on the management setup screen.
- 1: Validates the data that is set up on the management setup screen when issuing the H99 or D99 command.

**bit2: Measures against tool setter chattering**

Select a condition where a relieving operation completes after measurement with tools.

- 0: Sensor signals have stopped for 500 ms or longer.
- 1: 100  $\mu$  m or longer has passed after sensor signals stopped.

**bit3: Absolute coordinate switching (nose R)**

Select whether to display a nose position or coordinate value with the absolute coordinate counter.

- 0: Displays the nose position.
- 1: Displays the position specified by program command. Select a condition where a relieving operation completes after measurement with tools.

**bit5: Spindle rotation speed clamp**

Specify whether to clamp the rotation speed in constant surface speed mode when the spindle rotation clamp command is issued.

- 0: Clamps the rotation regardless of the constant surface speed mode.
- 1: Clamps the rotation only in constant surface speed mode.

**bit7: Switch the range of tool life data to be input**

Set up the range of tool life data to be input or compared.

- 0: Inputs or compares all of the data output.
- 1: Inputs or compares part of the data output

- 1) Tool life management I data to be input or compared tool number (D), lifetime (E), life count (F), and auxiliary data (B).
- 2) Tool life management II data to be input or compared Group number (G), method (M), life (E/F), tool number (D), and compensation number (H)

**【#1228】 aux12**

**bit1: Switch "offset and parameter" screen**

Select to switch the "offset and parameter" screen to the parameter screen.

- 0: Display the "offset and parameter" screen.
- 1: Display the "parameter" screen.

**bit2: Switch data protection in data transmission mode**

Select the range of data protection in data transmission mode.

- 0: Enable the protection for both send and receive data.
- 1: Enable the protection for receive data only.

**bit3: Nose R specification**

Select the method to specify the nose R compensation.

- 0: Specify the nose R compensation by shape number.
- 1: Specify the nose R compensation by wear number.

**bit4: Select operation error or stop code**

Select operation error or stop code to provide for both block start and cutting start interlocks.

- 0: Operation error
- 1: Stop code

**bit5: Select constant surface speed coordinates**

Select the constant surface speed coordinate.

- 0: Workpiece coordinate
- 1: Absolute value coordinate

**bit6: Switch relative values displayed**

Select whether to preset the relative coordinates with workpiece coordinate preset (G92.1) or counter preset (G92).

- 0: Preset the relative coordinates.
- 1: Not preset the relative coordinates.

**bit7: Protection with manual value command**

Select whether to protect a manual value command.

- 0: Not protect. (Conventional specification)
- 1: Protect.

**【#1229】 set01**

**bit0: Subprogram interrupt**

Select the type of the user macro interrupt.  
0: Macro type user macro interrupt  
1: Sub-program type user macro interrupt

**bit1: Accurate thread cutting E**

Select what the address E specifies in inch screw cutting.  
0: Number of threads per inch  
1: Precision lead

**bit2: Radius compensation type B (for M system only)**

Select the method of the arithmetic processing for the intersection point when the start-up or cancel command is operated during radius compensation.  
0: The processing does not handle the start-up or cancel command block: handle the offset vector in the direction vertical to that of the command instead.  
1: The processing is executed for the intersection point between the command block and the next block.

**bit2: Nose R compensation type B (for L system only)**

Select the method of the arithmetic processing for the intersection point when the start-up or cancel commands are operated during nose R or radius compensation.  
0: The processing does not handle the start-up or cancel command block: handle the offset vector in the direction vertical to that of the command instead.  
1: The processing is executed for the intersection point between the command block and the next block.

**bit3: Initial constant surface speed**

Select the initial state after the power-ON.  
0: Constant surface speed control cancel mode  
1: Constant surface speed control mode

**bit4: Synchronous tap**

Select the operation when ",R" is omitted in G74/G84 tapping cycle.  
0: Asynchronous tap  
1: Synchronous tap

**bit5: Start point alarm**

Select the operation when the operation start point cannot be found while executing the next block of G117.  
0: Enables the auxiliary function after the block has been executed.  
1: Outputs the program error (P33).

**bit6: Grid display selection**

Select the grid display type on the servo monitor screen during the dog type reference position return.  
0: Distance between dog OFF and basic point (including a grid mask amount)  
1: A value given by reducing a grid mask amount from the distance between dog OFF and basic point

**【#1230】 set02**

**bit7: Macro interface input/output for each part system**

Select the specification of the macro interface input/output.  
0: Shared by all part systems.  
1: Used independently by the part systems.



**【#1231】 set03**

**bit0: Graphic check compatibility parameter**

Select whether to return the data to the pre-starting data after having checked a machining program that rewrites the common variables, workpiece offsets and tool offsets.

- 0: Return the data.
- 1: Not return the data.

**bit1: Switch graphic trace coordinates**

Select whether to use machine coordinate value or tool position coordinate value (position being machined, obtained by subtracting the tool compensation amount from machine coordinate values) for drawing with trace display.

- 0: Machine coordinate value (conventional method)
- 1: Tool position coordinate value

**bit2: Switch graphic check trace**

Select the coordinates to draw at program check: both machine coordinate value (tool center path) and tool position coordinate value (program path) simultaneously, or only the coordinates selected with "#1231 set03/bit1 (Switch graphic trace coordinates)".

- 0: Both machine coordinates and tool position coordinates (conventional method)
- 1: Only coordinates designated with switch graphic coordinates

**bit4: Switch zero point mark display position**

Select the position for displaying the basic point mark in the graphic trace and 2D check.

- 0: Machine coordinate basic point (same as conventional method)
- 1: Workpiece coordinate basic point

**bit5: Switch graphic check counter display**

Select the type of counter displayed on the Graphic Check screen with the combination of "#1231 set03/bit1".

If the drawing coordinate system is other than "all workpiece coordinates", the counter displayed is workpiece coordinate position counter or tool position (workpiece coordinate) regardless of this setting.

- 0: (When "#1231 set03/bit1" is set to "0") Machine position counter  
(When "#1231 set03/bit1" is set to "1") Tool position (workpiece coordinate) counter
- 1: (When "#1231 set03/bit1" is set to "0") Workpiece coordinate counter  
(When "#1231 set03/bit1" is set to "1") Tool position (workpiece coordinate) counter

**【#1232】 set04**

Not used. Set to "0".

**【#1233】 set05**

**bit1 : Spindle clamp selection**

Select whether to enable/disable the spindle override for the spindle speed clamp command (G92 S?).

- 0 : Disable
- 1 : Enable

**【#1234】 set06**

**bit3: Interlock when tap retract enabled**

Select whether to enable automatic/manual interlock for the part system with "Tap retract enable" signal ON.

- 0: Interlock all the axes
- 1: Disable the interlock

## 【#1235】 set07

### bit0: Helical interpolation speed 2

- 0: Select normal speed designation also for 3rd axis
- 1: Select arc plane element speed designation

### bit2: Fixed type chopping compensation valid only at start

When the fixed type compensation value is selected, the method can be changed to the compensation value sequential update type after the first four cycles.

- 0: Disable the method changeover
- 1: Enable the method changeover

### bit4: Selection condition of synchronous tapping gear step

Select the parameters that determine the gear step for synchronous tapping.

- 0: #3005 through #3008 (smax1 to 4) when "#1223 aux07/bit7" is "0".  
Or #3013 through #3016 (stap1 to 4) when "#1223 aux07/bit7" is "1".
- 1: Always #3013 through #3016 (stap1 to 4)

## 【#1236】 set08

### bit0: Manual rotary axis feedrate unit

Select the unit of manual rotary axis feedrate.

- 0: Fixed to [°/min]
- 1: Same speed as before (When inch command, the speed is the command speed divided by 25.4.)

### bit1: Spindle speed detection

Select the pulse input source of actual spindle rotation speed (R6506/R6507) when the spindle encoder serial connection is selected ("#3025 enc-on" is set to "2").

- 0: Serial input
- 1: Encoder input connector

### bit2: Current limit droop cancel invalid

Select whether to cancel the position droop when the current limit changeover signal is canceled.

- 0: Cancel the droop.
- 1: Not cancel the droop.

### bit3: Rotary axis command speed scale

Select to multiply the rotary axis command speed by 10 times.

- 0: Invalid
- 1: During initial inching, the rotary axis command speed is multiplied by 10. In other words, if "F100" is commanded, the speed will be the same as when 1000°/min is commanded. The rotary axis speed display unit will be 10°/min.

## 【#1237(PR)】 set09

Not used. Set to "0".

**【#1238(PR)】 set10**

**bit0: Switch G36 function**

Select the function, the automatic tool length measurement or arc thread cutting (CCW), to be applied to G36 when the G code system 6 or 7 is selected.

- 0: Automatic tool length measurement
- 1: Arc thread cutting (CCW)

**bit6: Switch absolute position detection alarm**

Select the output destination of the absolute position detection alarm.

- 0: NC alarm 4 (AL4)
- 1: NC alarm 5 (AL5)

(Note) The absolute position detection alarm is listed in the alarm history regardless of this parameter setting.

**bit7: Switch operation alarm**

Select whether to enable the NC alarm 5 (AL5) signal output.

- 0: Disable NC alarm 5 (AL5) (default)
  - All operation alarms will be output to NC alarm 4 (AL4).
  - All operation alarms will be recorded in the alarm history.
- 1: Enable NC alarm 5 (AL5)
  - The following operation alarms will be output to NC alarm 5 (AL5), not to NC alarm 4 (AL4).
  - The operation alarms output to NC alarm 5 (AL5) will not be recorded in the alarm history.
  - External interlock axis found (M01 0004)
  - Cutting override zero (M01 0102)
  - External feedrate zero (M01 0103)
  - Block start interlock (M01 0109)
  - Cutting block start interlock (M01 0100)
  - Cutting interlock for spindle-spindle polygon (G51.2) (M01 1033)

**【#1239(PR)】 set11**

**bit0: Coil switching method**

Select the coil switching method.

- 0: Via PLC (Y189F).
- 1: NC internal processing. (Y189F is invalid.)

**bit1: Handle I/F selection**

Select the handle connection destination.

- 0: Use the handle connected to the encoder communication connector.
- 1: Use the remote I/O unit as a priority.

When HN341/HN342/HN351/HN391/HN392 is mounted, the handle connected to the operation panel I/O unit will be used regardless of this parameter setting.

**bit3: Polygon machining mode at reset**

Select whether to cancel the polygon machining mode when reset is applied.

- 0: Not cancel.
- 1: Cancel.

**bit4: Invalidate G51.1 phase command**

Select whether to enable the phase control with the spindle-spindle polygon function.

- 0: Always enable. (When R is not commanded, it will be handled as R0.)
- 1: Enable only at the R command.

**bit5: Door interlock spindle speed clamp valid**

Select whether to enable the spindle clamp speed changeover by the PLC signal.

- 0: Disable
- 1: Enable

## 【#1240(PR)】 set12

### bit0: Handle input pulse

Select the handle input pulse.

0: MITSUBISHI CNC standard handle pulse (25 pulse/rev)

1: Handle 400 pulse (100 pulse/rev)

### bit2: Zero point shift amount magnification

When "1" is set, the following magnification will be applied on the "#2027 G28sft Reference position shift distance", "#2057 Near zero point +" and "#2058 Near zero point -" settings.

For 0.1  $\mu$  m: 10-fold

For 0.01  $\mu$  m: 100-fold

### bit4: Optical communication automatic channel detection invalid

Select whether to enable the optical communication automatic channel detection.

0: Enable

1: Disable

## 【#1241(PR)】 set13

### bit0 : No G-CODE COMB. Error

Select the operation for when an illegal combination of modal and unmodal G codes are commanded in a same block.

0 : The program error (P45) will occur.

1 : A program error can be avoided but the modal G code will be ignored.

## 【#1242】 set14

Not used. Set to "0".

## 【#1243】 set15

Not used. Set to "0".

## 【#1244】 set16

Not used. Set to "0".

## 【#1245】 set17

### bit7: Synchronous tap spindle rotation direction type

Select whether the spindle's rotation direction is determined by the synchronous tapping axis' travel direction.

0: The spindle's rotation direction is determined by the synchronous tapping axis' travel direction.

When the travel direction is negative, the spindle rotates forward.

When the travel direction is positive, the spindle rotates in reverse.

1: The spindle always rotates forward regardless of the synchronous tapping axis' travel direction.

(Note)When a reverse tap is commanded, the spindle rotates in an opposite direction to that mentioned above.

**【#1246(PR)】 set18**

**bit2: Switch coordinate systems for radius compensation**

Select the coordinate system for radius compensation.

0: Type 1 (Conventional specification)

Perform radius compensation with reference to a position on the workpiece coordinate system.

1: Type 2

Perform radius compensation with reference to a position on the program coordinate system.

**bit3: Change repetition final return position at M2L**

Select the final return position after repetition, when in G99 modal and in M2 format with the label L.

0: Initial point

1: R point

**bit4: T-lifeover signal output**

Select the timing at which tool life over signal is output when using the M system tool life management I/II.

0: Turn the signal ON when a selected tool has reached the lifetime.

1: Turn the signal ON when any of tools in a selected group has reached the lifetime.

**bit5: Tool status update type**

Select whether to update tool status automatically when lifetime/usage data is changed on the screen in the M system tool life management I/II/III.

0: Not update.

1: Update.

(Note) When "1" is selected, tool status will be updated as follows.

- When usage data is "0", tool status will be "0".

- When usage data is smaller than lifetime data, tool status will be "1".

- When usage data is the same as or larger than lifetime data, tool status will be "2".

**bit6 : Switch F 1-digit feedrate change method**

Set whether to enable feedrate change with handle until power OFF, or change the parameters #1185 to #1189 with change of speed.

0: Enabled until power OFF

1: Change #1185 spd\_F1 to #1189 spd\_F5

**bit7: PLC axis random device assignment**

Select whether to enable the origin dog and H/W OT random assignment for a PLC axis.

0: Disable (assigned to a fixed device)

1: Enable (assigned to the parameter set device)

**【#1247】 set19**

**bit0 : Movement by tool length compensation command (for M system only)**

Select whether or not to move the axis by the compensation amount when tool length compensation/cancel is independently commanded.

(Note) This parameter is available for only M700V Series.

M700/M70V/M70 Series will perform the same operation as when this parameter is set to "0".

0: Move

1: Not move

**bit1: Thread cutting operation when manual speed command enabled**

Select the thread cutting operation in manual speed command.

0: The axis travels at the handle feed rate, jog feed rate, or manual rapid traverse rate

1: The axis travels following the program command

**【#1248】 set20**

Not used. Set to "0".

**【#1249】 set21**

Not used. Set to "0".

**【#1250】 set22**

Not used. Set to "0".

**【#1251】 set23**

Not used. Set to "0".

**【#1252】 set24**

Not used. Set to "0".

**【#1253】 set25**

Not used. Set to "0".

**【#1254】 set26**

Not used. Set to "0".

**【#1255】 set27**

Not used. Set to "0".

**【#1256】 set28**

Not used. Set to "0".

**【#1257】 set29**

Not used. Set to "0".

**【#1258(PR)】 set30**

**bit0: Skip I/F switch**

Select A or B contact for the skip interface.

0: A contact (Skip operation starts at rising edge of a signal)

1: B contact (Skip operation starts at falling edge of a signal)

(Note) This parameter is not applied to PLC skip.

**【#1259】 set31**

**bit0 : Enable normal life tool's data count (for M system only)**

Select whether to enable or disable too use data counting when the tool status is 2 (normal life tool).

0: Not count the use data of normal life tool.

1: Count the use data of normal life tool.

**【#1260】 set32**

Not used. Set to "0".

**【#1261】 set33**

Not used. Set to "0".

**【#1262】 set34**

Not used. Set to "0".

**【#1263】 set35**

Not used. Set to "0".

**【#1264】 set36**

Not used. Set to "0".

**【#1265(PR)】 ext01**

**bit0: Command format 1**

Select the command format for the fixed cycle for compound lathe.

- 0: Conventional format
- 1: MITSUBISHI CNC special format (1 block command method)

**bit1: Command format 2**

Select the command format for the lathe fixed cycle.

- 0: Conventional format
- 1: MITSUBISHI CNC special format

**bit2: Command format 3**

Select the command format for the hole drilling fixed cycle.

- 0: Conventional format
- 1: MITSUBISHI CNC special format

**【#1266(PR)】 ext02**

Not used. Set to "0".

**【#1267(PR)】 ext03**

**bit0: G code type**

Select the high-speed high-accuracy G code type.

- 0: Conventional format (G61.1)
- 1: MITSUBISHI special format (G08P1)

**【#1268(PR)】 ext04**

**bit2 : Enable synchronous tapping per minute**

Select whether to enable feed per minute with the F command of synchronous tapping cycle.

- 0: Disable (Command in pitch regardless of "G group 5" modal)
- 1: Enable (Follow "G group 5" modal)

**【#1269(PR)】 ext05**

Not used. Set to "0".

**【#1270(PR)】 ext06**

**bit3 : Finished shape judgement disable**

Select to enable/disable the judgement of shape when the finished shape's Z axis (or X axis at G72 command) does not move monotonously. Program error (a shape change at pocket machining) can be avoided when selected to disable.

- 0 : Enable
- 1 : Disable

**bit5: Coordinate rotation angle without command (for L system only)**

Select the operation when there is no rotation angle command R for the coordinate rotation.

- 0: Use the previously commanded value (modal value). If the command is the first issued command, the rotation angle will be 0°.
- 1: Use the set value in "#8081 Gcode Rotat".

**bit6: Switch continuous thread cutting Z phase wait operation**

Select when to start the 2nd block thread cutting when there is a command with no movement (MST command, etc.) between the thread cutting blocks.

- 0: Wait for the spindle's single rotation synchronization signal before starting the movement.
- 1: Start movement without waiting for the spindle's single rotation synchronization signal.

**bit7: Handle C axis coordinate during cylindrical interpolation**

Specify whether to keep the rotary axis coordinate as before the cylindrical interpolation start command is issued during the cylindrical interpolation.

- 0: Not keep
- 1: Keep

**【#1271(PR)】 ext07**

**bit0: Mirror image operation**

Select the type of mirror image operation.

0: Type 1

- The program mirror image, external mirror image, and parameter mirror image are exclusive to each other.
- An increment command moves the image to the position indicated by the travel amount with the sign inverted.

1: Type 2

- Mirror image operation is enabled when the program mirror image (G51.1) command is issued or when the external signal or parameter is ON.
- An increment command moves the image to the position determined by applying the mirror image to the absolute program coordinates.

**bit1: Address specifying fixed cycle repetition count (for M system only)**

Select the address that specifies the fixed cycle repetition count.

0: Address L only (Default)

1: Addresses K and L

If addresses K and L are specified simultaneously, the data at address K will be used for operation.

**bit2: F-command unit**

Select the unit to be used when a thread cutting lead command does not contain decimal point.

0: Type 1 (conventional specifications)

F1 -> 1 mm/rev, 1 inch/rev

1: Type 2

F1 -> 0.01 mm/rev, 0.0001 inch/rev

**bit3: G-code group for unidirectional positioning (for M system only)**

Select the G-code group for unidirectional positioning.

0: Unmodal G code (group 00)

1: Modal G code (group 01)

Related parameter: "#8209 G60 Shift" (Set the last positioning direction and distance for each axis applicable when the unidirectional positioning command is issued.)

**bit4: Operation by independent G40 command**

Select whether the radius compensation vector is canceled by the independent G40 command.

0: Type 1 (conventional specification) (Default)

The radius compensation vector will be canceled by the independent G40 command.

1: Type 2

The radius compensation vector won't be canceled by the independent G40 command: it will be canceled by the next travel command for the radius compensation plane.

**bit5: Cut start position (for L system only)**

Select the position from where cutting begins in a fixed cycle for compound lathe.

0: Conventional specification (Default)

The cut start position will be determined by the final shaping program.

1: Extended specification

The cut start position will be determined from the cycle start point.

**bit6: Nose R compensation (for L system only)**

Select whether to apply nose R compensation for shapes in a rough cutting cycle.

0: Conventional specification (Default)

The shape after nose R compensation in the final shaping program will be used as rough cutting shape (when the nose R compensation for the final shaping program).

1: Extended specifications

The shape without nose R compensation in the final shaping program will be used as rough cutting shape.

**bit7: Cut amount (for L system only)**

Select the operation to be performed when the program-specified cut amount exceeds the cut amount of the final shaping program.

0: Conventional specification (Default)

A program error will occur when the program-specified cut amount exceeds the cut amount of the final shaping program.

1: Extended specification

Rough cutting will be performed by one cut when the program-specified cut amount exceeds the cut amount of the final shaping program.



**【#1272(PR)】 ext08**

**bit0: Switch pocket machining operation**

Select the pocket machining specification.

0: Conventional specification

Pocket machining will be selected with the H designation.

The pull direction when pocket machining is ON will be the Z direction.

1: Extended specification

Pocket machining will start only when both X and Z axes are specified in the first travel block after the finished shape start block.

The pull direction when pocket machining is ON will be the X direction.

**bit1: M function synchronous tap cycle**

Specify whether to enable the M function synchronous tapping cycle.

0: Disable

1: Enable

**bit2: Spiral/conical interpolation command format 2**

Select the command format for spiral and conical interpolation.

0: Type 1 (conventional specification)

1: Type 2 (with the number of spiral rotation L designation and the increment designation)

**bit3: Switch macro call function**

Select whether to shift the argument to the subprogram if nests are overlapped when per block call (G66.1) is commanded.

0: Shift

1: Not shift (Conventional specification)

**bit4: Tap cycle selection**

Select the tapping cycle.

0: Pecking tapping cycle

1: Deep hole tapping cycle

**bit5: Deep hole tap cycle override selection**

Select whether to enable override on the pulling operation during synchronized tapping with the deep hole tapping cycle.

0: Disable

1: Enable

**bit6: Switch corner chamfering/ corner R command format**

Select the command format of the corner chamfering/corner R.

0: Command format I (conventional format)

Issue a command with comma (,C and ,R).

1: Command format II

In addition to command format I, addresses without comma can be used to command.

I/K or C can be used for corner chamfering, while R can be used for corner R.

**bit7: Return position after macro interrupt in fixed cycle selection**

Select the destination to return to after a macro interrupt in the fixed cycle.

0: Return to the block in the fixed cycle.

1: Return to the block next to the fixed cycle.

**【#1273(PR)】 ext09**

**bit0: Switch ASIN calculation results range**

Select the notation system for operation result of ASIN.  
0: Do not switch minus figures to positive figures. (-90° to 90°)  
1: Switch minus figures to positive figures. (270° to 90°)

**bit1: Switch system variable unit**

Select the unit for the system variable #3002 (time during automatic start).  
0: 1 ms unit  
1: 1 hour unit

**bit2: Switch G71, G72, G73 cutting direction judgment**

Select the cutting direction when the longitudinal rough cutting cycle (G71), face rough cutting cycle (G72) or closed loop cutting cycle (G73) is commanded.  
0: Conventional specification  
Determined according to the finished shape program.  
1: Extended specification  
Determined according to the finishing allowance and cutting allowance commanded in the program.

**bit3: Facing turret mirror image coordinate value type**

Select how to show the workpiece coordinate values of the axis for which the facing turret mirror image is valid.  
0: Movements in the workpiece coordinate system are in the same direction as those in the workpiece machine coordinate system.  
1: Movements in the workpiece coordinate system are in the opposite direction to those in the workpiece machine coordinate system.

**bit4: Facing turret mirror image valid axis selection**

Select the axis for which the facing turret mirror image is valid.  
0: Fixed to 1st axis.  
1: Determined according to the plane selected when the facing turret mirror image is commanded.

**【#1274(PR)】 ext10**

**bit7: Word range check**

Select whether to check that the operation expression of the word data in the program is enclosed in brackets ( [ ] ) when the machine program is executed.  
This check is also applied to the 08000 to 09999 and the machine tool builder macro program.  
0: Not check  
1: Check

**【#1275(PR)】 ext11**

Not used. Set to "0".

**【#1276(PR)】 ext12**

Not used. Set to "0".

**【#1277(PR)】 ext13**

**bit0: Tool life management II count type 2**

Select how and when the mount or use count will be incremented in tool life management II. The condition to output "tool group life over (TGLO)" signal will be changed accordingly.

0: Type 1 (Default)

Counts up when the spindle tool is used for cutting.

TGLO signal will be output when the last tool in selected group is judged as expired.

1: Type 2

Counts up by one for a tool used or mounted in a program at the time of resetting.

TGLO signal will be output when any of tool groups has reached its lifetime limit.

**bit1: Tool life management II life prediction**

Select whether to enable tool life prediction function in tool life management II.

0: Disable

1: Enable

**bit2: Tool life management II life end signal timing**

Select the timing at which tool life prediction signal is output in tool life management II.

0: Output only when the ["life value" - "used value"] matches the remaining life.

("life value" - "used value" = "remaining life")

1: Output when the ["life value" - "used value"] is less than the remaining life.

("life value" - "used value" ≤ "remaining life")

**bit3: Tool life management II life end signal tool**

Select the tool for which the tool life prediction signal is output in tool life management II.

0: Output the signal tool by tool.

1: Output the signal at the last tool in the group.

**bit4: Tool life management II count changeover (For M system only)**

Select the tool life count method and its timing.

0: Conforms to "ext13/bit0" setting.

1: When "ext13/bit0" is set to "0":

Counts up by one for a tool used or mounted in a program at the time of resetting.

When "ext13/bit0" is set to "1":

Follow the setting of "Method (Mthd)" on Tool life screen.

The output condition of "tool group life over" signal conforms to "ext13/bit0".

**【#1278(PR)】 ext14**

**bit0: Program restart method selection**

Select the program restart type.

0: Restart type A

1: Restart type B

**【#1279(PR)】 ext15**

**bit0: Part system synchronization method**

Select the part system synchronization method.

0: If one part system is not in the automatic operation, the synchronization command will be ignored and the next block will be executed.

1: Operate according to the "waiting ignore" signal.

If the "waiting ignore" signal is set to "1", the synchronization command will be ignored. When set to "0", synchronization will be applied.

**bit1: Interrupt amount during machine lock**

Select when to cancel the interruption amount during machine lock.

0: When resetting

1: During manual reference position return (not when resetting)

**bit2: Selection of cutting start interlock target block**

Select whether to enable the cutting start interlock for successive cutting blocks.

0: Enable

1: Disable

**bit5: Cancel G92 shift distance**

Select whether to clear the G92 (coordinate system setting) shift distance when the manual reference position is reached.

0: Not clear

1: Clear

**【#1280(PR)】 ext16**

**bit0: I/F per axis during mixed control (cross axis control)**

Select how to handle the following PLC interface for axes interchanged with the mixed control (cross axis control).

- Mirror image
- Manual/automatic interlock
- Manual/automatic machine lock
- 0: Follows axis configuration before the mixed control (cross axis control).
- 1: Follows axis configuration after the mixed control (cross axis control).

(Example)

The device No. of automatic interlock (+) for X1 will be as follows when the mixed control (cross axis control) is executed with the 1st axis (X1) in the 1st part system and 1st axis (X2) in the 2nd part system.

When "0" is set: Y820 (interface for 1st axis in 1st part system)

When "1" is set: Y828 (interface for 1st axis in 2nd part system)

(Note) If the number of axes in the part system changes with the mixed control (cross axis control), the interface of the target axis may change when this parameter is set to "1".

(Example)

When 1st part system's C axis is moved to 2nd part system with a 1st part system (X, Z, C, Y) and 2nd part system (X, Z) configuration:

When "1" is set: Y82A, Y7CA, Y8AA and later will be the interface for the C axis moved to the 2nd part system. Y7C2, Y822, Y8A2 and later will be the interface of the Y axis in the 1st part system, because the axes following the removed C axis (third place) are shifted up.

**bit1: Mixed control (cross axis control) cancel with reset**

Select whether to cancel the mixed control (cross axis control) when reset is applied.

- 0: Cancel.
- 1: Not cancel.

**bit2: Interchange coordinate position display**

Select whether to display interchanged (or moved) coordinate positions in the mixed control (cross axis control).

This setting will be applied when the axes are moved, as well as when the axes are interchanged.

- 0: Display interchanged (or moved) coordinate positions.
- 1: Display coordinate positions without being interchanged (nor moved).

(Example)

When 1st part system's C axis is moved to 2nd part system with a 1st part system (X, Z, C, Y) and 2nd part system (X, Z) configuration:

1st part system: X, Z and Y coordinate positions are displayed.

2nd part system: X, Z and C coordinate positions are displayed.

**bit3: Reset operation for synchronization/super-imposition control**

Select whether to cancel synchronization/superimposition control when reset is applied.

- 0: Cancel.
- 1: Not cancel.

**bit4: Mixed control (cross axis control) command method**

Select how to command mixed control (cross axis control).

- 0: Use PLC interface signal for mixed control
- 1: Use G command for mixed control

**bit5: Command method of control axis synchronization across part systems**

Select how to command the control axis synchronization across part systems.

- 0: Use PLC I/F.
- 1: Use G command.

**【#1281(PR)】 ext17**

**bit0: Switch manual high-speed reference position return in synchronous control**

Select the movement of synchronized axes in manual high-speed reference position return.

- 0: Primary and secondary axes start the return synchronizing. Even when one axis stops at its reference position, the other axis continues moving until it reaches its reference position.
- 1: Primary and secondary axes start the return synchronizing, and when the primary axis stops at the reference position, the secondary also stops. Thus, the relative position of the primary and secondary is kept.

**bit3: Synchronous control operation setting**

Select whether or not the positioning of secondary axis automatically aligns with that of primary axis when the axis subject to synchronous control is changed from servo OFF to servo ON.

- 0: The positioning automatically aligns.
- 1: The positioning does not align.

**bit5: High-speed synchronous tapping valid**

Select whether to enable the high-speed synchronous tapping.

- 0: Disable
- 1: Enable

**bit6 : Compensation method for external machine coordinate system/ball screw thermal expansion during synchronization**

Select the method of how to compensate the secondary axis when compensating external machine coordinate system or ball screw thermal expansion during synchronization control. The setting of this parameter will be validated when you select synchronous operation method by the synchronization control operation method signal.

- 0: Primary axis and secondary axis are independently compensated.
- 1: Primary axis' compensation amount is applied to secondary axis.

**bit7: Switch automatic high-speed reference position return in synchronous control**

Select the movement of synchronized axes in automatic high-speed reference position return.

- 0: Primary and secondary axes start the return synchronizing, and when the primary axis stops at the reference position, the secondary also stops. Thus, the relative position of the primary and secondary is kept.
- 1: Primary and secondary axes start the return synchronizing. Even when one axis stops at its reference position, the other axis continues moving until it reaches its reference position.

**【#1282(PR)】 ext18**

**bit1: Condition of the reference position reached signal in synchronous control**

This parameter switches only conditions of a master axis's reference position return reached signal in synchronous operation. A slave axis's signal is output when the slave axis reaches the reference position coordinate.

- 0: A master axis's reference position reached signal is output only when both of the master and slave axes reach the reference position coordinate by a reference position return.
- 1: A master axis's reference position reached signal is output when the master axis reaches the reference position coordinate.

**bit2: Measurement basic point for tool length measurement I (for L system only)**

Select how to specify the measurement base point coordinate for manual tool length measurement I.

- 0: Specify the coordinate of "#2015 tlml-" as the measurement basic point (default).
- 1: Specify the workpiece coordinate system offset (modal) as the measurement basic point.

**【#1283(PR)】 ext19**

Not used. Set to "0".

**【#1284(PR)】 ext20**

**bit0: Spindle speed clamp check**

Select whether to check the spindle speed clamp under the constant surface speed control.

- 0: Check the spindle speed clamp.
- 1: Not check the spindle speed clamp.

(Note) This parameter is enabled when the parameter "#1146 Sclamp" is set to "1".

**【#1285(PR)】 ext21**

**bit0: Multi-part system program management**

Select whether to use multi-part system program management.

0: Not use

1: Use

(Note) When this parameter's value is changed, the power must be turned OFF and ON, and the system formatted. Two or more part systems from [1] to [4] need to be set to "1" in "#1001 SYS\_ON". Otherwise this parameter will be disabled even though set to "1".

**bit1: Program search type switch**

Select how to search a program to operate.

0: Operation search is performed in the selected part system.

1: Operation search is performed for all part systems. (The program No. will be common to all part systems.)

**bit2: Multi-part system program generation and operation**

Select whether to perform the following processes for all the part systems or for each part system separately in multi-part system program management: newly create, delete or rename the machining programs in NC memory (including MDI program and machine tool builder macro program) or transfer, compare, merge the programs between NC memory and other device.

0: Perform these processes for the programs in all part systems. If no subprogram contents are found by the subprogram call during automatic operation, the program will be searched for from \$1.

1: Perform these processes for the programs in the selected part system.

**【#1286(PR)】 ext22**

**bit2: O No. for program input No.**

Select the operation when the same program No. is input during data input.

0: The O No. is handled as a character string data.

1: The O No. is handled as a program No. Whether to overwrite the program or cause an error is decided by "#1218 bit7 Input by program overwrite".

**bit3: No O No. at machining program input**

Select whether to enable the machining program input even if there is no program No. (O No.). The program No. is fixed to 01 in this case.

0: Disable

1: Enable

**bit5: Selection of multi-part system program input/output method**

Select whether to perform the transfer from NC memory to other device for all the part systems or for each part system separately in multi-part system program management.

0: Output the designated programs for all the part systems.

1: Output the programs of only the selected part system.

**【#1287(PR)】 ext23**

**bit1: Inclined surface coordinate display (for M system only)**

- 0: Display the position which includes tool length offset.
- 1: Display the position on the program which excludes tool length offset.

**bit2: Inclined surface coordinate display (for M system only)**

- 0: Display the position which includes tool radius compensation.
- 1: Display the position on the program which excludes tool radius compensation.

**bit4: Relative coordinate display**

- (M system)
- 0: Display the position which includes tool length offset.
- 1: Display the position on the program which excludes tool length offset.
- (L system)
- 0: Display the position which includes tool shape compensation.
- 1: Display the position on the program which excludes tool shape compensation.

**bit5: Relative coordinate display**

- (M system)
- 0: Display the position which includes tool radius compensation.
- 1: Display the position on the program which excludes tool radius compensation.
- (L system)
- 0: Display the position which includes nose R compensation.
- 1: Display the position on the program which excludes nose R compensation.

**bit6: Absolute coordinate display**

Select how coordinate values are displayed when absolute coordinate display is selected ("#1221 aux05/bit0="1").

- (M system)
- 0: Display the position which includes tool length offset.
- 1: Display the position on the program which excludes tool length offset.
- (L system)
- 0: Display the position which includes tool shape compensation.
- 1: Display the position on the program which excludes tool shape compensation.

**bit7: Absolute coordinate display**

Select how coordinate values are displayed when absolute coordinate display is selected ("#1221 aux05/bit0="1").

- (M system)
- 0: Display the position which includes tool radius compensation.
- 1: Display the position on the program which excludes tool radius compensation.
- (L system)
- 0: Display the position which includes nose R compensation.
- 1: Display the position on the program which excludes nose R compensation.

**【#1288(PR)】 ext24**

**bit0: MDI program clear**

Select whether to clear the MDI programs when MDI operation ends, the power is turned ON again, reset is input, or emergency stop is canceled.

- 0: Not clear.
- 1: Clear (save only % programs).

**【#1289(PR)】 ext25**

**bit0: Tool radius compensation switch corner judgment method (Nose R comp.)**

Select the criterion to execute the outer rounding at the small corner in tool radius compensation.

- (L system)
- 0: The corner angle is 0°; linear-linear; G02-G03/G03-G02; the radius is the same. (Conventional method)
- 1: The corner angle is 1° or smaller; linear-linear; G02-G03/G03-G02; the radius is almost the same. (Method for rounding minute corner angle)
- (M system)
- 0: The corner angle is 1° or smaller; linear-linear; G02-G03/G03-G02. (Conventional method)
- 1: The corner angle is 1° or smaller; linear-linear; G02-G03/G03-G02; the radius is almost the same. (Method for rounding minute corner angle)



## Appendix 1 Explanation of Parameters

### 【#1290(PR)】 ext26

Not used. Set to "0".

### 【#1291(PR)】 ext27

Not used. Set to "0".

### 【#1292(PR)】 ext28

Not used. Set to "0".

### 【#1293(PR)】 ext29

Not used. Set to "0".

### 【#1294(PR)】 ext30

Not used. Set to "0".

### 【#1295(PR)】 ext31

Not used. Set to "0".

### 【#1296(PR)】 ext32

Not used. Set to "0".

### 【#1297(PR)】 ext33

Not used. Set to "0".

### 【#1298(PR)】 ext34

Not used. Set to "0".

### 【#1299(PR)】 ext35

Not used. Set to "0".

### 【#1300(PR)】 ext36

#### bit0: Multiple spindle control II

Select multiple spindle control I or II.  
 0: Multiple spindle control I (L system only)  
 1: Multiple spindle control II (select from ladder)

#### bit7: Spindle synchronization command method

Select the spindle synchronization command method.  
 0: Spindle synchronization with PLC I/F  
 1: Spindle synchronization with machining program

### 【#1301】 nrfchk Near reference position check method

Select the method to judge the "near reference position".  
 0: Conventional method  
 1: Command machine position is used.  
 2: Feedback position is used.

### 【#1302】 AutoRP Automatic return by program restart

Select the method to move to the restart position when restarting the program.  
 0: Move the system manually to the restart position and then restart the program.  
 1: The system automatically moves to the restart position at the first activation after the program restarts.

### 【#1303(PR)】 V1comN No. of #100 address part system common variables

Set the number of common variables, common for part systems, starting from address #100.  
This is valid only when "#1052 MemVal" is set to "1".

---Setting range---  
0 to 100

### 【#1304(PR)】 V0comN No. of #500 address part system common variables

Set the number of common variables, common for part systems, starting from address #500.  
This is valid only when "#1052 MemVal" is set to "1".

---Setting range---  
0 to 500

### 【#1306】 InpsTyp Deceleration check specification type

Select the parameter specification type for the G0 or G1 deceleration check.  
0: Deceleration check specification type 1  
G0 is specified with "#1193 inpos", and G1+G9 with "#1223 aux07/bit1".  
1: Deceleration check specification type 2  
G0 or G1+G9 is specified with "#1193 inpos".

### 【#1309(PR)】 GType Switch command format

Select which is used to command the reverse tap.  
0: G84.1/G88.1  
1: D command with the value changed to negative

### 【#1310】 WtMmin Minimum value for synchronization M code

Set the minimum value for the M code. When "0" is set, the synchronization M code will be invalid.

---Setting range---  
0, 100 to 99999999

### 【#1311】 WtMmax Maximum value for synchronization M code

Set the maximum value for the M code. When "0" is set, the synchronization M code will be invalid.

---Setting range---  
0, 100 to 99999999

### 【#1312】 T\_base Tool life management standard number

Set the standard No. for the tool life management.  
When the value specified by the T code command exceeds the set value in this parameter, the set value will be subtracted from the command value, which will be used as tool group No. for tool life management.  
When the value specified by the T code command is equal to or less than the set value, the T code will be handled as a normal T code and not subjected to tool life management.  
When "0" is set in this parameter, the T code command will always specify a group No. (Valid for M-system tool life management II.)

---Setting range---  
0 to 9999

### 【#1313】 TapDw1 Synchronous tap hole bottom wait time

Set the hole bottom wait time for synchronous tapping.  
When P address is specified, the greater value will be used as the hole bottom wait time. When an in-position check is performed at the hole bottom, the wait time will be provided after the completion of the in-position check.

(Note) This parameter is valid only when "1" is set in "#1223 aux07/bit3" (synchronous tap in-position check improvement) and "#1223 aux07/bit4" (synchronous tap hole bottom in-position check).

---Setting range---  
0 to 999 (ms)

### 【#1314】 TapInp Synchronous tap in-position check width (tap axis)

Set the hole bottom in-position check width for synchronous tapping.

(Note) This parameter is valid only when "1" is set in "#1223 aux07/bit3" (synchronous tap in-position check improvement) and "#1223 aux07/bit4" (synchronous tap hole bottom in-position check).

#### ---Setting range---

0.000 to 99.999

### 【#1316(PR)】 CrossCom Reference of common variables common for part systems

Select whether to use the common variables from #100100 to #800199.

0: Not use

1: Use

This parameter is valid only when the number of variable sets is set to 600 or more.

When this parameter is set to "1", variables from #100100 to #100110 will not be available as the system variables for PLC data read function, and the setting of "#1052 MemVal" will be invalid.

### 【#1324(PR)】 Chop\_R Chopping compensation value fixing method

Set the head No. of the R register used as the compensation amount save area during fixed compensation amount method.

When the first number is an odd number, the operation message "Setting error" appears.

When the value overlaps with the chopping control data area, the operation message "Setting error" appears.

#### ---Setting range---

8300 to 9782

(Only the even number)

(Within backup area)

### 【#1326】 PLC Const Ext. Num PLC constant extension number

Set the number of PLC constant extension points.

#### ---Setting range---

0 to 750

### 【#1327】 3D ATC type Tool change method specification

Select the tool change method for determining the tool to draw solids.

With 3D drawing, the tool will be changed by the method designated with this parameter, and then the image will be drawn.

0: With one standby tool

1: With two standby tools

2: With no standby tool

### 【#1328】 TLM type Tool measurement standard positions election

Select the tool measurement method.

0: Use the machine position at TLM switch ON as 0.

1: Use the machine basic point as standard.

### 【#1329】 Emgcnt Emergency stop contactor shut-off time

Set the time taken for the drive section's main power to be shut-off when the confirmation of all the axes' stop failed after the emergency stop state.

The contactor shut-off signal is output as soon as all the axes are confirmed stopped if the confirmation is done prior to the set time.

When there is no safety observation option or "0" is set, the shut-off time will be 30(s).

#### ---Setting range---

0 to 60 (s)

### 【#1330(PR)】 MC\_dp1 Contactor weld detection device 1

When safety observation is executed, set the remote I/O device to input the contactor's auxiliary b contact signal used for the contactor weld detection.

If "0" is set, weld detection will not be executed.

#### ---Setting range---

0000 to 02FF (HEX)

### 【#1331(PR)】 MC\_dp2 Contactor weld detection device 2

When safety observation is executed, set the remote I/O device to input the contactor's auxiliary b contact signal used for the contactor weld detection.  
If "0" is set, weld detection will not be executed.

---Setting range---  
0000 to 02FF (HEX)

### 【#1332(PR)】 F-bus init delay Fieldbus communication error invalid time

Tuning the power ON, start the communication, and then set the time where Fieldbus communication error is not detected.  
Set this in 0.1 second increment.

---Setting range---  
0 to 255 (0.1s)  
Standard: 0

### 【#1333】 LMC restrain Lost motion compensation restraint in handle mode

Select whether to restrain the lost motion compensation in handle mode.  
0: Restrain  
1: Not restrain

### 【#1334】 DI/DO refresh cycl DI/DO refresh cycle

Select the DI/DO refresh cycle.  
0: Standard mode  
1: High-speed mode 1  
2: High-speed mode 2

(Note 1) This setting is valid only for M700VW/M700VS/M700/M70V Series and M70(typeA).  
"Standard mode" is applied to M70 (typeB) regardless of this parameter.

(Note 2) The speed may not be high if number of ladder steps is excessive.

(Note 3) If high-speed mode is selected, the fine segment processing performance may degrade.

### 【#1335】 man\_smg Manual feed acceleration/deceleration selection

Select the acceleration/deceleration mode in jog feed, incremental feed and manual reference position return (when rapid traverse signal OFF).  
0: Acceleration/Deceleration for rapid traverse  
1: Acceleration/Deceleration for cutting feed

### 【#1336(PR)】 #400\_Valtype #400 address variable type

Select whether the #400-level variables are used as machine tool builder macro variables or as common variables.  
0: #400 to #449 are not available; #450 to #499 are used as machine tool builder macro variables.  
1: #400 to #499 are used as common variables

(Note) 700 sets or more of common variables are required for using #400 to #499 as common variables. If this parameter is set to "1" while the number of common variables is set to less than 700, this parameter setting will be regarded as "0".

### 【#1338(PR)】 rev data save trg Trigger switching to save arbitrary reverse run data

Select the condition to start/stop saving reverse run data.  
0: Start when the reverse run control mode signal is turned ON. Stop when turned OFF.  
1: Start when the reverse run control mode signal is ON and macro interrupt is valid (M96/ION).  
Stop when the reverse run control mode signal is OFF or macro interruption is finished (M97/IOF) (compatible with M500M).

### 【#1339(PR)】 MC\_dp3 Contactor weld detection device 3

When safety observation is executed, set the remote I/O device to input the contactor's auxiliary b contact signal used for the contactor weld detection.  
If "0" is set, weld detection will not be executed.

---Setting range---  
000 to 02FF (HEX)

#### [#1340(PR)] MC\_dp4 Contactor weld detection device 4

When safety observation is executed, set the remote I/O device to input the contactor's auxiliary b contact signal used for the contactor weld detection.  
If "0" is set, weld detection will not be executed.

**---Setting range---**  
000 to 02FF (HEX)

#### [#1341(PR)] ssc\_rio Safety observation remote I/O connection

Assign the safety observation function's door switch input device and contactor shutoff output device to the remote I/O.  
Select whether to enable or disable the assignment.  
0: Disable  
1: Enable

#### [#1342] AlmDly Alarm display delay time

Set a time between when an operation alarm occurs and when the alarm display and signal turn ON. When set to "0", the alarm display and signal will turn ON immediately after the alarm occurrence. When set to "-1", the alarm display and signal will not turn ON after the alarm occurrence.  
Target alarms:  
M01 External interlock axis found 0004  
M01 Internal interlock axis found 0005  
M01 Sensor signal illegal ON 0019  
M01 No operation mode 0101

**---Setting range---**  
-1 to 30000 (ms)

#### [#1349(PR)] DOOR\_1 Door 1 switch input device

Set a remote I/O device to input the door sensor signal to detect Door 1's status in safety observation.  
When "0" is set, the door is always detected to be open.  
Thus, "X0" cannot be used as Door 1 switch input device.

**---Setting range---**  
0000 to 02FF (HEX)

#### [#1350(PR)] DOOR\_2 Door 2 switch input device

Set a remote I/O device to input the door sensor signal to detect Door 2's status in safety observation.  
When "0" is set, the door is always detected to be open.  
Thus, "X0" cannot be used as Door 2 switch input device.

**---Setting range---**  
0000 to 02FF (HEX)

#### [#1353(PR)] MC\_ct1 Contactor shutoff output 1 device

Set a device of an output remote I/O device to control contactor in safety observation.  
When set to "0", contactor shutoff output is disabled.  
Thus, "Y0" cannot be used as contactor shutoff output device.

**---Setting range---**  
0000 to 02FF (HEX)

#### [#1357(PR)] mchkt1 Contactor operation check allowed time 1

Set a period of time until emergency stop is issued when a contactor does not operate even though contactor shutoff output 1 is output.  
If the vertical axis drop prevention function is used, set a value bigger than the vertical axis drop prevention time (SV048 EMGrT).  
When "0" is set, the contactor operation check will be disabled.

**---Setting range---**  
0 to 30000 (ms)

### **【#1361(PR)】 aux\_acc Auxiliary axis acceleration/deceleration type**

Select the acceleration/deceleration type of auxiliary axis in PLC axis indexing.  
0: Acceleration/deceleration with constant time  
1: Acceleration/deceleration with a constant angle of inclination

### **【#1365】 manualFtype Manual speed command type**

Select the manual speed command type.  
0: Manual speed command  
The axis travels at the handle/jog feed rate.  
Reverse run is performed for each part system independently of the other ones.  
1: Manual speed command 2  
In a multi-part system configuration, the axis travels at the handle/jog feed rate multiplied by the ratio of each part system's program command speeds.  
When the block start point is reached in reverse run in any of the part systems, the axes in the other part systems stop simultaneously.

### **【#1366】 skipExTyp Multi-system simultaneous skip command**

Select the operation when G31 is commanded in more than one part system.  
(Note) When set to "1", the skip coordinate position will always be "0" whether G31 is commanded in a single part system or in one part system of a multi-part system.  
Set to "0" when using G31 command for measurement etc.  
0: Carry out G31 command in one part system, while the G31 is kept in an interlocked state in the other systems.  
1: Carry out G31 command simultaneously in more than one part system.  
Note that the skip coordinate is not read and so the skip coordinate value will be 0.

### **【#1367】 G1AccOVRMax Max. override value for cutting feed constant inclination acc./dec.**

Set the maximum override value to be applied to the cutting feed that is in constant inclination acceleration/deceleration.  
When the setting of this parameter is between 0 and 99, the override value is handled as 100% even though the specified cutting feed override is over 100%.

---Setting range---  
0 to 300(%)

### **【#1493(PR)】 ref\_syn Synchronization at zero point initialization**

0: Primary axis and second axis determine their zero points individually.  
1: The zero points of both primary and secondary axes are determined by initializing the primary axis' zero point.

The secondary axis moves in perfect synchronization with the primary axis.  
Set this to "1" for speed/current command synchronization control.

### **【#1494(PR)】 dsp\_ax\_change Axis order of counter display**

Set this in order to change the axis order of counter display.  
The axes will be displayed in ascending order of the setting values "1" to "8".  
However, axis whose setting is "0" will be displayed after axes whose settings are between "1" and "8" are displayed.

(Note 1) When the same value is set for more than one axis, axis that is displayed on the left side on the parameter screen will be first displayed.

(Note 2) When both of the mixed control (cross axis control) and interchange coordinate position display ("1280 ext16/bit2" OFF) are valid, and when there are two or more valid part systems, this parameter will be ignored.

---Setting range---

1 to 8: Axes are displayed in ascending order.  
Other than 1 to 8: Axes are displayed after the display of the axes with setting value "1" to "8".

**【#1495(PR)】 grf\_ax\_direction Axis travel direction in 2D graphic**

Select the axis travel direction in the 2D graphic drawing (trace, check).  
If set to 1, the positive/negative directions are reversed.

---Setting range---  
0/1

**【#1501】 polyax Rotational tool axis number (for L system only)**

Set the number of the rotational tool axis used for polygon machining (G51.2). Set "0" when not using polygon machining (spindle-servo axis), or when using spindle-spindle polygon machining. A value exceeding the base specification parameter "#1002 axisno" cannot be specified. This parameter is valid when the G code system is 6 or 7 (7 or 8 is set in base specification parameter "#1037 cmdtyp").

**【#1502】 G0lpfg G1 -> G0 deceleration check**

Select whether to perform a deceleration check when the travel direction is changed from G1 to G0.  
0: Not perform  
1: Perform

**【#1503】 G1lpfg G1 -> G1 deceleration check**

Select whether to perform a deceleration check when the travel direction is changed from G1 to G1.  
0: Not perform  
1: Perform

**【#1505】 ckref2 Second reference position return check**

Select whether the check is carried out at the specified position in manual second reference position return mode upon completion of spindle orientation or at second reference position return interlock signal.  
0: Upon completion of spindle orientation  
1: At second reference position return interlock signal

**【#1506】 F1\_FM Upper limit of F1-digit feedrate**

Set the maximum value up to which the F 1-digit feedrate can be changed.

---Setting range---  
0 to 1000000 (mm/min)

**【#1507】 F1\_K F 1-digit feedrate change constant**

Set the constant that determines the speed change rate per manual handle graduation in F 1-digit feedrate change mode.

---Setting range---  
0 to 32767

**【#1510】 DOOR\_H Shorten door interlock II axis stop time**

Select whether to shorten the time during which the axis is stopped when the door is opened.  
0 : Use the conventional axis stop time.  
1 : Shorten the axis stop time.

(Note) When the door interlock II signal is input via a ladder, the conventional axis stop time will be used.

**【#1511】 DOORPm Signal input device 1 for door interlock II: for each part system**

Set the fixed device number (X??) for door interlock II signal input for each part system. A device number from X01 to XFF can be specified.(Except X100.)  
Device number "000" is invalid.  
Set device number "100" when using no fixed device number for door interlock II signal input.  
Related parameter: "#1154 pdoor (Door interlock II for each part system) "

---Setting range---  
000 to 2FF (hexadecimal)

**【#1512】 DOORPs Signal input device 2 for door interlock II: for each part system**

Set the fixed device number (X??) for door interlock II signal input for each part system.  
(Set the same value as that of #1155.)  
Related parameter: "#1154 pdoor (Door interlock II for each part system)"

---Setting range---  
000 to 2FF (hexadecimal)

**【#1513】 stapM M code for synchronous tap selection**

Set the M code for the synchronous tapping selection.  
Select the synchronous tapping mode using the miscellaneous function code of the value set in this parameter. The M function command can be issued immediately before the tap command or in the same block. This function is valid only when "1" is set in "#1272 ext08/bit1 (Enable/disable M-function synchronous tap cycle)".  
(Note) Do not use M00, 01 02, 30, 98, and 99.

---Setting range---  
0 to 99999999

**【#1514】 expLinax Exponential function interpolation linear axis**

Set the axis name for the linear axis used in exponential function interpolation.

---Setting range---  
A to Z

**【#1515】 expRotax Exponential function interpolation rotary axis**

Set the axis name for the rotary axis used in exponential function interpolation.

---Setting range---  
A to Z

**【#1516】 mill\_ax Milling axis name**

Set the name of the rotary axis used in milling interpolation. Only one rotary axis can be set.  
When there is no E command in issuing the G12.1 command, this parameter will be followed.

---Setting range---  
A to Z

**【#1517】 mill\_C Milling interpolation hypothetical axis name**

Select the hypothetical axis command name for milling interpolation.  
When there is no D command in issuing the milling interpolation command, this parameter will be followed.  
0: Y axis command  
1: Command rotary axis name.

**【#1518】 polm Spindle-spindle polygon Workpiece spindle No.**

Set the workpiece axis No. used in spindle-spindle polygon machining.  
(Note) The 1st spindle will be selected when "0" is set.

**【#1519】 pols Spindle-spindle polygonTool spindle No.**

Set the number of the rotary tool spindle used in spindle-spindle polygon machining.  
(Note) The 2nd spindle will be selected when "0" is set.

**【#1520(PR)】 Tchg34 Additional axis tool compensation operation (for L system only)**

Select axis to carry out the additional axis' tool compensation function.  
0: 3rd axis.  
1: 4th axis.



**【#1521】 C\_min Minimum turning angle**

Set the minimum turning angle of the normal line control axis at the block joint during normal line control.

**---Setting range---**

0.000 to 360.000 (°) (Input setting increment applies)

**【#1522(PR)】 C\_axis Normal line control axis**

Set the number of the axis for normal line control.

Set a rotary axis No.

0: Normal line control disabled

1 to 8: Axis No. (number of control axes)

**【#1523】 C\_feed Normal line control axis turning speed**

Set the turning speed of the normal line control axis at the block joint during normal line control.

Set a value that does not exceed the normal line control axis' clamp speed ("#2002 clamp").

This is valid with normal line control type I.

**---Setting range---**

0 to 1000000 (°/min)

**【#1524】 C\_type Normal line control type**

Select the normal line control type.

0: Normal line control type I

1: Normal line control type II

**【#1533】 millPax Pole coordinate linear axis name**

Set the linear axis name used for pole coordinate interpolation.

**---Setting range---**

Axis name such as X, Y or Z

**【#1534】 SnG44.1 Spindle No. for G44.1 command**

Set the selected spindle No. for the G44.1 command.

The setting range differs according to the model.

If a spindle that does not exist is set, the 2nd spindle will be used. Note that if there is only one spindle, the 1st spindle will be used.

0: 2nd spindle

1: 1st spindle

2: 2nd spindle

3: 3rd spindle

4: 4th spindle

5: 5th spindle

6: 6th spindle

**【#1535】 C\_leng Minimum turning movement amount**

Set the minimum turning movement amount of the normal line control axis at the block joint during normal line control.

**---Setting range---**

0.000 to 99999.999 (mm) (Input setting increment applies)

**【#1537】 crsax[1] Mixed control (cross axis control) axis**

Set the axis to be interchanged during the mixed control (cross axis control).

Using two digits, set the name of the axis to be interchanged with the axis in the part system where the mixed control (cross axis control) request signal is input, or the name of the axis to be shifted to that part system.

**---Setting range---**

Two digits between A to Z and 1 to 9

(Setting will be cleared when "0" is set)

**【#1538】 crsax[2]**

Set the axis to be interchanged during the mixed control (cross axis control).  
Using two digits, set the name of the axis to be interchanged with the axis in the part system where the mixed control (cross axis control) request signal is input, or the name of the axis to be shifted to that part system.

**---Setting range---**

Two digits between A to Z and 1 to 9  
(Setting will be cleared when "0" is set)

**【#1539】 crsax[3]**

Set the axis to be interchanged during the mixed control (cross axis control).  
Using two digits, set the name of the axis to be interchanged with the axis in the part system where the mixed control (cross axis control) request signal is input, or the name of the axis to be shifted to that part system.

**---Setting range---**

Two digits between A to Z and 1 to 9  
(Setting will be cleared when "0" is set)

**【#1540】 crsax[4]**

Set the axis to be interchanged during the mixed control (cross axis control).  
Using two digits, set the name of the axis to be interchanged with the axis in the part system where the mixed control (cross axis control) request signal is input, or the name of the axis to be shifted to that part system.

**---Setting range---**

Two digits between A to Z and 1 to 9  
(Setting will be cleared when "0" is set)

**【#1541】 crsax[5]**

Set the axis to be interchanged during the mixed control (cross axis control).  
Using two digits, set the name of the axis to be interchanged with the axis in the part system where the mixed control (cross axis control) request signal is input, or the name of the axis to be shifted to that part system.

**---Setting range---**

Two digits between A to Z and 1 to 9  
(Setting will be cleared when "0" is set)

**【#1542】 crsax[6]**

Set the axis to be interchanged during the mixed control (cross axis control).  
Using two digits, set the name of the axis to be interchanged with the axis in the part system where the mixed control (cross axis control) request signal is input, or the name of the axis to be shifted to that part system.

**---Setting range---**

Two digits between A to Z and 1 to 9  
(Setting will be cleared when "0" is set)

**【#1543】 crsax[7]**

Set the axis to be interchanged during the mixed control (cross axis control).  
Using two digits, set the name of the axis to be interchanged with the axis in the part system where the mixed control (cross axis control) request signal is input, or the name of the axis to be shifted to that part system.

**---Setting range---**

Two digits between A to Z and 1 to 9  
(Setting will be cleared when "0" is set)

**【#1544】 crsax[8]**

Set the axis to be interchanged during the mixed control (cross axis control).  
Using two digits, set the name of the axis to be interchanged with the axis in the part system where the mixed control (cross axis control) request signal is input, or the name of the axis to be shifted to that part system.

**---Setting range---**

Two digits between A to Z and 1 to 9  
(Setting will be cleared when "0" is set)

**【#1561】 3Dcdc Switch workpiece coordinate display during 3D coordinate conversion**

Select the workpiece coordinate display during 3D coordinate conversion.

- 0: Workpiece coordinate system
- 1: G68 program coordinate system

(Note) The special display unit's absolute coordinates also follow this parameter setting.

**【#1562】 3Dremc Switch remaining command display during 3D coordinate conversion**

Select the remaining command display during 3D coordinate conversion.

- 0: Workpiece coordinate system
- 1: G68 program coordinate system

**【#1563】 3Dcdrc Switch coordinate reading during 3D coordinate conversion**

Select the coordinate system of the workpiece/skip coordinate read value in the 3D coordinate conversion modal.

- 0: G68 program coordinate system
- 1: Workpiece (local) coordinate system

**【#1564】 3Dspd Hole drilling speed during 3D coordinate conversion**

Select the rapid traverse rate for the hole drilling cycle during 3D coordinate conversion.

- 0: The cutting feed clamp speed is used.
- Other than 0: The set speed is used.

Note that if the rapid traverse rate is exceeded, the speed will be clamped at the rapid traverse rate.

**---Setting range---**

0 to 1000000mm/min

**【#1565】 helgear Helical machining base axis**

Set the base axis for helix angle calculation in helical machining. When no setting, Z axis will be used.

**---Setting range---**

Axis name such as X, Y, Z, U, V, W, A, B, and C

**【#1566】 3DSelctDrillaxMode Switch drill axis's mode from rapid traverse during 3D coordinate conversion**

Select the rapid traverse mode in non-drilling blocks among a drilling cycle to the cutting feed mode during 3-dimensional coordinate conversion.

- 0: Rapid traverse mode. The speed follows the setting of "#2001 rapid".
- 1: Cutting feed mode. The speed follows the setting of "#1564 3Dspd".

**【#1568】 SfiltG1 G01 soft acceleration/deceleration filter**

Set the filter time constant for smoothly changing the acceleration rate for the cutting feed acceleration/deceleration in pre-interpolation acceleration/deceleration.

**---Setting range---**

0 to 200 (ms)

**Notch frequency Hz**

Displays the notch frequency(Hz) for the S-pattern filter set in "#1568 SfiltG1 (G01 soft acceleration/deceleration filter)"

#### 【#1569】 SfiltG0 G00 soft acceleration/deceleration filter

Set the filter time constant for smoothly changing the acceleration rate for the rapid traverse acceleration/deceleration in pre-interpolation acceleration/deceleration.

---Setting range---  
0 to 200 (ms)

#### 【#1570】 Sfilt2 Soft acceleration/deceleration filter 2

Set the filter time constant for smoothly changing the acceleration rate in pre-interpolation acceleration/deceleration.  
This will be disabled when "0" or "1" is set.

---Setting range---  
0 to 50 (ms)

#### Notch frequency Hz

Displays the notch frequency(Hz) for the S-pattern filter set in "#1570 Sfilt2 (Soft acceleration/deceleration filter 2)".

#### 【#1571】 SSSdis SSS control adjustment coefficient fixed value selection

Fix the shape recognition range for SSS control.

#### 【#1572】 Cirorp Arc command overlap

This eliminates speed fluctuations at the joint of the arc and straight line and arc and arc.  
Set as a bit unit.  
0: Do not overlap the arc command blocks  
1: Overlap the arc command blocks

**bit0 : Arc command during high-speed high-accuracy control II**

**bit1 : Arc command during high-speed machining mode II**

**bit2 : Arc command during high-accuracy control (G61.1)**

**bit3 : Arc command during cutting mode (G64)**

The line command block and arc command block won't be overlapped during G61.2 modal regardless of this setting.

(Note) This parameter is invalid during SSS control.

#### 【#1573】 Ret1 Return type 1

Select the axis to be moved later after tool return.  
This is referred to with the movement path (transit point #1 -> interrupt point).  
Up to eight axes can be specified by expressing one axis with one bit.

**bit0 : Transit point #1 1st axis**

**bit1 : Transit point #1 2nd axis**

**bit2 : Transit point #1 3rd axis**

**bit3 : Transit point #1 4th axis**

**bit4 : Transit point #1 5th axis**

**bit5 : Transit point #1 6th axis**

**bit6 : Transit point #1 7th axis**

**bit7 : Transit point #1 8th axis**

---Setting range---  
00000000 to 11111111 (Binary)

### 【#1574】 Ret2 Return type 2

Select the axis to be moved later after tool return.  
This is referred to with the movement path (return start point -> transit point #2).  
Up to eight axes can be specified by expressing one axis with one bit.

**bit0 : Transit point #2 1st axis**

**bit1 : Transit point #2 2nd axis**

**bit2 : Transit point #2 3rd axis**

**bit3 : Transit point #2 4th axis**

**bit4 : Transit point #2 5th axis**

**bit5 : Transit point #2 6th axis**

**bit6 : Transit point #2 7th axis**

**bit7 : Transit point #2 8th axis**

---Setting range---

00000000 to 11111111 (Binary)

### 【#1590】 Animate ax direct Machine status animated display axis direction(+/-)

**<bit0>**

0: 1st axis + direction is set to the right direction.  
1: 1st axis + direction is set to the left direction.

**<bit1>**

0: 2nd axis + direction is set to the rear direction.  
1: 2nd axis + direction is set to the front direction.

**<bit2>**

0: 3rd axis + direction is set to the top direction.  
1: 3rd axis + direction is set to the bottom direction.

### 【#1591】 Animate ax-1 Machine status animated display axis name (1st axis)

Set the name of the 1st axis displayed with the machine status animation. When the axis name is not specified, the current 1st axis name ("#1013 axname") will be used.

---Setting range---

Axis name such as X, Y, Z

### 【#1592】 Animate ax-2 Machine status animated display axis name (2nd axis)

Set the name of the 2nd axis displayed with the machine status animation. When the axis name is not specified, the current 2nd axis name ("#1013 axname") will be used.

---Setting range---

Axis name such as X, Y, Z

### 【#1593】 Animate ax-3 Machine status animated display axis name (3rd axis)

Set the name of the 3rd axis displayed with the machine status animation. When the axis name is not specified, the current 3rd axis name ("#1013 axname") will be used.

---Setting range---

Axis name such as X, Y, Z

### 【#1901(PR)】 station addr

Not used. Set to "0".

**【#1902(PR)】 Din size**

Not used. Set to "0".

**【#1903(PR)】 Dout size**

Not used. Set to "0".

**【#1904(PR)】 data length**

Not used. Set to "0".

**【#1905(PR)】 baud rate**

Not used. Set to "0".

**【#1906(PR)】 stop bit**

Not used. Set to "0".

**【#1907(PR)】 parity check**

Not used. Set to "0".

**【#1908(PR)】 even parity**

Not used. Set to "0".

**【#1909(PR)】 Tout (ini)**

Not used. Set to "0".

**【#1910(PR)】 Tout (run)**

Not used. Set to "0".

**【#1911(PR)】 clock select**

Not used. Set to "0".

**【#1925】 EtherNet Start of service**

Start or stop the Ethernet communication function.  
0: Stop  
1: Start

**【#1926(PR)】 Global IP address IP address**

Set the main CPU's IP address.  
Set the NC IP address seen from an external source.

**【#1927(PR)】 Global Subnet mask Subnet mask**

Set the subnet mask for the IP address.

**【#1928(PR)】 Global Gateway Gateway**

Set the IP address for the gateway.

**【#1929】 Port number Port No.**

Set the port No. for the service function.

---Setting range---

1 to 9999

(Set 2000 when not connected to the Ethernet.)

**【#1930(PR)】 Host address Host address**

Set the host's IP address.

# Appendix 1 Explanation of Parameters

## 【#1931(PR)】 Host number Host No.

Set the host's port No.

---Setting range---  
1 to 9999

## 【#1934(PR)】 Local IP address

Set the HMI side CPU's IP address.

(Note) This parameter is valid only for M700/M700VW Series.

## 【#1935(PR)】 Local Subnet mask

Set the HMI side CPU's subnet mask.

(Note) This parameter is valid only for M700/M700VW Series.

## 【#11001(PR)】 APC type APC screen display type selection

Set the type of screen displayed with the pallet program registration screen.

0: Standard pallet registration screen  
1: Pallet 4-page registration screen

## 【#11002(PR)】 Valid pallet num Number of pallets setting

Set the number of pallets validated on the pallet program registration screen.

---Setting range---  
2 to 12 (Interpreted as 2 when 0 is set.)

## 【#11003(PR)】 APLC valid APLC valid

Temporarily disable APLC.

Normally set "1".

0: Disable  
1: Enable

## 【#11004(PR)】 PLCauto-run enable PLC automatic startup valid

Select starting condition of the built-in PLC.

0: Start PLC after NC screen startup  
1: Start PLC at NC startup

(Note) When standard NC screen is not used, set "1".

## 【#11005(PR)】 PC IP address IP address setting

Set the IP address for the display unit or PC in which machining programs are stored.

Set the IP address for the display unit on which the automatic power OFF will be executed.

When the 3D machine interference check function is enabled, set the IP address of the display unit that is used for the 3D machine interference check (for M700VW only).

(Note 1) When "0.0.0.0" is input, "192.168.100.2" is automatically set.

(Note 2) This parameter is valid only for M700VW/M700 Series.

### PC Subnet

Set the subnet mask for the display unit or PC in which machining programs are stored.

### PC Gateway

Set the gateway for the display unit or PC in which machining programs are stored.

## 【#11006】 PC Port number Port No. setting

Set the port No. for the display unit or PC in which machining programs are stored.

(Note 1) When "0" is input, "55555" is automatically set.

(Note 2) When changing the parameter, set the same value in "PD\_Control\_Port" in the PC side environment setting file.

---Setting range---  
0 to 65535

### 【#11007】 PC Timeout Communication timeout time setting

Set the NC side communication timeout time.

(Note 1) When "0" is input, "30" is automatically set.

(Note 2) When the value greater than "300" is set, a setting error occurs.

(Note 3) When changing the parameter, set the same value in "PD\_Time\_out" in the PC side environment setting file.

---Setting range---

0 to 300 (s)

### 【#11009(PR)] M2 label O M2 label O

Select the program number label when using the M2 format.

0: Label L

1: Label O

### 【#11010(PR)] Software keyboard Software keyboard

Select with touch panel whether to use software keyboard.

0: Do not use

1: Use

2: Use (Note1)

(Note1) Software keyboard automatically appears on a specific screen. (For M700VS/M70V/M70 Series only).

### 【#11011] Handy TERM. PW. Handy terminal password

Set the password used for the handy terminal customized downloading.

Blank (when "0" is set) and "0000" are regarded as no password.

Not the password of a new customizing file but the password of the customizing file downloaded to the last handy terminal is set.

Set blank or "0000" when initially downloading.

---Setting range---

0000 to 9999

### 【#11012(PR)] 16 axes for 1ch Connecting 16 axes for 1ch

Select the maximum number of axes (sum of the NC axis, spindle, and PLC axis) connected to the drive unit interface (channel 1) when not using the extension unit (FCU7-EX891+HN552)

0: Up to 8 axes can be connected to channel 1.

1: Up to 16 axes can be connected to channel 1. This parameter is disabled when the extension unit is connected. It is possible to connect only up to eight axes or less per channel.

### 【#11013] 3D\_MChk Invalidate 3D machine interference check

Select whether to enable the 3D machine interference check function.

0: Enable

1: Disable

### 【#11014] Chk\_len1 1st-step interference check distance

Set the 1st-step check distance when in 3D machine interference check mode.

The standard value is "30.000".

---Setting range---

0.000 to 99999.999(mm)

### 【#11015] Chk\_len2 2nd-step interference check distance

Set the 2nd-step check distance when in 3D machine interference check mode.

The standard value is "5.000".

---Setting range---

0.000 to 99999.999(mm)



**【#11016】 Expand\_Rate Shape expansion rate**

Set the model shape expansion rate to be used for 3D machine interference check. This parameter is used for expanding a model shape to be used for 3D machine interference check. The interference check is performed using a shape expanded by the amount of [Check length (mm) x Shape expansion rate (%)].

**---Setting range---**

0 to 300(%)

**【#11017】 T-ofs set at run**

Select whether to enable the tool compensation amount setting and life value setting during automatic operation and operation pause.

- 0: Disable
- 1: Enable

**【#11018】 M password hold**

Select whether to enable the "Machine user" password holding. When this is set to "1", the "Machine user" password will be held.

- 0: Disable
- 1: Enable

**【#11019】 2-system display 2-part system simultaneous display**

Select whether to validate 2-part system simultaneous display on operation screen.

- 0: Display one part system on operation screen
- 1: Display two part systems simultaneously on operation screen
- 2: Display two part systems simultaneously (Display type 2) on operation screen

(Note 1) Unless you set "1" in two or more of "#1001 SYS\_ON [1] to [4]", two-part system simultaneous display will fail regardless of this parameter.

**【#11021】 PLC mesg disp type Format of PLC alarm and operator message**

Select the format of PLC alarms and operator messages to be displayed on the bottom right of the screen.

- 0: Display up to the first 40 characters.
- 1: If text is longer than 40 characters, divide it into two and display separately. (Classification No. is displayed together)

**【#11022】 SRAM Output Type SRAM output type**

Set the SRAM output type.

(Note) In M700 Series, the conventional SRAM output type is set regardless of the setting of this parameter.

- 0: The latest SRAM output type is set.  
(Not compatible with F3 and versions older than F3.)
- 1: The conventional SRAM output type is set.  
(Compatible with F3 and versions older than F3.)

**【#11023】 G33.n Drn G33.n dryrun**

Select whether to enable dry run in C axis interpolation type thread cutting. The standard setting is "0".

- 0: Enable
- 1: Disable

**【#11024】 G33.n fhd G33.n feed hold**

Select whether to enable feed hold in C axis interpolation type thread cutting. The standard setting is "0".

- 0: Disable
- 1: Enable

### **【#11028】 Tolerance Arc Cent Tolerable correction value of arc center error**

Set the tolerable correction value for the calculated coordinate value error of R-specified circular center.  
When a difference between "a line between the start and end points" and "commanded radius x 2" is the tolerance or smaller, the error is corrected so that the middle of a line between the start and end points will be the arc center.

When [Setting value < 0] : 0 (Not correct)  
When [Setting value = 0] : 2 x minimum setting increment  
When [Setting value > 0] : Setting value

---Setting range---  
-1 to 0.100(mm)

### **【#11029】 Arc to G1 no Cent Change command from arc to linear when no arc center designation**

Select the operation when arc center or radius designation is omitted from arc command.  
0: Program error  
1: Change into linear command

### **【#11030】 Man tap sync cancel Synchronization cancel in manual synchronous tapping**

Select whether the tapping axis in manual synchronous tapping synchronizes with the spindle.  
0: Synchronize with the spindle  
1: Not synchronize with the spindle

### **【#11031(PR)】 Cursor pos search Cursor position search**

Select the cursor position searching method.  
0: Disable  
1: Pressing the INPUT key in [Monitr] - [Edit] menu starts the operation search for the block with the cursor.  
2: Turning ON/OFF the "Edit/Search" signal in [Monitr] - [Edit] menu starts the operation search for the block with the cursor.  
3: Turning ON/OFF the "Edit/Search" signal in [Monitr] - [Edit] menu starts the operation search for the block with the cursor. Pressing the reset key shows the top of the program on the [Edit/Search] window.

### **【#11032(PR)】 Menu sel para lkof Validate menu selection parameter setting**

Select whether to enable the setting of the "menu selection parameters" (#10501 to #10530, #10551 to #10580, and #10601 to #10630), with which the order of main menus on Monitor, Setup and Edit screens can be rearranged. And also select who is allowed to do this setting.  
0: Disable  
1: Enable (machine tool builder password is required)  
2: Enable (users are allowed to set)

### **【#11033(PR)】 skipB\_no\_sens Unconnected sensor selection when skip is set to contact B**

Select the contact of the sensor which you wish to set as unconnected, when the skip signal is set to contact B.  
Set "1" for the contact to be unconnected.

bit0: Skip input 1  
bit1: Skip input 2  
bit2: Skip input 3  
bit3: Skip input 4  
bit4: Skip input 5  
bit5: Skip input 6  
bit6: Skip input 7  
bit7: Skip input 8

(Note 1) This parameter is enabled when "#1258 set30/bit0" is set to "1".  
(Note 2) This parameter is independent of PLC skip.

---Setting range---  
00000000 to 11111111 (Binary)

**【#11034】 G12AddrCheckType Command address type to check in circular cutting**

Select the type of command address to check in circular cutting.

0: Regard command addresses other than D, F, I as illegal.

1: Regard the command address H as illegal. And commands other than D,F,I and M,S,T,B are disabled.

**【#11035】 Sys. change limit Part system switching restriction**

This restricts switching the part systems displayed on screen.

0: Not restrict

1: Disable the part system switching by pressing [ \$<->\$ ] key on touch panel.

2: Disable the part system switching by display switch signals(Y730 to Y733).

**【#11036】 meas dir judge Non-sensitive band for manual measurement direction judgment (for M system only)**

Set the non-sensitive band to be used for judging the manual measurement direction. If the feedback position fluctuates widely at the axis stop, set the fluctuation width or larger value in this set the parameter.

When set to "0", the band will be 1(um).

**---Setting range---**

0 to 1000(um)

0: 1(um)

**【#12001】 ManualB RectanA xH Manual feed rate B constant surface control intersecting part system axis name (horizontal)**

Set the part system axis name ("#1013 axname") for the two axes that intersect with the rotary axis direction. When one of the two axes is blank, a constant speed will be applied without using constant surface speed control.

**---Setting range---**

Axis addresses such as X, Y, Z, U, V, W, A, B, and C

**【#12002】 ManualB RectanA xV Manual feed rate B constant surface control intersecting part system axis name (vertical)**

Set the part system axis name ("#1013 axname") for the two axes that intersect with the rotary axis direction. When one of the two axes is blank, a constant speed will be applied without using constant surface speed control.

**---Setting range---**

Axis addresses such as X, Y, Z, U, V, W, A, B, and C

**【#12003】 ManualB RotCent erH Manual feed rate B constant surface control rotation center machine position (horizontal)**

Set the machine coordinate position (horizontal axis) at the center of the rotary axis.

**---Setting range---**

-99999.999 to 99999.999 (mm)

**【#12004】 ManualB RotCent erV Manual feed rate B constant surface control rotation center machine position (vertical)**

Set the machine coordinate position (vertical axis) at the center of the rotary axis.

**---Setting range---**

-99999.999 to 99999.999 (mm)

**【#12005(PR)】 Mfig Number of M**

Set the number of M that can be specified within the same block.

**---Setting range---**

1 to 4

#### 【#12006(PR)】 Mbin M binary

Data type 0 BCD  
Data type 1 Unsigned binary  
Data type -1 Singed binary

<For unsigned binary>  
The absolute value "1" is output for "-1".  
<For singed binary>  
"-1" is output as "0xFFFFFFFF".

##### ---Setting range---

Data type  
(-1,0,1)

#### 【#12007(PR)】 Sfig Number of S

Set the number of spindles.  
(Note 1) The setting range differs according to the model.  
(Note 2) Sfig is set in the range of 1 to 6. However, the number of outputs by Sfig cannot be controlled. Thus, only one S command is output regardless of the Sfig setting value.

##### ---Setting range---

1 to 6

#### 【#12008(PR)】 Sbin S binary

Data type 0 BCD  
Data type 1 Unsigned binary  
Data type -1 Singed binary

<For unsigned binary>  
The absolute value "1" is output for "-1".  
<For singed binary>  
"-1" is output as "0xFFFFFFFF".  
(Note 1) Sbin can be set with "-1", "0" and "1", but the S command cannot be BCD output.  
If BCD (0) is selected for Sbin, it will be handled as a singed binary (-1).

##### ---Setting range---

Data type  
(-1,0,1)

#### 【#12009(PR)】 Tfig Number of T

Set the number of T that can be specified within the same block.

##### ---Setting range---

1 to 4

#### 【#12010(PR)】 Tbin T binary

Data type 0 BCD  
Data type 1 Unsigned binary  
Data type -1 Singed binary

<For unsigned binary>  
The absolute value "1" is output for "-1".  
<For singed binary>  
"-1" is output as "0xFFFFFFFF".

##### ---Setting range---

Data type  
(-1,0,1)

#### 【#12011(PR)】 Bfig Number of B

Set the number of T that can be specified within the same block.

##### ---Setting range---

1 to 4

### **【#12012(PR)】 Bbin B binary**

Data type 0 BCD  
 Data type 1 Unsigned binary  
 Data type-1 Signed binary

<For unsigned binary>  
 The absolute value "1" is output for "-1".

<For signed binary>  
 "-1" is output as "0xFFFFFFFF".

#### **---Setting range---**

Data type  
 (-1,0,1)

### **【#12013】 G33.n rot G33.n rotary axis name**

Select the axis to use as C axis with its axis name.

#### **---Setting range---**

A to Z

### **【#12014】 G33.n ovr G33.n override**

Select which spindle's override is applied in C axis interpolation type thread cutting.  
 Setting values 1 to 6 correspond to the 1st to 6th spindles respectively.  
 Setting "0" disables the spindle override in thread cutting blocks: The override will be fixed to 100%.

#### **---Setting range---**

0 to 6  
 Standard value: 0

## Appendix 1.3 Axis Specifications Parameters

The parameters with "(PR)" requires the CNC to be turned OFF after the settings. Turn the power OFF and ON to enable the parameter settings.

### **【#2001】 rapid Rapid traverse rate**

Set the rapid traverse feedrate for each axis.

(Note) The maximum value to be set depends on the machine specifications.

#### **---Setting range---**

1 to 1000000 (mm/min)

### **【#2002】 clamp Cutting feedrate for clamp function**

Set the maximum cutting feedrate for each axis.


Even if the feedrate in G01 exceeds this value, the clamp will be applied at this feedrate.

#### **---Setting range---**

1 to 1000000 (mm/min)

# 【#2003(PR)】 smgst Acceleration and deceleration modes

Set acceleration and deceleration control modes.  
Set value is in hexadecimal.



## HEX-1 Rapid traverse acceleration/deceleration type

- 0(bit3,2,1,0 = 0000) : Step
- 1(bit3,2,1,0 = 0001) : Linear acceleration/deceleration
- 2(bit3,2,1,0 = 0010) : Prim ary delay
- 8(bit3,2,1,0 = 1000) : Exponential acceleration and linear deceleration
- F(bit3,2,1,0 = 1111) : Soft acceleration/deceleration


(Note) R1 > R3 when both R1 and R3 contain 1.

## HEX-2 Cutting feed acceleration/deceleration type

- 0(bit7,6,5,4 = 0000) : Step
- 1(bit7,6,5,4 = 0001) : Linear acceleration/deceleration
- 2(bit7,6,5,4 = 0010) : Prim ary delay
- 8(bit7,6,5,4 = 1000) : Exponential acceleration and linear deceleration
- F(bit7,6,5,4 = 1111) : Soft acceleration/deceleration

## HEX-3 Stroke end stop types

- 0(bit9,8 = 00) : Linear deceleration (Decelerates at G0t1)
- 1(bit9,8 = 01) : Linear deceleration (Decelerates at 2xG0t1)
- 2(bit9,8 = 10) : Position loop step stop
- 3(bit9,8 = 11) : Position loop step stop



(Note) OT1(bit8) is valid under the following conditions (valid for dog type zero point return):


- Stop type: Linear deceleration
- Acceleration/Deceleration mode: Exponential acceleration and Linear deceleration

## HEX-4

Not used. Set to "0".

### 【#2004】 G0tL G0 time constant (linear)

Set a linear control time constant for rapid traverse acceleration and deceleration.  
The time constant will be enabled when LR (rapid traverse feed with linear acceleration/deceleration) or F (soft acceleration/deceleration) is selected in "#2003 smgst Acceleration and deceleration modes".




---Setting range---  
1 to 4000 (ms)


### 【#2005】 G0t1 G0 time constant(primary delay) / Second-step time constant for soft acceleration/deceleration

Set a primary-delay time constant for rapid traverse acceleration and deceleration.  
The time constant will be enabled when R1 (rapid traverse feed with primary delay) or R3 (exponential acceleration and linear deceleration) is selected in "#2003 smgst Acceleration and deceleration modes".  
When the soft acceleration/deceleration is selected, the second-step time constant will be used.


<Rapid traverse feed with primary delay>



<Rapid traverse feed with exponential acceleration and linear deceleration>



<Soft acceleration/deceleration>  
- When "#1219 aux03/bit7" is set to "0"



(Note) The time constant setting for the soft acceleration/deceleration can be changed by the setting of "#1219 aux03/bit7"

---Setting range---  
1 to 5000 (ms)

### 【#2006】 G0t2


Not used. Set to "0".



**【#2007】 G1tL G1 time constant (linear)**

Set a linear control time constant for cutting acceleration and deceleration.

The time constant will be enabled when LC (cutting feed with linear acceleration/deceleration) or F (soft acceleration/deceleration) is selected in "#2003 smgst Acceleration or deceleration modes".



---Setting range---

1 to 4000 (ms)


**【#2008】 G1t1 G1 time constant (primary delay)/Second-step time constant for soft acceleration/deceleration**

Set the primary delay time constant for cutting acceleration and deceleration.


The time constant will be enabled when C1 (cutting feed with the primary delay) or C3 (cutting feed with exponential acceleration and linear deceleration) is selected in "#2003 smgst acceleration/ deceleration modes".

When the soft acceleration or deceleration is selected, the second-step time constant will be used.


<Cutting feed with primary delay>



<Cutting feed with exponential acceleration and linear deceleration>



<Soft acceleration/deceleration>



---Setting range---

1 to 5000 (ms)

**【#2009】 G1t2**

Not used. Set to "0".

### 【#2010】 fwd\_g Feed forward gain

Set a feed forward gain for pre-interpolation acceleration/deceleration.  
The larger the set value, the smaller the theoretical control error will be. However, if a machine vibration occurs, set the smaller value.

---Setting range---  
0 to 200 (%)

### 【#2011】 G0back G0 backlash

Set up the backlash compensation amount when the direction is reversed with the movement command in rapid traverse feed mode or in manual mode.

---Setting range---  
-9999999 to 9999999

### 【#2012】 G1back G1 backlash


Set up the backlash compensation amount when the direction is reversed with the movement command in cutting mode.

---Setting range---  
-9999999 to 9999999

### 【#2013】 OT - Soft limit I -

Set a soft limit area with reference to the zero point of the basic machine coordinate. Set the coordinate in the negative direction for the movable area of stored stroke limit 1. The coordinate in the positive direction is set in "#2014 OT+".

To narrow the available range in actual use, use the parameters "#8204 OT-" and "#8205 OT+".  
When the same value (other than "0") is set in this parameter and "#2014 OT+", this function will be disabled.



---Setting range---  
-99999.999 to 99999.999 (mm)


## Appendix 1 Explanation of Parameters

### 【#2014】 OT + Soft limit I +

Set a soft limit area with reference to the zero point of the basic machine coordinate. Set the coordinate in the positive direction for the movable area of stored stroke limit 1. The coordinate in the negative direction is set in "#2013 OT-".

To narrow the available range in actual use, use the parameters "#8204 OT-" and "#8205 OT+".

When the same value (other than "0") is set in this parameter and "#2013 OT-", this function will be disabled.



#### ---Setting range---

-99999.999 to 99999.999 (mm)

### 【#2015】 t1m1- Negative direction sensor of tool setter or TLM standard length

Set a sensor position in the negative direction when using the tool setter.

When the TLM is used, set the distance from a tool change point (reference position) to the measurement basic point (surface) in order to measure the tool length.

(Note) In the case of the basic axis and inclined axis of the inclined axis specifications, set the position on the orthogonal coordinate.

#### ---Setting range---

-99999.999 to 99999.999 (mm)

### 【#2016】 t1m1+ Positive direction sensor of tool setter

Set the sensor position in the positive direction when using the tool setter.

(Note) In the case of the basic axis and inclined axis of the inclined axis specifications, set the position on the orthogonal coordinate.

#### ---Setting range---

-99999.999 to 99999.999 (mm)

### 【#2017】 tap\_g Axis servo gain

Set the position loop gain for special operations (synchronized tapping, interpolation with spindle C axis, etc.).

Set the value in 0.25 increments.

The standard setting value is "10".

#### ---Setting range---

0.25 to 200.00 (rad/s)

### 【#2018(PR)】 no\_srv Operation with no servo control

Select when performing test operation without connecting the drive unit and motor.

0: Normal operation

1: Test operation

When "1" is set, the operation will be possible even if drive units and motor are not connected, because the drive system alarm will be ignored.

This parameter is used for test operation during start up: Do not use during normal operation. If "1" is set during normal operation, errors will not be detected even if they occur.

### 【#2019】 revnum Return steps

Set the steps required for reference position return for each axis.

0: Not execute reference position return.

1 to max. number of NC axes: Steps required for reference position return

**【#2020】 o\_chkp Spindle orientation completion check during second reference position return**

Set the distance from the second reference position to the position for checking that the spindle orientation has completed during second reference position return.  
When the set value is "0", the above check will be omitted.

---Setting range---  
0 to 99999.999 (mm)

**【#2021】 out\_f Maximum speed outside soft limit range**

Set the maximum speed outside the soft limit range.

---Setting range---  
0 to 1000000 (mm/min)

**【#2022】 G30SLX Validate soft limit (automatic and manual)**

Select whether to disable a soft limit check during the second to the fourth reference position return in both automatic and manual operation modes.

0: Enable  
1: Disable

**【#2023】 ozfmin Set up ATC speed lower limit**

Set the minimum speed outside the soft limit range during the second to the fourth reference position return.

---Setting range---  
0 to 1000000 (mm/min)

**【#2024】 synerr Allowable error**

Set the maximum synchronization error, allowable at the synchronization error check, for the primary axis.  
When "0" is set, the error check will not be carried out.

---Setting range---  
0 to 99999.999 (mm)

**【#2025】 G28rap G28 rapid traverse rate**

Set a rapid traverse rate for the dog type reference position return command.  
This is not used for the distance-coded reference position detection.

---Setting range---  
1 to 1000000 (mm/min)

**【#2026】 G28crp G28 approach speed**

Set the approach speed to the reference position.

(Note) The G28 approach speed unit is (10°/min) only when using the Z-phase type encoder (#1226 aux10/bit3=1) for the spindle/C-axis reference position return type. The same unit is used for both the micrometric and sub-micrometric specifications.

---Setting range---  
1 to 60000 (mm/min)

**【#2027】 G28sft Reference position shift distance**

Set the distance from the electrical zero-point detection position to the reference position.  
 This is not used for the distance-coded reference position detection.


- (Note 1) When "#1240 set12/bit2" is ON, a magnification (C: 10-fold, D: 100-fold and E: 1000-fold) corresponding to the input setting unit ("#1003 iunit") will be applied to the setting value.
- (Note 2) The sign of setting value is will be following: the direction of "#2030 dir (-)" Reference position direction (-)" is plus, and the opposite direction is minus.
- (Note 3) When set value is set to minus, the axis moves to electrical zero-point detection position at first and then moves in opposite direction.

**---Setting range---**

-99.999 to +99.999 (mm)

**【#2028】 grmask Grip mask amount**

Set the distance where the grid point will be ignored when near-point dog OFF signals are close to that grid point during reference position return.



The grid mask is valid for one grid.  
 This is not used for the distance-coded reference position detection.

**---Setting range---**

0.000 to 99.999 (mm)

**【#2029】 grspc Grid interval**

Grid space (#2029 grspc)

Set the distance between grids.

Normally, the ball screw pitch value (#2218 PIT) or the movement amount per motor rotation is set as the grid space. To make the grid space smaller, set a divisor of the grid space.

<Calculation method for movement amount per motor rotation>

(1) When linear feed mechanism is a ball screw:

The movement amount per motor rotation = the motor side gear ration / the machine side gear ratio x the ball screw pitch

(2) When linear feed mechanism is a rack and pinion:

The movement amount per motor rotation = the motor side gear ration / the machine side gear ratio x number of pinion gear teeth x the rack pitch

(3) For the rotary axis:

The movement angle per motor rotation = the motor side gear ration / the machine side gear ratio x 360


**---Setting range---**

0.000 to 999.999 (mm)

### 【#2030(PR)】 dir (-) Reference position direction (-)

Select which side of the near-point dog the reference position is established.  
0: Positive direction  
1: Negative direction

Directions in which reference position is established as viewed from the near-point dog



### 【#2031】 noref Axis without reference position

Select whether the reference position is provided for the axis.  
0: Reference position is provided. (Normal controlled axis)  
1: No reference position is provided.  
When "1" is set, reference position return is not required before automatic operation starts.

### 【#2032】 nochk Whether reference position return is completed not checked

Select whether to check the reference position return completion.  
0: Check the reference position return completion.  
1: Not check the reference position return completion.  
When "1" is set, the absolute and incremental commands can be executed even if dog type (or Z phase pulse system) reference position return is not completed.  
Note that this setting is available for a rotary axis only.

### 【#2033】 zp\_no Z phase pulse system reference position return spindle encoder No.

Set the spindle encoder No. to be used when the reference position return is performed with the Z phase pulse of the spindle encoder.  
0: Dog type  
1 to 6: Spindle No.  
\*The setting range differs according to the model.

---Setting range---  
0 to 6

### 【#2034】 rfpofs Distance-coded reference position detection offset

Set the offset value from the position for the initial reference position setting to the machine's actual basic point in reference position return in the distance-coded reference position detection.  
Input the value of the machine value counter that is displayed immediately after the reference position is established.  
When the power is turned ON and this parameter is set to "0", the manual reference position return is regarded as initial reference position setting.  
If this parameter is set to "0", automatic operation won't be available.

---Setting range---  
-99999.999 to 99999.999 (mm)

**【#2035】 srchmax Distance-coded reference position detection scan distance**

Set the maximum distance for scanning the reference marks when the reference position is not established in the distance-coded reference position detection.  
For the scan distance, set the distance that fully covers the number of reference marks as you wish to detect.

(Example) When adding about 10% of additional coverage:  
Scan distance = Base reference mark interval [mm] \* 2 \* 1.1

**---Setting range---**

0.000 to 99999.999 (mm)


**【#2036】 slv\_adjust Reference position adjustment value**

Set the distance from the first grid point after leaving the near point dog on the secondary axis to the position where the reference position is actually established in dog-type reference position return in synchronous control. (Reference position shift amount is not included.)

The adjustment value will be automatically set in the secondary axis's parameter according to the reference position adjustment complete signal from PLC.

Fine adjustment is also available from the parameter screen.

In the distance-coded reference position detection, the reference position adjustment value will be invalid.



(Note 1) This parameter is enabled when the synchronization at zero point initialization ("#1493 ref\_syn" = "1" of the primary axis) is applied.

(Note 2) This parameter can be set when one of the following settings is applied.

- Relative position detection ("#2049 type" = "0")
- Dog-type absolute position detection ("#2049 type" = "3")
- Simple absolute position ("#2049 type" = "9")

(Note 3) Set "0" when using the speed/current command synchronization control.

(Note 4) A setting unit of this parameter is [mm]. It is not influenced by the content of the following parameters setting.

- "#1003 iunit"
- "#1004 ctrl\_unit"
- "#1005 plcunit"
- "#1040 M\_inch"
- "#1041 I\_inch"
- "#1240 set12/bit2" (Zero point shift amount magnification)

(Note 5) The number of the significant digits after decimal point follows "#1004 ctrl\_unit"


(Note 6) A change of this parameter requires reference position return. When the automatic operation starts without reference position return, an alarm will occur.

**---Setting range---**

0 to 99999.999999 (mm)

### 【#2037】 G53ofs Reference position #1

Set the position of the first reference position from the zero point of the basic machine coordinate.




---Setting range---

-99999.999 to 99999.999 (mm)

### 【#2038】 #2\_rfp Reference position #2

Set the position of the second reference position from the zero point of the basic machine coordinate.




---Setting range---

-99999.999 to 99999.999 (mm)



**【#2039】 #3\_rfp Reference position #3**

Set the position of the third reference position from the zero point of the basic machine coordinate.




---Setting range---

-99999.999 to 99999.999 (mm)

**【#2040】 #4\_rfp Reference position #4**

Set the position of the fourth reference position from the zero point of the basic machine coordinate.



---Setting range---

-99999.999 to 99999.999 (mm)

**【#2049(PR)】 type Absolute position detection method**

Select the absolute position zero point alignment method.

- 0: Not absolute position detection
- 1: Stopper method (push against mechanical stopper)
- 2: Marked point alignment method (align to alignment point)
- 3: Dog-type (align with dog and near point detection switch)
- 4: Marked point alignment method II (Align to alignment mark. Grid return won't be performed after marked point alignment)
- 9: Simple absolute position (Not absolute position detection, but the position when the power is turned off is registered.)

**【#2050】 absdir Basic point of Z direction**

Select the direction of the grid point immediately before the machine basic position (basic point of detector) in the marked point alignment.

- 0: Positive direction
- 1: Negative direction

**【#2051】 check Check**

Set the tolerable range of travel distance (deviation distance) while the power is turned OFF.  
If the difference of the positions when the power is turned OFF and when turned ON again is larger than this value, an alarm will be output.  
Set "0" to omit the check.

**---Setting range---**

0 to 99999.999 (mm)

**【#2054】 clpush Current limit (%)**

Set the current limit value during the stopper operation in the dogless-type absolute position detection.  
The setting value is the ratio of the current limit value to the rated current value.

**---Setting range---**

0 to 100 (%)

**【#2055】 pushf Push speed**

Set the feedrate for the automatic initial setting during stopper method.

**---Setting range---**

1 to 999 (mm/min)

**【#2056】 aproch Approach**

Set the approach distance of the stopper when deciding the absolute position basic point with the stopper method.  
After using stopper once, the tool returns with this distance, and then use stopper again.

**---Setting range---**

0 to 999.999 (mm)

**【#2057】 nrefp Near zero point +**

Set the positive direction width where the near reference position signal is output.  
When set to "0", the width will be equivalent to the grid width setting.  
(Note) When "#1240 set12/bit2" is ON, a magnification (C: 10-fold, D: 100-fold, E:1000-fold) corresponding to the input setting increment ("#1003 iunit") will be applied to the setting value.

**---Setting range---**

0 to 999.999 (mm)  
(Input setting increment applied)

**【#2058】 nrefn Near zero point -**

Set the negative direction width where the near reference position signal is output.  
When set to "0", the width will be equivalent to the grid width setting.  
(Note) When "#1240 set12/bit2" is ON, a magnification (C: 10-fold, D: 100-fold, E:1000-fold) corresponding to the input setting increment ("#1003 iunit") will be applied to the setting value.

**---Setting range---**

0 to 999.999 (mm)  
(Input setting increment applied)

**【#2059】 zerbas Select zero point parameter and basic point**

Select which is to be the zero point coordinate position during absolute position initial setting.  
0: Position where the axis was stopped.  
1: Grid point just before stopper.

**【#2061】 OT\_1B- Soft limit IB-**

Set the coordinate of the lower limit of the area where the stored stroke limit IB is inhibited.  
Set a value from zero point in the basic machine coordinate system.  
If the same value (non-zero) with the same sign as that of "#2062 OT\_1B+" is set, the stored stroke limit IB function will be disabled.

**---Setting range---**

-99999.999 to 99999.999 (mm)

**【#2062】 OT\_1B+ Soft limit IB+**

Set the coordinate of the upper limit of the area where the stored stroke limit IB is inhibited.  
 Set a value from zero point in the basic machine coordinate system.

**---Setting range---**

-99999.999 to 99999.999 (mm)

**【#2063】 OT\_1B type Soft limit IB type**

Select the type that applies the settings of "#2062 OT\_1B+" and "#2061 OT\_1B-" in stored stroke limit I.

0: Soft limit IB

1: The settings are invalid

2: Soft limit IC

3: Soft limit is checked for the inclined axis control axis with the program coordinate system.

(Note) This is valid only for inclined axis' base axis and inclined axis.

**【#2068】 G0fwdg G00 feed forward gain**

Set a feed forward gain for G00 pre-interpolation acceleration/deceleration.  
 The larger the setting value, the shorter the positioning time during in-position checking.  
 If a machine vibration occurs, set the smaller value.

**---Setting range---**

0 to 200 (%)

**【#2069】 Rcoeff Axis arc radius error correction coefficient**

Set the percentage to increase or decrease the arc radius error correction amount for each axis.

**---Setting range---**

-100.0 to +100.0 (%)

**【#2070(PR)】 div\_RT Rotational axis division count**

Set the number of divisions of one turn of the rotary axis under control.

(Example)

When "36" is set, one turn is supposed to be 36.000.

(Note 1) When "0" is set, the normal rotary axis (360.000 degrees for one turn) is assumed.

(Note 2) If this parameter is changed when the absolute position detection specification is used, absolute position data will be lost. Initialization must be performed again.

**---Setting range---**

0 to 999

**【#2071】 s\_axis Inclined axis selection (for L system only)**

Select whether the axis is to be under the inclined-axis control or to be the base axis corresponding to the inclined axis.

0: Not to be under the inclined-axis control

1: Inclined axis

2: Base axis corresponding to inclined axis

(Note) Each of "1" and "2" values must be set for only one axis. If either value is set for two or more axes, inclined-axis control does not work.

**【#2072】 rslimt Restart limit**

Set the most minus (-) side position where restart search is possible.

If the machine is positioned on the more minus (-) side than the set value in T-command restart mode, restart search in type 3 will be disabled.

**---Setting range---**

-99999.999 to 99999.999 (mm)

**【#2073】 zrn\_dog Origin dog Random assignment device**

Under the standard specifications, the origin dog signal is assigned to a fixed device. Set the input device in this parameter when it is desired to assign the origin dog signal to a position other than the fixed device.

(Note1) This parameter is enabled in the following conditions.

NC axis: When "#1226 aux10/bit5" is set to "1".

PLC axis: When "#1246 set18/bit7" is set to "1".

(Note 2) When this parameter is valid, do not set the existing device number. If the existing device number is set, an emergency stop will occur. However, no device number check will be performed for an axis to which the "near-point dog ignored" signal is input.

**---Setting range---**

0000 to 02FF (HEX)

**【#2074】 H/W\_OT+ H/W OT+ Random assignment device**

Under the standard specifications, the OT (+) signal is assigned to a fixed device. Set the input device in this parameter when it is desired to assign the OT (+) signal to a position other than the fixed device.

(Note1) This parameter is enabled in the following conditions.

NC axis: When "#1226 aux10/bit5" is set to "1".

PLC axis: When "#1246 set18/bit7" is set to "1".

(Note 2) When this parameter is valid, do not set the existing device number. If the existing device number is set, an emergency stop will occur. However, no device number check will be performed for an axis to which the "OT ignored" signal is input.

**---Setting range---**

0000 to 02FF (HEX)

**【#2075】 H/W\_OT- H/W OT- Random assignment device**

Under the standard specifications, the OT (-) signal is assigned to a fixed device. Set the input device in this parameter when it is desired to assign the OT (-) signal to a position other than the fixed device.

(Note1) This parameter is enabled in the following conditions.

NC axis: When "#1226 aux10/bit5" is set to "1".

PLC axis: When "#1246 set18/bit7" is set to "1".

(Note 2) When this parameter is valid, do not set the existing device number. If the existing device number is set, an emergency stop will occur. However, no device number check will be performed for an axis to which the "OT ignored" signal is input.

**---Setting range---**

0000 to 02FF (HEX)

**【#2076】 index\_x Index table indexing axis**

Select whether the axis is a normal axis or an index table indexing axis.

0: Normal axis

1: Index table indexing axis

(Note) This parameter is valid only for the NC axis. The parameter is invalid if set for the PLC axis.

**【#2077】 G0inps G0 in-position width**

Set the in-position width for G0.

Between SV024 and this parameter, the parameter with a larger value will be applied.

When "0" is set, this parameter will be invalid: only SV024 will be available.

**---Setting range---**

0.000 to 99.999 (mm)

**【#2078】 G1inps G1 in-position width**

Set the in-position width for G1.  
Between SV024 and this parameter, the parameter with a larger value will be applied.  
When "0" is set, this parameter will be invalid: only SV024 will be available.

---Setting range---  
0.000 to 99.999 (mm)

**【#2079(PR)】 chcomp Chopping compensation coefficient**

Set the coefficient to be applied to the compensation amount for the insufficient amount caused by servo delay during chopping.

---Setting range---  
0 to 10 (standard value: 8)

**【#2080】 chwid Bottom dead center position width**

Set the tolerance between the commanded stroke and actual stroke.  
Compensation will be applied during chopping so that the result of [command width - maximum stroke of top or bottom dead point/ 2] will be within this tolerance.

---Setting range---  
0 to 10.000 (mm)

**【#2081】 chclsp Maximum chopping speed**

Set the clamp speed in chopping operation.  
When "0" is set, the clamp speed will be determined by "#2002 clamp".

---Setting range---  
0 to 60000 (mm/min)

**【#2082】 a\_rstax Restart position return order**

Set the No. for each axis in order from the 1st automatically returning axis to the restart position.  
When "0" is set, the axis will not return.  
Note that when "0" is set for all axes, all of the axes will return simultaneously.

---Setting range---  
0 to 8

**【#2084】 G60\_ax Unidirectional positioning operation selection**

Select how to operate the unidirectional positioning when the positioning command (G00) is issued.  
0: Carry out unidirectional positioning according to the command and modal.  
1: Carry out unidirectional positioning regardless of the command and modal.  
Set "1" for the axis to carry out the unidirectional positioning at every positioning command, regardless of whether the unidirectional positioning command and modal are issued.

<Related parameters>  
"#8209 G60 SHIFT" and "#2076 index\_x"

**【#2087】 syncnt Synchronization/super-imposition control setting for each axis**

Set the polarity of synchronous axis with respect to basic axis to the bit corresponding to each axis.  
0: Polarity with respect to basic axis is positive  
1: Polarity with respect to basic axis is negative

---Setting range---  
0 to FF (hexadecimal)

**【#2088】 bsax\_sy Reference axis for synchronous control**

Set the basic axis for synchronous control with the 2nd axis name (axname2).A numerical character cannot be set as the 1st character.

---Setting range---  
Axis name

**【#2089】 bsax\_pl**

Not used. Set to "0".

**【#2090】 plrapid Rapid traverse rate for super-imposition control**

Set the rapid traverse rate for superimposition control.  
(Equivalent to "#2001 rapid Rapid traverse rate".)

**---Setting range---**

1 to 1000000 (mm/min)

**【#2091】 plclamp Cutting feed clamp speed for super-imposition control**

Set the cutting feed clamp speed for superimposition control.  
(Equivalent to "#2002 clamp Cutting feed clamp speed".)

**---Setting range---**

1 to 1000000 (mm/min)

**【#2092】 plG0tL G0 time constant for superimposition control (linear)**

Set the G0 time constant (linear) for superimposition control.  
(Equivalent to "#2004 G0tL G0 time constant (linear)".)

**---Setting range---**

1 to 4000 (ms)

**【#2093】 plG0t1 G0 time constant for superimposition control (primary delay)**

Set the G0 time constant (primary delay) for superimposition control.  
(Equivalent to "#2005 G0t1 G0 time constant (primary delay)".)

**---Setting range---**

1 to 5000 (ms)

**【#2094】 plG1tL G1 time constant for superimposition control (linear)**

Set the G1 time constant (linear) for superimposition control.  
(Equivalent to "#2007 G1tL G1 time constant (linear)".)

**---Setting range---**

1 to 4000 (ms)

**【#2095】 plG1t1 G1 time constant for superimposition control (primary delay)**

Set the G1 time constant (primary delay) for superimposition control.  
(Equivalent to "#2008 G1t1 G1 time constant (primary delay)".)

**---Setting range---**

1 to 5000 (ms)

**【#2096】 crncsp Minimum corner deceleration speed**

Set the minimum clamp speed for corner deceleration in the high-accuracy control mode. Normally set "0".

(Note) This parameter is invalid during SSS control.

**---Setting range---**

0 to 1000000 (mm/min)

**【#2097】 tlm12- Sub side tool setter - direction sensor**

Set the sensor position (on sub side) in the (-) direction when using the tool setter on the sub spindle side.

(Note) In the case of the basic axis and inclined axis of the inclined axis specifications, set the position on the orthogonal coordinate.

**---Setting range---**

-99999.999 to 99999.999 (mm)

**【#2098】 tlm12+ Sub side tool setter + direction sensor**

Set the sensor position (on sub side) in (+) direction when using the tool setter on the sub spindle side.

(Note) In the case of the basic axis and inclined axis of the inclined axis specifications, set the position on the orthogonal coordinate.

**---Setting range---**

-99999.999 to 99999.999 (mm)

**【#2102】 skip\_tL Skip time constant linear**

Set a linear control time constant for variable speed skip acceleration and deceleration, or for an occasion where a skip command issues acceleration/deceleration time constant enabled (R1). The time constant will be enabled when LC (cutting feed with linear acceleration and deceleration) or "F" (soft acceleration/deceleration) is selected in "#2003 smgst Acceleration and deceleration modes".

When set to "0", the time constant set by "#2008 G1t1" is used.

**---Setting range---**

0 to 4000 (ms)

**【#2103】 skip\_t1 Skip time constant primary delay / Second-step time constant for soft acceleration/deceleration**

Set a primary-delay time constant for variable speed skip acceleration and deceleration, or for an occasion where a skip command issues acceleration/deceleration time constant enabled (R1). The time constant will be enabled when C1 (cutting feed with primary delay) or C3 (exponential acceleration and linear deceleration) is selected in "#2003 smgst Acceleration and deceleration modes". When the soft acceleration/deceleration is selected, the second-step time constant will be used.

When set to "0", the time constant set by "#2008 G1t1" is used.

**---Setting range---**

0 to 5000 (ms)

**【#2106】 Index unit Indexing unit**

Set the indexing unit to which the rotary axis can be positioned.

**---Setting range---**

0 to 360 (°)

**【#2109】 Rapid (H-precision) Rapid traverse rate for high-accuracy control mode**

Set the rapid traverse rate for each axis in the high-accuracy control mode. "#2001 rapid" will be used when "0" is set.

**---Setting range---**

0 to 1000000 (mm/min)

**【#2110】 Clamp (H-precision) Cutting feed clamp speed for high-accuracy control mode**

Set the cutting feed maximum speed for each axis in the high-accuracy control mode. "#2002 clamp" will be used when "0" is set.

**---Setting range---**

0 to 1000000 (mm/min)

**【#2111】 Blf valid Quadrant protrusion compensation valid**

Set whether to enable the quadrant protrusion compensation.

0: Disable

1: Enable

If either of "#2112 Blf motor inertia", "#2115 Blf motor stl trq" or "#2113 Blf visc friction" is set to "0", quadrant protrusion compensation will not work even if this parameter is set to "1".

#### 【#2112】 Blf motor inertia Motor inertia

Set the motor inertia for quadrant protrusion compensation.  
Refer to the servo manual and input the value appropriate for the motor.

**---Setting range---**

1 to 32000 ( $10^{-6}\text{kgm}^2$ )

#### 【#2113】 Blf visc friction Viscous friction

Set the viscous friction for quadrant protrusion compensation.  
After setting the other parameters to the appropriate values, monitor the machine end and gradually adjust the value.  
If this parameter setting is small, a recess will form on the inner side of the circle, and if large, a protrusion will form on the outer side of the circle. When the value is appropriate, a spike-shaped quadrant protrusion will form based on normal step-shaped backlash.

**---Setting range---**

1 to 32767 (1/16 Nm/(rad/s))

#### 【#2114】 Blf fwdg Compensation FF gain

Set the feed forward gain for quadrant protrusion compensation.  
After setting the other parameters to the appropriate values, monitor the machine end and gradually adjust the value.  
If this parameter setting is small, a large quadrant protrusion will form, and if large, a recess will form on the inner side of the circle.

**---Setting range---**

0 to 1000 (%)

#### 【#2115】 Blf motor stl trq Motor stall torque

Set the motor rated current for quadrant protrusion compensation.  
Refer to the servo manual and input the value appropriate for the motor.

**---Setting range---**

1 to 16000 (1/256 Nm)

#### 【#2118(PR)】 SscDrSel Speed monitor Door selection

Select which door group of the speed monitoring the spindle belongs to.

0000: Door 1 group.

0001: Door 1 group.

0002: Door 2 group.

0003: Door 1 and 2 group.

The speed monitoring will not be executed when "#2313 SV113 SSF8/BitF" is OFF regardless of this parameter.

The selected door group must be set when setting the synchronous control.

The spindle/C axis control enables the door selection in "#3071 SscDrSelSp" for the corresponding spindle.

#### 【#2121】 vbacklash valid Variable backlash valid/continuous or Variable backlash II valid

Select whether the variable backlash is to be disabled/enabled/continuous, or variable backlash II enabled.

0: Disable

1: Enable

2: Continuous

3: Enable variable backlash II

("#2011 G0back" and "#2012 G1back" will not work unless "0: Disable" is selected. )

#### 【#2122】 G0vback+ Variable G0 backlash +

Set the compensation amount for the range of each position during rapid traverse.  
(+: B1, -: B2, -: B3 on the compensation amount table)

**---Setting range---**

-99999999 to 99999999 (Interpolation unit)



**【#2123】 G0vback= Variable G0 backlash =**

Set the compensation amount for the range of each position during rapid traverse.  
(+: B1, -: B2, -: B3 on the compensation amount table)

**---Setting range---**

-99999999 to 99999999 (Interpolation unit)

**【#2124】 G0vback- Variable G0 backlash -**

Set the compensation amount for the range of each position during rapid traverse.  
(+: B1, -: B2, -: B3 on the compensation amount table)

**---Setting range---**

-99999999 to 99999999 (Interpolation unit)

**【#2125】 G1vback+ Variable G1 backlash +**

Set the compensation amount for the range of each position during cutting feed.  
(+: A1, -: A2, -: A3 on the compensation amount table)

**---Setting range---**

-99999999 to 99999999 (Interpolation unit)

**【#2126】 G1vback= Variable G1 backlash =**

Set the compensation amount for the range of each position during cutting feed.  
(+: A1, -: A2, -: A3 on the compensation amount table)

**---Setting range---**

-99999999 to 99999999 (Interpolation unit)

**【#2127】 G1vback- Variable G1 backlash -**

Set the compensation amount for the range of each position during cutting feed.  
(+: A1, -: A2, -: A3 on the compensation amount table)

**---Setting range---**

-99999999 to 99999999 (Interpolation unit)

**【#2128】 G1vback feed1 G1 variable backlash compensation amount changeover speed 1**

Set the speed range during cutting feed.  
(The speed less than 1 is the low speed, and the speed exceeding 2 is the high speed.)  
Note that the speed range is identified in the order of low, high and medium speed. Consider whether the set value should be larger or smaller than other values.

**---Setting range---**

0 to 480000 (mm/min)

**【#2129】 G1vback feed2 G1 variable backlash compensation amount changeover speed 2**

Set the range of the speed during cutting feed.  
(The speed less than 1 is the low speed, and the speed exceeding 2 is the high speed.)  
Note that the speed range is identified in the order of low, high and medium speed. Consider whether the set value should be larger or smaller than other values.

**---Setting range---**

0 to 480000 (mm/min)

**【#2130】 G1vback dist1 G1 variable backlash compensation amount changeover distance 1**

Set the range of the distance during cutting feed.  
(The distance less than 1 is the small distance, and the distance exceeding 2 is the large distance.)  
Note that the distance range is identified in the order of small, large and medium. Consider whether the set value should be larger or smaller than other values.

**---Setting range---**

0 to 999999.999999 (mm)

**【#2131】 G1vback dist2 G1 variable backlash compensation amount changeover distance 2**

Set the range of the distance during cutting feed.

(The distance less than 1 is the small distance, and the distance exceeding 2 is the large distance.)

Note that the distance range is identified in the order of small, large and medium. Consider whether the set value should be larger or smaller than other values.

**---Setting range---**

0 to 999999.999999 (mm)

**【#2132】 vback pos1 Variable backlash compensation amount changeover end point position 1**

Set the range of the center of the end point position.

(The range less than position 1 is the - range, and the range exceeding position 2 is the + range.)

The end point position range is determined in the order of -, +, and center. Consider whether the set value should be larger or smaller than other values.

(Note 1) If continuous variable backlash is set with "#2121 vbacklash valid", position 1 will be set as the position - point and position 2 will be set as the position + point.

(Note 2) When the size relation of the compensation amount changeover speed and distance 1 and 2 is not appropriate while the variable backlash compensation is valid, the followings will be applied: If the backlash speed and distance are smaller than the compensation amount changeover speed and distance 1, both the speed and distance will be small; if larger than the compensation amount changeover speed and distance 2, both the speed and distance will be large.

**---Setting range---**

-999999.999999 to 999999.999999 (mm)

**【#2133】 vback pos2 Variable backlash compensation amount changeover end point position 2**

Set the range of the center of the end point position.

(The range less than position 1 is the - range, and the range exceeding position 2 is the + range.)

The end point position range is determined in the order of -, +, and center. Consider whether the set value should be larger or smaller than other values.

(Note 1) If continuous variable backlash is set with "#2121 vbacklash valid", position 1 will be set as the position - point and position 2 will be set as the position + point.

(Note 2) When the size relation of the compensation amount changeover speed and distance 1 and 2 is not appropriate while the variable backlash compensation is valid, the followings will be applied: If the backlash speed and distance are smaller than the compensation amount changeover speed and distance 1, both the speed and distance will be small; if larger than the compensation amount changeover speed and distance 2, both the speed and distance will be large.

**---Setting range---**

-999999.999999 to 999999.999999 (mm)

**【#2134】 vback arc K Variable backlash arc compensation coefficient**

Set the arc compensation coefficient.

**---Setting range---**

0 to 300 (%)

**【#2135】 vback feed refpt Variable backlash reference position selection (speed)**

Select the speed range to be used as the reference position.

0: Low speed

1: Medium speed

2: High speed

**【#2136】 vback pos refpt Variable backlash reference position selection (end point position)**

Select the end point range to be used as the reference position.

0: Position + range

1: Position center range

2: Position - range

**【#2137】 vback dir refpt Variable backlash reference position selection (entry direction)**

Select the entry direction to be used as the reference position.

- 0: Entry direction +
- 1: Entry direction -

**【#2138】 vback pos center Continuous variable backlash position center point**

Set the position center point. (This is used only when continuous variable backlash is set with "#2121 vbacklash valid".) Set a value between "#2132 vback pos1" and "#2133 vbackpos2" for the position center point.

(Note ) When the size relation of the compensation amount changeover speed and distance 1 and 2 is not appropriate while the variable backlash compensation is valid, the followings will be applied:

If the backlash speed and distance are smaller than the compensation amount changeover speed and distance 1, both the speed and distance will be small; if larger than the compensation amount changeover speed and distance 2, both the speed and distance will be large.

**---Setting range---**

-999999.999999 to 999999.999999 (mm)

**【#2139】 omrff\_off OMR-FF invalid**

Select whether to enable or temporarily disable the OMR-FF control when OMR-FF is valid.

- 0: Enable
- 1: Temporarily disable

When "1" is selected while OMR-FF is valid, OMR-FF can be temporarily disabled and conventional feed forward control can be applied instead.

**【#2140(PR)】 Ssc Svof Filter Speed monitor Error detection time during servo OFF**

Set the error detection time of command speed monitoring and feedback speed monitoring during servo OFF.

An alarm will occur if the time, for which the speed has been exceeding the safe speed or safe rotation speed, exceeds the error detection time set in this parameter.

If "0" is set, it will be handled as 200 (ms).


**---Setting range---**

0 to 9999 (ms)

**【#2141】 chtL Chopping first-step time constant for soft acceleration and deceleration**

Set the first-step time constant for the chopping axis when soft acceleration/deceleration is applied. Note that, however, there may be cases where actual time constant is shorter than the set time constant, because the time constant is automatically calculated according to the feedrate so that the acceleration rate during acceleration/deceleration (clamp speed/chopping time constant) will be constant.

When "0" is set, "#2007 G1tL" will be valid.



**---Setting range---**

0 to 4000 (ms)


### 【#2142】 cht1 Chopping second-step time constant for soft acceleration and deceleration

Set the second-step time constant for the chopping axis when soft acceleration/deceleration is applied.  
Note that, however, there may be cases where actual time constant is shorter than the set time constant, because the time constant is automatically calculated so that the ratio between first-step and second-step time constant will be constant.  
When "0" is set, "#2008 G1t1" will be valid.

---Setting range---  
0 to 4000 (ms)

### 【#2143】 polar Control axis relative polarity


Set "0" for the basic axis, and set the polarity of the superimposing axis relative to the basic axis.  
0: Relative to basic axis, polarity is positive  
1: Relative to basic axis, polarity is negative



### 【#2144】 baseps Base machine coordinate zero point relative distance

Set each axis's position of the base machine coordinate zero point when an arbitrary point M on the machine is regarded as a base point.  
Unify the directions of all part systems' machine zero point positions with the direction of the machine coordinate system of the 1st part system.  
If the 1st part system doesn't have a parallel axis, determine the direction arbitrarily.


Example: System1(X1, Z1), System2(X2, Z2)



---Setting range---  
-99999.999 to 99999.999 (mm)

**【#2146】 Blf\_L1 Reference distance for position-dependent increasing-type backlash compensation 1**

Set the distance for specifying the compensation change rate in position-dependent increasing-type backlash compensation.




When "#2146 Blf\_E1" is set to "0", the position-dependent increasing-type backlash compensation function will be disabled.

---Setting range---

0.000 to 99999.999 (mm)

**【#2147】 Blf\_L2 Reference distance for position-dependent increasing-type backlash compensation 2**

Set the distance for specifying the compensation change rate in position-dependent increasing-type backlash compensation.




When "#2146 Blf\_E1" is set to "0", the position-dependent increasing-type backlash compensation function will be disabled.

---Setting range---

0.000 to 99999.999 (mm)

**【#2148】 Blf\_E1 Reference amount of position-dependent increasing-type backlash compensation 1**

Set the compensation amount for specifying the compensation change rate in position-dependent increasing-type backlash compensation.




When "#2146 Blf\_E1" is set to "0", the position-dependent increasing-type backlash compensation function will be disabled.

---Setting range---

0 to 9999999 (Machine error compensation unit)

### 【#2149】 Blf\_E2 Reference amount of position-dependent increasing-type backlash compensation 2

Set the compensation amount for specifying the compensation change rate in position-dependent increasing-type backlash compensation.



When "#2146 Blf\_E1" is set to "0", the position-dependent increasing-type backlash compensation function will be disabled.

#### ---Setting range---

0 to 9999999 (Machine error compensation unit)

### 【#2150】 Rot\_len Farthest distance from rotary axis center

Set the farthest distance of the rotating part from the rotation center for executing the 3D machine interference check.

When "0" is set, this distance will conform to the rotary axis' specification speed.

#### ---Setting range---


0.000 to 99999.999(mm)

### 【#2151】 rated\_spd Rated speed

Set the maximum speed which can be driven with the motor's maximum torque.

(Note 1) This parameter's setting value must be smaller than "#2001 rapid Rapid traverse". If bigger, constant inclination acceleration/deceleration will be applied.

(Note 2) If rapid traverse constant inclination multi-step acceleration/deceleration is valid, and also if this parameter is set to "0", constant inclination acceleration/deceleration will be applied.




#### ---Setting range---

0 to 1000000(mm/min)

**【#2152】 acc\_rate Acceleration rate in proportion to the maximum acceleration rate**

Set the rate in proportion to the maximum acceleration rate in rapid traverse.

(Note) If this parameter is set to "0" or "100", constant inclination acceleration/deceleration will be applied.



---Setting range---  
 0 to 100(%)

**【#2153】 G0t\_rated G0 time constant up to rated speed (multi-step acceleration/deceleration)**

Set the acceleration rate up to the rated speed of rapid traverse constant inclination multi-step acceleration/deceleration.

(Note) If this parameter is set to "0", constant inclination acceleration/deceleration will be applied.

---Setting range---  
 0 to 4000(ms)

**(G0t\_rapid) G0 time constant up to rapid traverse speed (multi-step acc./dec.)**

Set the acceleration time until the rapid traverse speed of rapid traverse constant inclination multi-step acceleration/deceleration is applied.

(Note) Set the acceleration time when a pertinent axis is operated independently.

**【#2155】 hob\_fwd\_g Feed forward gain for hobbing machining**

Set the feed forward gain when controlling as workpiece axis of tool spindle synchronization II (hobbing).

---Setting range---  
 0 to 200 (%)

**【#2169】 Man meas rtnr dir Return direction in manual measurement**

Select the direction of return operation in manual measurement.

- 0: Opposite to the contact direction
- 1: Fixed to the + direction
- 2: Fixed to the - direction

**【#2170】 Lmc1QR Lost motion compensation gain 1 for high-speed retract**

Set the lost motion compensation gain in drilling cycle at high-speed retract (CW: - to + direction, CCW: + to - direction).

Set "-1" when drilling cycle at high-speed retract is not performed.

When set to 0, the performance will follow the setting of "#2171 Lmc2QR (Lost motion compensation gain 2 for high-speed retract)".

---Setting range---  
 -1, 0 to 200(%)

**【#2171】 Lmc2QR Lost motion compensation gain 2 for high-speed retract**

Set the lost motion compensation gain in drilling cycle at high-speed retract (CW: - to + direction, CCW: + to - direction).

Set "-1" when drilling cycle at high-speed retract is not performed.

When set to "0", the performance will follow the setting of "#2170 Lmc1QR (Lost motion compensation gain 1 for high-speed retract)".

**---Setting range---**

-1, 0 to 200(%)

**【#2172】 LmcdQR Lost motion compensation timing for high-speed retract**

Set the timing of the lost motion compensation in drilling cycle at high-speed retract.

When set to "0", the performance will follow the setting of "#2239 SV039 LMCD (Lost motion compensation timing)".

**---Setting range---**

0 to 2000 (ms)

**【#2173】 LmckQR Lost motion compensation 3 spring constant for high-speed retract**

Set the machine system's spring constant when using lost motion compensation type 3 in drilling cycle with high-speed retract.

When set to "0", the performance will follow the setting of "#2285 SV085 LMCK (Lost motion compensation 3 spring constant)".

**---Setting range---**

0 to 32767(0.01%/  $\mu$  m)

**【#2174】 LmccQR Lost motion compensation 3 viscous coefficient for high-speed retract**

Set the machine system's viscous coefficient when using lost motion compensation type 3 in drilling cycle at high-speed retract.

When set to "0", the performance will follow the setting of "#2286 SV086 LMCc (Lost motion compensation 3 viscous coefficient)".

**---Setting range---**

0 to 32767(0.01%/  $\mu$  m)

**【#2175】 Special Ax Radius Special diametral axis radius**

Set the radius of the special diametral axis.

**---Setting range---**

0 to 99999.999 (mm)

**【#2176】 Special Ax Clamp Special diametral axis clamp speed**

Set a clamp speed for the special diametral axis control.

**---Setting range---**

0 to 1000000 (°/min)

(Note)For "#2001 rapid" and "#2002 clamp", set speeds on a machining line.

When the value in "#2176 Special Ax Clamp" is smaller than that in "#2001 rapid", "Special Ax Clamp" value will be applied to the clamp speed.

**【#2177】 ManualFeedBtL Time constant for manual feed rate B**

Set the acceleration/deceleration time constant for manual feed rate B.

(Note)When set to "0", this parameter will not be used: conventional acceleration/deceleration will be performed.

**---Setting range---**

0 to 40000 (ms)



### 【#2180(PR)】 S\_DIN Speed observation input door No.

Set the door signal input in the drive unit.  
Use this parameter only when the axis with a door signal belongs to several door groups.  
The correspondence between the door signals and bits are as follows.  
bit0 : Door1 signal  
bit1 : Door2 signal  
If the axis does not receive any door signal, set to "0".  
An error (Y20 0027) will occur in the following cases.  
- Several bits are enabled.  
- Any bit other than those set in "#2118 S\_DSI" is enabled.

**---Setting range---**  
0000 to 0002 (HEX)

### 【#2561】 VBL2 VG1 Variable backlash comp II Changeover speed 1

Set the changeover speed at speed normalization.  
Set a value smaller than that in "#2562 VBL2 VG0".  
Normally, the "#2561 VBL2 VG1" value corresponds to the cutting feedrate, the "#2562 VBL2 VG0" value to the rapid traverse rate.

**---Setting range---**  
1 to 1000000 (mm/min)

### 【#2562】 VBL2 VG0 Variable backlash comp II Changeover speed 2

Set the changeover speed at speed normalization.  
Set a value greater than that in "#2561 VBL2 VG1".  
Normally, the "#2561 VBL2 VG1" value corresponds to the cutting feedrate, the "#2562 VBL2 VG0" value to the rapid traverse rate.

**---Setting range---**  
1 to 1000000 (mm/min)

### 【#2563】 VBL2 P1 Variable backlash comp II Stroke position 1

Set the most plus (+) side stroke position among the three.  
Set the parameters VBL2 P1 to P3 to be "VBL2 P1 > VBL2 P2 > VBL2 P3".  
Normally, divide the axis's stroke by four, and set a dividing position (except for the both ends) to be a stroke position.

**---Setting range---**  
-99999.999 to 99999.999 (mm)

### 【#2564】 VBL2 P2 Variable backlash comp II Stroke position 2

Set the middle stroke position among the three.  
Set the parameters VBL2 P1 to P3 to be "VBL2 P1 > VBL2 P2 > VBL2 P3".  
Normally, divide the axis's stroke by four, and set a dividing position (except for the both ends) to be a stroke position.

**---Setting range---**  
-99999.999 to 99999.999 (mm)

### 【#2565】 VBL2 P3 Variable backlash comp II Stroke position 3

Set the most minus (-) side stroke position among the three.  
Set the parameters VBL2 P1 to P3 to be "VBL2 P1 > VBL2 P2 > VBL2 P3".  
Normally, divide the axis's stroke by four, and set a dividing position (except for the both ends) to be a stroke position.

**---Setting range---**  
-99999.999 to 99999.999 (mm)

**【#2566】 VBL2 BL11 Variable backlash comp II Comp data at changeover spd 1 and stroke pos 1**

Set the compensation data (backlash amount) at changeover speed 1 and stroke position 1.  
Calculate the current compensation data according to the current speed and position.

**---Setting range---**

-99999999 to 99999999 (Machine error compensation unit)

**【#2567】 VBL2 BL12 Variable backlash comp II Comp data at changeover spd 1 and stroke pos 2**

Set the compensation data (backlash amount) at changeover speed 1 and stroke position 2.  
Calculate the current compensation data according to the current speed and position.

**---Setting range---**

-99999999 to 99999999 (Machine error compensation unit)

**【#2568】 VBL2 BL13 Variable backlash comp II Comp data at changeover spd 1 and stroke pos 3**

Set the compensation data (backlash amount) at changeover speed 1 and stroke position 3.  
Calculate the current compensation data according to the current speed and position.

**---Setting range---**

-99999999 to 99999999 (Machine error compensation unit)

**【#2569】 VBL2 BL01 Variable backlash comp II Comp data at changeover spd 2 and stroke pos 1**

Set the compensation data (backlash amount) at changeover speed 2 and stroke position 1.  
Calculate the current compensation data according to the current speed and position.

**---Setting range---**

-99999999 to 99999999 (Machine error compensation unit)

**【#2570】 VBL2 BL02 Variable backlash comp II Comp data at changeover spd 2 and stroke pos 2**

Set the compensation data (backlash amount) at changeover speed 2 and stroke position 2.  
Calculate the current compensation data according to the current speed and position.

**---Setting range---**

-99999999 to 99999999 (Machine error compensation unit)

**【#2571】 VBL2 BL03 Variable backlash comp II Comp data at changeover spd 2 and stroke pos 3**

Set the compensation data (backlash amount) at changeover speed 2 and stroke position 3.  
Calculate the current compensation data according to the current speed and position.

**---Setting range---**

-99999999 to 99999999 (Machine error compensation unit)

**【#2572】 VBL2 FloatTC Variable backlash comp II Time constant in calculating float amt**

Set the time constant in calculating the float amount. Set a value greater than the calculation cycle.

**---Setting range---**

0 to 10000 (ms)

**【#2573】 VBL2 LMMul Variable backlash comp II Multiplier in calculating lost motion amt**

Set the multiplier in calculating the lost motion compensation amount, before multiplied by  $10^{-3}$ .  
When "1000" is set, the multiplier is "1".

**---Setting range---**

0 to 1000

**【#2574】 VBL2 VBound Variable backlash comp II Speed boundary value**

Set the speed boundary value in calculating the lost motion compensation amount.

**---Setting range---**

1 to 1000000 (mm/min)

**【#2575】 VBL2 CompMag Variable backlash comp II Compensation magnification**

Set the compensation magnification in calculating the lost motion compensation amount. When "0" is set, the magnification is 100%.

**---Setting range---**

0 to 300 (%)

**【#2576】 VBL2 CompMul Variable backlash comp II Multiplier in calculating compensation amount**

Set the multiplier in applying the lost motion compensation magnification, before multiplied by  $10^{-3}$ . When "1000" is set, the multiplier is "1".

**---Setting range---**

0 to 1000

**【#2577】 VBL2 BLE Variable backlash comp II Gradually increase amount**

Set the value to subtract from the lost motion compensation amount at reversing the axis travel direction.

**---Setting range---**

-99999999 to 99999999 (Machine error compensation unit)

**【#2578】 VBL2 BLL Variable backlash comp II Gradually increase travel distance**

Set the travel distance to return to the lost motion compensation amount from the reverse point of the axis travel direction.

**---Setting range---**

0 to 99999.999 (mm)

## Appendix 1.4 Servo Parameters

The parameters with "(PR)" requires the CNC to be turned OFF after the settings. Turn the power OFF and ON to enable the parameter settings.

### 【#2201(PR)】 SV001 PC1 Motor side gear ratio

Set the gear ratio in the motor side when there is the gear between the servomotor's shaft and machine (ball screw, etc.).

For the rotary axis, set the total deceleration (acceleration) ratio.

Even if the gear ratio is within the setting range, the electronic gears may overflow and an initial parameter error (servo alarm 37) may occur.

For linear servo system  
Set to "1".

---Setting range---  
1 to 32767

### 【#2202(PR)】 SV002 PC2 Machine side gear ratio

Set the gear ratio in the machine side when there is the gear between the servomotor's shaft and machine (ball screw, etc.).

For the rotary axis, set the total deceleration (acceleration) ratio.

Even if the gear ratio is within the setting range, the electronic gears may overflow and an initial parameter error (servo alarm 37) may occur.

For linear servo system  
Set to "1".

---Setting range---  
1 to 32767

### 【#2203】 SV003 PGN1 Position loop gain 1

Set the position loop gain. The standard setting is "33".

The higher the setting value is, the more accurately the command can be followed, and the shorter the settling time in positioning gets, however, note that a bigger shock will be applied to the machine during acceleration/deceleration.

When using the SHG control, also set SV004 (PGN2) and SV057 (SHGC).

---Setting range---  
1 to 200 (rad/s)

### 【#2204】 SV004 PGN2 Position loop gain 2

When performing the SHG control, set the value of "SV003 x 8/3" to "SV004".

When not using the SHG control, set to "0".

Related parameters: SV003, SV057

---Setting range---  
0 to 999 (rad/s)

### 【#2205】 SV005 VGN1 Speed loop gain 1

Set the speed loop gain.

The higher the setting value is, the more accurate the control will be, however, vibration tends to occur.

If vibration occurs, adjust by lowering by 20 to 30%.

The value should be determined to the 70 to 80% of the value at which the vibration stops.


The value differs depending on servo motors.

Aim at the standard value determined by the servo motor type and load inertia ratio to adjust.

---Setting range---  
1 to 30000

[#2206] SV006 VGN2 Speed loop gain 2

Set the speed loop gain at the motor limitation speed VLMT (maximum rotation speed x 1.15) with "VCS(SV029: Speed at the change of speed loop gain)".  
 Use this to suppress noise at high speed rotation during rapid traverse, etc. Then, the speed loop gain decreases at faster speed than the setting value of VCS.  
 When not using, set to "0".



---Setting range---  
 -1000 to 30000

[#2207] SV007 VIL Speed loop delay compensation

Set this when the limit cycle occurs in the full-closed loop, or overshooting occurs in positioning.  
 The speed loop delay compensation method can be selected with SV027/bit1,0.  
 Normally, use "Changeover type 2". Changeover type 2 controls the occurrence of overshooting by lowering the speed loop lead compensation after the position droop gets 0.  
 When setting this parameter, make sure to set the torque offset (SV032).

---Setting range---  
 0 to 32767

[#2208] SV008 VIA Speed loop lead compensation

Set the gain of the speed loop integral control.  
 Standard setting: 1364  
 Standard setting in the SHG control: 1900  
 Adjust the value by increasing/decreasing this by about 100 at a time.  
 Raise this value to improve contour tracking accuracy in high-speed cutting.  
 Lower this value when the position droop does not stabilize (when the vibration of 10 to 20Hz occurs).

---Setting range---  
 1 to 9999

[#2209] SV009 IQA Current loop q axis lead compensation

Set the fixed value of each motor.  
 Set the standard value for each motor described in the standard parameter list.

---Setting range---  
 1 to 20480

[#2210] SV010 IDA Current loop d axis lead compensation

Set the fixed value of each motor.  
 Set the standard value for each motor described in the standard parameter list.

---Setting range---  
 1 to 20480

[#2211] SV011 IQG Current loop q axis gain

Set the fixed value of each motor.  
 Set the standard value for each motor described in the standard parameter list.

---Setting range---  
 1 to 8192

#### **【#2212】 SV012 IDG Current loop d axis gain**

Set the fixed value of each motor.  
Set the standard value for each motor described in the standard parameter list.

---Setting range---  
1 to 8192

#### **【#2213】 SV013 ILMT Current limit value**

Set the current (torque) limit value in a normal operation.  
This is a limit value in forward run and reverse run (for linear motors:forward and reverse direction).  
When the standard setting value is "800", the maximum torque is determined by the specification of the motor.  
Set this parameter as a proportion (%) to the stall current.

---Setting range---  
0 - 999 (Stall current %)

#### **【#2214】 SV014 ILMTsp Current limit value in special control**

Set the current (torque) limit value in a special operation (absolute position initial setting, stopper control and etc.).  
This is a limit value in forward and reverse directions.  
Set to "800" when not using.  
Set this parameter as a proportion (%) to the stall current.

---Setting range---  
0 - 999 (Stall current %)  
However, when SV084/bitB=1, the setting range is from 0 to 32767 (Stall current 0.01%).

#### **【#2215】 SV015 FFC Acceleration rate feed forward gain**

When a relative error in synchronous control is too large, set this parameter to the axis that is delaying.  
The standard setting is "0". The standard setting in the SHG control is "100".  
To adjust a relative error in acceleration/deceleration, increase the value by 50 - 100 at a time.

---Setting range---  
0 to 999 (%)

#### **【#2216】 SV016 LMC1 Lost motion compensation 1**

Set this parameter when the protrusion (that occurs due to the non-sensitive band by friction, torsion, backlash, etc.) at quadrant change is too large. This sets the compensation torque at quadrant change (when an axis feed direction is reversed) by the proportion (%) to the stall torque. Whether to enable the lost motion compensation and the method can be set with other parameters.

Type 2: When SV027 (SSF1)/bit9, 8 (Imc) = 10 (Compatible with obsolete type)  
Set the type 2 method compensation torque. The standard setting is double the friction torque.  
Related parameters: SV027/bit9,8, SV033/bitF, SV039, SV040, SV041, SV082/bit2, SV113/bit7


Type 3: When SV082(SSF5)/bit1= 1  
Set the compensation torque equivalent of dynamic friction amount of the type 3 method compensation amount. The standard setting is double the dynamic friction torque.  
Related parameters: SV041, SV082/bit2,1, SV085, SV086, SV113/bit7

To vary compensation amount according to the direction.  
When SV041 (LMC2) is "0", compensate with the value of SV016 (LMC1) in both +/-directions.  
If you wish to change the compensation amount depending on the command direction, set this and SV041 (LMC2).  
(SV016: + direction, SV041: - direction. However, the directions may be opposite depending on other settings.)  
When "-1" is set, the compensation will not be performed in the direction of the command.

---Setting range---  
-1 to 200 (Stall current %)  
Note that when SV082/bit2 is "1", the setting range is between -1 and 20000 (Stall current 0.01%).

# [#2217(PR)] SV017 SPEC1 Servo specification 1

Select the servo specifications.  
A function is allocated to each bit.  
Set this in hexadecimal format.



## bit F-C : spm Motor series selection

- 0: 200V HF, HP motor 1
- 1: 200V HF, HP motor 2 (Standard)
- 2: 400V HF-H, HP-H motor 1
- 3: 400V HF-H, HP-H motor 2 (Standard)
- 6: 200V LM-F linear motor
- 7: 200V direct-drive motor
- 8: 400V LM-F linear motor
- 9: 400V direct-drive motor

## bit B :

Not used. Set to "0".

## bit A : drvup Combined drive unit:

- For MDS-DM Series
  - 0: Normal setting (Combined drive unit: normal)
  - 1: Combined drive unit: one upgrade
- In the following combination of the drive unit and servomotors, set to "bitA=1".  
MDS-DM-V3-404040 ----- HF75, HF105, HF123, HF142  
MDS-DM-SPV2/SPV3 ----- HF54, HF104, HF223, HF302

## bit 9 :

Not used. Set to "0".

## bit 8 : mp MPI scale pole number setting

- 0: 360 poles 1: 720 poles

## bit 7 : abs Position control

These parameters are set automatically by the NC system.  
0: Incremental 1: Absolute position control

## bit 6-5 :

Not used. Set to "0".

## bit 4 : sdir Sub side detector feedback

Set the machine side detector's installation polarity.  
0: Forward polarity 1: Reverse polarity

## bit 3 : vfb Speed feedback filter

- 0: Stop 1: Start (2250Hz)

## bit 2 : seqh Ready on sequence

- 0: Normal 1: High-speed

## bit 1 : dfbx Dual feedback control

Control the position FB signal in full closed control by the combination of a motor side detector and machine side detector.  
0: Stop 1: Start

Related parameters: SV051, SV052

**bit 0 : mdir Machine side detector feedback (for Linear/direct-drive motor)**

Set the detector installation polarity in the linear servo and direct-drive motor control.

0: Forward polarity 1: Reverse polarity

**【#2218(PR)】 SV018 PIT Ball screw pitch/Magnetic pole pitch**

For servo motor:

Set the ball screw pitch. For the rotary axis, set to "360".

For direct-drive motor

Set to "360".

- For linear motor

Set the ball screw pitch. (For LM-F series, set to "48")

**---Setting range---**

For general motor: 1 to 32767 (mm/rev)

- For linear motor 1 to 32767 (mm)

**【#2219(PR)】 SV019 RNG1 Sub side detector resolution**

For semi-closed loop control

Set the same value as SV020.

For full-closed loop control

Set the number of pulses per ball screw pitch.

For direct-drive motor

Set the same value as SV020.

For 1000 pulse unit resolution detector, set the number of pulses in SV019 in increments of 1000 pulse (kp).

In this case, make sure to set "0" to SV117.

For high-accuracy binary resolution detector, set the number of pulses to four bite data of SV117 (high-order) and SV019 (low-order) in pulse (p) unit.

SV117 = number of pulses / 65536 (when =0, set "-1" to SV117)

SV019 = the remainder of number of "pulses / 65536"

When the NC is C70 and "SV019 > 32767", set "the reminder of above - 65536 (negative number)" to "SV019".

**---Setting range---**

When SV117 = 0, the setting range is from 0 to 32767 (kp)

When SV117 ≠ 0

M700V, M70V, M70: 0 to 65536 (p)

C70: -32768 to 32767 (p)



**【#2220(PR)】 SV020 RNG2 Main side detector resolution**

Set the number of pulses per revolution of the motor side detector.

OSA18 (-A48) (260,000 p/rev) ----- SV020 = 260

OSA105 (-A51) (1,000,000 p/rev) ----- SV020 = 1000

OSA166 (-A74) (16,000,000 p/rev) ----- SV020 = 16000

For linear motor

Set the number of pulses of the detector per magnetic pole pitch with SV118.

For direct-drive motor

Set the number of pulses per revolution of the motor side detector.

For 1000 pulse unit resolution detector, set the number of pulses to SV020 in increments of 1000 pulse(kp).

In this case, make sure to set SV118 to "0".

For high-accuracy binary resolution detector, set the number of pulses to four bite data of SV118 (high-order) and SV020 (low-order) in pulse(p) unit.

SV118 = number of pulses / 65536 (when =0, set "-1" to SV118)

SV019 = the remainder of "number of pulses / 65536"

When the NC is C70 and "SV020 > 32767", set "the remainder of above - 65536 (negative number)" to "SV020".

**---Setting range---**

When SV118 = 0, the setting range is from 0 to 32767 (kp)

When SV118 ≠ 0

For M700V,M70V,M70: 0 to 65536 (p)

For C70: -32768 to 32767 (p)

**【#2221】 SV021 OLT Overload detection time constant**

Normally, set to "60". (For machine tool builder adjustment.)

Related parameters: SV022

**---Setting range---**

1 to 999 (s)

**【#2222】 SV022 OLL Overload detection level**

Set the "Overload 1" (Alarm 50) current detection level as percentage to the stall current.

Normally set this parameter to "150". (For machine tool builder adjustment.)

Related parameters: SV021

**---Setting range---**

110 to 500 (Stall current %)

**【#2223】 SV023 OD1 Excessive error detection width during servo ON**

Set the excessive error detection width in servo ON.

<Standard setting value>

$OD1=OD2= (\text{Rapid traverse rate [mm/min]}) / (60 \times PGN1) / 2 \text{ [mm]}$

When set to "0", the excessive error alarm detection will be ignored.

Related parameters: SV026

**---Setting range---**

0 to 32767 (mm)

However, when SV084/bitC=1, the setting range is from 0 to 32767 (μm).

(Only for MDS-D/DH and MDS-DM)

### 【#2224】 SV024 INP In-position detection width


Set the in-position detection width.  
Set the positioning accuracy required for the machine.  
The lower the setting is, the higher the positioning accuracy will be. However the cycle time (settling time) becomes longer.  
The standard setting value is "50".

#### ---Setting range---

0 to 32767 ( $\mu$  m)

### 【#2225(PR)】 SV025 MTYP Motor/Detector type

Set the position detector type, speed detector type and motor type.  
The setting value is a four-digit hex (HEX).



#### bit F-C : pen(HEX-4) Position detector

Semi-closed loop control by general motor  
pen=2

Full-closed loop control by general motor

- Ball screw end detector (OSA105-ET2, OSA166-ET2)

pen=6

- For serial signal output rotary scale (including MDS-B-HR)

pen=6

- For rectangular wave signal output scale

pen=8

- For serial signal output linear scale (including MDS-B-HR and MPI scale)

pen=A

- For speed command synchronization control

Primary axis pen=A

Secondary axis pen=D

For linear motor

pen=A

For direct-drive motor

pen=2

#### bit B-8 : ent(HEX-3) Speed detector

For general motor ent=2

For linear motor ent=A

For direct-drive motor ent=2

### bit 7-0 : mtyp(HEX-2,1) Motor type

Set the motor type. Set this with SV017/bitF-C.

For SV017/bitF-C = 1 (200V standard motor series)

HF75 : 01h	HP54 : 11h	HF-KP13 : E9h (Note 3)
HF105 : 02h	HP104 : 12h	HF-KP23 : EAh
HF54 : 03h	HP154 : 13h	HF-KP43 : EBh
HF104 : 04h	HP224 : 1Bh	HF-KP73 : ECh
HF154 : 05h, 0Fh (Note 1)	HP204 : 14h	
HF224 : 06h	HP354 : 15h	
HF204 : 07h	HP454 : 16h	
HF354 : 08h	HP704 : 17h	
HF123 : 24h	HP903 : 18h	
HF223 : 26h, 2Dh (Note 2)	HP1103 : 19h	
HF303 : 28h		
HF453 : 09h		
HF703 : 0Ah		
HF903 : 0Bh		
HF142 : 25h		
HF302 : 27h, 2Eh (Note 2)		

(Note 1) When MDS-DM-V3 is connected

(Note 2) When MDS-DM-V3 M/S axis is connected

(Note 3) MDS-D-SVJ3 only

For SV017/bitF-C = 3 (400V standard motor series)

HF-H75 : 01h,	HP-H54 : 11h
HF-H105 : 02h,	HP-H104 : 12h
HF-H54 : 03h,	HP-H154 : 13h
HF-H104 : 04h,	HP-H204 : 14h
HF-H154 : 05h,	HP-H354 : 15h
	HP-H454 : 16h
HF-H204 : 07h,	HP-H704 : 17h
HF-H354 : 08h,	HP-H903 : 18h
HF-H453 : 09h,	HP-H1103 : 19h
HF-H703 : 0Ah	
HF-H903 : 0Bh,	HP-H224 : 1Bh
HC-H1502 : B9h	

For linear motor and direct-drive motor, follow the settings stated in respective materials.

### 【#2226】 SV026 OD2 Excessive error detection width during servo OFF

Set the excessive error detection width during servo OFF.

<Standard setting value>

OD1=OD2= (Rapid traverse rate [mm/min]) / (60×PGN1) / 2 [mm]

When set to "0", the excessive error alarm detection will be ignored.

Related parameters: SV023

#### ---Setting range---


0 to 32767 (mm)

However, when SV084/bitC=1, the setting range is from 0 to 32767 (μm).

(Only for MDS-D/DH and MDS-DM)

## 【#2227】 SV027 SSF1 Servo function 1

Select the servo functions.  
A function is assigned to each bit.  
Set this in hexadecimal format.



### bit F :

Not used. Set to "0".

### bit E : zrn2

Set to "1". (Fixed)

### bit D :

Not used. Set to "0".

### bit C :

Not used. Set to "0".

### bit B-A : ovs Overshooting compensation type selection

Set this if overshooting occurs during positioning.

bitB,A=

00: Compensation stop

01: Setting prohibited

10: Setting prohibited

11: Type 3

(Set the compensation amount in SV031 and SV042.)

Related parameters: SV031, SV042, SV034/bitF-C

### bit 9-8 : lmc Lost motion compensation type selection

Type 2 has an obsolete type compatible control.

bit9,8=

00: Compensation stop

01: Setting prohibited

10: Type 2

11: Setting prohibited

(Set the compensation amount in SV016 and SV041.)

(Note) When "SV082/bit1=1", the lost motion compensation type 3 will be selected.

### bit 7 :

Not used. Set to "0".

### bit 6 :

Not used. Set to "0".

### bit 5-4 : vfct Jitter compensation pulse number

Suppress vibration by machine backlash when axis stops.

bit5,4=

00: Disable

01: 1 pulse

10: 2 pulses

11: 3 pulses

### bit 3 :

Not used. Set to "0".

### bit 2 :

Not used. Set to "0".

**bit 1-0 : vcnt Speed loop delay compensation changeover type selection**

Normally, use "Changeover type 2".  
 bit1,0=  
 00: Disable  
 01: Changeover type 1  
 10: Changeover type 2  
 11: Setting prohibited

Related parameters: SV007

**【#2228(PR)】 SV028 MSFT Magnetic pole shift amount (for linear/direct-drive motor)**

Set this parameter to adjust the motor magnetic pole position and detector's installation phase when using linear motors or direct-drive motors.  
 During the DC excitation of the initial setup (SV034/bit4=1), set the same value displayed in "AFLT gain" on the NC monitor screen.

Related parameters: SV034/bit4, SV061, SV062, SV063

For general motor:  
 Not used. Set to "0".

---Setting range---  
 -18000 to 18000 (Mechanical angle 0.01°)

**【#2229】 SV029 VCS Speed at the change of speed loop gain**

Noise at high speed rotation including rapid traverse can be reduced by lowering the speed loop gain at high speeds.  
 Set the speed at which the speed loop gain changes. Use this with SV006 (VGN2).  
 When not using, set to "0".

---Setting range---  
 0 to 9999 (r/min)

**【#2230】 SV030 IVC Voltage non-sensitive band compensation**

When 100% is set, the voltage reduction amount equivalent to the logical non-energization in the PWM control will be compensated.  
 When "0" is set, 100% compensation will be performed.  
 Adjust in increments of 10% from the default value of 100%.  
 If increased too much, vibration or vibration noise may be generated.

---Setting range---  
 0 to 255 (%)

**【#2231】 SV031 OVS1 Overshooting compensation 1**

This compensates the motor torque when overshooting occurs during positioning. This is valid only when the overshooting compensation (SV027/bitB,A) is selected.

Type 3 SV027(SSF1)/bitB,A(ovs) = 11  
 Set the compensation amount based on the motor stall current. Observing positioning droop waveform, increase in increments of 1% and find the value where overshooting does not occur.

To vary compensation amount depending on the direction.

When SV042 (OVS2) is "0", change the SV031 (OVS1) value in both of the +/- directions to compensate.

To vary the compensation amount depending on the command direction, set this and SV042 (OVS2).

(SV031: + direction, SV042: - direction. However, the directions may be opposite depending on other settings.)

When "-1" is set, the compensation will not be performed in the direction of the command.

Related parameters: SV027/bitB,A, SV034/bitF-C, SV042, SV082/bit2

---Setting range---  
 -1 to 100 (Stall current %)  
 Note that the range will be "-1 - 10000" (Stall current 0.01%) when SV082/bit2 is "1".

**【#2232】 SV032 TOF Torque offset**

Set the unbalance torque on vertical axis and inclined axis.

When the vertical axis pull up function is enabled, the pull up compensation direction is determined by this parameter's sign. When set to "0", the vertical axis pull up will not be executed.

This can be used for speed loop delay compensation and collision detection function.

To use load inertia estimation function (drive monitor display), set this parameter, friction torque (SV045) and load inertia display enabling flag(SV035/bitF).


Related parameters: SV007, SV033/bitE, SV059

**---Setting range---**

-100 to 100 (Stall current %)

**【#2233】 SV033 SSF2 Servo function 2**

Select the servo functions.  
A function is assigned to each bit.  
Set this in hexadecimal format.

**bit F : lmc2a Lost motion compensation 2 timing**

0: Normal 1: Change

**bit E : zup Vertical axis pull up function**

0: Stop 1: Enable

Related parameters: SV032, SV095

**bit D : rps Speed setting increment**

Change the setting units of the specified speed signal output speed (SV073) and safety observation safety speed (SV238).

0: mm/min 1: 100mm/min

Related parameters: SV073, SV238

**bit C-8 :**

Not used. Set to "0".

**bit 7-5 : nfd2 Depth of Notch filter 2**

Set the depth of Notch filter 2 (SV046).

bit7,6,5=

000: - ∞

001: -18.1[dB]

010: -12.0[dB]

011: -8.5[dB]

100: -6.0[dB]

101: -4.1[dB]

110: -2.5[dB]

111: -1.2[dB]

Set the adaptive frequency of Notch filter 2 in "#2246 SV046 FHz2".

**bit 4 : nfd3 Notch filter 3**

0: Stop 1: Start (1,125Hz)

**bit 3-1 : nfd1 Depth of Notch filter 1**

Set the depth of Notch filter 1 (SV038).

bit3,2,1=

000: - ∞

001: -18.1[dB]

010: -12.0[dB]

011: -8.5[dB]

100: -6.0[dB]

101: -4.1[dB]

110: -2.5[dB]

111: -1.2[dB]

Set the adaptive frequency of Notch filter 1 in "#2238 SV038 FHz1".


**bit 0 : zck Feedback error alarm 42 detection**

This ignores the false detection of alarms when using multipoint Z phase scale including distance-coded reference scale.

0: Normal setting 1: Disable

# [#2234] SV034 SSF3 Servo function 3

Select the servo functions.  
A function is assigned to each bit.  
Set this in hexadecimal format.



## bit F-C: ovsN Overshooting compensation type 3 Non-sensitive band

Set the non-sensitive band of the model position droop overshooting amount in increments of  $2 \mu\text{m}$ .  
In the feed forward control, set the non-sensitive band of the model position droop and ignore the overshooting of the model.

0 :  $0 \mu\text{m}$ , 1:  $2 \mu\text{m}$ , 2:  $4 \mu\text{m}$ ,---, E :  $28 \mu\text{m}$ , F:  $30 \mu\text{m}$

## bit B-8 : linN The number of parallel connections when using linear motors (for linear)

Set to "2" to perform 1 amplifier 2 motor control by linear servo.

## bit 7-5 :

Not used. Set to "0".

## bit 4 : dcd (linear/direct-drive motor)

0: Normal setting 1: DC excitation mode

Related parameters: SV061, SV062, SV063

## bit 3 :

Not used. Set to "0".

## bit 2 : mohn Thermistor temperature detection (linear/direct-drive motor)

0: Normal setting 1: Disable

## bit 1 : has HAS control

This stabilizes the speed overshooting by torque saturation phenomenon.

0: Normal setting 1: Enable

Related parameters: SV084/bitF


## bit 0 :

Not used. Set to "0".



[#2235] SV035 SSF4 Servo function 4

Select the servo functions.  
 A function is assigned to each bit.  
 Set this in hexadecimal format.



**bit F : clt Inertia ratio display**

0: Setting for normal use  
 1: Display the total inertia ratio estimated at acceleration/deceleration at the inertia ratio on the servo monitor screen  
 To display it on the screen, set an imbalance torque and friction torque to both SV032 and SV045 and repeat acceleration/deceleration operations for several times.

**bit E-C: clG1 G1 Collision detection level**

Set the collision detection level in the collision detection method 1 during cutting feed (G1) in multiples of that of rapid traverse (G0). When set to "0", detection of collision detection method 1 during cutting feed will be ignored.  

$$G1 \text{ Collision detection level} = G0 \text{ collision detection level (SV060)} \times clG1$$

**bit B : cl2n Collision detection method 2**

0: Enable 1: Disable

**bit A :**

Not used. Set to "0".

**bit 9-8 : cltq Retract torque in collision detection**

Set the retract torque in collision detection using the ratio of motor's maximum torque.  
 bit9,8=  
 00: 100%  
 01: 90%  
 10: 80%(Standard)  
 11: 70%

**bit 7 : ckab No signal detection 2**

Set this to use rectangular wave output linear scale.  
 This enables the detection of No signal 2 (alarm 21).  
 0: Disable 1: Enable


**bit 6-0 :**

Not used. Set to "0".

**【#2236(PR)】 SV036 PTPP Power supply type/ Regenerative resistor type**

**MDS-D/DH Series: Power supply type**

When connecting a power supply unit, set a code for each power supply unit.



**bit F-C : amp**

Not used. Set to "0".

**bit B-8 : rtp**

Not used. Set to "0".

**bit 7-0 : ptyp External emergency stop setting**

When the emergency stop input signal of the power supply unit is "disabled"

Power supply unit is not connected	: 00
MDS-D-CV-37 / MDS-DH-CV-37	: 04
MDS-D-CV-75 / MDS-DH-CV-75	: 08
MDS-D-CV-110 / MDS-DH-CV-110	: 11
MDS-D-CV-185 / MDS-DH-CV-185	: 19
MDS-D-CV-300 / MDS-DH-CV-300	: 30
MDS-D-CV-370 / MDS-DH-CV-370	: 37
MDS-D-CV-450 / MDS-DH-CV-450	: 45
MDS-D-CV-550 / MDS-DH-CV-550	: 55
MDS-DH-CV-750	: 75

When the emergency stop input signal of the power supply unit is "enabled"

(Note) Set the power supply rotary switch to "4".

Power supply unit is not connected	: 00
MDS-D-CV-37 / MDS-DH-CV-37	: 44
MDS-D-CV-75 / MDS-DH-CV-75	: 48
MDS-D-CV-110 / MDS-DH-CV-110	: 51
MDS-D-CV-185 / MDS-DH-CV-185	: 59
MDS-D-CV-300 / MDS-DH-CV-300	: 70
MDS-D-CV-370 / MDS-DH-CV-370	: 77
MDS-D-CV-450 / MDS-DH-CV-450	: 85
MDS-D-CV-550 / MDS-DH-CV-550	: 95
MDS-DH-CV-750	: B5


**MDS-DM-SPV Series**

Not used. Set to "0000".

Power supply type is set by spindle side.

# MDS-D-SVJ3 Series: Regenerative resistor type

Set the regenerative resistor type.



## bit F-8 : amp(bit F-C) / rtyp(bit B-8)

Resistor built-in drive unit	: 10
Setting prohibited	: 11
MR-RB032	: 12
MR-RB12 or GZG200W39OHMK	: 13
MR-RB32 or GZG200W120OHMK 3 units connected in parallel	: 14
MR-RB30 or GZG200W39OHMK 3 units connected in parallel	: 15
MR-RB50 or GZG300W39OHMK 3 units connected in parallel	: 16
MR-RB31 or GZG200W20OHMK 3 units connected in parallel	: 17
MR-RB51 or GZG300W20OHMK 3 units connected in parallel	: 18
Setting prohibited	: 19-1F
Setting prohibited	: 20-23
FCUA-RB22	: 24
FCUA-RB37	: 25
FCUA-RB55	: 26
Setting prohibited	: 27
R-UNIT1	: 28
R-UNIT2	: 29
R-UNIT3	: 2A
R-UNIT4	: 2B
R-UNIT5	: 2C
FCUA-RB75/2 2 units connected in parallel	: 2D
FCUA-RB55 2 units connected in parallel	: 2E
Setting prohibited	: 2F

## bit 7-4 : emgx External emergency stop function

Set the external emergency stop function. (Do not set a value other than specified.)  
0: Disable 4: Enable

## bit 3-0 :

Not used. Set to "0".

## [#2237] SV037 JL Load inertia scale

Set the motor axis conversion total load inertia including motor itself in proportion to the motor inertia.

$$SV037(JL) = (J_m + J_l) / J_m \times 100$$

Jm: Motor inertia

Jl: Motor axis conversion load inertia

For linear motor, set the gross mass of the moving sections in kg unit.

<<Drive monitor load inertia ratio display>>

Set SV035/bitF=1 and imbalance torque and friction torque to both SV032 and SV045, and then repeat acceleration/deceleration for several times.

### ---Setting range---

For general motor: 0 to 5000 (%)

For linear motor 0 to 5000 (kg)

#### **【#2238】 SV038 FHz1 Notch filter frequency 1**

Set the vibration frequency to suppress when machine vibration occurs.  
(Normally, do not set 80 or less.)  
Set to "0" when not using.

Related parameters: SV033/bit3-1, SV115

**---Setting range---**  
0 to 2250 (Hz)

#### **【#2239】 SV039 LMCD Lost motion compensation timing**

Set this when the timing of lost motion compensation type 2 does not match.  
Adjust increments of 10 at a time.

**---Setting range---**  
0 to 2000 (ms)

#### **【#2240】 SV040 LMCT Lost motion compensation non-sensitive band**

Set the non-sensitive band of the lost motion compensation in the feed forward control.  
When "0" is set, 2  $\mu$  m is the actual value to be set. Adjust increments of 1  $\mu$  m.

**---Setting range---**  
0 to 255 ( $\mu$  m)

#### **【#2241】 SV041 LMC2 Lost motion compensation 2**

Set this with SV016 (LMC1) only when you wish to vary the lost motion compensation amount depending on the command directions.  
Normally, set to "0".

Related parameters: SV016

**---Setting range---**  
-1 to 200 (Stall current %)  
Note that when SV082/bit2 is "1", the setting range is between -1 and 20000 (Stall current 0.01%).

#### **【#2242】 SV042 OVS2 Overshooting compensation 2**

Set this with SV031 (OVS1) only when you wish to vary the overshooting compensation amount depending on the command directions.  
Normally, set to "0".

Related parameters: SV031

**---Setting range---**  
-1 to 100 (Stall current %)  
Note that when SV082/bit2 is "1", the setting range is between -1 and 10000 (Stall current 0.01%).

#### **【#2243】 SV043 OBS1 Disturbance observer filter frequency**

Set the disturbance observer filter band.  
Normally, set to "100". Setting values of 49 or less is equal to "0" setting.  
To use the disturbance observer, also set SV037 (JL) and SV044 (OBS2).  
When disturbance observer related parameters are changed, lost motion compensation needs to be readjusted.  
Set to "0" when not using.

**---Setting range---**  
0 to 1000 (rad/s)

**【#2244】 SV044 OBS2 Disturbance observer gain**

Set the disturbance observer gain. The standard setting is "100 to 300".  
To use the disturbance observer, also set SV037 (JL) and SV043 (OBS1).  
When disturbance observer related parameters are changed, lost motion compensation needs to be readjusted.  
Set to "0" when not using.

---Setting range---  
0 to 500 (%)

**【#2245】 SV045 TRUB Friction torque**

Set the frictional torque when using the collision detection function.  
To use load inertia estimation function (drive monitor display), set this parameter, imbalance torque (SV032) and load inertia display enabling flag (SV035/bitF).

---Setting range---  
0 to 255 (Stall current %)

**【#2246】 SV046 FHz2 Notch filter frequency 2**

Set the vibration frequency to suppress when machine vibration occurs.  
(Normally, do not set 80 or less.)  
Set to "0" when not using.

Related parameters: SV033/bit7-5, SV115

---Setting range---  
0 to 2250 (Hz)

**【#2247】 SV047 EC Inductive voltage compensation gain**

Set the inductive voltage compensation gain. Standard setting value is "100".  
If the current FB peak exceeds the current command peak, lower the gain.

---Setting range---  
0 to 200 (%)

**【#2248】 SV048 EMGrt Vertical axis drop prevention time**

Input the time required to prevent the vertical axis from dropping by delaying READY OFF until the brake works at an emergency stop.  
Increase in increments of 100ms at a time, find and set the value where the axis does not drop.  
When using a motor with a break of HF(-H) Series or HP(-H) Series, set to "200ms" as a standard.  
When the pull up function is enabled (SV033/bitE=1), the pull up is established during the drop prevention time.

Related parameters: SV033/bitE, SV055, SV056

---Setting range---  
0 to 20000 (ms)

**【#2249】 SV049 PGN1sp Position loop gain 1 in spindle synchronous control**

Set the position loop gain during spindle synchronization control (synchronous tapping and synchronization control with spindle C-axis).  
Set the same value as that of the position loop gain for spindle synchronous tapping control.  
When performing the SHG control, set this parameter with SV050 (PGN2sp) and SV058 (SHGCsp).  
When changing the value, change the value of "#2017 tap\_g Axis servo gain".

---Setting range---  
1 to 200 (rad/s)

#### **【#2250】 SV050 PGN2sp Position loop gain 2 in spindle synchronous control**

When using SHG control during spindle synchronous control (synchronous tapping and synchronization control with spindle C-axis), set this parameter with SV049 (PGN1sp) and SV058 (SHGCsp).

Make sure to set the value 8/3 times that of SV049.

When not using the SHG control, set to "0".

**---Setting range---**

0 to 999 (rad/s)

#### **【#2251】 SV051 DFBT Dual feedback control time constant**

Set the control time constant in dual feed back.

When "0" is set, it operates at 1ms.

The higher the time constant is, the closer it gets to the semi-closed control, so the limit of the position loop gain will be raised.

For linear servo/direct-drive motor system

Not used. Set to "0".

Related parameters: SV017/bit1, SV052

**---Setting range---**

0 to 9999 (ms)

#### **【#2252】 SV052 DFBN Dual feedback control non-sensitive band**

Set the non-sensitive band in the dual feedback control.

Normally, set to "0".

For linear servo/direct-drive motor system

Not used. Set to "0".

Related parameters: SV017/bit1, SV052

**---Setting range---**

0 to 9999 ( $\mu$  m)

#### **【#2253】 SV053 OD3 Excessive error detection width in special control**

Set the excessive error detection width when servo ON in a special control (initial absolute position setting, stopper control and etc.).

When "0" is set, excessive error detection will not be performed when servo ON during a special control.

**---Setting range---**

0 to 32767 (mm)

However, when SV084/bitC=1, the setting range is from 0 to 32767 ( $\mu$  m).

(Only for MDS-D/DH and MDS-DM)

#### **【#2254】 SV054 ORE Overrun detection width in closed loop control**

Set the overrun detection width in the full-closed loop control.

When the gap between the motor side detector and the linear scale (machine side detector) exceeds the value set by this parameter, it will be judged as overrun and "Alarm 43" will be detected.

When "-1" is set, the alarm detection will not be performed.

When "0" is set, overrun will be detected with a 2mm width.

For linear servo/direct-drive motor system

Not used. Set to "0".

**---Setting range---**

-1 to 32767 (mm)

However, when SV084/bitD=1, the setting range is from -1 to 32767 ( $\mu$  m).

(Only for MDS-D/DH and MDS-DM)

**【#2255】 SV055 EMGx Max. gate off delay time after emergency stop**

Set the time required between an emergency stop and forced READY OFF.  
Set the maximum value "+ 100ms" of the SV056 setting value of the servo drive unit electrified by the same power supply unit.  
When executing the vertical axis drop prevention, the gate off will be delayed for the length of time set at SV048 even when SV055's is smaller than that of SV048.

Related parameters: SV048, SV056

**---Setting range---**

0 to 20000 (ms)

**【#2256】 SV056 EMGt Deceleration time constant at emergency stop**

Set the time constant used for the deceleration control at emergency stop.  
Set the time required to stop from rapid traverse rate (rapid).  
The standard setting value is  $EMGt \leq G0tL * 0.9$ .  
However, note that the standard setting value differs from the above-mentioned value when the setting value of "#2003:smgst Acceleration and deceleration modes bit 3-0:Rapid traverse acceleration/deceleration type" is 8 or F. Refer to Instruction Manual of the drive unit (section "Deceleration control") for details.  
When the axis is used in the synchronous control, set the same value with minus sign to both axes.  
If one of the axes switches to dynamic brake by an alarm during deceleration control, another axis will also switch.

Related parameters: SV048, SV055

**---Setting range---**

-20000 to 20000 (ms)

**【#2257】 SV057 SHGC SHG control gain**

When performing the SHG control, set to  $SV003(PGN1)*6$ .  
When not using the SHG control, set to "0".

Related parameters: SV003, SV004

**---Setting range---**

0 to 1200 (rad/s)

**【#2258】 SV058 SHGCsp SHG control gain in spindle synchronous control**

When using SHG control during spindle synchronization control (synchronous tapping and synchronous control with spindle C-axis), set this parameter with SV049 (PGN1sp) and SV050 (PGN2sp).  
Make sure to set the value 6 times that of SV049.  
When not using the SHG control, set to "0".

**---Setting range---**

0 to 1200 (rad/s)

**【#2259】 SV059 TCNV Collision detection torque estimated gain**

Set the torque estimated gain when using the collision detection function.  
The standard setting value is the same as the load inertia ratio (SV037 setting value) including motor inertia.  
Set to "0" when not using the collision detection function.

Related parameters: SV032, SV035/bitF-8, SV037, SV045, SV060

<<Drive monitor load inertia ratio display>>

Set SV035/bitF=1 and imbalance torque and friction torque to both SV032 and SV045, and then repeat acceleration/deceleration for several times.

**---Setting range---**

For general motor: 0 to 5000 (%)

For linear motor: 0 to 5000 (kg)

**【#2260】 SV060 TLMT Collision detection level**

When using the collision detection function, set the collision detection level at the G0 feeding.  
When "0" is set, none of the collision detection function will work.

Related parameters: SV032, SV035/bitF-8, SV037, SV045, SV059

**---Setting range---**

0 to 999 (Stall current %)

**【#2261】 SV061 DA1NO D/A output ch1 data No. / Initial DC excitation level**

Input the data number you wish to output to the D/A output channel 1.  
When using the 2-axis drive unit, set "-1" to the axis that the data will not be output.

When the DC excitation is running (SV034/bit4=1):

Use this when the DC excitation is running (SV034/bit4=1) to adjust the initial magnetic pole position (when measuring the magnetic pole shift amount) for linear motor and direct-drive motor.  
Set the initial excitation level in DC excitation control.

Set 5% as standard.

Related parameters: SV062, SV063

**---Setting range---**

-1 to 127

When the DC excitation is running (SV034/bit4=1): 0 to 100 (Stall current %)

**【#2262】 SV062 DA2NO D/A output ch2 data No. / Final DC excitation level**

Input the data number you wish to output to the D/A output channel 2.  
When using the 2-axis drive unit, set "-1" to the axis that the data will not be output.

When the DC excitation is running (SV034/bit4=1):

Use this when the DC excitation is running (SV034/bit4=1) to adjust the initial magnetic pole position (when measuring the magnetic pole shift amount) for linear motor and direct-drive motor.  
Set the final excitation level in DC excitation control.

Set 5% as standard.

When the magnetic pole shift amount measurement value is unsteady, adjust the value in increments of 5%.

Related parameters: SV061, SV063

**---Setting range---**

-1 to 127

When the DC excitation is running (SV034/bit4=1): 0 to 100 (Stall current %)

**【#2263】 SV063 DA1MPY D/A output ch1 output scale / Initial DC excitation time**

Set output scale of the D/A output channel 1 in increment of 1/100.  
When "0" is set, the magnification is the same as when "100" is set.

When the DC excitation is running (SV034/bit4=1):

Use this when the DC excitation is running (SV034/bit4=1) to adjust the initial magnetic pole position (when measuring the magnetic pole shift amount) for linear motor and direct-drive motor.  
Set the initial excitation time in DC excitation control.

Set 500ms as standard.

When the magnetic pole shift amount measurement value is unsteady, adjust the value in increments of 500ms.

Related parameters: SV061, SV062

**---Setting range---**

-32768 to 32767 (1/100-fold)

When the DC excitation is running (SV034/bit4=1): 0 to 10000 (ms)

**【#2264】 SV064 DA2MPY D/A output ch2 output scale**

Set output scale of the D/A output channel 2 in increment of 1/100.  
When "0" is set, the magnification is the same as when "100" is set.

**---Setting range---**

-32768 to 32767 (1/100-fold)



[#2265] SV065 TLC Machine end compensation gain

The shape of the machine end is compensated by compensating the spring effect from the machine end to the motor end.

Set the machine end compensation gain. Measure the error amount by roundness measurement and estimate the setting value by the following formula.

Compensation amount (  $\mu$  m ) = Command speed F(mm/min)<sup>2</sup> \* SV065 / (Radius R(mm) \* SV003 \* 16,200,000)

Set to "0" when not using.

---Setting range---

-30000 to 30000 (Acceleration ratio 0.1%)

[#2266-2272] SV066 - SV072

This parameter is set automatically by the NC system.

[#2273(PR)] SV073 FEEDout Specified speed output speed

Set the specified speed.

Also set SV082/bit9,8 to output digital signal.

---Setting range---

-32768 to 32767 (r/min)

However, when SV033/bitD=1, the setting range is from -32768 to 32767 (100mm/min).

[#2274-2280] SV074 - SV080


This parameter is set automatically by the NC system.

[#2281(PR)] SV081 SPEC2 Servo specification 2

Select the servo functions.

A function is assigned to each bit.

Set this in hexadecimal format.



bit F-A :

Not used. Set to "0".

bit 9 : npg Earth fault detection

0: Disable 1: Enable (standard)

Set "0" and it is constantly "Enable" for MDS-D-SVJ3 Series.

bit 8 :

Not used. Set to "0".

bit 7 : szchk Distance-coded reference scale reference mark

0: Check at 4 points (standard) 1: Check at 3 points

bit 6-4 :

Not used. Set to "0".

bit 3 : absc Distance-coded reference scale


0: Disable 1: Enable

bit 2-0 :

Not used. Set to "0".

## [#2282] SV082 SSF5 Servo function 5

Select the servo functions.  
A function is assigned to each bit.  
Set this in hexadecimal format.



### bit F-C : dis Digital signal input selection

- 0: No signal
- 1: Safety observation function door state signal
- 2: Battery box voltage drop warning (It is not available for MDS-D-SVJ3 Series.)
- 3 to F: Setting prohibited

### bit B-A : dos3 Digital signal output 3 selection

- bitB,A=
- 00: Disable
- 01: Setting prohibited
- 10: Contactor control signal output (For MDS-D-SVJ3)
- 11: Setting prohibited

### bit 9-8 : dos2 Digital signal output 2 selection

- bit9,8=
- 00: Disable
- 01: Specified speed output
- 10: Setting prohibited
- 11: Setting prohibited

### bit 7-3 :

Not used. Set to "0".

### bit 2 : ccu Lost motion overshoot compensation compensation amount setting increment

- 0: Stall current % 1: Stall current 0.01%

### bit 1 : Imc3 Lost motion compensation type 3

Set this when protrusion at a quadrant change is too big.  
0: Stop 1: Start

Related parameters: SV016, SV041, SV085, SV086

### bit 0 :


Not used. Set to "0".

**【#2283】 SV083 SSF6 Servo function 6**

Select the servo functions.

A function is assigned to each bit.

Set this in hexadecimal format.

**bit F-8 :**

Not used. Set to "0".

**bit 7-5 : nfd5 Depth of Notch filter 5**

Set the depth of Notch filter 5.

bit7,6,5=

000: -  $\infty$

001: -18.1[dB]

010: -12.0[dB]

011: -8.5[dB]

100: -6.0[dB]

101: -4.1[dB]

110: -2.5[dB]

111: -1.2[dB]

Set the adaptive frequency of Notch filter 5 in "#2288 SV088 FHz5".

**bit 4 :**

Not used. Set to "0".

**bit 3-1 : nfd4 Depth of Notch filter 4**

Set the depth of Notch filter 4.

bit3,2,1=

000: -  $\infty$

001: -18.1[dB]

010: -12.0[dB]

011: -8.5[dB]

100: -6.0[dB]

101: -4.1[dB]

110: -2.5[dB]

111: -1.2[dB]


Set the adaptive frequency of Notch filter 4 in "#2287 SV087 FHz4".

**bit 0 :**

Not used. Set to "0".

# [#2284] SV084 SSF7 Servo function 7

Select the servo functions.  
A function is assigned to each bit.  
Set this in hexadecimal format.



## bit F : h2c HAS control cancel amount

0: 1/4 (standard) 1: 1/2

Related parameters: SV034/bit1

## bit E :

Not used. Set to "0".

## bit D : oru Overrun detection width unit (for MDS-D/DH and MDS-DM)

0: mm (normal setting) 1:  $\mu$  m  
It is not available for MDS-D-SVJ3 Series.

## bit C : odu Excessive error detection width unit (for MDS-D/DH and MDS-DM)

0: mm (normal setting) 1:  $\mu$  m  
It is not available for MDS-D-SVJ3 Series.

## bit B : ilm2u Current limit value (SV014) in special control setting unit

0: Stall current % (normal setting) 1: Stall current 0.01%

## bit A-1 :

Not used. Set to "0".

## bit 0 : irms Motor current display

0: Motor q axis current display (normal) 1: Motor effective current display

# [#2285] SV085 LMCK Lost motion compensation 3 spring constant

Set the machine system's spring constant when using lost motion compensation type 3.  
When not using, set to "0".

Related parameters: SV016, SV041, SV082/bit2,1, SV086

## ---Setting range---

0 to 32767 (0.01%/  $\mu$  m)

# [#2286] SV086 LMCc Lost motion compensation 3 viscous coefficient

Set the machine system's viscous coefficient when using lost motion compensation type 3.  
When not using, set to "0".

Related parameters: SV016, SV041, SV082/bit2,1, SV086

## ---Setting range---

0 to 32767 (0.01%/  $\mu$  m)

# [#2287] SV087 FH4 Notch filter frequency 4

Set the vibration frequency to suppress when machine vibration occurs.  
(Normally, do not set 80 or less.)  
Set to "0" when not using.

Related parameters: SV083/bit3-1, SV115

## ---Setting range---

0 to 2250 (Hz)

**【#2288】 SV088 FHz5 Notch filter frequency 5**

Set the vibration frequency to suppress when machine vibration occurs.  
(Normally, do not set 80 or less.)  
Set to "0" when not using.

Related parameters: SV083/bit7-5, SV115

---Setting range---  
0 to 2250 (Hz)

**【#2289】 SV089**

Not used. Set to "0".

**【#2290】 SV090**

Not used. Set to "0".

**【#2291】 SV091 LMC4G Lost motion compensation 4 gain**

Use this with LMC compensation type 3. As the delay in path tracking is monitored and compensated, the delay in path tracking will be minimized even if machine friction amount changes by aging. Use the lost motion compensation amount (SV016) \* 5 (10% of the dynamic friction torque) as the target. The higher the setting value is, the more accurate the quadrant change be; however, the more likely vibrations occur.

---Setting range---  
0 to 20000 (Stall current 0.01%)

**【#2292】 SV092**

Not used. Set to "0".

**【#2293】 SV093**

Not used. Set to "0".

**【#2294】 SV094 MPV Magnetic pole position error detection speed**

The magnetic pole position detection function monitors the command speed and motor speed at the position command stop and detects the magnetic pole position error alarm (3E) if any. Set the error detection level for the command speed and motor speed at the position command stop.  
Be aware when setting the parameter as the setting units for general motors and linear motors are different.

<<For general motor>>

When the command speed error detection level is set to "0", the magnetic pole position error (3E) is detected at 10r/min.

Set "10" as standard.

This detects the magnetic pole position error (3E) when the motor rotation speed is 100r/min and more.

<<For linear motor>>

When the command motor speed level is set to "0", the magnetic pole position error (3E) is detected at 1mm/s.

Set "10" as standard.

This detects the magnetic pole position error (3E) when the motor speed is 10mm/s and more.

---Setting range---  
0 to 31999

<<For general motor>>

Ten-thousands digit, Thousands digit ----- Command speed error detection level (10r/min)

Hundreds digit, Tens digit, Ones digit ----- Motor speed error detection level (10r/min)

<<For linear motor>>

Ten-thousands digit, Thousands digit ----- Command speed error detection speed level (10r/min)

Hundreds digit, Tens digit, Ones digit ----- Motor speed error detection level (10r/min)

# **【#2295】 SV095 ZUPD Vertical axis pull up distance**

Set this parameter to adjust the pull up distance when the vertical axis pull up function is enabled. When the pull up function is enabled and this parameter is set to "0", for a rotary motor, 8/1000 of a rotation at the motor end is internally set as the pull up distance, and for a linear motor, 80[ $\mu$ m] is set.

Related parameters:

SV032 : The pull up direction is determined. When "0" is set, pull up control is not executed.

SV033/bitE : Start-up of the pull up function

SV048 : Set the drop prevention time. When "0" is set, pull up control is not executed.

---Setting range---

0 to 2000 ( $\mu$ m)

# **【#2296】 SV096**

Not used. Set to "0".

# **【#2297】 SV097**

Not used. Set to "0".

# **【#2298】 SV098**

Not used. Set to "0".

# **【#2299】 SV099**

Not used. Set to "0".

# **【#2300】 SV100**

Not used. Set to "0".

# **【#2301】 SV101**

Not used. Set to "0".

# **【#2302】 SV102**

Not used. Set to "0".

# **【#2303】 SV103**

Not used. Set to "0".

# **【#2304】 SV104**

Not used. Set to "0".

# **【#2305】 SV105**

Not used. Set to "0".

# **【#2306】 SV106**

Not used. Set to "0".

# **【#2307】 SV107**

Not used. Set to "0".

# **【#2308】 SV108**

Not used. Set to "0".

# **【#2309】 SV109**

Not used. Set to "0".

**【#2310】 SV110**

Not used. Set to "0".

**【#2311】 SV111**


Not used. Set to "0".

**【#2312】 SV112**

Not used. Set to "0".

**【#2313】 SV113 SSF8 Servo function 8**

Select the servo functions.  
A function is assigned to each bit.  
Set this in hexadecimal format.



**bit F : ssc Safety observation function**

0: Stop 1: Start

**bit E-8 :**

Not used. Set to "0".

**bit 7 : nmerc Machine error compensation amount**

When disabled, the machine error compensation amount including backlash and pitch error to be compensated by an NC will be ignored by the servo control.  
Use this to adjust the lost motion compensation by the electric end roundness measurement.


0: Normal setting 1: Disable

**bit 6-0 :**

Not used. Set to "0".

**【#2314】 SV114 SSF9 Servo function 9**

Select the servo functions.  
A function is assigned to each bit.  
Set this in hexadecimal format.



**bit F-9 :**

Not used. Set to "0".

**bit 8 : nohis History of communication error alarm between NC and DRV (34, 36, 38, 39)**

Set "1" for C70.

0: Enable 1: Disable

**bit 7 : cse Command speed monitoring function**


0: Normal setting 1: Enable

**bit 6-0 :**

Not used. Set to "0".

# [#2315] SV115 SSF10 Servo function 10

Select the servo functions.  
A function is assigned to each bit.  
Set this in hexadecimal format.



## bit F : are Notch filter5 all frequencies adapted

When enabled, Notch filter5 all frequencies adaptive range is not limited regardless of SV115/bit4,5 setting.  
0: Disable 1: Enable

## bit E-C: dsl Notch filter frequency display

Switch the "AFLT frequency" display on drive monitor screen to check every notch filter frequency. When the selected notch filter is not used, "0" is displayed.

bitE,D,C=  
000 : Estimated resonance frequency (Normal display)  
001 : Notch filter 1 frequency  
010 : Notch filter 2 frequency  
011 : Notch filter 3 frequency (always displays 1125Hz)  
100 : Notch filter 4 frequency  
101 : Notch filter 5 frequency  
Other settings: setting prohibited

## bit B : ade5 Notch filter 5 / Adaptive follow-up function

0: Disable 1: Enable

## bit A : ade4 Notch filter 4 / Adaptive follow-up function

0: Disable 1: Enable

## bit 9 : ade2 Notch filter 2 / Adaptive follow-up function

0: Disable 1: Enable

## bit 8 : ade1 Notch filter 1 / Adaptive follow-up function

0: Disable 1: Enable

## bit 7-6 : dsn Estimated resonance frequency display holding time

Set the estimated resonance frequency display holding time to the "AFLT frequency" display on drive monitor screen.

bit7,6=  
00: 4 [s]  
01: 8 [s]  
10: 12 [s]  
11: 16 [s]

## bit 5-4 : dfhz Notch filter frequency range

Set the adaptive range of the notch filter frequency. When the adaptive follow-up function is enabled and if the estimated resonance frequency exists in the set range, the notch filter will be adapted. Normally set this parameter to "00".

bit5,4=  
00: -10 to 10 [%]  
01: -20 to 20 [%]  
10: -30 to 30 [%]  
11: -40 to 40 [%]



**bit 3-0 : esn Sensitivity of estimated resonance frequency**

Set the sensitivity of the estimated resonance frequency. Smaller setting value enables to detect smaller vibration component, however, adaptive movement will be repeated frequently. Normally set this parameter to "0".

0 : Normal setting (same sensitivity as A) 1 : Sensitivity high to F : Sensitivity low

**【#2316】 SV116 SSF11 Servo function 11**

Not used. Set to "0000".

**【#2317(PR)】 SV117 RNG1ex Expansion sub side detector resolution**

For high-accuracy binary resolution detector, set the number of pulses to four bite data of SV117 (high-order) and SV019 (low-order) by pulse(p).  
When SV117=0, the setting unit of SV019 is (kp).  
Refer to SV019 for details.

Related parameters: SV019, SV020, SV118

---Setting range---

-1 to 32767

**【#2318(PR)】 SV118 RNG2ex Expansion main side detector resolution**

When using high-accuracy binary resolution detector, set the number of pulses to four bite data of SV118 (high-order) and SV020 (low-order) by pulse(p).  
When SV118=0, the setting unit of SV020 is (kp).  
Refer to SV020 for details.

Related parameters: SV019, SV020, SV117

---Setting range---

-1 to 32767

**【#2319】 SV119**

Not used. Set to "0".

**【#2320】 SV120**

Not used. Set to "0".

**【#2321】 SV121**

Not used. Set to "0".

**【#2322】 SV122**

Not used. Set to "0".

**【#2323】 SV123**

Not used. Set to "0".

**【#2324】 SV124**

Not used. Set to "0".

**【#2325】 SV125**

Not used. Set to "0".

**【#2326】 SV126**

Not used. Set to "0".

**【#2327】 SV127**

Not used. Set to "0".

#### 【#2328】 SV128

Not used. Set to "0".

#### 【#2329】 SV129 Kwf Synchronous control feed forward filter frequency

Set the acceleration rate feed forward filter frequency in high-speed synchronous tapping control.  
The standard setting is "600".

Related parameters: SV244

---Setting range---  
0 to 32767 (rad/s)

#### 【#2330(PR)】 SV130 RPITS Base reference mark interval

Set the base reference mark intervals of distance-coded reference scale. When the distance-coded reference scale is not used, set to "0".  
The interval of basic reference mark (SV130) and auxiliary interval (SV131) must be in the specified relationship. Other settings cause the initial parameter error (alarm 37).  
Following is the specified relationship.

The quotient of  $(SV130 \times 1000) / SV131$  must be 4 or more and leaves no remainder.

Related parameters: SV081/bit7,3, SV131, SV134 to SV137

---Setting range---  
0 to 32767 (mm)

#### 【#2331(PR)】 SV131 DPITS Auxiliary reference mark interval

Set the auxiliary interval of reference mark in the distance-coded reference scale. When the distance-coded reference scale is not used, set to "0".  
The interval of basic reference mark (SV130) and auxiliary interval (SV131) must be in the specified relationship. Other settings cause the initial parameter error (alarm 37).  
Following is the specified relationship.

The quotient of  $(SV130 \times 1000) / SV131$  must be 4 or more and leaves no remainder.

Related parameters: SV081/bit7,3, SV130, SV134 to SV137

---Setting range---  
0 to 32767 ( $\mu m$ )

#### 【#2332】 SV132

Not used. Set to "0".

#### 【#2333】 SV133

Not used. Set to "0".

#### 【#2334】 SV134 RRn0 Distance-coded reference check / revolution counter

Set this parameter to operate distance-coded reference check when using distance-coded reference scale.

During the distance-coded reference check initial setup (SV137 : RAER=-1), set the following items on the NC drive monitor screen after the distance-coded reference check initial setup warning A3 turns OFF.

SV134=Rn, SV135=Pn, SV136=MPOS

When reference point is set, the warning A3 turns OFF.  
To enable the distance-coded reference check function, SV081/bit3=1 setting and a battery option are needed.

Related parameters: SV081/bit3,7, SV130, SV131, SV134 to SV137

---Setting range---  
-32768 to 32767

# Appendix 1 Explanation of Parameters

## [#2335] SV135 RPN0H Distance-coded reference check /position within one rotation High

Set this parameter to operate distance-coded reference check when using distance-coded reference scale.

During the distance-coded reference check initial setup (SV137 : RAER=-1), set the following items on the NC drive monitor screen after the distance-coded reference check initial setup warning A3 turns OFF.

SV134=Rn, SV135=Pn, SV136=MPOS

When reference point is set, the warning A3 turns OFF.

To enable the distance-coded reference check function, SV081/bit3=1 setting and a battery option are needed.

Related parameters: SV081/bit3,7, SV130, SV131, SV134 to SV137

### ---Setting range---

-32768 to 32767

## [#2336] SV136 RPN0L Distance-coded reference check / position within one rotation Low

Set this parameter to operate distance-coded reference check when using distance-coded reference scale.

During the distance-coded reference check initial setup (SV137 : RAER=-1), set the following items on the NC drive monitor screen after the distance-coded reference check initial setup warning A3 turns OFF.

SV134=Rn, SV135=Pn, SV136=MPOS

When reference point is set, the warning A3 turns OFF.

To enable the distance-coded reference check function, SV081/bit3=1 setting and a battery option are needed.

Related parameters: SV081/bit3,7, SV130, SV131, SV134 to SV137

### ---Setting range---

-32768 to 32767

## [#2337] SV137 RAER Distance-coded reference check allowable width

For the distance-coded reference check function when using distance-coded reference scale, set the allowable gap from the reference point position data calculated by the main side detector. When the gap exceeds the allowable range, reference point created by distance-code is judged as wrong and detects alarm 42.

The standard setting value is "basic reference mark interval (SV130) / 4".

SV137=0 setting carries out the same operation as the standard setting value.

SV137=-1 setting enables the distance-coded reference initial set up mode and displays setting values of SV134 to SV136 on NC drive monitor.

To enable the distance-coded reference check function, SV081/bit3=1 setting and a battery option are needed.

When SV137=32767, the distance-coded reference check function is disabled.

Related parameters: SV081/bit3,7, SV130, SV131, SV134 to SV136

### ---Setting range---

-1 to 32767 (mm)

## [#2338-2397] SV138 - SV197

Not used. Set to "0".

## [#2398] SV198 NSE No signal 2 special detection width

Set the special detection width for the no signal 2 (alarm 21).

This detects no signal 2 (alarm 21) when machine side feedback is not invoked even if the motor side detector feedback exceeds this setting in the rectangular wave signal output linear scale.

When "0" is set, the detection will be performed with a 15  $\mu$  m width.

For MDS-D-SVJ3, this parameter setting is invalid and the detection width is fixed to 15  $\mu$  m.

### ---Setting range---

0 to 32767 ( $\mu$  m)

**【#2399-2437】 SV199 - SV237**

Not used. Set to "0".

**【#2438】 SV238 SSCFEED Safety observation Safety speed**

Set the machine's safety speed for the safety observation function.

Set this parameter within the following setting ranges.

For linear axis: 2000mm/min or less

For rotary axis: 18000°/min (50r/min) or less

When not using, set to "0".

Related parameters: SV033/bitD, SV113/bitF, SV239

**---Setting range---**

0 to 18000 (mm/min) or (°/min)

However, when SV033/bitD=1, the setting range is from -32768 to 32767 (100 mm/min) or (100°/min).

**【#2439】 SV239 SSCRPM Safety observation Safety motor speed**

Set the motor's safety speed for the safety observation function.

Set a value to hold the following relationship.

$$SV239 = (SV238/SV018) \times (SV002/SV001)$$

Only when the product is 0, set to "1".

When not using, set to "0".

Related parameters: SV033/bitD, SV113/bitF, SV239

**---Setting range---**

0 to 32767 (r/min)

**【#2440-2443】 SV240 - SV243**

Not used. Set to "0".

**【#2444(PR)】 SV244 DUNIT Communication interpolation unit for communication among drive units**

Set the communication interpolation unit among drive units.

When set to "0", it will be regarded as 20 (0.05  $\mu$  m) is set.

Related parameters: SV129

**---Setting range---**

0 to 2000 (1/ $\mu$  m)

**【#2445-2456】 SV245 - SV256**

Not used. Set to "0".

## Appendix 1.5 Spindle Parameters

The parameters with "(PR)" requires the CNC to be turned OFF after the settings. Turn the power OFF and ON to enable the parameter settings.

### 【#3001】 slimt 1 Limit rotation speed (Gear: 00)

Set the spindle speed for maximum motor speed with gear 00.  
(Set the spindle speed for the S analog output 10V.)

---Setting range---

0 to 99999 (r/min)

### 【#3002】 slimt 2 Limit rotation speed (Gear: 01)

Set the spindle speed for maximum motor speed with gear 01.  
(Set the spindle speed for the S analog output 10V.)

---Setting range---

0 to 99999 (r/min)

### 【#3003】 slimt 3 Limit rotation speed (Gear: 10)

Set the spindle speed for maximum motor speed with gear 10.  
(Set the spindle speed for the S analog output 10V.)

---Setting range---

0 to 99999 (r/min)

### 【#3004】 slimt 4 Limit rotation speed (Gear: 11)

Set the spindle speed for maximum motor speed with gear 11.  
(Set the spindle speed for the S analog output 10V.)

---Setting range---

0 to 99999 (r/min)

### 【#3005】 smax 1 Maximum rotation speed (Gear: 00)

Set the maximum spindle speed with gear 00.  
Set this as slimt  $\geq$  smax.  
By comparing the S command value and the values of gear 1 - 4, a spindle gear shift command will be output automatically.

---Setting range---

0 to 99999 (r/min)

### 【#3006】 smax 2 Maximum rotation speed (Gear: 01)

Set the maximum spindle speed with gear 01.  
Set this as slimt  $\geq$  smax.  
By comparing the S command value and the values of gear 1 - 4, a spindle gear shift command will be output automatically.

---Setting range---

0 to 99999 (r/min)

### 【#3007】 smax 3 Maximum rotation speed (Gear: 10)

Set the maximum spindle speed with gear 10.  
Set this as slimt  $\geq$  smax.  
By comparing the S command value and the values of gear 1 - 4, a spindle gear shift command will be output automatically.

---Setting range---

0 to 99999 (r/min)

#### **【#3008】 smax 4 Maximum rotation speed (Gear: 11)**

Set the maximum spindle speed with gear 11.  
Set this as slimt  $\geq$  smax.  
By comparing the S command value and the values of gear 1 - 4, a spindle gear shift command will be output automatically.

---Setting range---  
0 to 99999 (r/min)

#### **【#3009】 ssift 1 Shift rotation speed (Gear: 00)**

Set the spindle speed for gear shifting with gear 00.  
(Note) Setting too large value may cause a gear nick when changing gears.

---Setting range---  
0 to 32767 (r/min)

#### **【#3010】 ssift 2 Shift rotation speed (Gear: 01)**

Set the spindle speed for gear shifting with gear 01.  
(Note) Setting too large value may cause a gear nick when changing gears.

---Setting range---  
0 to 32767 (r/min)

#### **【#3011】 ssift 3 Shift rotation speed (Gear: 10)**

Set the spindle speed for gear shifting with gear 10.  
(Note) Setting too large value may cause a gear nick when changing gears.

---Setting range---  
0 to 32767 (r/min)

#### **【#3012】 ssift 4 Shift rotation speed (Gear: 11)**

Set the spindle speed for gear shifting with gear 11.  
(Note) Setting too large value may cause a gear nick when changing gears.

---Setting range---  
0 to 32767 (r/min)

#### **【#3013】 stap 1 Tap rotation speed (Gear: 00)**

Set the maximum spindle speed during tapping cycle with gear 00.

---Setting range---  
0 to 99999 (r/min)

#### **【#3014】 stap 2 Tap rotation speed (Gear: 01)**

Set the maximum spindle speed during tapping cycle with gear 01.

---Setting range---  
0 to 99999 (r/min)

#### **【#3015】 stap 3 Tap rotation speed (Gear: 10)**

Set the maximum spindle speed during tapping cycle with gear 10.

---Setting range---  
0 to 99999 (r/min)

#### **【#3016】 stap 4 Tap rotation speed (Gear: 11)**

Set the maximum spindle speed during tapping cycle with gear 11.

---Setting range---  
0 to 99999 (r/min)

## Appendix 1 Explanation of Parameters

### 【#3017】 stapt 1 Tap time constant (Gear: 00)

Set the time constant for constant inclination synchronous tapping cycle with gear 00 (linear acceleration/deceleration pattern).

---Setting range---  
1 to 5000 (ms)

### 【#3018】 stapt 2 Tap time constant (Gear: 01)

Set the time constant for constant inclination synchronous tapping cycle with gear 01 (linear acceleration/deceleration pattern).

---Setting range---  
1 to 5000 (ms)

### 【#3019】 stapt 3 Tap time constant (Gear: 10)

Set the time constant for constant inclination synchronous tapping cycle with gear 10 (linear acceleration/deceleration pattern).

---Setting range---  
1 to 5000 (ms)

### 【#3020】 stapt 4 Tap time constant (Gear: 11)

Set the time constant for constant inclination synchronous tapping cycle with gear 11 (linear acceleration/deceleration pattern).

---Setting range---  
1 to 5000 (ms)

### 【#3021】 sori Orientation rotation speed

Set the spindle orientation speed.  
Set the speed for when the spindle rotates at the constant speed.

---Setting range---  
0 to 32767 (r/min)

### 【#3022】 sgear Encoder gear ratio

Set the gear ratio of the spindle to the detector.

Setting value 0 ---> Detector : Spindle = 1:1

Setting value 1 ---> Detector : Spindle = 1:2

Setting value 2 ---> Detector : Spindle = 1:4

Setting value 3 ---> Detector : Spindle = 1:8

This parameter is enabled only when "S-analog" is set by the spindle connection parameter "#3024 sout".

---Setting range---  
0 to 3

### 【#3023】 smini Minimum rotation speed

Set the minimum spindle speed.

If an S command below this setting is issued, the spindle will rotate at the minimum speed set by this parameter.

---Setting range---  
0 to 32767 (r/min)

### 【#3024(PR)】 sout Spindle connection

Select the type of interface with a spindle drive unit.

0: No connection with a spindle

1: Dedicated network, dedicated optical communication

2 - 5: S-analog

---Setting range---  
0 to 5

### 【#3025(PR)】 enc-on Spindle encoder

Set the connection condition of a spindle's detector.

Setting 0 ---> Not connected

Setting 1 ---> Connected (Spindle detector connection check function is enabled.)

Setting 2 ---> Serially connected

---Setting range---

0 to 2

### 【#3026】 cs\_ori Selection of winding in orientation mode

0: Perform orientation using the coil selected when the orientation command is issued.

1: Use the coil L whenever the orientation command is issued.

### 【#3027】 cs\_syn Selection of winding in spindle synchronous mode

0: Select the coil H or L based on the actual spindle motor speed (calculated from commanded speed) when spindle synchronization starts. (Coil switch is not performed during spindle synchronous tapping control. This control is carried out using the coil selected at start.)

If the actual spindle motor speed is less than the setting of SP020, the coil L is selected. But if the actual speed exceeds the setting of SP020, the coil H is selected.

1: Use the coil H whenever the spindle synchronization command is issued.

### 【#3028】 sprcmm Tap cycle spindle forward run/reverse run M command

Set the M codes for the spindle forward run/reverse run commands.

High-order 3 digits: Set the M code for spindle forward run command.

Low-order 3 digits: Set the M code for spindle reverse run command.

When "0" is set, the M code for spindle forward run command is handled as "3" and the M code for spindle reverse run command as "4".

---Setting range---

0 to 999999

### 【#3029】 tapsel Asynchronous tap gear selection

Select whether to use the tapping speed or maximum speed for the gear that is selected when an asynchronous tapping command is issued.

0: Tapping speed

1: Maximum speed

This parameter is enabled only when the M-function synchronous tapping cycle enable parameter "#1272 ext08/bit1" is ON.

### 【#3030】


Not used. Set to "0".



# Appendix 1 Explanation of Parameters

## 【#3031(PR)】 smcp\_no Drive unit I/F channel No. (spindle)

Set the interface channel No. of CNC control unit to which the spindle is connected and the axis No. within each channel.  
Set this parameter in 4-digit (hexadecimal) format.



HEX-4 : Drive unit interface channel No.

HEX-3 : Not used. Set to "0".

HEX-2, 1 : Axis No.

For a spindle to be connected to CNC via analog interface, set to "0000".

### ---Setting range---

1001 to 1010, 2001 to 2010

- For MDS-DM-SPV2/SPV3 Series

These drive units have no rotary switches for axis No. selection.

The spindle axis No. is fixed to 1st axis, so set "01" as the number of axes. (last 2 digits).

## 【#3032】

Not used. Set to "0".

## 【#3035(PR)】 spunit Output unit

Select the data unit for communication with the spindle drive unit.

This selection is applied to the data communicated between the NC and spindle drive unit as well as the spindle movement data. Note, however, that this parameter is enabled only for the MDS-D Series spindle drive unit.

Spindle/C axis depends on this parameter setting and the C axis output unit (servo) is ignored.

When MDS-D Series is used, follow the setting of "#1003 ctrl\_unit".

B: 1  $\mu$  m

C: 0.1  $\mu$  m

D: 10nm

E: 1nm

## 【#3037】 taps21 Synchronous tap switching spindle speed 2 (Gear: 00)

Set the spindle speed at which the 2nd step acceleration/deceleration time constant is to be switched with gear 00.

### ---Setting range---

0 to 99999 (r/min)

## 【#3038】 taps22 Synchronous tap switching spindle speed 2 (Gear: 01)

Set the spindle speed at which the 2nd step acceleration/deceleration time constant is to be switched with gear 01.

### ---Setting range---

0 to 99999 (r/min)

**【#3039】 taps23 Synchronous tap switching spindle speed 2 (Gear: 10)**

Set the spindle speed at which the 2nd step acceleration/deceleration time constant is to be switched with gear 10.

---Setting range---  
0 to 99999 (r/min)

**【#3040】 taps24 Synchronous tap switching spindle speed 2 (Gear: 11)**

Set the spindle speed at which the 2nd step acceleration/deceleration time constant is to be switched with gear 11.

---Setting range---  
0 to 99999 (r/min)

**【#3041】 tapt21 Synchronous tap switching time constant 2 (Gear: 00)**

Set the time constant to reach synchronous tapping switching spindle speed 2 (taps21 - 24) with gear 00.

---Setting range---  
1 to 5000 (ms)

**【#3042】 tapt22 Synchronous tap switching time constant 2 (Gear: 01)**

Set the time constant to reach synchronous tapping switching spindle rotation speed 2 (taps21 - 24) with gear 01.

---Setting range---  
1 to 5000 (ms)

**【#3043】 tapt23 Synchronous tap switching time constant 2 (Gear: 10)**

Set the time constant to reach synchronous tapping switching spindle rotation speed 2 (taps21 - 24) with gear 10.

---Setting range---  
1 to 5000 (ms)

**【#3044】 tapt24 Synchronous tap switching time constant 2 (Gear: 11)**

Set the time constant to reach synchronous tapping switching spindle rotation speed 2 (taps21 - 24) with gear 11.

---Setting range---  
1 to 5000 (ms)

**【#3045】 tapt31 Synchronous tap switching time constant 3 (Gear: 00)**

Set the time constant to reach the maximum speed (smax1 - 4) with gear 00.

---Setting range---  
1 to 5000 (ms)

**【#3046】 tapt32 Synchronous tap switching time constant 3 (Gear: 01)**

Set the time constant to reach the maximum speed (smax1 - 4) with gear 01.

---Setting range---  
1 to 5000 (ms)

**【#3047】 tapt33 Synchronous tap switching time constant 3 (Gear: 10)**

Set the time constant to reach the maximum speed (smax1 - 4) with gear 10.

---Setting range---  
1 to 5000 (ms)

**【#3048】 tapt34 Synchronous tap switching time constant 3 (Gear: 11)**

Set the time constant to reach the maximum speed (smax1 - 4) with gear 11.

---Setting range---  
 1 to 5000 (ms)

**【#3049】 spt Spindle synchronization acceleration/deceleration time constant**

Set the acceleration/deceleration time constant for when the commanded spindle synchronization speed changes under spindle synchronization control.

---Setting range---  
 0 to 9999 (ms)

**【#3050】 sprlv Spindle synchronization rotation speed attainment level**

Set the level of difference between the commanded synchronization spindle speeds and actual speeds of both the basic and synchronous spindles during spindle synchronization, below which the spindle speed synchronization complete signal will go ON.

---Setting range---  
 0 to 4095 (pulse) (1 pulse = 0.088°)

**【#3051】 spplv Spindle phase synchronization attainment level**

Set the level of phase difference between the basic and synchronous spindles during spindle synchronization, below which the spindle phase synchronization complete signal will go ON.

---Setting range---  
 0 to 4095 (pulse) (1 pulse = 0.088°)

**【#3052】 spplr Spindle motor spindle relative polarity**

Set the spindle motor and spindle's relative polarity.

- 0: Positive polarity  
     Spindle CW rotation at motor CW rotation
- 1: Negative polarity  
     Spindle CCW rotation at motor CW rotation

---Setting range---  
 0000/0001 (HEX)

**【#3053】 sppst Spindle encoder Z -phase position**

Set the deviation amount from the spindle's basic point to the spindle detector's Z phase. Obtain the deviation amount, considering a clockwise direction as positive when viewed from the spindle's front side.

---Setting range---  
 0 to 359999 (1/1000°)

**【#3054】 sptc1 speed 1 Spindle synchronization multi-step acceleration/deceleration changeover speed 1**

Set the spindle speed for changing the 1st step's acceleration/deceleration time constant.

---Setting range---  
 0 to 99999 (r/min)

**【#3055】 sptc2 speed 2 Spindle synchronization multi-step acceleration/deceleration changeover speed 2**

Set the spindle speed for changing the 2nd step's acceleration/deceleration time constant.

---Setting range---  
 0 to 99999 (r/min)

**【#3056】 sptc3 Spindle synchronization multi-step acceleration/deceleration changeover speed 3**

Set the spindle speed for changing the 3rd step's acceleration/deceleration time constant.

---Setting range---  
0 to 99999 (r/min)

**【#3057】 sptc4 Spindle synchronization multi-step acceleration/deceleration changeover speed 4**

Set the spindle speed for changing the 4th step's acceleration/deceleration time constant.

---Setting range---  
0 to 99999 (r/min)

**【#3058】 sptc5 Spindle synchronization multi-step acceleration/deceleration changeover speed 5**

Set the spindle speed for changing the 5th step's acceleration/deceleration time constant.

---Setting range---  
0 to 99999 (r/min)

**【#3059】 sptc6 Spindle synchronization multi-step acceleration/deceleration changeover speed 6**

Set the spindle speed for changing the 6th step's acceleration/deceleration time constant.

---Setting range---  
0 to 99999 (r/min)

**【#3060】 sptc7 Spindle synchronization multi-step acceleration/deceleration changeover speed 7**

Set the spindle speed for changing the 7th step's acceleration/deceleration time constant.

---Setting range---  
0 to 99999 (r/min)

**【#3061】 spdiv1 Magnification for time constant changeover speed 1**

Set the acceleration/deceleration time constant from the spindle synchronization multi-step acceleration/deceleration changeover speed 1 (sptc1) to the spindle synchronization multi-step acceleration/deceleration changeover speed 2 (sptc2). Set this as a magnification in relation to the spindle synchronization acceleration/deceleration time constant (spt).

---Setting range---  
0 to 127

**【#3062】 spdiv2 Magnification for time constant changeover speed 2**

Set the acceleration/deceleration time constant from the spindle synchronization multi-step acceleration/deceleration changeover speed 2 (sptc2) to the spindle synchronization multi-step acceleration/deceleration changeover speed 3 (sptc3). Set this as a magnification in relation to the spindle synchronization acceleration/deceleration time constant (spt).

---Setting range---  
0 to 127

**【#3063】 spdiv3 Magnification for time constant changeover speed 3**

Set the acceleration/deceleration time constant from the spindle synchronization multi-step acceleration/deceleration changeover speed 3 (sptc3) to the spindle synchronization multi-step acceleration/deceleration changeover speed 4 (sptc4). Set this as a magnification in relation to the spindle synchronization acceleration/deceleration time constant (spt).

---Setting range---  
0 to 127

**【#3064】 spdiv4 Magnification for time constant changeover speed 4**

Set the acceleration/deceleration time constant from the spindle synchronization multi-step acceleration/deceleration changeover speed 4 (sptc4) to the spindle synchronization multi-step acceleration/deceleration changeover speed 5 (sptc5). Set this as a magnification in relation to the spindle synchronization acceleration/deceleration time constant (spt).

**---Setting range---**

0 to 127

**【#3065】 spdiv5 Magnification for time constant changeover speed 5**

Set the acceleration/deceleration time constant from the spindle synchronization multi-step acceleration/deceleration changeover speed 5 (sptc5) to the spindle synchronization multi-step acceleration/deceleration changeover speed 6 (sptc6). Set this as a magnification in relation to the spindle synchronization acceleration/deceleration time constant (spt).

**---Setting range---**

0 to 127

**【#3066】 spdiv6 Magnification for time constant changeover speed 6**

Set the acceleration/deceleration time constant from the spindle synchronization multi-step acceleration/deceleration changeover speed 6 (sptc6) to the spindle synchronization multi-step acceleration/deceleration changeover speed 7 (sptc7). Set this as a magnification in relation to the spindle synchronization acceleration/deceleration time constant (spt).

**---Setting range---**

0 to 127

**【#3067】 spdiv7 Magnification for time constant changeover speed 7**

Set the acceleration/deceleration time constant for the spindle synchronization multi-step acceleration/deceleration changeover speed 7 (sptc7) and higher. Set this as a magnification in relation to the spindle synchronization acceleration/deceleration time constant (spt).

**---Setting range---**

0 to 127

**【#3068】 symtm1 Phase synchronization start confirmation time**

Set the time to confirm that synchronization is attained before phase synchronization control is started.

When "0" is set, the time will be 0.5 seconds. When "100" or less is set, the time will be 100ms.

**---Setting range---**

0 to 9999 (ms)

**【#3069】 symtm2 Phase synchronization end confirmation time**

Set a period of waiting time for phase synchronization control's completion as a time in which the speed stays within the attainment range.

When "0" is set, the time will be 0.5 seconds. When "100" or less is set, the time will be 100ms.

**---Setting range---**

0 to 9999 (ms)

**【#3070】 syprt Phase synchronization speed**

Set the amount of speed fluctuation of synchronous spindle during phase synchronization control.

Set this as a proportion to commanded speed.

When "0" is set, the amount will be 5%.

**---Setting range---**

0 to 100 (%)

### **【#3071(PR)】 SscDrSelSp Speed monitor Door selection**

Select which door group of the speed monitoring a spindle belongs to.

0000: Belong to the door 1 group.

0001: Belong to the door 1 group.

0002: Belong to the door 2 group.

0003: Belong to the door 1 and 2 groups.

(Note) Speed monitoring is not executed when SP229:SFNC9/bitF is "OFF".

#### **---Setting range---**

0000 to 0003 (HEX)

### **【#3072(PR)】 Ssc Svof Filter Sp Speed monitor Error detection time during servo OFF**

Set the error detection time for when an error of command speed monitoring or feedback speed monitoring is detected during servo OFF.

The alarm will occur if actual speed exceeds safe speed or safe rotation speed for a period of time longer than this setting.

When "0" is set, the detection time will be 200 (ms).

#### **---Setting range---**

0 to 9999 (ms)

### **【#3101】 sp\_t 1 Time constant for spindle rotation with S command (Gear: 00)**

Set the acceleration/deceleration time constant for spindle rotation using the S command (spindle control mode = speed operation mode) with gear 00 (Linear acceleration/deceleration pattern).

#### **---Setting range---**

0 to 30000 (ms)

### **【#3102】 sp\_t 2 Time constant for spindle rotation with S command (Gear: 01)**

Set the acceleration/deceleration time constant for spindle rotation using the S command (spindle control mode = speed operation mode) with gear 01 (Linear acceleration/deceleration pattern).

#### **---Setting range---**

0 to 30000 (ms)

### **【#3103】 sp\_t 3 Time constant for spindle rotation with S command (Gear: 10)**

Set the acceleration/deceleration time constant for spindle rotation using the S command (spindle control mode = speed operation mode) with gear 10 (Linear acceleration/deceleration pattern).

#### **---Setting range---**

0 to 30000 (ms)

### **【#3104】 sp\_t 4 Time constant for spindle rotation with S command (Gear: 11)**

Set the acceleration/deceleration time constant for spindle rotation using the S command (spindle control mode = speed operation mode) with gear11 (Linear acceleration/deceleration pattern).

#### **---Setting range---**

0 to 30000 (ms)

### **【#3105】 sut Speed reach range**

Set the speed deviation rate with respect to the commanded speed, at which the speed reach signal will be output.

It will be 15% when set to "0".


If the speed deviation is smaller than 45r/min, it will be set as 45r/min.

#### **---Setting range---**

0 to 100 (%)

**【#3106】 zrn\_typ Zero point return specifications**

Select the zero point return specification.  
Functions are allocated to each bit.  
Set this in hexadecimal format.

**bit F : Spindle zero point detection with contactless switch**

0: Normal    1: Enable spindle zero point detection using proximity switch

**bit E : Interpolation mode selection in orientation**

0: Interpolation mode (Use the interpolation mode gain "SP002 PGN".)  
1: Non-interpolation mode (Use the non-interpolation mode gain "SP001 PGV")  
Select this when vibration occurs since the gain is too high during the orientation.

**bit D-B :**

Not used. Set to "0".

**bit A-9 : Spindle/C axis zero point return direction**

bitA,9=  
00: Short-cut  
01: Forward run  
10: Reverse run

**bit 8 : Designate zero point return/deceleration stop of spindle/C axis**

0: Zero point return    1: Deceleration stop

**bit 7 : Synchronous tapping command polarity**

0: Forward direction    1: Reverse direction

**bit 6-5 : Synchronous tapping zero point return direction**

bit 6,5=  
00: Short-cut  
01: Forward run  
10: Reverse run

**bit 4 : Designate zero point return/deceleration stop in synchronous tapping**

0: Zero point return    1: Deceleration stop

**bit 3 :**

Not used. Set to "0".

**bit 2-1 : Orientation direction**

bit 2,1=  
00: Short-cut  
01: Forward run  
10: Reverse run

**bit 0 : Z phase detection direction**

0: Forward direction    1: Reverse direction

**【#3107】 ori\_spd Orientation command speed**

Set the spindle speed during orientation command.

---Setting range---

1 to 99999 (r/min)

### **【#3108】 ori\_sft In-position shift amount for orientation**

Set the orientation stop position.  
The clockwise direction when viewed from the load side is considered as minus (-).

---Setting range---  
-35999 to 35999 (0.01°)

### **【#3109】 zdetspd Z phase detection speed**

When "#3106/bitF = 0" (Normal), set the spindle speed at initial Z phase detection.  
Guideline for the initial setting value is from 50 to 300.

When "#3106/bitF = 1" (Spindle zero point proximity switch detection enabled), set the spindle speed at initial spindle zero point proximity switch detection.

(Note) When spindle zero point proximity switch detection is enabled, the rotation direction of the orientation/zero point return (synchronous tapping, spindle/C axis) will follow Z phase detection direction. And the speed will follow Z phase detection speed. Guideline for the initial setting value is from 50 to 300.

---Setting range---  
1 to 99999 (r/min)

### **【#3110】 tap\_spd Synchronous tapping zero point return speed**

Set the synchronous tapping zero point return speed.

---Setting range---  
1 to 99999 (r/min)

### **【#3111】 tap\_sft Synchronous tapping zero point return shift amount**

Set the synchronous tapping zero point return shift amount.

---Setting range---  
0.00 to 35999 (0.01°)

### **【#3112】 cax\_spd Spindle C axis zero point return speed**

Set the spindle C axis zero point return speed.

---Setting range---  
1 to 99999 (r/min)

### **【#3113】 cax\_sft Spindle C axis zero point return shift amount**

Set the spindle C axis zero point return shift amount

---Setting range---  
0.00 to 359999 (0.001°)

### **【#3114】 cax\_para\_chg Spindle/C axis parameter switch**

Select whether to switch detector's parameters between spindle control and C axis control during spindle/C axis control.

0: Not switch  
1: Switch

---Setting range---  
0/1 (Standard: 0)



## Appendix 1 Explanation of Parameters

### 【#3115】 sp2\_t1 Time constant in orientation/position loop reference position return (Gear: 00)

Set the acceleration/deceleration time constant to reach the spindle's limit speed (slimt) when spindle rotates in orientation/position loop zero point return method (C axis, tapping) using gear 00 (Linear acceleration/deceleration pattern).

(Note) Set a value that is bigger than the values set by "#3101 sp\_t1 - #3104 sp\_t4".

---Setting range---

0 to 30000 (ms)

### 【#3116】 sp2\_t2 Time constant in orientation/position loop reference position return (Gear: 01)

Set the acceleration/deceleration time constant to reach the spindle's limit speed (slimt), when spindle rotates in the orientation/position loop zero point return method (C axis, tapping) using gear 01 (Linear acceleration/deceleration pattern).

(Note) Set a value that is bigger than the values set by "#3101 sp\_t1 - #3104 sp\_t4".

---Setting range---

0 to 30000 (ms)

### 【#3117】 sp2\_t3 Time constant in orientation/position loop reference position return (Gear: 10)

Set the acceleration/deceleration time constant to reach the spindle's limit speed (slimt), when spindle rotates in the orientation/position loop zero point return method (C axis, tapping) using gear 10 (Linear acceleration/deceleration pattern).

(Note) Set a value that is bigger than the values set by "#3101 sp\_t1 - #3104 sp\_t4".

---Setting range---

0 to 30000 (ms)

### 【#3118】 sp2\_t4 Time constant in orientation/position loop reference position return (Gear: 11)

Set the acceleration/deceleration time constant to reach the spindle's limit speed (slimt), when spindle rotates in the orientation/position loop zero point return method (C axis, tapping) using gear 11 (Linear acceleration/deceleration pattern).

(Note) Set a value that is bigger than the values set by "#3101 sp\_t1 - #3104 sp\_t4".

---Setting range---

0 to 30000 (ms)

### 【#3120】 staptr Time constant reduction rate in high-speed synchronous tapping

When performing high-speed synchronous tapping, set the reduction rate of the time constant compared to the time constant in normal synchronous tapping.

(Setting "0" or "100" will be regarded as reduction rate zero, so the time constant won't be reduced.)

E.g.) When set to "10", time constant in high-speed synchronous tapping will be 90% of that in normal synchronous tapping.

---Setting range---

0 to 100(%)

### 【#3121】 tret Turret indexing

Select the validity of turret indexing.

0: Invalid

1: Valid

### 【#3122】 GRC Turret side gear ratio

Set the number of teeth on the turret side when the gear selection command (control input 4/bit6, 5) is set to 00. Set a value of GRC so that the ratio of GRC to the spindle side gear ratio (#13057 SP057) will be 1:N (an integer).  
If this parameter is set to "0", it will be regarded as "1".

---Setting range---  
0 to 32767

### 【#3123】 tret\_spd Turret indexing speed

Set the turret end indexing speed when in turret indexing.  
When this parameter is set to 0, the value of Orientation command speed (#3107 ori\_spd) will be used for the turret indexing speed.

---Setting range---  
0 to 32767(r/min)

### 【#3124】 tret\_t Turret indexing time constant

Set the acceleration/deceleration time constant to reach Limit rotation speed (#3001 slimt) at gear 00 when in turret indexing (linear acceleration/deceleration pattern). Set this parameter to a larger value than #3115 sp2\_t1 at gear 00.

---Setting range---  
0 to 30000 (ms)

### 【#3125】 tret\_inpos Turret indexing in-position width

Set the position error range in which the index positioning complete signal is output when in turret indexing. When this parameter is set to 0, the value of In-position width (#13024 SP024) will be used for this width.

---Setting range---  
0 to 32767(1°/1000)

### 【#3126】 tret\_fin\_off Index positioning complete signal OFF time

Set the time to forcibly turn OFF the index positioning complete signal since the indexing start signal turns ON. If this period of time has not passed yet, the index positioning complete signal will not turn ON even at the completion of index positioning.

---Setting range---  
0 to 10000 (ms)

### 【#3127】 SPECSP Spindle specification

#### bit0: Select the gear changeover method.

0: Gear change type 1  
1: Gear change type 2

---Setting range---  
0x0000 to 0xffff (hexadecimal)

### 【#3128】 ori\_spec Orientation specification

#### bit0: Orientation imposition advance output

0: Invalid  
1: Valid

---Setting range---  
0x0000 to 0xffff (hexadecimal)

### 【#3129】 cax\_spec Spindle/C axis specification

Not used. Set to "0".

**【#3130】 syn\_spec Spindle synchronization specification**

**bit0: Tool spindle synchronization II (hobbing) automatic compensation selection**

1: Compensate hobbing axis delay (advance) with workpiece axis.  
0: No compensation.

**【#3131】 tap\_spec Synchronous tapping specification**

Not used. Set to "0".

**【#3132】 ori\_inp2 2nd in-position width for orientation**

Use this when detecting a different in-position from the normal in-position detection, such as advancing the in-position signal. When using, set a bigger value than the value of the spindle parameter SP024.

**---Setting range---**

0 to 32767 (1deg/1000)

**【#3133】 spherr Hobbing axis delay (advance) allowable angle**

Set the allowable angle between the commanded position and actual position of hobbing axis when it is in tool spindle synchronization II (hobbing) mode (X18AE ON), and also when hobbing axis and workpiece axis are synchronizing (X18A9 ON).

**---Setting range---**

0 to 32767 (1deg/1000)

**【#3134】 sphtc Primary delay time constant for hobbing axis automatic compensation**

Set the primary delay time constant of hobbing axis automatic compensation primary delay filter control in tool spindle synchronization II (hobbing).  
When set to 0, primary delay filter control is invalid.

**---Setting range---**

0 to 32767 (ms)

**【#3135】 sfwd\_g Feed forward gain for hobbing axis**

Set the feed forward gain for the hobbing axis in tool spindle synchronization II (hobbing) mode.

**---Setting range---**

0 to 200 (%)

**【#3137】 stap\_ax\_off High-speed synchronous tapping disabled axis**

Set the high-speed synchronous tapping disabled axis.

**bit 0-F : High-speed synchronous tapping disabled axis**

0: Enabled  
1: Disabled

If communication between drive units is disabled for a certain axis, set the axis's bits of all the spindles as disabled.

If communication between drive units is disabled for a certain spindle, set all the bits of the spindle as disabled (0xFFFF).

(Note) Each bit (bit0 -) corresponds to the order of the axis name parameter (#1013 axname) setting.

**【#3138】 motor\_type Spindle motor type**

Set the spindle motor type. The set type will be displayed on the drive monitor screen, and it will be also output to the system configuration data.

**---Setting range---**

Character string within 26 characters including A-Z, a-z, 0-9, "." (decimal point), "-" (hyphen), "/" (slash)  
(Cleared by inputting "0".)

### 【#3140(PR)】 S\_DINSp Speed observation input door No.

Set the door signal input in the drive unit.  
Use this parameter only when the axis with a door signal belongs to several door groups.  
The correspondence between the door signals and bits are as follows.  
bit0 : Door1 signal  
bit1 : Door2 signal  
If the axis does not receive any door signal, set to "0".  
An error (Y20 0027) will occur in the following cases.  
- Several bits are enabled.  
- Any bit other than those set in "#3071 S\_DSISp" is enabled.

---Setting range---  
0000 to 0002 (HEX)

### 【#13001】 SP001 PGV Position loop gain non-interpolation mode

Set the position loop gain for "Non-interpolation" control mode.  
When the setting value increases, the command tracking ability will enhance and the positioning settling time can be shorter. However, the impact on the machine during acceleration/deceleration will increase.  
Use the selection command, the control mode "bit 2, 1, 0 = 000" in control input 4.  
(Note) The control mode is commanded by NC.

---Setting range---  
1 to 200 (1/s)

### 【#13002】 SP002 PGN Position loop gain interpolation mode

Set the position loop gain for "interpolation" control mode.  
When the setting value increases, the command tracking ability will enhance and the positioning settling time can be shorter. However, the impact on the machine during acceleration/deceleration will increase.  
Use the selection command, the control mode "bit 2, 1, 0 = 010 or 100" in control input 4.  
(Note) The control mode is commanded by NC.  
When carrying out the SHG control, set SP035(SFNC3) bitC to "1".

---Setting range---  
1 to 200 (1/s)

### 【#13003】 SP003 PGS Position loop gain spindle synchronization

Set the position loop gain for "spindle synchronization" control mode.  
When the setting value increases, the command tracking ability will enhance and the positioning settling time can be shorter. However, the impact on the machine during acceleration/deceleration will increase.  
Use the selection command, the control mode "bit 2, 1, 0 = 001" in control input 4.  
(Note) The control mode is commanded by NC.  
When carrying out the SHG control, set SP036(SFNC4) bit4 to "1".

---Setting range---  
1 to 200 (1/s)

### 【#13004】 SP004

Not used. Set to "0".

### 【#13005】 SP005 VGN1 Speed loop gain 1

Set the speed loop gain.  
Set this according to the load inertia size.  
The higher setting value will increase the accuracy of control, however, vibration tends to occur.  
If vibration occurs, adjust by lowering by 20 to 30%.  
The final value should be 70 to 80% of the value at which the vibration stops.

---Setting range---  
1 to 9999

## Appendix 1 Explanation of Parameters

### 【#13006】 SP006 VIA1 Speed loop lead compensation 1

Set the speed loop integral control gain.  
The standard setting is "1900". Adjust the value by increasing/decreasing the value by about 100.  
Raise this value to improve the contour tracking accuracy in high-speed cutting.  
Lower this value when the position droop does not stabilize (when the vibration of 10 to 20Hz occurs).

---Setting range---  
1 to 9999

### 【#13007】 SP007 VIL1 Speed loop delay compensation 1

Set this parameter when the limit cycle occurs in the full-closed loop or overshooting occurs in positioning.  
For MDS-D/DH-SP, the control method can be selected by SP033(SFNC1)/bit1,0(vcnt).  
Normally, use "Changeover type 2".  
When setting this parameter, make sure to set the torque offset "SP050(TOF)".  
When not using, set to "0".

---Setting range---  
0 to 32767

### 【#13008】 SP008 VGN2 Speed loop gain 2

Normally SP005(VGN1), SP006(VIA1), SP007(VIL1) are used.  
By setting "SP035(SFNC3)/bit1(vgin), SP035(SFNC3)/bit9(vgn) or SP036(SFNC4)/bit1(vgs)=1", gain 2 can be used according to the application.  
Gain 2 can also be used by setting "Speed gain set 2 changeover request (control input 5/ bitC) = 1".  
Refer to SP005(VGN1), SP006(VIA1), SP007(VIL1) for procedures.

---Setting range---  
1 to 9999

### 【#13009】 SP009 VIA2 Speed loop lead compensation 2

Normally SP005(VGN1), SP006(VIA1), SP007(VIL1) are used.  
By setting "SP035(SFNC3)/bit1(vgin), SP035(SFNC3)/bit9(vgn) or SP036(SFNC4)/bit1(vgs)=1", gain 2 can be used according to the application.  
Gain 2 can also be used by setting "Speed gain set 2 changeover request (control input 5/ bitC) = 1".  
Refer to SP005(VGN1), SP006(VIA1), SP007(VIL1) for procedures.

---Setting range---  
1 to 9999

### 【#13010】 SP010 VIL2 Speed loop delay compensation 2

Normally SP005(VGN1), SP006(VIA1), SP007(VIL1) are used.  
By setting "SP035(SFNC3)/bit1(vgin), SP035(SFNC3)/bit9(vgn) or SP036(SFNC4)/bit1(vgs)=1", gain 2 can be used according to the application.  
Gain 2 can also be used by setting "Speed gain set 2 changeover request (control input 5/ bitC) = 1".  
Refer to SP005(VGN1), SP006(VIA1), SP007(VIL1) for procedures.

---Setting range---  
0 to 32767

### 【#13011】 SP011

Not used. Set to "0".

### 【#13012】 SP012

Not used. Set to "0".

### 【#13013】 SP013

Not used. Set to "0".

#### 【#13014】 SP014 PY1 Minimum excitation rate 1

Set the minimum value for the variable excitation rate. The standard setting is "50".  
Set to "0" when using an IPM spindle motor.  
If noise including gear noise is loud, select a small value. However, a larger setting value is more effective for impact response.

(Note) When setting a value at "50 or more", check if there is no problem with gear noise, motor excitation noise, vibration during low-speed rotation or vibration when the servo is locked during orientation stop, etc.  
When setting a value at "less than 50", check if there is no problem with the impact load response or rigidity during servo lock.

---Setting range---  
0 to 100 (%)

#### 【#13015】 SP015 PY2 Minimum excitation rate 2

Normally, SP014(PY1) is used.  
By setting "SP035(SFNC3)/bit2(pyin), SP035(SFNC3)/bitA(pyn) or SP036(SFNC4)/bit2(pys)=1", the excitation rate 2 can be used according to the application.  
The excitation rate 2 can also be used by setting "the minimum excitation rate 2 changeover request (control input 5/ bitB) = 1". Refer to SP014(PY1) for procedures.  
Set to "0" when using an IPM spindle motor.

---Setting range---  
0 to 100 (%)


#### 【#13016】 SP016 DDT Phase alignment deceleration rate

Set the single-rotation position alignment deceleration rate for orientation stopping, phase alignment while rotating and switching from non-interpolation mode to spindle synchronization mode while rotating.  
When the load inertia is larger, the setting value should be smaller.  
When the setting value is larger, the orientation in-position and single-rotation position alignment complete faster, but the impact applied on the machine will increase.  
To change the deceleration rate only during rotation command (command F  $\triangle$  T  $\neq$  0), set this parameter together with SP070 (KDDT).

---Setting range---  
1 to 32767 (0.1(r/min)/ms)

# 【#13017(PR)】 SP017 SPEC1 Spindle specification 1

Select the spindle specification.  
A function is allocated to each bit.  
Set this in hexadecimal format.



## bit F-C : msr Motor series selection

- 0: 200V specification IM spindle motor
  - 1: 200V specification IPM spindle motor
  - 2: 400V specification IM spindle motor
  - 3: 400V specification IPM spindle motor
  - 4: 200V specification Tool spindle motor
- Only "0" or "4" setting is available for MDS-D-SPJ3 Series.

- For MDS-DM Series  
For MDS-DM-SPV2/SPV3, set to "0".

## bit B-5 :

Not used. Set to "0".

## bit 4 : fdir Position feedback

- 0: Forward polarity    1: Reverse polarity

## bit 3 : vfb Speed feedback filter

- 0: Disable    1: Enable (2250Hz)

## bit 2 : seqh READY ON sequence

- 0: Normal    1: High-speed

## bit 1 : dfbx Dual feedback control


- 0: Stop    1: Start

## bit 0 : fdir2 Speed feedback polarity

- 0: Forward polarity    1: Reverse polarity

## 【#13018(PR)】 SP018 SPEC2 Spindle specification 2

Select the spindle specification.  
A function is allocated to each bit.  
Set this in hexadecimal format.



### bit F-A :

Not used. Set to "0".

### bit 9 : mpg Earth fault detection

0: Disable 1: Enable (standard)  
Set "0" and it is constantly "Enable" for MDS-D-SPJ3 Series.

### bit 8 : spsu Speed setting unit

0: r/min 1: 4 r/min

### bit 7-6 :

Not used. Set to "0".

### bit 5 : mkch Coil switch function

0: Disable 1: Enable

### bit 4-2 :

Not used. Set to "0".

### bit 1 : oplp Open loop

0: Disable 1: Enable

### bit 0 :

Not used. Set to "0".

## 【#13019(PR)】 SP019 RNG1 Sub side detector resolution

[For semi-closed loop]  
Set the same value as SP020 (RNG2). (Refer to the explanation of SP020.)

[For full-closed loop]  
Set the number of pulses per revolution of the speed detector.  
When using ABZ pulse encoder, used this with SP097(RNG1ex).

E.g.: The setting for ABZ pulse encoder "OSE-1024-3-15-68"  
SP019 = 4096  
SP097 = -1

### ---Setting range---

-32768 to 32767 (kp/rev)  
When using SP097: (p/rev)



**【#13020(PR)】 SP020 RNG2 Main side detector resolution**

Set the number of pulses per revolution of the main side detector.  
When using the serial changer MDS-B-HR, use this with SP098(RNG2ex).

Detector

TS5691(128 teeth): SP020 = 2000  
TS5691(180 teeth): SP020 = 2880  
TS5691(256 teeth): SP020 = 4000  
TS5691(384 teeth): SP020 = 6000  
TS5691(512 teeth): SP020 = 8000

TS5690( 64 teeth): SP020 = 2000  
TS5690( 90 teeth): SP020 = 2880  
TS5690(128 teeth): SP020 = 4000  
TS5690(192 teeth): SP020 = 6000  
TS5690(256 teeth): SP020 = 8000  
TS5690(384 teeth): SP020 = 12000

ERM280(1200 teeth): SP020 = 4800  
ERM280(2048 teeth): SP020 = 8000

MPCI : SP020 = 7200  
MBE205: SP020 = 2000

OSA18(-A48): SP020 = 260

**---Setting range---**

-32768 to 32767 (kp/rev)  
When using SP098: (p/rev)

**【#13021(PR)】 SP021 OLT Overload detection time constant**

Set the detection time constant of Overload 1 (Alarm 50). (For machine tool builder adjustment)  
Normally, set to "60".  
Set to "300" when using an IPM spindle motor.

**---Setting range---**

1 to 15300 (s)

**【#13022】 SP022 OLL Overload detection level**

Set the current detection level of "Overload 1" (Alarm 50) as a percentage against the motor short-time rated output current. (For machine tool builder adjustment)  
Normally, set to "120".  
Set to "100" when using an IPM spindle motor.

**---Setting range---**

1 to 200 (Short-time rated %)

**【#13023】 SP023 OD1 Excessive error detection width (interpolation mode - spindle synchronization)**

Set the excessive error detection width for the interpolation mode and spindle synchronization.  
The standard setting is "120".  
When set to "0", the excessive error detection will not be performed.

**---Setting range---**

1 to 32767 (°)

**【#13024】 SP024 INP In-position width**

Set the in-position detection width.  
Set the positioning accuracy required to the machine.  
Lower setting value increases the positioning accuracy, but makes the cycle time (settling time) longer.  
The standard setting is "875".

**---Setting range---**

0 to 32767 (1° /1000)

**【#13025】 SP025 INP2 2nd in-position width**

Use this when detecting an in-position different from normal in-position width such as advancing the in-position signal.  
The procedure is the same as SP024 (INP).  
The standard setting is "875".

**---Setting range---**

0 to 32767 (1° /1000)

**【#13026(PR)] SP026 TSP Maximum motor speed**

Set the maximum motor speed.  
If the motor speed exceeds the set maximum speed, an overspeed alarm will occur.

**---Setting range---**

1 to 32767 (r/min)

**【#13027】 SP027 ZSP Motor zero speed**

Set the motor speed for detecting zero speed.  
If the motor speed drops below the set speed, the zero speed detection turns ON.  
The standard setting is "50".

**---Setting range---**

1 to 1000 (r/min)

**【#13028】 SP028 SDTS Speed detection set value**

Set the motor speed for detecting the speed.  
If the motor speed drops below the set speed, the zero speed detection turns ON.  
The standard setting is 10% of the maximum motor speed.

**---Setting range---**

10 to 32767 (r/min)

**【#13029】 SP029 SDTR Speed detection reset width**

Set the hysteresis width in which the speed detection changes from ON to OFF.  
If the setting value is small, the speed detection will chatter easily.  
The standard setting is "30".

**---Setting range---**

10 to 1000 (r/min)

**【#13030】 SP030 SDT2 2nd speed detection setting value**

Set the specified speed of the specified speed output.  
When carrying out digital output of the specified speed output, set SP229(SFNC9)/bitC(sdt2) to "1".  
It is not available for MDS-D-SPJ3 Series.

**---Setting range---**

-32768 to 32767 (r/min)


**【#13031(PR)] SP031 MTYP Motor type**

Set the control system of the spindle drive unit.  
2200: Semi closed loop control  
4200: Full closed loop control by using spindle side ABZ pulse output detector  
6200: Full closed loop control by using spindle side serial output detector

**【#13032(PR)】 SP032 PTYP Power supply type/ Regenerative resistor type**

**MDS-D/DH Series: Power supply type**

When connecting a power supply unit, set a code for each power supply unit.



**bit F-C : amp**

Not used. Set to "0".

**bit B-8 : rtp**

Not used. Set to "0".

**bit 7-0 : ptyp External emergency stop setting**

When the emergency stop input signal of the power supply unit is "disabled"

Power supply unit is not connected	: 00
MDS-D-CV-37 / MDS-DH-CV-37	: 04
MDS-D-CV-75 / MDS-DH-CV-75	: 08
MDS-D-CV-110 / MDS-DH-CV-110	: 11
MDS-D-CV-185 / MDS-DH-CV-185	: 19
MDS-D-CV-300 / MDS-DH-CV-300	: 30
MDS-D-CV-370 / MDS-DH-CV-370	: 37
MDS-D-CV-450 / MDS-DH-CV-450	: 45
MDS-D-CV-550 / MDS-DH-CV-550	: 55
MDS-DH-CV-750	: 75


When the emergency stop input signal of the power supply unit is "enabled"

(Note) Set the power supply rotary switch to "4".

Power supply unit is not connected	: 00
MDS-D-CV-37 / MDS-DH-CV-37	: 44
MDS-D-CV-75 / MDS-DH-CV-75	: 48
MDS-D-CV-110 / MDS-DH-CV-110	: 51
MDS-D-CV-185 / MDS-DH-CV-185	: 59
MDS-D-CV-300 / MDS-DH-CV-300	: 70
MDS-D-CV-370 / MDS-DH-CV-370	: 77
MDS-D-CV-450 / MDS-DH-CV-450	: 85
MDS-D-CV-550 / MDS-DH-CV-550	: 95
MDS-DH-CV-750	: B5

**MDS-DM-SPV Series: Power supply type**

Set as follows for the spindle drive section of the MDS-DM-SPV.



**bit F-C : amp**

Not used. Set to "0".

**bit B-8 : rtp**


Not used. Set to "0".

**bit 7-0 : ptyp External emergency stop setting**

Normal	: 19
External emergency stop function	59

### MDS-D-SPJ3 Series: Regenerative resistor type

Set the regenerative resistor type.



#### bit F-8 : amp(bit F-C) / rtyp(bit B-8)

Setting prohibited	: 10
Setting prohibited	: 11
MR-RB032	: 12
MR-RB12 or GZG200W39OHMK	: 13
MR-RB32 or GZG200W120OHMK 3 units connected in parallel	: 14
MR-RB30 or GZG200W39OHMK 3 units connected in parallel	: 15
MR-RB50 or GZG300W39OHMK 3 units connected in parallel	: 16
MR-RB31 or GZG200W20OHMK 3 units connected in parallel	: 17
MR-RB51 or GZG300W20OHMK 3 units connected in parallel	: 18
Setting prohibited	: 19-1F
Setting prohibited	: 20-23
FCUA-RB22	: 24
FCUA-RB37	: 25
FCUA-RB55	: 26
FCUA-RB75/2 1 unit	: 27
R-UNIT1	: 28
R-UNIT2	: 29
R-UNIT3	: 2A
R-UNIT4	: 2B
R-UNIT5	: 2C
FCUA-RB75/2 2 units connected in parallel	: 2D
Setting prohibited	: 2E,2F

#### bit 7-4 : emgx External emergency stop function


Set the external emergency stop function. (Do not set a value other than specified.)  
0: Disable 4: Enable

#### bit 3-0 :

Not used. Set to "0".

[#13033] SP033 SFNC1 Spindle function 1

Select the spindle specification.  
 A function is allocated to each bit.  
 Set this in hexadecimal format.



**bit F-C :**

Not used. Set to "0".

**bit B-A : ovs Overshoot compensation**

bitB,A=  
 00: Compensation stop  
 01: Setting prohibited  
 10: Setting prohibited  
 11: Compensation type 3

(Note) Set the compensation amount in SP043(OVS1) and SP042(OVS2).

**bit 9-8 : lmc Lost motion compensation**

bit9,8=  
 00: Compensation stop  
 01: Setting prohibited  
 10: Compensation type 2  
 11: Setting prohibited

(Note) Set the compensation amount in SP048(LMC1) and SP041(LMC2).

When "SP227/lmc3" is set to "1", the lost motion compensation type 3 is selected regardless of this setting.

**bit 7 : lmc2a Lost motion compensation 2 timing**

0: Normal timing    1: Timing changed

**bit 6-2 :**


Not used. Set to "0".

**bit 1-0 : vcnt Delay compensation changeover**

bit1,0=  
 00: Disable  
 01: Changeover type 1  
 10: Changeover type 2  
 11: Changeover type 2

## 【#13034】 SP034 SFNC2 Spindle function 2

Select the spindle function.  
A function is allocated to each bit.  
Set this in hexadecimal format.



### bit F-D : nfd5 Depth of Notch filter 5

Set the depth of Notch filter 5.

bit F,E,D=

- 000: - ∞
- 001: -18.1[dB]
- 010: -12.0[dB]
- 011: -8.5[dB]
- 100: -6.0[dB]
- 101: -4.1[dB]
- 110: -2.5[dB]
- 111: -1.2[dB]

### bit C :

Not used. Set to "0".

### bit B-9 : nfd4 Depth of Notch filter 4

Set the depth of Notch filter 4.

bit B,A,9=

- 000: - ∞
- 001: -18.1[dB]
- 010: -12.0[dB]
- 011: -8.5[dB]
- 100: -6.0[dB]
- 101: -4.1[dB]
- 110: -2.5[dB]
- 111: -1.2[dB]

### bit 8 : pwm Current control

0: Standard current control    1: High frequency current control

### bit 7-5 : nfd2 Depth of Notch filter 2

Set the depth of Notch filter 2.

bit 7,6,5=

- 000: - ∞
- 001: -18.1[dB]
- 010: -12.0[dB]
- 011: -8.5[dB]
- 100: -6.0[dB]
- 101: -4.1[dB]
- 110: -2.5[dB]
- 111: -1.2[dB]

### bit 4 : nfd3 Notch filter 3(1125Hz)

0: Stop    1: Start

## Appendix 1 Explanation of Parameters

### bit 3-1 : nfd1 Depth of Notch filter 1

Set the depth of Notch filter 1.

bit3,2,1=

000: -  $\infty$

001: -18.1[dB]

010: -12.0[dB]

011: -8.5[dB]

100: -6.0[dB]

101: -4.1[dB]

110: -2.5[dB]

111: -1.2[dB]

### bit 0 : zck Z phase check (ALM42)


0: Enable 1: Disable

## 【#13035(PR)】 SP035 SFNC3 Spindle function 3

Select the spindle function.

A function is allocated to each bit.

Set this in hexadecimal format.



### bit F-D :

Not used. Set to "0".

### bit C : shgn SHG control

0: Stop 1: Start

### bit B :

Not used. Set to "0".

### bit A : pyn Excitation rate selection

0: Select Excitation rate 1 1: Select Excitation rate 2

### bit 9 : vgn Speed loop gain set selection

0: Select Set 1 1: Select Set 2

### bit 8-3 :

Not used. Set to "0".

### bit 2 : pyin Excitation rate selection

The excitation rate after the in-position can be selected.

0: Select Excitation rate 1 1: Select Excitation rate 2

### bit 1 : vgin Speed loop gain set selection

The speed loop gain set after the in-position can be selected.


0: Select Set 1 1: Select Set 2

### bit 0 :

Not used. Set to "0".

### 【#13036(PR)】 SP036 SFNC4 Spindle function 4

Select the spindle function.  
A function is allocated to each bit.  
Set this in hexadecimal format.



#### bit F-8 :

Not used. Set to "0".

#### bit 7 : mksl Spindle coil selection

0: Select the coil commanded during synchronization 1: Select high-speed coil

#### bit 6-5 :

Not used. Set to "0".

#### bit 4 : shgs SHG control

0: Stop 1: Start

#### bit 3 :

Not used. Set to "0".

#### bit 2 : pys Excitation rate selection

0: Select Excitation rate 1 1: Select Excitation rate 2

#### bit 1 : vgs Speed loop gain set selection

0: Select Gain Set 1 1: Select Gain set 2

#### bit 0 :

Not used. Set to "0".

### 【#13037】 SP037 JL Load inertia scale

Set "the motor inertia + motor axis conversion load inertia" in proportion to the motor inertia.  
 $SV037(JL) = (Jm + Jl) / Jm \times 100$   
 Jm: Motor inertia  
 Jl: Motor axis conversion load inertia

---Setting range---  
0 to 5000 (%)

### 【#13038】 SP038 FHZ1 Notch filter frequency 1

Set the vibration frequency to suppress when machine vibration occurs.  
 (Enabled at 50 or more.)  
 When not using, set to "0".

---Setting range---  
0 to 2250 (Hz)

### 【#13039】 SP039 LMCD Lost motion compensation timing

Set this parameter when the lost motion compensation timing does not match.  
 Adjust by increasing the value by 10 at a time.

---Setting range---  
0 to 2000 (ms)



**【#13040】 SP040 LMCT Lost motion compensation non-sensitive band**

Set the non-sensitive band of the lost motion compensation in the feed forward control.  
When "0" is set,  $2^{\circ}/1000$  is set. Adjust by increasing the value by  $1^{\circ}/1000$  at a time.

**---Setting range---**

-32768 to 32767 ( $1^{\circ}/1000$ )

**【#13041】 SP041 LMC2 Lost motion compensation 2**

Set this parameter with SP048(LMC1) only to vary the lost motion compensation amount depending on the command directions.  
Normally, set to "0".

**---Setting range---**

-1 to 200 (Short-time rated %)

Note that when SP227/bit2 is "1", the range will be -1 to 20000 (Short-time rated 0.01%).

**【#13042】 SP042 OVS2 Overshooting compensation 2**

Set this parameter with SP043(OVS1) only to vary the lost motion compensation amount depending on the command directions.  
Normally, set to "0".

**---Setting range---**

-1 to 100 (Short-time rated %)

Note that when SP227/bit2 is "1", the range will be -1 to 10000 (Short-time rated 0.01%).

**【#13043】 SP043 OVS1 Overshooting compensation 1**

Set this parameter when overshooting occurs during positioning. This compensates the motor torque during positioning.  
This is valid only when the overshooting compensation SP033 (SFNC1/ovs) is selected.

[Type 3 "When SP033(SFNC1)/ bitB,A(ovs)=11"]

Use this when performing overshoot compensation in the feed forward control during arc cutting mode.

Set the compensation amount based on the motor short-time rated current.

Increase the value in increments of 1% to find the value where overshooting ceases.

[To vary compensation amount depending on the direction]

When SV042 (OVS2) is "0", change the SP043 (OVS1) value in both +/- directions to compensate. To change the compensation amount depending on the command direction, set this with SP042 (OVS2).

(SP043: + direction, SP042: - direction, However, the directions may be opposite depending on other settings. )

When "-1" is set, the compensation will not be performed in the command direction.

**---Setting range---**

-1 to 100 (Short-time rated %)

Note that when SP227/bit2 is "1", the range will be -1 to 10000 (Short-time rated 0.01%).

**【#13044】 SP044 OBS2 Disturbance observer gain**

Set the disturbance observer gain. The standard setting is "100".

To use the disturbance observer, also set SP037(JL), SP045(OBS1) and SP226(SFNC6)/ bitE(obs).  
When not using, set to "0".

**---Setting range---**

0 to 500 (%)

**【#13045】 SP045 OBS1 Disturbance observer filter frequency**

Set the disturbance observer filter band.

Normally, set to "100".

To use the disturbance observer, also set SP037(JL), SP044(OBS2) and SP226(SFNC6)/ bitE(obs).  
When not using, set to "0".

**---Setting range---**

0 to 1000 (rad/s)

#### **【#13046】 SP046 FHz2 Notch filter frequency 2**

Set the vibration frequency to suppress when machine vibration occurs.  
(Enabled at 50 or more.)  
When not using, set to "0".

**---Setting range---**  
0 to 2250 (Hz)

#### **【#13047】 SP047 EC Inductive voltage compensation gain**

Set the inductive voltage compensation gain. Normally, set to "100".  
Lower the gain when the current FB peak exceeds the current command peak.

**---Setting range---**  
0 to 200 (%)

#### **【#13048】 SP048 LMC1 Lost motion compensation 1**

Set this parameter when the protrusion (that occurs due to the non-sensitive band by friction, torsion, backlash, etc.) at quadrant change is too large.  
This compensates the torque at quadrant change.  
This is valid only when the overshooting compensation SP033 (SFNC1/lmc) is selected.

[Type 2 "When SP033(SFNC1)/bit9,8(lmc)=10"]

Set the compensation amount based on the motor short-time rated current.  
The standard setting is double of the friction torque. The compensation amount will be 0 when "0" is set.

[Other than type 2 "When SP033(SFNC1)/bit9,8(lmc) ≠ 10"]  
Lost motion compensation (Type 2) is not executed.

[To vary compensation amount depending on the direction]  
When SP041 (LMC2) is "0", change SP048 (LMC1) value in both of +/- directions to compensate.  
To vary the compensation amount depending on the command direction, set this with SP041 (LMC2).  
(SP048: + direction, SP041: - direction, However, the directions may be opposite depending on other settings. )  
When "-1" is set, the compensation will not be performed in the command direction.

**---Setting range---**  
-1 to 200 (Short-time rated %)  
Note that when SP227/bit2 is "1", the range will be -1 to 20000 (Short-time rated 0.01%).

#### **【#13049】 SP049 FFC Acceleration rate feed forward gain**

When a relative error in the synchronous control is too large, set this parameter to the axis that is delaying.  
The standard setting is "0".  
The standard setting in the SHG control is "100".  
Adjust relative errors in acceleration/deceleration by increasing the value by 50 to 100.

**---Setting range---**  
0 to 999 (%)

#### **【#13050】 SP050 TOF Torque offset**

Set the imbalance torque.

**---Setting range---**  
-100 to 100 (Short-time rated %)

**【#13051】 SP051 DFBT Dual feed back control time constant**

Set the control time constant in dual feed back.  
When the function is valid, the standard setting is "100". When "0" is set, the value is 1 ms.  
When the time constant is increased, the operation will get closer to the semi-closed control and the limit of the position loop gain will be raised.  
However, this cannot be used when the spindle slip occurs in machine configuration such as V-belt drive.

---Setting range---  
0 to 9999 (ms)

**【#13052】 SP052 DFBN Dual feedback control non-sensitive band**

Set the non-sensitive band in the dual feedback control.  
Normally set to "0".

---Setting range---  
0 to 9999 (1/1000")

**【#13053】 SP053 ODS Excessive error detection width (non-interpolation mode)**

Set the excessive error detection width in non-interpolation mode.  
Standard setting value:  $ODS = \text{Maximum motor speed [r/min]} \times 6/PGV/2$

When set to "0", the excessive error detection will not be performed.

---Setting range---  
0 to 32767 (°)

**【#13054】 SP054 ORE Overrun detection width in closed loop control**

Set the overrun detection width in the full-closed loop control.  
When the gap between the main side detector and the sub side detector exceeds the set value, it is judged as an overrun and "Alarm 43" is detected.  
When "-1" is set, the alarm detection will not be performed.  
When "0" is set, overrun will be detected with 2°.  
In the full-closed loop control, normally set this parameter to "360". During V-belt drive, set to "-1".

---Setting range---  
-32768 to 32767 (°)

**【#13055】 SP055 EMGx Max. gate off delay time after emergency stop**

Set the time required to forcibly execute READY OFF after the emergency stop is input.  
Normally set to "20000".  
When "0" is set, READY OFF is forcibly executed with "7000ms".  
When the set time is shorter than the time to decelerate and stop, the spindle will stop with the dynamic brake after the set time is out.

---Setting range---  
0 to 29900 (ms)

**【#13056】 SP056 EMGt Deceleration time constant at emergency stop**

Set the time constant used for the deceleration control at emergency stop. Set the time required to stop from the maximum motor speed (TSP).  
When "0" is set, the deceleration control is executed with "7000ms".

---Setting range---  
-29900 to 29900 (ms)

**【#13057(PR)】 SP057 GRA1 Spindle side gear ratio 1**

Set the number of teeth on the spindle side when "the gear selection command (control input 4/bit6, 5) "is set to "00".

---Setting range---  
1 to 32767

**【#13058(PR)】 SP058 GRA2 Spindle side gear ratio 2**

Set the number of teeth on the spindle side when "the gear selection command (control input 4/bit6, 5) " is set to "01".

---Setting range---  
1 to 32767

**【#13059(PR)】 SP059 GRA3 Spindle side gear ratio 3**

Set the number of teeth on the spindle side when "the gear selection command (control input 4/bit6, 5) " is set to "10".

---Setting range---  
1 to 32767

**【#13060(PR)】 SP060 GRA4 Spindle side gear ratio 4**

Set the number of teeth on the spindle side when "the gear selection command (control input 4/bit6, 5) " is set to "11".

---Setting range---  
1 to 32767

**【#13061(PR)】 SP061 GRB1 Motor side gear ratio 1**

Set the number of teeth on the motor side when "the gear selection command (control input 4/bit6, 5) " is set to "00".

---Setting range---  
1 to 32767

**【#13062(PR)】 SP062 GRB2 Motor side gear ratio 2**

Set the number of teeth on the motor side when "the gear selection command (control input 4/bit6, 5) " is set to "01".

---Setting range---  
1 to 32767

**【#13063(PR)】 SP063 GRB3 Motor side gear ratio 3**

Set the number of teeth on the motor side when "the gear selection command (control input 4/bit6, 5) " is set to "10".

---Setting range---  
1 to 32767

**【#13064(PR)】 SP064 GRB4 Motor side gear ratio 4**

Set the number of teeth on the motor side when "the gear selection command (control input 4/bit6, 5) " is set to "11".

---Setting range---  
1 to 32767

**【#13065】 SP065 TLM1 Torque limit 1**

Set the torque limit value when "the torque limit (control input 1/bitA, 9, 8) " is set to "001".

---Setting range---  
0 to 999 (Short-time rated %)

**【#13066】 SP066 TLM2 Torque limit 2**

Set the torque limit value when "the torque limit (control input 1/bitA, 9, 8) " is set to "010".

---Setting range---  
0 to 999 (Short-time rated %)

**【#13067】 SP067 TLM3 Torque limit 3**

Set the torque limit value when "the torque limit (control input 1/bitA, 9, 8) " is set to "011".

**---Setting range---**

0 to 999 (Short-time rated %)

**【#13068】 SP068 TLM4 Torque limit 4**

Set the torque limit value when "the torque limit (control input 1/bitA, 9, 8) " is set to "100".

**---Setting range---**

0 to 999 (Short-time rated %)

**【#13069】 SP069 PCMP Phase alignment completion width**

Set the single-rotation position alignment completion width for phase alignment and changing from non-interpolation to spindle synchronization mode during rotation.

Set the rotation error that is required to the machine.

When the setting value decreases, the rotation error will decrease, but the cycle time (settling time) will get longer. The standard setting is "875".

**---Setting range---**

0 to 32767 (1° /1000)

**【#13070】 SP070 KDDT Phase alignment deceleration rate scale**

Set the scale for SP016 (DDT) to change the deceleration rate only during rotation command (command F  $\Delta$  T  $\neq$  0).

When the setting value increases, the single-rotation position alignment will be completed faster, but the impact to the machine will also increase. When not using, set to "0".

**---Setting range---**


0 to 255 (1/16-fold)

**【#13071】 SP071 DIQM Variable current limit during deceleration, lower limit value**

Set this parameter to adjust the deceleration time by changing the current limit value during deceleration depending on the motor speed.

As shown below, set the lower limit rate of the current limit in SP071 (DIQM), and use with SP072 (DIQN).

When DIQM is set to 100%, the current limit value in deceleration (TMRL) set in the motor constants is applied.



**---Setting range---**


0 to 999 (%)

### 【#13072】 SP072 DIQN Variable current limit during deceleration, break point speed

Set this parameter to adjust the deceleration time by changing the current limit value during deceleration depending on the motor speed.

As shown below, set the lower limit rate of the current limit in SP071 (DIQM), and use with SP072 (DIQN).

When DIQM is set to 100%, the current limit value in deceleration (TMLR) set in the motor constants is applied.



---Setting range---

1 to 32767 (r/min)

### 【#13073】 SP073 VGVN Variable speed gain target value


If noise is bothersome during high speed rotation, it may be reduced by lowering the speed loop gain at high speed.

Set this value to ensure the adequate response by suppressing noise and vibration at low speeds and increasing the speed loop gain at high speeds for a high-speed spindle of machining center, etc. As shown below, set the speed loop gain rate for the overspeed detection speed in SP073 (VGVN), and use with SP074 (VGVS).


When not using, set to "0".

The overspeed detection speed (VLMT) is 115% of the maximum motor speed (TSP).

This function can be used when either VGN1 or VGN2 is selected.



When lowering the speed loop gain at high speed



When increasing the speed loop gain at high speed

---Setting range---

0 to 999 (%)

### [#13074] SP074 VGV S Variable speed gain change start speed


If noise is bothersome during high speed rotation, it may be reduced by lowering the speed loop gain at high speed.

Set this value to ensure the adequate response by suppressing noise and vibration at low speeds and increasing the speed loop gain at high speeds for a high-speed spindle of machining center, etc. As shown below, set the speed loop gain rate for the overspeed detection speed in SP073 (VGVN), and use with SP074 (VGV S).


When not using, set to "0".

The overspeed detection speed (VLMT) is 115% of the maximum motor speed (TSP).

This function can be used when either VGN1 or VGN2 is selected.



When lowering the speed loop gain at high speed



When increasing the speed loop gain at high speed

---Setting range---

0 to 32767 (r/min)

### [#13075] SP075 DWSH Slip compensation scale during regeneration high-speed coil

Set the slip frequency scale during deceleration.

Normally, set to "0". (For machine tool builder adjustment)

---Setting range---

0 to 255 (1/16-fold)

### [#13076] SP076 DWSL Slip compensation scale during regeneration low-speed coil

Set the slip frequency scale at deceleration when using the low-speed coil.

Normally, set to "0". (For machine tool builder adjustment)

---Setting range---

0 to 255 (1/16-fold)

### [#13077] SP077 IQA Q axis current lead compensation

Set the current loop gain.

To use the coil switch function, set the current loop gain for when the high-speed coil is selected.

The setting value is determined by the motor's electrical characteristics so that the value is fixed to each motor used.

Set the value given in the spindle parameter list. (For machine tool builder adjustment)

---Setting range---

1 to 20480

### [#13078] SP078 IDA D axis current lead compensation

Set the current loop gain.

To use the coil switch function, set the current loop gain for when the high-speed coil is selected.

The setting value is determined by the motor's electrical characteristics so that the value is fixed to each motor used.

Set the value given in the spindle parameter list. (For machine tool builder adjustment)

---Setting range---

1 to 20480

#### **【#13079】 SP079 IQG Q axis current gain**

Set the current loop gain.  
To use the coil switch function, set the current loop gain for when the high-speed coil is selected.  
The setting value is determined by the motor's electrical characteristics so that the value is fixed to each motor used.  
Set the value given in the spindle parameter list. (For machine tool builder adjustment)

**---Setting range---**  
1 to 8192

#### **【#13080】 SP080 IDG D axis current gain**

Set the current loop gain.  
To use the coil switch function, set the current loop gain for when the high-speed coil is selected.  
The setting value is determined by the motor's electrical characteristics so that the value is fixed to each motor used.  
Set the value given in the spindle parameter list. (For machine tool builder adjustment)

**---Setting range---**  
1 to 8192

#### **【#13081】 SP081 IQAL Q axis current lead compensation low-speed coil**

When using coil switch function, set the current loop gain for when the low-speed coil is selected.  
The setting value is determined by the motor's electrical characteristics so that the value is fixed to each motor used.  
Set the value given in the spindle parameter list. (For machine tool builder adjustment)

**---Setting range---**  
1 to 20480

#### **【#13082】 SP082 IDAL D axis current lead compensation low-speed coil**

When using coil switch function, set the current loop gain for when the low-speed coil is selected.  
The setting value is determined by the motor's electrical characteristics so that the value is fixed to each motor used.  
Set the value given in the spindle parameter list. (For machine tool builder adjustment)

**---Setting range---**  
1 to 20480

#### **【#13083】 SP083 IQGL Q axis current gain low-speed coil**

When using coil switch function, set the current loop gain for when the low-speed coil is selected.  
The setting value is determined by the motor's electrical characteristics so that the value is fixed to each motor used.  
Set the value given in the spindle parameter list. (For machine tool builder adjustment)

**---Setting range---**  
1 to 8192

#### **【#13084】 SP084 IDGL D axis current gain low-speed coil**

When using coil switch function, set the current loop gain for when the low-speed coil is selected.  
The setting value is determined by the motor's electrical characteristics so that the value is fixed to each motor used.  
Set the value given in the spindle parameter list. (For machine tool builder adjustment)

**---Setting range---**  
1 to 8192

#### **【#13085】 SP085 LMCK Lost motion compensation 3 spring constant**

Set the compensation amount for the spring constant when using lost motion compensation type 3.  
When not using, set to "0".

**---Setting range---**  
0 to 32767 (0.01%/0.001° )



**【#13086】 SP086 LMCc Lost motion compensation 3 viscous coefficient**

Set the compensation amount for the viscous coefficient when using lost motion compensation type 3.  
When not using, set to "0".

**---Setting range---**

0 to 32767 (0.01% - s/ 1° )

**【#13087】 SP087 FHz4 Notch filter frequency 4**

Set the vibration frequency to suppress when machine vibration occurs.  
(Enabled at 50 or more.)  
When not using, set to "0".

**---Setting range---**

0 to 2250 (Hz)

**【#13088】 SP088 FHz5 Notch filter frequency 5**

Set the vibration frequency to suppress when machine vibration occurs.  
(Enabled at 50 or more.)  
When not using, set to "0".

**---Setting range---**

0 to 2250 (Hz)

**【#13089】 SP089 TMKQ Spindle output stabilizing gain Q axis**

Set the magnification of the torque current stabilizing gain. (For machine tool builder adjustment)  
When set to "0", the torque current stabilization is disabled.  
When not using, set to "0".

**---Setting range---**

0 to 32767

**【#13090】 SP090 TMKD Spindle output stabilizing gain D axis**

Set the magnification of the excitation current stabilizing gain. (For machine tool builder adjustment)  
When set to "0", the excitation current stabilization is disabled.  
When not using, set to "0".

**---Setting range---**

0 to 32767

**【#13091】 SP091**

Not used. Set to "0".

**【#13092】 SP092**

Not used. Set to "0".

**【#13093】 SP093**

Not used. Set to "0".

#### 【#13094】 SP094 MPV Magnetic pole error detection speed

When not using, set to "0".  
In the magnetic pole position detection function, the command motor speed and motor speed during the position command stop are monitored.  
Set the command motor speed level and motor speed level during the position command stop in "r/min" unit.  
When the command motor speed level is set to "0", the magnetic pole position error is detected at 10r/min.  
Set to "10" as a standard setting when the magnetic pole position error detection function is enabled. This detects the magnetic pole position error when the motor speed is "100r/min".

Ten-thousands digit, Thousands digit ----- Command motor speed level (10r/min)  
Hundreds digit, Tens digit, Ones digit ----- Motor speed level (10r/min)

---Setting range---  
0 to 31999

#### 【#13095】 SP095 VIAX Lead compensation scale during high-response acceleration/deceleration

Set the magnification against delay/lead compensation (SP006) of the high-response acceleration/deceleration (valid when SP226(SFNC6)/ bitD (vup) is set to "1").  
Normally, set to "0". Set this parameter to suppress overshooting when the speed is reached.

---Setting range---  
0 to 10000 (0.01%)

#### 【#13096】 SP096 SDW Speed slowdown allowable width

When the spindle slows down due to multiple cutting, set the processable speed as percentage against the NC command speed.  
When "0" is set, the magnification is the same as when "85" is set. When set to "-1", the allowable width will be disabled.

---Setting range---  
-1,0 to 100(%)

#### 【#13097】 SP097 RNG1ex Sub side extension detector resolution

Normally set to "0".  
When setting the sub side detector resolution in pulse (p) unit, set the number of pulses to four bite data of SP097 (upper 16 bits) and SP019 (lower 16 bits).

SP097 = number of pulses / 65536 (When = 0, set SP097 = -1)  
SP019 = the remainder of "number of pulses / 65536" (values can be set by the pulse)  
For detectors not using the upper 16 bits, set to "-1".

When "SP019 > 32767", set "the remainder of above - 65536 (negative number)" to "SP019".

---Setting range---  
-1,0 to 32767

#### 【#13098】 SP098 RNG2ex Main side extension detector resolution

Normally set to "0".  
When setting the main side detector resolution in pulse (p) unit, set the number of pulses to four bite data of SP098 (upper 16 bits) and SP020 (lower 16 bits).

SP098 = number of pulses / 65536 (When = 0, set SP098 = -1)  
SP020 = the remainder of "number of pulses / 65536" (values can be set by the pulse)  
For detectors not using the upper 16 bits, set to "-1".

When "SP020 > 32767", set "the remainder of above - 65536 (negative number)" to "SP020".

---Setting range---  
-1,0 to 32767

## Appendix 1 Explanation of Parameters

### 【#13099】 SP099

Not used. Set to "0".

### 【#13100】 SP100

Not used. Set to "0".

### 【#13101】 SP101

Not used. Set to "0".

### 【#13102】 SP102

Not used. Set to "0".

### 【#13103】 SP103

Not used. Set to "0".

### 【#13104】 SP104

Not used. Set to "0".

### 【#13105】 SP105

Not used. Set to "0".

### 【#13106】 SP106

Not used. Set to "0".

### 【#13107】 SP107

Not used. Set to "0".

### 【#13108】 SP108

Not used. Set to "0".

### 【#13109】 SP109

Not used. Set to "0".

### 【#13110】 SP110

Not used. Set to "0".

### 【#13111】 SP111

Not used. Set to "0".

### 【#13112】 SP112

Not used. Set to "0".

### 【#13113】 SP113 OPLP Current command value for open loop

Set the current command value for when the open loop control is enabled.

When "0" is set, the state will be the same as when "50" is set.

When not using, set to "0".

The open loop control is enabled when "SP018 (SPEC2)/bit1 (oplp)" is set to "1".

#### ---Setting range---

0 to 999 (Short-time rated %)

**【#13114】 SP114 MKT Coil changeover gate cutoff timer**

Set the time required to cut off the gate when turning OFF/ON the coil switch contactor.  
The value should be longer than the coil switch contactor's OFF/ON time.  
The standard setting is "150".

---Setting range---  
0 to 3500 (ms)

**【#13115】 SP115 MKT2 Coil changeover current limit timer**

Set the time required to limit the current immediately after the coil switch contactor ON/OFF is completed and the gate is turned ON.  
The standard setting is "250".

---Setting range---  
0 to 3500 (ms)

**【#13116】 SP116 MKIL Coil changeover current limit value**

Set the time required to limit the current immediately after the coil switch contactor ON/OFF is completed and the gate is turned ON.  
The standard setting is "120".

---Setting range---  
0 to 999 (Short-time rated %)

**【#13117】 SP117 SETM Excessive speed deviation timer**

Set the time to detect the speed excessive error alarm.  
Set the time required to the machine.  
The standard setting is "12".

---Setting range---  
0 to 60 (s)

**【#13118(PR)】 SP118 MSFT Magnetic pole shift amount**

Set the magnetic pole shift amount of IPM spindle motor.  
During DC excitation of the initial setup: Set the same value displayed in the "AFLT gain" on the NC monitor screen in SP225(SFNC5)/bit4(dcd)=1.  
When not using, set to "0".

---Setting range---  
-18000 to 18000 (electrical angle 0.01°)

**【#13119】 SP119 FSP4 Notch filter specifications 4**

When not using, set to "0".  
Set the target attenuation and damping coefficient of the notch filter.  
To determine the value, multiply the damping coefficient by 10000, and add it to the absolute value of the target attenuation -dB.  
The setting range of each coefficient is as follows.  
Damping coefficient: 0.01 - 1.00 (Increment: 0.01)  
When "0" is set, the actual value to be set is 1.00.  
Target attenuation: -80db - -1db (Increment: 1dB)  
When "0" is set, the actual value to be set is -80.  
E.g.: When the target attenuation is -40dB, and damping coefficient is 1.00  
 $1.00 \times 10000 + \text{ABS}(-40) = 10040$

---Setting range---  
0 to 32767

**【#13120】 SP120 FSP5 Notch filter specifications 5**

When not using, set to "0".

Set the target attenuation and damping coefficient of the notch filter.

To determine the value, multiply the damping coefficient by 10000, and add it to the absolute value of the target attenuation -dB.

The setting range of each coefficient is as follows.

Damping coefficient: 0.01 - 1.00 (Increment: 0.01)

When "0" is set, the actual value to be set is 1.00.

Target attenuation: -80db - -1db (Increment: 1dB)

When "0" is set, the actual value to be set is -80.

E.g.: When the target attenuation is -40dB, and damping coefficient is 1.00

$1.00 \times 10000 + \text{ABS}(-40) = 10040$

---Setting range---

0 to 32767

**【#13121】 SP121 MP Kpp Magnetic pole detection position loop gain**

Set the position loop gain in the magnetic polar detection loop.

This is used in the initial magnetic polar detection when the IPM spindle motor is turned ON.

Set to "0" when using an IM spindle motor.

---Setting range---

0 to 32767

**【#13122】 SP122 MP Kvp Magnetic pole detection speed loop gain**

Set the speed loop gain in the magnetic polar detection loop.

This is used in the initial magnetic polar detection when the IPM spindle motor is turned ON.

Set to "0" when using an IM spindle motor.

---Setting range---

0 to 32767

**【#13123】 SP123 MP Kvi Magnetic pole detection speed loop lead compensation**

Set the speed loop lead compensation in the magnetic polar detection loop.

This is used in the initial magnetic polar detection when the IPM spindle motor is turned ON.

Set to "0" when using an IM spindle motor.

---Setting range---

0 to 32767

**【#13124】 SP124 ILMTsp Magnetic pole detection current limit value**

Set the current limit value for the magnetic polar detection loop.

This is used in the initial magnetic polar detection when the IPM spindle motor is turned ON.

Set to "0" when using an IM spindle motor.

---Setting range---

0 to 999 (Short-time rated %)

**【#13125】 SP125 DA1NO D/A output ch1 data No. / Initial DC excitation level**

Input the desired data number to D/A output channel.

[When driving an IPM spindle motor (MDS-D/DH Series)]

Use in the DC excitation function.

DC excitation: Set the initial excitation level when SP225(SFNC5)/bit4(dcd)=1.

When "0" is set, the state will be the same as when "20" is set.

---Setting range---

-32768 to 32767

**【#13126】 SP126 DA2NO D/A output ch2 data No. / Final DC excitation level**

Input the desired data number to D/A output channel.

[When driving an IPM spindle motor (MDS-D/DH Series)]

Use in the DC excitation function.

DC excitation: Set the final excitation level when SP225(SFNC5)/bit4(dcd)=1.

When "0" is set, the state will be the same as when "50" is set.

---Setting range---

-32768 to 32767

**【#13127】 SP127 DA1MPY D/A output ch1 output scale / Initial DC excitation time**

Set the output scale in increments of 1/100.

When "0" is set, the scale is the same as when "100" is set.

[When driving an IPM spindle motor (MDS-D/DH Series)]

Use in the DC excitation function.

DC excitation: Set the initial excitation time when SP225(SFNC5)/bit4(dcd)=1.

When "0" is set, the state will be the same as when "10000" is set.

---Setting range---

-32768 to 32767 (1/100-fold)

**【#13128】 SP128 DA2MPY D/A output ch2 output scale**

Set the output scale in increments of 1/100.

When "0" is set, the scale is the same as when "100" is set.

---Setting range---

-32768 to 32767 (1/100-fold)

**【#13129(PR)】 SP129**

Set the unique constants for the spindle motor. (High-speed coil)

The setting value is determined by the motor's mechanical and electrical characteristics and specifications, so normally set the value given in the spindle parameter list.

**【#13130(PR)】 SP130**

Set the unique constants for the spindle motor. (High-speed coil)

The setting value is determined by the motor's mechanical and electrical characteristics and specifications, so normally set the value given in the spindle parameter list.

**【#13131(PR)】 SP131**

Set the unique constants for the spindle motor. (High-speed coil)

The setting value is determined by the motor's mechanical and electrical characteristics and specifications, so normally set the value given in the spindle parameter list.

**【#13132(PR)】 SP132**

Set the unique constants for the spindle motor. (High-speed coil)

The setting value is determined by the motor's mechanical and electrical characteristics and specifications, so normally set the value given in the spindle parameter list.

**【#13133(PR)】 SP133**

Set the unique constants for the spindle motor. (High-speed coil)

The setting value is determined by the motor's mechanical and electrical characteristics and specifications, so normally set the value given in the spindle parameter list.

**【#13134(PR)】 SP134**

Set the unique constants for the spindle motor. (High-speed coil)

The setting value is determined by the motor's mechanical and electrical characteristics and specifications, so normally set the value given in the spindle parameter list.

## Appendix 1 Explanation of Parameters

### [#13135(PR)] SP135

Set the unique constants for the spindle motor. (High-speed coil)  
The setting value is determined by the motor's mechanical and electrical characteristics and specifications, so normally set the value given in the spindle parameter list.

### [#13136(PR)] SP136

Set the unique constants for the spindle motor. (High-speed coil)  
The setting value is determined by the motor's mechanical and electrical characteristics and specifications, so normally set the value given in the spindle parameter list.

### [#13137(PR)] SP137

Set the unique constants for the spindle motor. (High-speed coil)  
The setting value is determined by the motor's mechanical and electrical characteristics and specifications, so normally set the value given in the spindle parameter list.

### [#13138(PR)] SP138

Set the unique constants for the spindle motor. (High-speed coil)  
The setting value is determined by the motor's mechanical and electrical characteristics and specifications, so normally set the value given in the spindle parameter list.

### [#13139(PR)] SP139

Set the unique constants for the spindle motor. (High-speed coil)  
The setting value is determined by the motor's mechanical and electrical characteristics and specifications, so normally set the value given in the spindle parameter list.

### [#13140(PR)] SP140

Set the unique constants for the spindle motor. (High-speed coil)  
The setting value is determined by the motor's mechanical and electrical characteristics and specifications, so normally set the value given in the spindle parameter list.

### [#13141(PR)] SP141

Set the unique constants for the spindle motor. (High-speed coil)  
The setting value is determined by the motor's mechanical and electrical characteristics and specifications, so normally set the value given in the spindle parameter list.

### [#13142(PR)] SP142

Set the unique constants for the spindle motor. (High-speed coil)  
The setting value is determined by the motor's mechanical and electrical characteristics and specifications, so normally set the value given in the spindle parameter list.  
For IPM spindle motor  
This parameter is used in initial magnetic pole detection of IPM spindle motor.  
(1) Pulse application time: Set it in [ $\mu$  s] unit.(0 < application time < 350)  
(2) Pulse application coil: To select a low-speed coil, add 1000 to the pulse application time.  
(3) Polarity of estimated magnetic pole: When it is set to the reverse polarity, add "-" to the total of (1) and (2).  
E.g.: When performing 333  $\mu$  s pulse-applied magnetic pole estimation in a low-speed coil and selecting the reverse polarity for the estimated polarity  
$$SP142 = -(333+1000) = -1333$$

### [#13143(PR)] SP143

Set the unique constants for the spindle motor. (High-speed coil)  
The setting value is determined by the motor's mechanical and electrical characteristics and specifications, so normally set the value given in the spindle parameter list.

### [#13144(PR)] SP144

Set the unique constants for the spindle motor. (High-speed coil)  
The setting value is determined by the motor's mechanical and electrical characteristics and specifications, so normally set the value given in the spindle parameter list.

**【#13145(PR)】 SP145**

Set the unique constants for the spindle motor. (High-speed coil)  
The setting value is determined by the motor's mechanical and electrical characteristics and specifications, so normally set the value given in the spindle parameter list.

**【#13146(PR)】 SP146**

Set the unique constants for the spindle motor. (High-speed coil)  
The setting value is determined by the motor's mechanical and electrical characteristics and specifications, so normally set the value given in the spindle parameter list.

**【#13147(PR)】 SP147**

Set the unique constants for the spindle motor. (High-speed coil)  
The setting value is determined by the motor's mechanical and electrical characteristics and specifications, so normally set the value given in the spindle parameter list.

**【#13148(PR)】 SP148**

Set the unique constants for the spindle motor. (High-speed coil)  
The setting value is determined by the motor's mechanical and electrical characteristics and specifications, so normally set the value given in the spindle parameter list.

**【#13149(PR)】 SP149**

Set the unique constants for the spindle motor. (High-speed coil)  
The setting value is determined by the motor's mechanical and electrical characteristics and specifications, so normally set the value given in the spindle parameter list.

**【#13150(PR)】 SP150**

Set the unique constants for the spindle motor. (High-speed coil)  
The setting value is determined by the motor's mechanical and electrical characteristics and specifications, so normally set the value given in the spindle parameter list.

**【#13151(PR)】 SP151**

Set the unique constants for the spindle motor. (High-speed coil)  
The setting value is determined by the motor's mechanical and electrical characteristics and specifications, so normally set the value given in the spindle parameter list.

**【#13152(PR)】 SP152**

Set the unique constants for the spindle motor. (High-speed coil)  
The setting value is determined by the motor's mechanical and electrical characteristics and specifications, so normally set the value given in the spindle parameter list.

**【#13153(PR)】 SP153**

Set the unique constants for the spindle motor. (High-speed coil)  
The setting value is determined by the motor's mechanical and electrical characteristics and specifications, so normally set the value given in the spindle parameter list.

**【#13154(PR)】 SP154**

Set the unique constants for the spindle motor. (High-speed coil)  
The setting value is determined by the motor's mechanical and electrical characteristics and specifications, so normally set the value given in the spindle parameter list.

**【#13155(PR)】 SP155**

Set the unique constants for the spindle motor. (High-speed coil)  
The setting value is determined by the motor's mechanical and electrical characteristics and specifications, so normally set the value given in the spindle parameter list.

**【#13156(PR)】 SP156**

Set the unique constants for the spindle motor. (High-speed coil)  
The setting value is determined by the motor's mechanical and electrical characteristics and specifications, so normally set the value given in the spindle parameter list.



## Appendix 1 Explanation of Parameters

### 【#13157(PR)】 SP157

Set the unique constants for the spindle motor. (High-speed coil)  
The setting value is determined by the motor's mechanical and electrical characteristics and specifications, so normally set the value given in the spindle parameter list.

### 【#13158(PR)】 SP158

Set the unique constants for the spindle motor. (High-speed coil)  
The setting value is determined by the motor's mechanical and electrical characteristics and specifications, so normally set the value given in the spindle parameter list.

### 【#13159(PR)】 SP159

Set the unique constants for the spindle motor. (High-speed coil)  
The setting value is determined by the motor's mechanical and electrical characteristics and specifications, so normally set the value given in the spindle parameter list.

### 【#13160(PR)】 SP160

Set the unique constants for the spindle motor. (High-speed coil)  
The setting value is determined by the motor's mechanical and electrical characteristics and specifications, so normally set the value given in the spindle parameter list.

### 【#13161(PR)】 SP161

Set the unique constants for the spindle motor. (Low-speed coil)  
The setting value is determined by the motor's mechanical and electrical characteristics and specifications, so normally set the value given in the spindle parameter list.

### 【#13162(PR)】 SP162

Set the unique constants for the spindle motor. (Low-speed coil)  
The setting value is determined by the motor's mechanical and electrical characteristics and specifications, so normally set the value given in the spindle parameter list.

### 【#13163(PR)】 SP163

Set the unique constants for the spindle motor. (Low-speed coil)  
The setting value is determined by the motor's mechanical and electrical characteristics and specifications, so normally set the value given in the spindle parameter list.

### 【#13164(PR)】 SP164

Set the unique constants for the spindle motor. (Low-speed coil)  
The setting value is determined by the motor's mechanical and electrical characteristics and specifications, so normally set the value given in the spindle parameter list.

### 【#13165(PR)】 SP165

Set the unique constants for the spindle motor. (Low-speed coil)  
The setting value is determined by the motor's mechanical and electrical characteristics and specifications, so normally set the value given in the spindle parameter list.

### 【#13166(PR)】 SP166

Set the unique constants for the spindle motor. (Low-speed coil)  
The setting value is determined by the motor's mechanical and electrical characteristics and specifications, so normally set the value given in the spindle parameter list.

### 【#13167(PR)】 SP167

Set the unique constants for the spindle motor. (Low-speed coil)  
The setting value is determined by the motor's mechanical and electrical characteristics and specifications, so normally set the value given in the spindle parameter list.

### 【#13168(PR)】 SP168

Set the unique constants for the spindle motor. (Low-speed coil)  
The setting value is determined by the motor's mechanical and electrical characteristics and specifications, so normally set the value given in the spindle parameter list.

**【#13169(PR)】 SP169**

Set the unique constants for the spindle motor. (Low-speed coil)  
The setting value is determined by the motor's mechanical and electrical characteristics and specifications, so normally set the value given in the spindle parameter list.

**【#13170(PR)】 SP170**

Set the unique constants for the spindle motor. (Low-speed coil)  
The setting value is determined by the motor's mechanical and electrical characteristics and specifications, so normally set the value given in the spindle parameter list.

**【#13171(PR)】 SP171**

Set the unique constants for the spindle motor. (Low-speed coil)  
The setting value is determined by the motor's mechanical and electrical characteristics and specifications, so normally set the value given in the spindle parameter list.

**【#13172(PR)】 SP172**

Set the unique constants for the spindle motor. (Low-speed coil)  
The setting value is determined by the motor's mechanical and electrical characteristics and specifications, so normally set the value given in the spindle parameter list.

**【#13173(PR)】 SP173**

Set the unique constants for the spindle motor. (Low-speed coil)  
The setting value is determined by the motor's mechanical and electrical characteristics and specifications, so normally set the value given in the spindle parameter list.

**【#13174(PR)】 SP174**

Set the unique constants for the spindle motor. (Low-speed coil)  
The setting value is determined by the motor's mechanical and electrical characteristics and specifications, so normally set the value given in the spindle parameter list.

**【#13175(PR)】 SP175**

Set the unique constants for the spindle motor. (Low-speed coil)  
The setting value is determined by the motor's mechanical and electrical characteristics and specifications, so normally set the value given in the spindle parameter list.

**【#13176(PR)】 SP176**

Set the unique constants for the spindle motor. (Low-speed coil)  
The setting value is determined by the motor's mechanical and electrical characteristics and specifications, so normally set the value given in the spindle parameter list.

**【#13177(PR)】 SP177**

Set the unique constants for the spindle motor. (Low-speed coil)  
The setting value is determined by the motor's mechanical and electrical characteristics and specifications, so normally set the value given in the spindle parameter list.

**【#13178(PR)】 SP178**

Set the unique constants for the spindle motor. (Low-speed coil)  
The setting value is determined by the motor's mechanical and electrical characteristics and specifications, so normally set the value given in the spindle parameter list.

**【#13179(PR)】 SP179**

Set the unique constants for the spindle motor. (Low-speed coil)  
The setting value is determined by the motor's mechanical and electrical characteristics and specifications, so normally set the value given in the spindle parameter list.

**【#13180(PR)】 SP180**

Set the unique constants for the spindle motor. (Low-speed coil)  
The setting value is determined by the motor's mechanical and electrical characteristics and specifications, so normally set the value given in the spindle parameter list.

## Appendix 1 Explanation of Parameters

### 【#13181(PR)】 SP181

Set the unique constants for the spindle motor. (Low-speed coil)  
The setting value is determined by the motor's mechanical and electrical characteristics and specifications, so normally set the value given in the spindle parameter list.

### 【#13182(PR)】 SP182

Set the unique constants for the spindle motor. (Low-speed coil)  
The setting value is determined by the motor's mechanical and electrical characteristics and specifications, so normally set the value given in the spindle parameter list.

### 【#13183(PR)】 SP183

Set the unique constants for the spindle motor. (Low-speed coil)  
The setting value is determined by the motor's mechanical and electrical characteristics and specifications, so normally set the value given in the spindle parameter list.

### 【#13184(PR)】 SP184

Set the unique constants for the spindle motor. (Low-speed coil)  
The setting value is determined by the motor's mechanical and electrical characteristics and specifications, so normally set the value given in the spindle parameter list.

### 【#13185(PR)】 SP185

Set the unique constants for the spindle motor. (Low-speed coil)  
The setting value is determined by the motor's mechanical and electrical characteristics and specifications, so normally set the value given in the spindle parameter list.

### 【#13186(PR)】 SP186

Set the unique constants for the spindle motor. (Low-speed coil)  
The setting value is determined by the motor's mechanical and electrical characteristics and specifications, so normally set the value given in the spindle parameter list.

### 【#13187(PR)】 SP187

Set the unique constants for the spindle motor. (Low-speed coil)  
The setting value is determined by the motor's mechanical and electrical characteristics and specifications, so normally set the value given in the spindle parameter list.

### 【#13188(PR)】 SP188

Set the unique constants for the spindle motor. (Low-speed coil)  
The setting value is determined by the motor's mechanical and electrical characteristics and specifications, so normally set the value given in the spindle parameter list.

### 【#13189(PR)】 SP189

Set the unique constants for the spindle motor. (Low-speed coil)  
The setting value is determined by the motor's mechanical and electrical characteristics and specifications, so normally set the value given in the spindle parameter list.

### 【#13190(PR)】 SP190

Set the unique constants for the spindle motor. (Low-speed coil)  
The setting value is determined by the motor's mechanical and electrical characteristics and specifications, so normally set the value given in the spindle parameter list.

### 【#13191(PR)】 SP191

Set the unique constants for the spindle motor. (Low-speed coil)  
The setting value is determined by the motor's mechanical and electrical characteristics and specifications, so normally set the value given in the spindle parameter list.

### 【#13192(PR)】 SP192

Set the unique constants for the spindle motor. (Low-speed coil)  
The setting value is determined by the motor's mechanical and electrical characteristics and specifications, so normally set the value given in the spindle parameter list.

**【#13193】 SP193 LMR Change magnification for load meter standard output (High-speed coil)**

Set the standard output to be displayed as 100% in load meter using the short-time rated output ratio.

To display the continuous rated output as 100%, set as follows.

Continuous rated output/Short-time rated output × 100

When "0" is set, normal display will be applied.

It is not available for MDS-D-SPJ3 Series.

**---Setting range---**

0 to 100 (%)

**【#13194】 SP194 LMN Base speed for load meter standard output (High-speed coil)**

Set the base speed of the standard output to be displayed as 100% in load meter.

When "0" is set, the base speed of the short-time rated output will be applied.

It is not available for MDS-D-SPJ3 Series.

**---Setting range---**

0 to 32767 (r/min)

**【#13195】 SP195 LMRL Change magnification for load meter standard output (Low-speed coil)**

Set the standard output to be displayed as 100% in load meter using the short-time rated output ratio.

To display the continuous rated output as 100%, set as follows.

Continuous rated output/Short-time rated output × 100

When "0" is set, normal display will be applied.

It is not available for MDS-D-SPJ3 Series.

**---Setting range---**

0 to 100 (%)

**【#13196】 SP196 LMNL Base speed for load meter standard output (Low-speed coil)**

Set the base speed of the standard output to be displayed as 100% in load meter.

When "0" is set, the base speed of the short-time rated output will be applied.

It is not available for MDS-D-SPJ3 Series.

**---Setting range---**

0 to 32767 (r/min)

**【#13197】 SP197**

Not used. Set to "0".

**【#13198】 SP198**

Not used. Set to "0".

**【#13199】 SP199**

Not used. Set to "0".

**【#13200】 SP200**

Not used. Set to "0".

**【#13201】 SP201**

Not used. Set to "0".

**【#13202】 SP202**

Not used. Set to "0".

**【#13203】 SP203**

Not used. Set to "0".

# Appendix 1 Explanation of Parameters

## 【#13204】 SP204

Not used. Set to "0".

## 【#13205】 SP205

Not used. Set to "0".

## 【#13206】 SP206

Not used. Set to "0".

## 【#13207】 SP207

Not used. Set to "0".

## 【#13208】 SP208

Not used. Set to "0".

## 【#13209】 SP209

Not used. Set to "0".

## 【#13210】 SP210

Not used. Set to "0".

## 【#13211】 SP211

Not used. Set to "0".

## 【#13212】 SP212

Not used. Set to "0".

## 【#13213】 SP213

Not used. Set to "0".

## 【#13214】 SP214

Not used. Set to "0".

## 【#13215】 SP215

Not used. Set to "0".

## 【#13216】 SP216

Not used. Set to "0".

## 【#13217】 SP217

Not used. Set to "0".

## 【#13218】 SP218

Not used. Set to "0".

## 【#13219】 SP219

Not used. Set to "0".

## 【#13220】 SP220

Not used. Set to "0".

## 【#13221】 SP221

Not used. Set to "0".

### 【#13222】 SP222

Not used. Set to "0".

### 【#13223】 SP223


Not used. Set to "0".

### 【#13224】 SP224

Not used. Set to "0".

### 【#13225】 SP225 SFNC5 Spindle function 5

Select the spindle functions.  
Functions are allocated to each bit.  
Set this in hexadecimal format.



#### bit F-C : ovsn Overshooting compensation type 3 non-sensitive band

Set the non-sensitive band of the overshooting compensation type 3 in increments of 2°/1000.  
In the feed forward control, set the non-sensitive band for the model position droop and ignore the model overshooting. Set to "2°/1000" as a standard.

#### bit B-9 :

Not used. Set to "0".

#### bit 8 : mken Coil switch allowance in deceleration control

This enables a coil changeover while decelerating after an emergency stop for a spindle motor with coil changeover specification. A coil changeover may enable an excessive load inertia to stop within the maximum delay time.  
0: Normal (Disable) 1: Enable

#### bit 7-6 : thno

Select the thermistor characteristics.  
When SP225/bit3=0 (N type) is selected  
bit7,6=  
00: For Mitsubishi spindle motor  
01: Setting prohibited  
10: Setting prohibited  
11: Setting prohibited  
When SP225/bit3=1 (P type) is selected  
00: KTY84-130 (Manufactured by Philips)  
01: Setting prohibited  
10: Setting prohibited  
11: Setting prohibited

#### bit 5 : ddir Proximity switch signal enable edge

0: Falling edge 1: Rising edge

#### bit 4 : dcd DC excitation mode

0: Normal 1: Start

#### bit 3 : thtyp

Select the thermistor type.  
0: Type N thermistor (Mitsubishi standard) 1: Type P thermistor

#### bit 2 : mohn Thermistor temperature detection


0: Normal 1: Disable (Except for TS5690/5691)

#### bit 1-0 :

Not used. Set to "0".

**【#13226】 SP226 SFNC6 Spindle function 6**

Select the spindle functions.  
Functions are allocated to each bit.  
Set this in hexadecimal format.

**bit F : clt Spindle monitor load inertia ratio**

0: Normal 1: Display

**bit E : obs Disturbance observer**

0: Normal 1: Enable

**bit D : vup High response acceleration / deceleration**

This suppresses a temporal delay which occurs when the target speed is attained from acceleration and when the spindle stops from deceleration.

0: Normal acceleration/deceleration 1: High response acceleration/deceleration Enable

**bit C : tqof Spindle output stabilization during acceleration**

0: Normal 1: Disable

**bit B-9 :**

Not used. Set to "0".

**bit 8 : r2c Temperature compensation adjustment indicator**

0: Normal 1: Display

**bit 7 : ckab No signal detection 2**

0: Disable 1: Enable

- For MDS-DM Series  
Not used. Set to "0".

**bit 6 :**

Not used. Set to "0".

**bit 5 : pon IPM spindle pulse application magnetic pole estimation**


0: Normal 1: Enable  
It is not available for MDS-D-SPJ3 Series.

**bit 4-0 :**

Not used. Set to "0".

## 【#13227】 SP227 SFNC7 Spindle function 7

Select the spindle functions.  
Functions are allocated to each bit.  
Set this in hexadecimal format.



### bit F-C : dis Digital signal input selection

0: No signal 1: Safety observation function door state signal 4: Proximity switch signal detection  
Other settings: setting prohibited

### bit B-A : dos3 Digital signal output 3 selection

bitB,A=  
00: Disable  
01: Setting prohibited  
10: Contactor control signal output (For MDS-D-SPJ3)  
11: Setting prohibited

### bit 9 :

Not used. Set to "0".

### bit 8 : alcdsp

0: Display alarm history 1: Display alarm counter

- For MDS-DM Series  
Not used. Set to "0".

### bit 7-3 :

Not used. Set to "0".

### bit 2 : ccu Lost motion/overshoot compensation compensation amount setting unit

0: Short-time rated % 1: Short-time rated 0.01%

### bit 1 : Imc3 Lost motion compensation 3

0: Disable 1: Enable

### bit 0 : Imct Lost motion compensation 3 adjustment time measurement

0: Disable 1: Enable

## 【#13228】 SP228 SFNC8 Spindle function 8


Not used. Set to "0000".



# Appendix 1 Explanation of Parameters

## 【#13229】 SP229 SFNC9 Spindle function 9

Select the spindle functions.  
 Functions are allocated to each bit.  
 Set this in hexadecimal format.



### bit F : ssc Safety observation function

0: Disable 1: Enable

### bit E :

Not used. Set to "0".

### bit D : rps Safety observation speed setting unit

0: Normal 1: 100°/min

### bit C : sdt2 Specified speed output digital signal 2 output


0: Normal 1: Enable

### bit B-0 :

Not used. Set to "0".

## 【#13230】 SP230 SFNC10 Spindle function 10

Select the spindle functions.  
 Functions are allocated to each bit.  
 Set this in hexadecimal format.



### bit F-9 :

Not used. Set to "0".

### bit 8 : nohis Communication error alarm(34,36,38,39) between NC and DRV Specific alarm history disabled

0: Enable 1: Disable

### bit 7 : cse Spindle C axis command speed monitoring function

0: Normal setting (function disabled) 1: Function enabled  
 It is not available for MDS-D-SPJ3 Series.

### bit 6-0 :

Not used. Set to "0".


## 【#13231】 SP231

Not used. Set to "0".

## 【#13232】 SP232

Not used. Set to "0".

**【#13233】 SP233 IVC/lcx Voltage non-sensitive band compensation/Current bias cx**



**bit F-8 :**

Not used. Set to "0".


**bit 7-0 : IVC Voltage non-sensitive band compensation**

When 100% is set, the voltage equivalent to the logical non-energized time will be compensated.  
When "0" is set, 100% compensation will be performed.  
Adjust in increments of 10% from the default value 100%.  
If the value is too large, vibration or vibration noise may be generated.

**---Setting range---**

0 to 255 (%)

**【#13234】 SP234 lcy/lb1 Current bias cy/Current bias b1**



**bit F-8 : lb1 Current bias 1**

Normally, set to "0". (For machine tool builder adjustment)  
When using this parameter, use this with SP233(lcx), SP234(lcy).

**---Setting range---**

0 to 255

**bit 7-0 : lcy Current bias**

Normally, set to "0". (For machine tool builder adjustment)  
When using this parameter, use this with SP233(lcx), SP234(lb1).

**---Setting range---**

0 to 255

**【#13235(PR)】 SP235 R2H Temperature compensation gain**

Set the magnification in converting the thermistor temperature to the control compensation amount.  
When "0" is set, the temperature compensation function is disabled.  
When not using, or when using an IPM spindle motor, set to "0".

**---Setting range---**

0 to 400 (%)

**【#13236(PR)】 SP236 WIH Temperature compensation time constant**

Set the delay time constant from the thermistor temperature to the control compensation amount.  
When "0" is set, the delay time constant is disabled.  
When not using, or when using an IPM spindle motor, set to "0".

**---Setting range---**

0 to 150 (min)

**【#13237(PR)】 SP237 TCF Torque command filter**

Set the filter for the torque command.  
When not using, set to "0".  
The standard value is "500" when using the motor side detector TS5690 or TS5691.

**---Setting range---**

0 to 4500 (Hz)

**【#13238】 SP238 SSCFEED Safety observation Safety speed**

Set the safety speed at the spindle end for the safety observation function.  
 When not using, set to "0".

**---Setting range---**

0 to 18000 (° /min)

However, when SP229/bitD is set to "1", the setting range is from -32768 to 32767 (100° /min).

**【#13239】 SP239 SSCRPM Safety observation Safety motor speed**

Set the motor's safety speed for the safety observation function.  
 When not using, set to "0".

**---Setting range---**

0 to 32767 (r/min)

**【#13240(PR)】 SP240**

Not used. Set to "0".

**【#13241(PR)】 SP241**

This is automatically set by the NC system.

**【#13242(PR)】 SP242**

This is automatically set by the NC system.

**【#13243(PR)】 SP243**

This is automatically set by the NC system.

**【#13244(PR)】 SP244**

This is automatically set by the NC system.

**【#13245(PR)】 SP245**

This is automatically set by the NC system.

**【#13246(PR)】 SP246**

This is automatically set by the NC system.

**【#13247(PR)】 SP247**

This is automatically set by the NC system.

**【#13248(PR)】 SP248**

This is automatically set by the NC system.

**【#13249(PR)】 SP249**

This is automatically set by the NC system.

**【#13250(PR)】 SP250**

This is automatically set by the NC system.

**【#13251(PR)】 SP251**

This is automatically set by the NC system.

**【#13252(PR)】 SP252**

This is automatically set by the NC system.

**【#13253(PR)】 SP253**

This is automatically set by the NC system.

**【#13254(PR)】 SP254**

This is automatically set by the NC system.

**【#13255(PR)】 SP255**

This is automatically set by the NC system.

**【#13256(PR)】 SP256**

This is automatically set by the NC system.

## Appendix 1.6 Rotary Axis Configuration Parameters

The parameters with "(PR)" requires the CNC to be turned OFF after the settings. Turn the power OFF and ON to enable the parameter settings.

### 【#7900(PR)】 RCDAX\_I Orthogonal coordinate horizontal axis name

Set the name of the horizontal axis in the orthogonal coordinate system.

---Setting range---

A,B,C,U,V,W,X,Y,Z

### 【#7901(PR)】 RCDAX\_J Orthogonal coordinate vertical axis name

Set the name of the vertical axis in the orthogonal coordinate system.

---Setting range---

A,B,C,U,V,W,X,Y,Z

### 【#7902(PR)】 RCDAX\_K Orthogonal coordinate height axis name

Set the name of the height axis in the orthogonal coordinate system.

---Setting range---

A,B,C,U,V,W,X,Y,Z

### 【#7903】 G92\_CRD Origin zero set coordinate selection

Select the coordinate to preset when issuing an origin zero command (G92X\_Y\_Z\_).

- 0: Tool center coordinate
- 1: Holder center coordinate

### 【#7904】 NO\_TIP Tool handle feed function selection

Select whether to enable the tool handle feed.

- 0: Enable (tool handle feed)
- 1: Disable (standard)

### 【#7905】 NO\_ABS Selection of tool axis travel amount display at manual ABS switch ON/OFF

Select how to update the display of tool axis travel amount.

- 0: Update at ABS switch OFF
- 1: Update at every ON and OFF of ABS switch

### 【#7906】 PASSTYP Singular point passage type

Select the movement after passing a singular point.

- 0: Type 1  
A/B axis rotation angle will be in the same sign direction as that when the tool center point control started.
- 1: Type 2  
C axis rotation amount on the singular point will be smaller.

### 【#7907】 CHK\_ANG Near singular judgment angle

Set the angle for judging a position near the singular point.

---Setting range---

0.000 to 5.000 (°)

### 【#7908】 SLCT\_PRG\_COORD Programming coordinate system selection

Select the coordinate system for the programming coordinate.

- 0: Table coordinate system (coordinate system that rotates together with workpiece)
- 1: Workpiece coordinate system

### 【#7909】 IJK\_VEC\_MR Posture vector mirror image selection

Select whether to enable the mirror image on the posture vector (IJK) when Type 2 is selected in "#7906 PASSTYP".

- 0: Disable
- 1: Enable

#### **【#7910】 SLCT\_INT\_MODE Interpolation method selection**

Select the interpolation method.  
0: Joint interpolation method  
1: Single axis rotation interpolation method

#### **【#7911】 SLCT\_STANDARD\_POS Rotary axis basic position selection**

Select the basic position of the rotary axis.  
0: Workpiece coordinate zero point  
1: The position when the tool center point is commanded.

(Note) Even if the position is changed, it is not changed during tool center point control. It is changed when next tool center point control will be commanded.

#### **【#7912】 NO\_MANUAL Selection of manual feed for 5-axis machining**

Select whether to enable the manual feed for 5-axis machining.  
0: Enable (manual feed for 5-axis machining)  
1: Disable (standard manual feed)

#### **【#7913】 MCHN\_SPEED\_CTRL Machine speed fluctuation suppression**

Select whether to suppress the machine speed fluctuation due to rotary axis movement.  
0: Not suppress  
1: Suppress

(Note) This parameter is disabled when SSS control is enabled.

#### **【#7914】 ROT\_PREFILT Rotary axis prefilter time constant**

Set the time constant for rotary axis prefilter.  
Setting this parameter can smoothen the tool angle change (rotary axis' motion) under tool center point control.  
When set to "0", "Rotary axis prefiltering" will be disabled.

---Setting range---  
0 to 200 (ms)

#### **【#7915】 SLCT\_SLOPE\_CRD\_MOD Rotary axis basic position in inclined surface machining**

Set the basic position of rotary axis to establish the feature coordinate system when inclined surface machining is commanded.  
\* The position will not change when inclined surface machining is running. It will change when the next inclined surface machining is commanded.  
0: At zero degree  
1: At the start position

#### **【#7920(PR)】 SLCT\_T1 Rotary axis selection**

Select in which axis direction to rotate the tool rotating type base-side rotary axis.  
If the tool axis is inclined, use the second digit to set the axis direction in which the tool axis is inclined.  
0: Invalid  
1: I axis rotation  
2: J axis rotation  
3: K axis rotation

(Note) 0 to 99 can be set from the screen, but if an invalid value is set, the operation error "M01 0127 Rot axis parameter error" will occur when the power supply is turned ON.

---Setting range---  
0 to 3  
12, 13, 21, 23, 31, 32

### 【#7921(PR)】 TIANGT1 Inclination angle

Set the inclination angle if the tool-rotation type base-side rotary axis is inclined. Set the angle regarding CCW direction of the inclined plane as plus direction.

---Setting range---

-359.999 to 359.999 (°)

(Follow as "#1003 iunit Input setup unit".)

### 【#7922(PR)】 ROTAXT1 Rotary axis name

Set the name of the tool rotating type base-side rotary axis.

Set "0" when the axis has the mechanical axis specifications. (The setting is, however, invalid in the tool center point control.)

---Setting range---

0, A, B, C, U, V, W, X, Y, Z

### 【#7923】 DIR\_T1 Rotation direction

Select the rotation direction of the tool rotating type base-side rotary axis.

0: CW

1: CCW

### 【#7924】 COFST1H Horizontal axis rotation center offset

Set the distance in the horizontal axis direction between the rotation centers of the tool-side rotary axis and the base-side rotary axis.

---Setting range---

-99999.999 to 99999.999 (mm)

### 【#7925】 COFST1V Vertical axis rotation center offset

Set the distance in the vertical axis direction between the rotation centers of the tool-side rotary axis and the base-side rotary axis.

---Setting range---

-99999.999 to 99999.999 (mm)

### 【#7926】 COFST1T Height axis rotation center offset

Set the distance in the height axis direction between the rotation centers of the tool-side rotary axis and the base-side rotary axis.

---Setting range---

-99999.999 to 99999.999 (mm)

### 【#7927】 CERRT1H Horizontal axis rotation center error compensation amount

Set the error compensation amount in the horizontal axis direction of the tool rotating type base-side rotary axis rotation center.

---Setting range---

-99999.999 to 99999.999 (mm)

(Follow as "#1006 mcmpunit Machine error compensation unit".)

### 【#7928】 CERRT1V Vertical axis rotation center error compensation amount

Set the error compensation amount in the vertical axis direction of the tool rotating type base-side rotary axis rotation center.

---Setting range---

-99999.999 to 99999.999 (mm)

(Follow as "#1006 mcmpunit Machine error compensation unit".)

**【#7930(PR)】 SLCT\_T2 Rotary axis selection**

Select in which axis direction to rotate the tool rotating type tool-side rotary axis.  
If the tool axis is inclined, use the second digit to set the axis direction in which the tool axis is inclined.

- 0: Invalid
- 1: I axis rotation
- 2: J axis rotation
- 3: K axis rotation

(Note) 0 to 99 can be set from the screen, but if an invalid value is set, the operation error "M01 0127 Rot axis parameter error" will occur when the power supply is turned ON.

**---Setting range---**

- 0 to 3
- 12, 13, 21, 23, 31, 32

**【#7931(PR)】 TIANGT2 Inclination angle**

Set the inclination angle if the tool-rotation type tool-side rotary axis is inclined. Set the angle regarding CCW direction of the inclined plane as plus direction.

**---Setting range---**

- 359.999 to 359.999 (°)
- (Follow as "#1003 iunit Input setup unit".)

**【#7932(PR)】 ROTAXT2 Rotary axis name**

Set the name of the tool rotating type tool-side rotary axis.  
Set "0" when the axis has the mechanical axis specifications. (The setting is, however, invalid in the tool center point control.)

**---Setting range---**

- 0, A, B, C, U, V, W, X, Y, Z

**【#7933】 DIR\_T2 Rotation direction**

Set the rotation direction of the tool rotating type tool-side rotary axis.

- 0: CW
- 1: CCW

**【#7934】 COFST2H Horizontal axis rotation center offset**

Set the distance in the horizontal axis direction between the spindle holder center and the rotation center of the tool-side rotary axis.

**---Setting range---**

- 99999.999 to 99999.999 (mm)

**【#7935】 COFST2V Vertical axis rotation center offset**

Set the distance in the vertical axis direction between the spindle holder center and the rotation center of the tool-side rotary axis.

**---Setting range---**

- 99999.999 to 99999.999 (mm)

**【#7936】 COFST2T Height axis rotation center offset**

Set the distance in the height axis direction between the spindle holder center and the rotation center of the tool-side rotary axis.

**---Setting range---**

- 99999.999 to 99999.999 (mm)

**【#7937】 CERRT2H Horizontal axis rotation center error compensation amount**

Set the error compensation amount in the horizontal axis direction of the tool rotating type tool-side rotary axis rotation center.

**---Setting range---**

- 99999.999 to 99999.999 (mm)
- (Follow as "#1006 mcpunit Machine error compensation unit".)



**【#7938】 CERRT2V Vertical axis rotation center error compensation amount**

Set the error compensation amount in the vertical axis direction of the tool rotating type tool-side rotary axis rotation center.

**---Setting range---**

-99999.999 to 99999.999 (mm)

(Follow as "#1006 mcompunit Machine error compensation unit".)

**【#7940(PR)】 SLCT\_W1 Rotary axis selection**

Select in which axis direction to rotate the table rotating type base-side rotary axis.

If the tool axis is inclined, use the second digit to set the axis direction in which the tool axis is inclined.

0: Invalid

1: I axis rotation

2: J axis rotation

3: K axis rotation

(Note) 0 to 99 can be set from the screen, but if an invalid value is set, the operation error "M01 0127 Rot axis parameter error" will occur when the power supply is turned ON.

**---Setting range---**

0 to 3

12, 13, 21, 23, 31, 32

**【#7941(PR)】 TIANGW1 Inclination angle**

Set the inclination angle if the table-rotation type base-side rotary axis is inclined. Set the angle regarding CCW direction of the inclined plane as plus direction.

**---Setting range---**

-359.999 to 359.999 (°)

(Follow as "#1003 iunit Input setup unit".)

**【#7942(PR)】 ROTAXW1 Rotary axis name**

Set the name of the table rotating type base-side rotary axis.

Set "0" when the axis has the mechanical axis specifications. (The setting is, however, invalid in the tool center point control.)

**---Setting range---**

0, A, B, C, U, V, W, X, Y, Z

**【#7943】 DIR\_W1 Rotation direction**

Set the rotation direction for the table rotating type base-side rotary axis.

0: CW

1: CCW

**【#7944】 COFSW1H Horizontal axis rotation center offset**

When all axes are at the machine basic point, set the distance in the horizontal axis direction from the machine basic point to the rotation center of the base-side rotary axis.

**---Setting range---**

-99999.999 to 99999.999 (mm)

**【#7945】 COFSW1V Vertical axis rotation center offset**

When all axes are at the machine basic point, set the distance in the vertical axis direction from the machine basic point to the rotation center of the base-side rotary axis.

**---Setting range---**

-99999.999 to 99999.999 (mm)

**【#7946】 COFSW1T Height axis rotation center offset**

When all axes are at the machine basic point, set the distance in the height axis direction from the machine basic point to the rotation center of the base-side rotary axis.

**---Setting range---**

-99999.999 to 99999.999 (mm)

**【#7947】 CERRW1H Horizontal axis rotation center error compensation amount**

Set the error compensation amount in the horizontal axis direction of the table rotating type base-side rotary axis rotation center.

**---Setting range---**

-99999.999 to 99999.999 (mm)

(Follow as "#1006 mcompunit Machine error compensation unit".)

**【#7948】 CERRW1V Vertical axis rotation center error compensation amount**

Set the error compensation amount in the vertical axis direction of the table rotating type base-side rotary axis rotation center.

**---Setting range---**

-99999.999 to 99999.999 (mm)

(Follow as "#1006 mcompunit Machine error compensation unit".)

**【#7950(PR)】 SLCT\_W2 Rotary axis selection**

Set in which direction to rotate the table rotating type workpiece-side rotary axis.

If the tool axis is inclined, use the second digit to set the axis direction in which the tool axis is inclined.

0: Invalid

1: I axis rotation

2: J axis rotation

3: K axis rotation

(Note) 0 to 99 can be set from the screen, but if an invalid value is set, the operation error "M01 0127 Rot axis parameter error" will occur when the power supply is turned ON.

**---Setting range---**

0 to 3

12, 13, 21, 23, 31, 32

**【#7951(PR)】 TIANGW2 Inclination angle**

Set the inclination angle if the table rotating type workpiece-side rotary axis is inclined. Set the angle regarding CCW direction of the inclined plane as minus direction.

**---Setting range---**

-359.999 to 359.999 (°)

(Follow as "#1003 iunit Input setup unit".)

**【#7952(PR)】 ROTAXW2 Rotary axis name**

Set the name of the table rotating type workpiece-side rotary axis.

Set "0" when the axis has the mechanical axis specifications. (The setting is, however, invalid in the tool center point control.)

**---Setting range---**

0, A, B, C, U, V, W, X, Y, Z

**【#7953】 DIR\_W2 Rotation direction**

Set the rotation direction for the table rotating type workpiece-side rotary axis.

0: CW

1: CCW

**【#7954】 COFSW2H Horizontal axis rotation center offset**

When all axes are at the machine basic point, set the distance in the horizontal axis direction between rotation centers of the base-side rotary axis and the workpiece-side rotary axis.

**---Setting range---**

-99999.999 to 99999.999 (mm)

**【#7955】 COFSW2V Vertical axis rotation center offset**

When all axes are at the machine basic point, set the distance in the vertical axis direction between rotation centers of the base-side rotary axis and the workpiece-side rotary axis.

**---Setting range---**

-99999.999 to 99999.999 (mm)

**【#7956】 COFSW2T Height axis rotation center offset**

When all axes are at the machine basic point, set the distance in the height axis direction between rotation centers of the base-side rotary axis and the workpiece-side rotary axis.

**---Setting range---**

-99999.999 to 99999.999 (mm)

**【#7957】 CERRW2H Horizontal axis rotation center error compensation amount**

Set the error compensation amount in the horizontal axis direction of the table rotating type workpiece-side rotary axis rotation center.

**---Setting range---**

-99999.999 to 99999.999 (mm)

(Follow as "#1006 mcmpunit Machine error compensation unit".)

**【#7958】 CERRW2V Vertical axis rotation center error compensation amount**

Set the error compensation amount in the vertical axis direction of the table rotating type workpiece-side rotary axis rotation center.

**---Setting range---**

-99999.999 to 99999.999 (mm)

(Follow as "#1006 mcmpunit Machine error compensation unit".)

## Appendix 1.7 Machine Error Compensation Parameters

The parameters with "(PR)" requires the CNC to be turned OFF after the settings. Turn the power OFF and ON to enable the parameter settings.

### **【#4000(PR)】 Pinc Machine error compensation increment method**

Select the method to set the machine error compensation data.

- 0: Absolute amount method
- 1: Incremental amount method

### **【#4001+10(n-1)】 cmpax Basic axis <n-th axis>**

Set a name of the basic axis for machine error compensation.

- (1) For pitch error compensation, set the name of the axis to be compensated.
  - (2) For relative position compensation, set the name of the axis to be the basic axis.
- Set "system No. + axis name" when using the multi-part system.  
(Example) Z axis for 2nd part system: 2Z

When two or more same name exist, set "axis name + serial number".

The serial number is common to all systems.

(Example) If C axis of the 1st system has 2 axes, and another C axis in the 2nd system has 1 axis, set the C axis of the 2nd system as "C3".

#### **---Setting range---**

Abbreviation as X, Y, Z, U, V, W, A, B, C, etc.

### **【#4002+10(n-1)】 drcax Compensation axis <n-th axis>**

Set a name of the compensation axis for machine error compensation.

- (1) For pitch error compensation, set the same axis name as in "#4001 cmpax".
  - (2) For relative position compensation, set the name of the axis to be actually compensated.
- Set "system No. + axis name" when using the multi-part system.  
(Example) Z axis for 2nd part system: 2Z

When two or more same name exist, set "axis name + serial number".

The serial number is common to all systems.

(Example) If C axis of the 1st system has 2 axes, and another C axis in the 2nd system has 1 axis, set the C axis of the 2nd system as "C3".

#### **---Setting range---**

Abbreviation as X, Y, Z, U, V, W, A, B, C, etc.

### **【#4003+10(n-1)】 rdvno Division point number at reference position <n-th axis>**

Set the compensation data No. corresponding to the reference position. As the reference position is actually the base position, there is no compensation No. Therefore set the number that is decremented by 1.

(Note) When two-way pitch error compensation is enabled, set compensation data No. corresponding to reference point in shifting in plus direction.

#### **---Setting range---**

4101 to 5124

### **【#4004+10(n-1)】 mdvno Division point number at the most negative side <n-th axis>**

Set the compensation data No. at the farthest end on the negative side.

(Note) When the axis moves in positive direction with two-way pitch error compensation enabled, set compensation data No. of which locates on the nearest point to negative side. The compensation point should be set with even number.

#### **---Setting range---**

4101 to 5124

**【#4005+10(n-1)】 pdvno Division point number at the most positive side <n-th axis>**

Set the compensation data No. at the farthest end on the positive side.

(Note) When the axis moves in negative direction with two-way pitch error compensation enabled, set compensation data No. of which locates on the nearest point to positive side. The compensation point should be set with even number.

**---Setting range---**

4101 to 5124

**【#4006+10(n-1)】 sc Compensation scale factor <n-th axis>**

Set the scale factor for the compensation amount.

**---Setting range---**

0 to 99

**【#4007+10(n-1)】 spcdv Division interval <n-th axis>**

Set the interval to divide the basic axis.

Each compensation data will be the compensation amount for each of these intervals.

**---Setting range---**

1 to 9999999 (control unit applied)

**【#4008+10(n-1)】 twopc Two-way pitch error compensation <n-th axis>**

Select whether to enable two-way pitch error compensation.

0: Disable

1: Enable

**【#4009+10(n-1)】 refcmp Reference position compensation amount <n-th axis>**

When two-way pitch error compensation is enabled, set the compensation amount of the reference position when the axis moves to the position from the opposite direction of the zero point return.

**---Setting range---**

-32768 to 32767

(Note) The actual compensation amount will be the value obtained by multiplying the setting value with the compensation scale.

**【#4101 - 5124】**

Set the compensation amount for each axis.

**---Setting range---**

-32768 to 32767

(Note) The actual compensation amount will be the value obtained by multiplying the setting value with the compensation scale.

## Appendix 1.8 PLC Constants

### 【#6401,6402 - 6495,6496】 R7800-Low,R7800-High - R7847-Low,R7847-High Bit selection

This is the bit type parameter used in the PLC program (ladder).

Even if the data is set in the R register that corresponds to the PLC side when this parameter is displayed, the screen will not change. Enter a different screen once, and then select this screen again.

Some of the parameters following #6449 may be fixed according to the usage purpose.

Refer to "Appendix1.21 Contents of bit selection parameters #6449 to #6496".

- 0 : OFF
- 1 : ON

### 【#6497,6498 - 6595,6596】 R7848-Low,R7848-High - R7897-Low,R7897-High Bit selection expansion

This is the bit type parameter (expansion) used in the PLC program (ladder).

Even if the data is set in the R register that corresponds to the PLC side when this parameter is displayed, the screen will not change. Enter a different screen once, and then select this screen again.

- 0 : OFF
- 1 : ON

### 【#16000 - 16703】 T0 - T703 PLC timer <10ms/100ms>

Set the time for the timer used in the PLC program (ladder).

The 10ms timer and 100ms timer are identified by the command used.

(Note1) This setting value is valid when bit selection parameter "#6449/bit0" is set to "0".

(Note2) Setting the timer setting value from the setting and display unit

The timer T setting value can be set with the following two methods.

- Method to validate the setting value (Kn) programmed with the sequence program (fixed timer)
- Method to validate the setting value set from the setting and display unit (variable timer)

(Note3) As described below, the setting method of timer T and No. of points can be set with the bit selection parameters (#6454/bit0 to bit3).

- #6454/bit0=0, bit1=0, bit2=0, bit3=0

No. of points: 0

Range: None

Setting method: All fixed timers

- #6454/bit0=1, bit1=0, bit2=0, bit3=0

No. of points: 100

Range: #16000 to #16099

Setting method: Set above range with variable timers.

- #6454/bit0=0, bit1=1, bit2=0, bit3=0

No. of points: 200

Range: #16000 to #16199

Setting method: Set above range with variable timers.

- #6454/bit0=1, bit1=1, bit2=0, bit3=0

No. of points: 300

Range: #16000 to #16299

Setting method: Set above range with variable timers.

- #6454/bit0=0, bit1=0, bit2=1, bit3=0

No. of points: 400

Range: #16000 to #16399

Setting method: Set above range with variable timers.

- #6454/bit0=1, bit1=0, bit2=1, bit3=0

No. of points: 500

Range: #16000 to #16499

Setting method: Set above range with variable timers.

- #6454/bit0=0, bit1=1, bit2=1, bit3=0

No. of points: 600

Range: #16000 to #16599

Setting method: Set above range with variable timers.

- #6454/bit0=1, bit1=1, bit2=1, bit3=0

No. of points: All points

Range: #16000 to #16703

Setting method: All variable timers

---Setting range---

0 to 32767( x 10ms or x 100ms)

**【#17000 - 17063】 ST0 - ST63 PLC integrated timer <100ms INC.>**

Set the time for the integrated timer used with the PLC program (ladder).

(Note1) This setting value is valid when bit selection parameter "#6449/bit0" is set to "0".

(Note2) Setting the timer setting value from the setting and display unit

The timer T setting value can be set with the following two methods.

- Method to validate the setting value (Kn) programmed with the sequence program (fixed integrated timer)
- Method to validate the setting value set from the setting and display unit (variable integrated timer)

(Note3) As described bellow, the setting method of timer ST and No. of points can be set with the bit selection parameters (#6453/bit5 to bit7).

- #6453/bit5=0, bit6=0, bit7=0

No. of points: 0

Range: None

Setting method: All fixed integrated timers

- #6453/bit5=1, bit6=0, bit7=0

No. of points: 20

Range: #17000 to #17019

Setting method: Set above range with variable integrated timer.

- #6453/bit5=0, bit6=1, bit7=0

No. of points: 40

Range: #17000 to #17039

Setting method: Set above range with variable integrated timer.

- #6453/bit5=1, bit6=1, bit7=0

No. of points: All points

Range: #17000 to #17063

Setting method: All variable integrated timers

**---Setting range---**

0 to 32767( x 100ms)

## 【#17200 - 17455】 C000 - C255 Counter

Set the time for the counter used with the PLC program (ladder).

(Note1) This setting value is valid when bit selection parameter "#6449/bit1" is set to "0".

(Note2) Setting the counter setting value from the setting and display unit

The counter C setting value can be set with the following two methods.

- Method to validate the setting value (Kn) programmed with the sequence program (fixed counter)
- Method to validate the setting value set from the setting and display unit (variable counter)

(Note3) As described below, the setting method of counter C and No. of points can be set with the bit selection parameters (#6454/bit4 to bit7).

- #6454/bit4=0, bit5=0, bit6=0, bit7=0

No. of points: 0

Range: None

Setting method: All fixed counters

- #6454/bit4=1, bit5=0, bit6=0, bit7=0

No. of points: 40

Range: #17200 to #17239

Setting method: Set above range with variable counter.

- #6454/bit4=0, bit5=1, bit6=0, bit7=0

No. of points: 80

Range: #17200 to #17279

Setting method: Set above range with variable counter.

- #6454/bit4=1, bit5=1, bit6=0, bit7=0

No. of points: 120

Range: #17200 to #17319

Setting method: Set above range with variable counter.

- #6454/bit4=0, bit5=0, bit6=1, bit7=0

No. of points: 160

Range: #17200 to #17359

Setting method: Set above range with variable counter.

- #6454/bit4=1, bit5=0, bit6=1, bit7=0

No. of points: 200

Range: #17200 to #17399

Setting method: Set above range with variable counter.

- #6454/bit4=0, bit5=1, bit6=1, bit7=0

No. of points: 240

Range: #17200 to #17439

Setting method: Set above range with variable counter.

- #6454/bit4=1, bit5=1, bit6=1, bit7=0

No. of points: All points

Range: #17200 to #17455

Setting method: All variable counters

---Setting range---

0 to 32767

## 【#18001 - 18150】 R7500,7501 - R7798,7799 PLC constant (Base area)

Set the value to be set in the data type R register used in the PLC program (ladder).

Even if the data is set in the R register that corresponds to the PLC side when this parameter is displayed. The screen will not change. Enter a different screen once, and then select this screen again.

---Setting range---

-99999999 to 99999999

## 【#18151-18900】 R8300,8301 - R9798,9799 PLC constant (Extension area)

Set the value to be set in the data type R register(R8300 to R9799) used in the PLC program (ladder).

Even if the data is set in the R register that corresponds to the PLC side when this parameter is displayed, the screen will not change. Enter a different screen once, and then select this screen again.

#18151 to #18900 is used as the PLC constant extended area.

The area is valid for the number of PLC constant extension points ("#1326 PLC Const Ext. Num" setting value), starting with #18151.

---Setting range---

-99999999 to 99999999



## Appendix 1.9 Macro List

### 【#7001】 M[01] Code

Set the M code used for calling out the macro with the M command.  
This is valid when "#1195 Mmac" is set to "1".

---Setting range---  
1 to 9999

### 【#7002】 M[01] Type

Set the macro call out type.

0: M98 P △△△△ ; and equivalent value call  
1: G65 P △△△△ ; and equivalent value call  
2: G66 P △△△△ ; and equivalent value call  
3: G66.1 P △△△△ ; and equivalent value call  
others: M98 P △△△△ ; and equivalent value call

### 【#7003】 M[01] Program No.

Set the No. of the program or file name to be called out. The file name can contain up to 32 characters.

---Setting range---  
Program name or file name (up to 32 characters)

### 【#7011】 M[02] Code

Set the M code used for calling out the macro with the M command.  
This is valid when "#1195 Mmac" is set to "1".

---Setting range---  
1 to 9999

### 【#7012】 M[02] Type

Set the macro call out type.

0: M98 P △△△△ ; and equivalent value call  
1: G65 P △△△△ ; and equivalent value call  
2: G66 P △△△△ ; and equivalent value call  
3: G66.1 P △△△△ ; and equivalent value call  
others: M98 P △△△△ ; and equivalent value call

### 【#7013】 M[02] Program No.

Set the No. of the program or file name to be called out. The file name can contain up to 32 characters.

---Setting range---  
Program name or file name (up to 32 characters)

### 【#7021】 M[03] Code

Set the M code used for calling out the macro with the M command.  
This is valid when "#1195 Mmac" is set to "1".

---Setting range---  
1 to 9999

**【#7022】 M[03] Type**

Set the macro call out type.

0: M98 P △△△△ ; and equivalent value call  
 1: G65 P △△△△ ; and equivalent value call  
 2: G66 P △△△△ ; and equivalent value call  
 3: G66.1 P △△△△ ; and equivalent value call  
 others: M98 P △△△△ ; and equivalent value call

**【#7023】 M[03] Program No.**

Set the No. of the program or file name to be called out. The file name can contain up to 32 characters.

**---Setting range---**

Program name or file name (up to 32 characters)

**【#7031】 M[04] Code**

Set the M code used for calling out the macro with the M command.  
 This is valid when "#1195 Mmac" is set to "1".

**---Setting range---**

1 to 9999

**【#7032】 M[04] Type**

Set the macro call out type.

0: M98 P △△△△ ; and equivalent value call  
 1: G65 P △△△△ ; and equivalent value call  
 2: G66 P △△△△ ; and equivalent value call  
 3: G66.1 P △△△△ ; and equivalent value call  
 others: M98 P △△△△ ; and equivalent value call

**【#7033】 M[04] Program No.**

Set the No. of the program or file name to be called out. The file name can contain up to 32 characters.

**---Setting range---**

Program name or file name (up to 32 characters)

**【#7041】 M[05] Code**

Set the M code used for calling out the macro with the M command.  
 This is valid when "#1195 Mmac" is set to "1".

**---Setting range---**

1 to 9999

**【#7042】 M[05] Type**

Set the macro call out type.

0: M98 P △△△△ ; and equivalent value call  
 1: G65 P △△△△ ; and equivalent value call  
 2: G66 P △△△△ ; and equivalent value call  
 3: G66.1 P △△△△ ; and equivalent value call  
 others: M98 P △△△△ ; and equivalent value call

**【#7043】 M[05] Program No.**

Set the No. of the program or file name to be called out. The file name can contain up to 32 characters.

**---Setting range---**

Program name or file name (up to 32 characters)

## Appendix 1 Explanation of Parameters

### 【#7051】 M[06] Code

Set the M code used for calling out the macro with the M command.  
This is valid when "#1195 Mmac" is set to "1".

---Setting range---  
1 to 9999

### 【#7052】 M[06] Type

Set the macro call out type.

0: M98 P  $\Delta\Delta\Delta\Delta$  ; and equivalent value call  
1: G65 P  $\Delta\Delta\Delta\Delta$  ; and equivalent value call  
2: G66 P  $\Delta\Delta\Delta\Delta$  ; and equivalent value call  
3: G66.1 P  $\Delta\Delta\Delta\Delta$  ; and equivalent value call  
others: M98 P  $\Delta\Delta\Delta\Delta$  ; and equivalent value call

### 【#7053】 M[06] Program No.

Set the No. of the program or file name to be called out. The file name can contain up to 32 characters.

---Setting range---  
Program name or file name (up to 32 characters)

### 【#7061】 M[07] Code

Set the M code used for calling out the macro with the M command.  
This is valid when "#1195 Mmac" is set to "1".

---Setting range---  
1 to 9999

### 【#7062】 M[07] Type

Set the macro call out type.

0: M98 P  $\Delta\Delta\Delta\Delta$  ; and equivalent value call  
1: G65 P  $\Delta\Delta\Delta\Delta$  ; and equivalent value call  
2: G66 P  $\Delta\Delta\Delta\Delta$  ; and equivalent value call  
3: G66.1 P  $\Delta\Delta\Delta\Delta$  ; and equivalent value call  
others: M98 P  $\Delta\Delta\Delta\Delta$  ; and equivalent value call

### 【#7063】 M[07] Program No.

Set the No. of the program or file name to be called out. The file name can contain up to 32 characters.

---Setting range---  
Program name or file name (up to 32 characters)

### 【#7071】 M[08] Code

Set the M code used for calling out the macro with the M command.  
This is valid when "#1195 Mmac" is set to "1".

---Setting range---  
1 to 9999

### 【#7072】 M[08] Type

Set the macro call out type.

0: M98 P  $\Delta\Delta\Delta\Delta$  ; and equivalent value call  
1: G65 P  $\Delta\Delta\Delta\Delta$  ; and equivalent value call  
2: G66 P  $\Delta\Delta\Delta\Delta$  ; and equivalent value call  
3: G66.1 P  $\Delta\Delta\Delta\Delta$  ; and equivalent value call  
others: M98 P  $\Delta\Delta\Delta\Delta$  ; and equivalent value call

**【#7073】 M[08] Program No.**

Set the No. of the program or file name to be called out. The file name can contain up to 32 characters.

**---Setting range---**

Program name or file name (up to 32 characters)

**【#7081】 M[09] Code**

Set the M code used for calling out the macro with the M command.  
This is valid when "#1195 Mmac" is set to "1".

**---Setting range---**

1 to 9999

**【#7082】 M[09] Type**

Set the macro call out type.

0: M98 P △△△△ ; and equivalent value call  
1: G65 P △△△△ ; and equivalent value call  
2: G66 P △△△△ ; and equivalent value call  
3: G66.1 P △△△△ ; and equivalent value call  
others: M98 P △△△△ ; and equivalent value call

**【#7083】 M[09] Program No.**

Set the No. of the program or file name to be called out. The file name can contain up to 32 characters.

**---Setting range---**

Program name or file name (up to 32 characters)

**【#7091】 M[10] Code**

Set the M code used for calling out the macro with the M command.  
This is valid when "#1195 Mmac" is set to "1".

**---Setting range---**

1 to 9999

**【#7092】 M[10] Type**

Set the macro call out type.

0: M98 P △△△△ ; and equivalent value call  
1: G65 P △△△△ ; and equivalent value call  
2: G66 P △△△△ ; and equivalent value call  
3: G66.1 P △△△△ ; and equivalent value call  
others: M98 P △△△△ ; and equivalent value call

**【#7093】 M[10] Program No.**

Set the No. of the program or file name to be called out. The file name can contain up to 32 characters.

**---Setting range---**

Program name or file name (up to 32 characters)

### 【#7102】 M2mac Type

Set the type for when calling out the macro with the 2nd miscellaneous command.  
The macro will be called out with the "#1170 M2name" address command when "#1198 M2mac" is set to "1".

0: M98 P △△△△ ; and equivalent value call  
1: G65 P △△△△ ; and equivalent value call  
2: G66 P △△△△ ; and equivalent value call  
3: G66.1 P △△△△ ; and equivalent value call  
others: M98 P △△△△ ; and equivalent value call

### 【#7103】 M2mac Program No.

Set the program No. for when calling out the macro with the 2nd miscellaneous command.  
The macro will be called out with the "#1170 M2name" address command when "#1198 M2mac" is set to "1".  
Set the No. of the program or file name to be called out. The file name can contain up to 32 characters.

---Setting range---

Program name or file name (up to 32 characters)

### 【#7201】 G[01] Code

Set the G code to be used when calling the macro with a G command.  
Do not set a G code used in the system.

---Setting range---

1 to 999

### 【#7202】 G[01] Type

Set the macro call out type.

0: M98 P △△△△ ; and equivalent value call  
1: G65 P △△△△ ; and equivalent value call  
2: G66 P △△△△ ; and equivalent value call  
3: G66.1 P △△△△ ; and equivalent value call  
others: M98 P △△△△ ; and equivalent value call

### 【#7203】 G[01] Program No.

Set the No. of the program or file name to be called out. The file name can contain up to 32 characters.

---Setting range---

Program name or file name (up to 32 characters)

### 【#7211】 G[02] Code

Set the G code to be used when calling the macro with a G command.  
Do not set a G code used in the system.

---Setting range---

1 to 999

### 【#7212】 G[02] Type

Set the macro call out type.

0: M98 P △△△△ ; and equivalent value call  
1: G65 P △△△△ ; and equivalent value call  
2: G66 P △△△△ ; and equivalent value call  
3: G66.1 P △△△△ ; and equivalent value call  
others: M98 P △△△△ ; and equivalent value call

**【#7213】 G[02] Program No.**

Set the No. of the program or file name to be called out. The file name can contain up to 32 characters.

**---Setting range---**

Program name or file name (up to 32 characters)

**【#7221】 G[03] Code**

Set the G code to be used when calling the macro with a G command.  
Do not set a G code used in the system.

**---Setting range---**

1 to 999

**【#7222】 G[03] Type**

Set the macro call out type.

0: M98 P △△△△ ; and equivalent value call  
1: G65 P △△△△ ; and equivalent value call  
2: G66 P △△△△ ; and equivalent value call  
3: G66.1 P △△△△ ; and equivalent value call  
others: M98 P △△△△ ; and equivalent value call

**【#7223】 G[03] Program No.**

Set the No. of the program or file name to be called out. The file name can contain up to 32 characters.

**---Setting range---**

Program name or file name (up to 32 characters)

**【#7231】 G[04] Code**

Set the G code to be used when calling the macro with a G command.  
Do not set a G code used in the system.

**---Setting range---**

1 to 999

**【#7232】 G[04] Type**

Set the macro call out type.

0: M98 P △△△△ ; and equivalent value call  
1: G65 P △△△△ ; and equivalent value call  
2: G66 P △△△△ ; and equivalent value call  
3: G66.1 P △△△△ ; and equivalent value call  
others: M98 P △△△△ ; and equivalent value call

**【#7233】 G[04] Program No.**

Set the No. of the program or file name to be called out. The file name can contain up to 32 characters.

**---Setting range---**

Program name or file name (up to 32 characters)

**【#7241】 G[05] Code**

Set the G code to be used when calling the macro with a G command.  
Do not set a G code used in the system.

**---Setting range---**

1 to 999

### **【#7242】 G[05] Type**

Set the macro call out type.

- 0: M98 P △△△△ ; and equivalent value call
- 1: G65 P △△△△ ; and equivalent value call
- 2: G66 P △△△△ ; and equivalent value call
- 3: G66.1 P △△△△ ; and equivalent value call
- others: M98 P △△△△ ; and equivalent value call

### **【#7243】 G[05] Program No.**

Set the No. of the program or file name to be called out. The file name can contain up to 32 characters.

**---Setting range---**

Program name or file name (up to 32 characters)

### **【#7251】 G[06] Code**

Set the G code to be used when calling the macro with a G command.  
Do not set a G code used in the system.

**---Setting range---**

1 to 999

### **【#7252】 G[06] Type**

Set the macro call out type.

- 0: M98 P △△△△ ; and equivalent value call
- 1: G65 P △△△△ ; and equivalent value call
- 2: G66 P △△△△ ; and equivalent value call
- 3: G66.1 P △△△△ ; and equivalent value call
- others: M98 P △△△△ ; and equivalent value call

### **【#7253】 G[06] Program No.**

Set the No. of the program or file name to be called out. The file name can contain up to 32 characters.

**---Setting range---**

Program name or file name (up to 32 characters)

### **【#7261】 G[07] Code**

Set the G code to be used when calling the macro with a G command.  
Do not set a G code used in the system.

**---Setting range---**

1 to 999

### **【#7262】 G[07] Type**

Set the macro call out type.

- 0: M98 P △△△△ ; and equivalent value call
- 1: G65 P △△△△ ; and equivalent value call
- 2: G66 P △△△△ ; and equivalent value call
- 3: G66.1 P △△△△ ; and equivalent value call
- others: M98 P △△△△ ; and equivalent value call

### **【#7263】 G[07] Program No.**

Set the No. of the program or file name to be called out. The file name can contain up to 32 characters.

**---Setting range---**

Program name or file name (up to 32 characters)

**【#7271】 G[08] Code**

Set the G code to be used when calling the macro with a G command.  
Do not set a G code used in the system.

**---Setting range---**  
1 to 999

**【#7272】 G[08] Type**

Set the macro call out type.

0: M98 P △△△△ ; and equivalent value call  
1: G65 P △△△△ ; and equivalent value call  
2: G66 P △△△△ ; and equivalent value call  
3: G66.1 P △△△△ ; and equivalent value call  
others: M98 P △△△△ ; and equivalent value call

**【#7273】 G[08] Program No.**

Set the No. of the program or file name to be called out. The file name can contain up to 32 characters.

**---Setting range---**  
Program name or file name (up to 32 characters)

**【#7281】 G[09] Code**

Set the G code to be used when calling the macro with a G command.  
Do not set a G code used in the system.

**---Setting range---**  
1 to 999

**【#7282】 G[09] Type**

Set the macro call out type.

0: M98 P △△△△ ; and equivalent value call  
1: G65 P △△△△ ; and equivalent value call  
2: G66 P △△△△ ; and equivalent value call  
3: G66.1 P △△△△ ; and equivalent value call  
others: M98 P △△△△ ; and equivalent value call

**【#7283】 G[09] Program No.**

Set the No. of the program or file name to be called out. The file name can contain up to 32 characters.

**---Setting range---**  
Program name or file name (up to 32 characters)

**【#7291】 G[10] Code**

Set the G code to be used when calling the macro with a G command.  
Do not set a G code used in the system.

**---Setting range---**  
1 to 999

**【#7292】 G[10] Type**

Set the macro call out type.

0: M98 P △△△△ ; and equivalent value call  
1: G65 P △△△△ ; and equivalent value call  
2: G66 P △△△△ ; and equivalent value call  
3: G66.1 P △△△△ ; and equivalent value call  
others: M98 P △△△△ ; and equivalent value call



## Appendix 1 Explanation of Parameters

### 【#7293】 G[10] Program No.

Set the No. of the program or file name to be called out. The file name can contain up to 32 characters.

**---Setting range---**

Program name or file name (up to 32 characters)

### 【#7302】 Smac Type

Set the type for when calling the macro with an S command.  
This is valid when "#1196 Smac" is set to "1".

- 0: M98 P △△△△ ; and equivalent value call
- 1: G65 P △△△△ ; and equivalent value call
- 2: G66 P △△△△ ; and equivalent value call
- 3: G66.1 P △△△△ ; and equivalent value call
- others: M98 P △△△△ ; and equivalent value call

### 【#7303】 Smac Program No.

Set the program No. for when calling the macro with an S command.  
This is valid when "#1196 Smac" is set to "1".  
Set the No. of the program or file name to be called out. The file name can contain up to 32 characters.

**---Setting range---**

Program name or file name (up to 32 characters)

### 【#7312】 Tmac Type

Set the type for when calling the macro with a T command.  
This is valid when "#1197 Tmac" is set to "1".

- 0: M98 P △△△△ ; and equivalent value call
- 1: G65 P △△△△ ; and equivalent value call
- 2: G66 P △△△△ ; and equivalent value call
- 3: G66.1 P △△△△ ; and equivalent value call
- others: M98 P △△△△ ; and equivalent value call

### 【#7313】 Tmac Program No.

Set the program No. for when calling the macro with a T command.  
This is valid when "#1197 Tmac" is set to "1".  
Set the No. of the program or file name to be called out. The file name can contain up to 32 characters.

**---Setting range---**

Program name or file name (up to 32 characters)

### 【#7401】 ASCII[01] Valid

The ASCII code macro parameters (#7402 to 7405) are validated.  
0: Invalid  
1: Valid

### 【#7402】 ASCII[01] Code

Set the ASCII code used to call macros with the ASCII code.  
L system: A,B,D,F,H,I,J,K,M,Q,R,S,T  
M system: A,B,F,H,I,K,M,Q,R,S,T

### 【#7403】 ASCII[01] Type

Set the macro call type.  
0: M98  
1: G65  
2: G66  
3: G66.1

**【#7404】 ASCII[01] Program No.**

Set the program No. called with macro call.

**---Setting range---**

Program name or file name (up to 32 characters)

**【#7405】 ASCII[01] Variable**

When the call type is "0", set the variable No. set after the ASCII code.

**---Setting range---**

100 to 149

**【#7411】 ASCII[02] Valid**

The ASCII code macro parameters (#7412 to 7415) are validated.

0: Invalid

1: Valid

**【#7412】 ASCII[02] Code**

Set the ASCII code used to call macros with the ASCII code.

L system: A,B,D,F,H,I,J,K,M,Q,R,S,T

M system: A,B,F,H,I,K,M,Q,R,S,T

**【#7413】 ASCII[02] Type**

Set the macro call type.

0: M98

1: G65

2: G66

3: G66.1

**【#7414】 ASCII[02] Program No.**

Set the program No. called with macro call.

**---Setting range---**

Program name or file name (up to 32 characters)

**【#7415】 ASCII[02] Variable**

When the call type is "0", set the variable No. set after the ASCII code.

**---Setting range---**

100 to 149

## Appendix 1.10 Position Switches

### 【#7500】 Pcheck High-speed switching of position switch

Specify whether to perform position switch area checking at high speeds.

0: Do not perform position switch area checking at high speed (do it the same as before).

1: Perform position switch area checking at high speed.

### 【#7501】 PSW1 axis Axis name

Specify the name of the axis for which a position switch is provided.

---Setting range---

X, Y, Z, U, V, W, A, B, or C axis address

### 【#7502】 PSW1 dog1 Imaginary dog position 1

When the machine enters the range between imaginary dog positions 1 and 2, a signal is output to the PLC.

1st part system device: X1D00

2nd part system device: X1D20

---Setting range---

-99999.999 to 99999.999 (mm)

### 【#7503】 PSW1 dog2 Imaginary dog position 2

When the machine enters the range between imaginary dog positions 1 and 2, a signal is output to the PLC.

1st part system device: X1D00

2nd part system device: X1D20

---Setting range---

-99999.999 to 99999.999 (mm)

### 【#7504】 PSW1 check Selection of area check method

When position switch area checking at high speed is selected, specify the mode of area checking, i.e., whether to use the command type machine position or detector feedback position, for each position switch point.

0: Use the command type machine position as the machine position for position switch area checking.

1: Use the detector feedback position as the machine position for position switch area checking.

(Note) This parameter is valid only when "1" set in "#7500 Pcheck".

### 【#7511】 PSW2 axis Axis name

Specify the name of the axis for which a position switch is provided.

---Setting range---

X, Y, Z, U, V, W, A, B, or C axis address

### 【#7512】 PSW2 dog1 Imaginary dog position 1

When the machine enters the range between imaginary dog positions 1 and 2, a signal is output to the PLC.

1st part system device: X1D01

2nd part system device: X1D21

---Setting range---

-99999.999 to 99999.999 (mm)

#### **【#7513】 PSW2 dog2 Imaginary dog position 2**

When the machine enters the range between imaginary dog positions 1 and 2, a signal is output to the PLC.

1st part system device: X1D01

2nd part system device: X1D21

##### **---Setting range---**

-99999.999 to 99999.999 (mm)

#### **【#7514】 PSW2 check Selection of area check method**

When position switch area checking at high speed is selected, specify the mode of area checking, i.e., whether to use the command type machine position or detector feedback position, for each position switch point.

0: Use the command type machine position as the machine position for position switch area checking.

1: Use the detector feedback position as the machine position for position switch area checking.

(Note) This parameter is valid only when "1" set in "#7500 Pcheck".

#### **【#7521】 PSW3 axis Axis name**

Specify the name of the axis for which a position switch is provided.

##### **---Setting range---**

X, Y, Z, U, V, W, A, B, or C axis address

#### **【#7522】 PSW3 dog1 Imaginary dog position 1**

When the machine enters the range between imaginary dog positions 1 and 2, a signal is output to the PLC.

1st part system device: X1D02

2nd part system device: X1D22

##### **---Setting range---**

-99999.999 to 99999.999 (mm)

#### **【#7523】 PSW3 dog2 Imaginary dog position 2**

When the machine enters the range between imaginary dog positions 1 and 2, a signal is output to the PLC.

1st part system device: X1D02

2nd part system device: X1D22

##### **---Setting range---**

-99999.999 to 99999.999 (mm)

#### **【#7524】 PSW3 check Selection of area check method**

When position switch area checking at high speed is selected, specify the mode of area checking, i.e., whether to use the command type machine position or detector feedback position, for each position switch point.

0: Use the command type machine position as the machine position for position switch area checking.

1: Use the detector feedback position as the machine position for position switch area checking.

(Note) This parameter is valid only when "1" set in "#7500 Pcheck".

#### **【#7531】 PSW4 axis Axis name**

Specify the name of the axis for which a position switch is provided.

##### **---Setting range---**

X, Y, Z, U, V, W, A, B, or C axis address

**【#7532】 PSW4 dog1 Imaginary dog position 1**

When the machine enters the range between imaginary dog positions 1 and 2, a signal is output to the PLC.

1st part system device: X1D03

2nd part system device: X1D23

**---Setting range---**

-99999.999 to 99999.999 (mm)

**【#7533】 PSW4 dog2 Imaginary dog position 2**

When the machine enters the range between imaginary dog positions 1 and 2, a signal is output to the PLC.

1st part system device: X1D03

2nd part system device: X1D23

**---Setting range---**

-99999.999 to 99999.999 (mm)

**【#7534】 PSW4 check Selection of area check method**

When position switch area checking at high speed is selected, specify the mode of area checking, i.e., whether to use the command type machine position or detector feedback position, for each position switch point.

0: Use the command type machine position as the machine position for position switch area checking.

1: Use the detector feedback position as the machine position for position switch area checking.

(Note) This parameter is valid only when "1" set in "#7500 Pcheck".

**【#7541】 PSW5 axis Axis name**

Specify the name of the axis for which a position switch is provided.

**---Setting range---**

X, Y, Z, U, V, W, A, B, or C axis address

**【#7542】 PSW5 dog1 Imaginary dog position 1**

When the machine enters the range between imaginary dog positions 1 and 2, a signal is output to the PLC.

1st part system device: X1D04

2nd part system device: X1D24

**---Setting range---**

-99999.999 to 99999.999 (mm)

**【#7543】 PSW5 dog2 Imaginary dog position 2**

When the machine enters the range between imaginary dog positions 1 and 2, a signal is output to the PLC.

1st part system device: X1D04

2nd part system device: X1D24

**---Setting range---**

-99999.999 to 99999.999 (mm)

**【#7544】 PSW5 check Selection of area check method**

When position switch area checking at high speed is selected, specify the mode of area checking, i.e., whether to use the command type machine position or detector feedback position, for each position switch point.

0: Use the command type machine position as the machine position for position switch area checking.

1: Use the detector feedback position as the machine position for position switch area checking.

(Note) This parameter is valid only when "1" set in "#7500 Pcheck".

#### **【#7551】 PSW6 axis Axis name**

Specify the name of the axis for which a position switch is provided.

**---Setting range---**

X, Y, Z, U, V, W, A, B, or C axis address

#### **【#7552】 PSW6 dog1 Imaginary dog position 1**

When the machine enters the range between imaginary dog positions 1 and 2, a signal is output to the PLC.

1st part system device: X1D05

2nd part system device: X1D25

**---Setting range---**

-99999.999 to 99999.999 (mm)

#### **【#7553】 PSW6 dog2 Imaginary dog position 2**

When the machine enters the range between imaginary dog positions 1 and 2, a signal is output to the PLC.

1st part system device: X1D05

2nd part system device: X1D25

**---Setting range---**

-99999.999 to 99999.999 (mm)

#### **【#7554】 PSW6 check Selection of area check method**

When position switch area checking at high speed is selected, specify the mode of area checking, i.e., whether to use the command type machine position or detector feedback position, for each position switch point.

0: Use the command type machine position as the machine position for position switch area checking.

1: Use the detector feedback position as the machine position for position switch area checking.

(Note) This parameter is valid only when "1" set in "#7500 Pcheck".

#### **【#7561】 PSW7 axis Axis name**

Specify the name of the axis for which a position switch is provided.

**---Setting range---**

X, Y, Z, U, V, W, A, B, or C axis address

#### **【#7562】 PSW7 dog1 Imaginary dog position 1**

When the machine enters the range between imaginary dog positions 1 and 2, a signal is output to the PLC.

1st part system device: X1D06

2nd part system device: X1D26

**---Setting range---**

-99999.999 to 99999.999 (mm)

#### **【#7563】 PSW7 dog2 Imaginary dog position 2**

When the machine enters the range between imaginary dog positions 1 and 2, a signal is output to the PLC.

1st part system device: X1D06

2nd part system device: X1D26

**---Setting range---**

-99999.999 to 99999.999 (mm)

**【#7564】 PSW7 check Selection of area check method**

When position switch area checking at high speed is selected, specify the mode of area checking, i.e., whether to use the command type machine position or detector feedback position, for each position switch point.

- 0: Use the command type machine position as the machine position for position switch area checking.
- 1: Use the detector feedback position as the machine position for position switch area checking.

(Note) This parameter is valid only when "1" set in "#7500 Pcheck".

**【#7571】 PSW8 axis Axis name**

Specify the name of the axis for which a position switch is provided.

**---Setting range---**

X, Y, Z, U, V, W, A, B, or C axis address

**【#7572】 PSW8 dog1 Imaginary dog position 1**

When the machine enters the range between imaginary dog positions 1 and 2, a signal is output to the PLC.

1st part system device: X1D07

2nd part system device: X1D27

**---Setting range---**

-99999.999 to 99999.999 (mm)

**【#7573】 PSW8 dog2 Imaginary dog position 2**

When the machine enters the range between imaginary dog positions 1 and 2, a signal is output to the PLC.

1st part system device: X1D07

2nd part system device: X1D27

**---Setting range---**

-99999.999 to 99999.999 (mm)

**【#7574】 PSW8 check Selection of area check method**

When position switch area checking at high speed is selected, specify the mode of area checking, i.e., whether to use the command type machine position or detector feedback position, for each position switch point.

- 0: Use the command type machine position as the machine position for position switch area checking.
- 1: Use the detector feedback position as the machine position for position switch area checking.

(Note) This parameter is valid only when "1" set in "#7500 Pcheck".

**【#7581】 PSW9 axis Axis name**

Specify the name of the axis for which a position switch is provided.

**---Setting range---**

X, Y, Z, U, V, W, A, B, or C axis address

**【#7582】 PSW9 dog1 Imaginary dog position 1**

When the machine enters the range between imaginary dog positions 1 and 2, a signal is output to the PLC.

1st part system device: X1D08

2nd part system device: X1D28

**---Setting range---**

-99999.999 to 99999.999 (mm)

#### 【#7583】 PSW9 dog2 Imaginary dog position 2

When the machine enters the range between imaginary dog positions 1 and 2, a signal is output to the PLC.

1st part system device: X1D08

2nd part system device: X1D28

##### ---Setting range---

-99999.999 to 99999.999 (mm)

#### 【#7584】 PSW9 check Selection of area check method

When position switch area checking at high speed is selected, specify the mode of area checking, i.e., whether to use the command type machine position or detector feedback position, for each position switch point.

0: Use the command type machine position as the machine position for position switch area checking.

1: Use the detector feedback position as the machine position for position switch area checking.

(Note) This parameter is valid only when "1" set in "#7500 Pcheck".

#### 【#7591】 PSW10 axis Axis name

Specify the name of the axis for which a position switch is provided.

##### ---Setting range---

X, Y, Z, U, V, W, A, B, or C axis address

#### 【#7592】 PSW10 dog1 Imaginary dog position 1

When the machine enters the range between imaginary dog positions 1 and 2, a signal is output to the PLC.

1st part system device: X1D09

2nd part system device: X1D29

##### ---Setting range---

-99999.999 to 99999.999 (mm)

#### 【#7593】 PSW10 dog2 Imaginary dog position 2

When the machine enters the range between imaginary dog positions 1 and 2, a signal is output to the PLC.

1st part system device: X1D09

2nd part system device: X1D29

##### ---Setting range---

-99999.999 to 99999.999 (mm)

#### 【#7594】 PSW10 check Selection of area check method

When position switch area checking at high speed is selected, specify the mode of area checking, i.e., whether to use the command type machine position or detector feedback position, for each position switch point.

0: Use the command type machine position as the machine position for position switch area checking.

1: Use the detector feedback position as the machine position for position switch area checking.

(Note) This parameter is valid only when "1" set in "#7500 Pcheck".

#### 【#7601】 PSW11 axis Axis name

Specify the name of the axis for which a position switch is provided.

##### ---Setting range---

X, Y, Z, U, V, W, A, B, or C axis address



**【#7602】 PSW11 dog1 Imaginary dog position 1**

When the machine enters the range between imaginary dog positions 1 and 2, a signal is output to the PLC.

1st part system device: X1D0A

2nd part system device: X1D2A

**---Setting range---**

-99999.999 to 99999.999 (mm)

**【#7603】 PSW11 dog2 Imaginary dog position 2**

When the machine enters the range between imaginary dog positions 1 and 2, a signal is output to the PLC.

1st part system device: X1D0A

2nd part system device: X1D2A

**---Setting range---**

-99999.999 to 99999.999 (mm)

**【#7604】 PSW11 check Selection of area check method**

When position switch area checking at high speed is selected, specify the mode of area checking, i.e., whether to use the command type machine position or detector feedback position, for each position switch point.

0: Use the command type machine position as the machine position for position switch area checking.

1: Use the detector feedback position as the machine position for position switch area checking.

(Note) This parameter is valid only when "1" set in "#7500 Pcheck".

**【#7611】 PSW12 axis Axis name**

Specify the name of the axis for which a position switch is provided.

**---Setting range---**

X, Y, Z, U, V, W, A, B, or C axis address

**【#7612】 PSW12 dog1 Imaginary dog position 1**

When the machine enters the range between imaginary dog positions 1 and 2, a signal is output to the PLC.

1st part system device: X1D0B

2nd part system device: X1D2B

**---Setting range---**

-99999.999 to 99999.999 (mm)

**【#7613】 PSW12 dog2 Imaginary dog position 2**

When the machine enters the range between imaginary dog positions 1 and 2, a signal is output to the PLC.

1st part system device: X1D0B

2nd part system device: X1D2B

**---Setting range---**

-99999.999 to 99999.999 (mm)

**【#7614】 PSW12 check Selection of area check method**

When position switch area checking at high speed is selected, specify the mode of area checking, i.e., whether to use the command type machine position or detector feedback position, for each position switch point.

0: Use the command type machine position as the machine position for position switch area checking.

1: Use the detector feedback position as the machine position for position switch area checking.

(Note) This parameter is valid only when "1" set in "#7500 Pcheck".

#### **【#7621】 PSW13 axis Axis name**

Specify the name of the axis for which a position switch is provided.

**---Setting range---**

X, Y, Z, U, V, W, A, B, or C axis address

#### **【#7622】 PSW13 dog1 Imaginary dog position 1**

When the machine enters the range between imaginary dog positions 1 and 2, a signal is output to the PLC.

1st part system device: X1D0C

2nd part system device: X1D2C

**---Setting range---**

-99999.999 to 99999.999 (mm)

#### **【#7623】 PSW13 dog2 Imaginary dog position 2**

When the machine enters the range between imaginary dog positions 1 and 2, a signal is output to the PLC.

1st part system device: X1D0C

2nd part system device: X1D2C

**---Setting range---**

-99999.999 to 99999.999 (mm)

#### **【#7624】 PSW13 check Selection of area check method**

When position switch area checking at high speed is selected, specify the mode of area checking, i.e., whether to use the command type machine position or detector feedback position, for each position switch point.

0: Use the command type machine position as the machine position for position switch area checking.

1: Use the detector feedback position as the machine position for position switch area checking.

(Note) This parameter is valid only when "1" set in "#7500 Pcheck".

#### **【#7631】 PSW14 axis Axis name**

Specify the name of the axis for which a position switch is provided.

**---Setting range---**

X, Y, Z, U, V, W, A, B, or C axis address

#### **【#7632】 PSW14 dog1 Imaginary dog position 1**

When the machine enters the range between imaginary dog positions 1 and 2, a signal is output to the PLC.

1st part system device: X1D0D

2nd part system device: X1D2D

**---Setting range---**

-99999.999 to 99999.999 (mm)

#### **【#7633】 PSW14 dog2 Imaginary dog position 2**

When the machine enters the range between imaginary dog positions 1 and 2, a signal is output to the PLC.

1st part system device: X1D0D

2nd part system device: X1D2D

**---Setting range---**

-99999.999 to 99999.999 (mm)

#### 【#7634】 PSW14 check Selection of area check method

When position switch area checking at high speed is selected, specify the mode of area checking, i.e., whether to use the command type machine position or detector feedback position, for each position switch point.

- 0: Use the command type machine position as the machine position for position switch area checking.
- 1: Use the detector feedback position as the machine position for position switch area checking.

(Note) This parameter is valid only when "1" set in "#7500 Pcheck".

#### 【#7641】 PSW15 axis Axis name

Specify the name of the axis for which a position switch is provided.

##### ---Setting range---

X, Y, Z, U, V, W, A, B, or C axis address

#### 【#7642】 PSW15 dog1 Imaginary dog position 1

When the machine enters the range between imaginary dog positions 1 and 2, a signal is output to the PLC.

1st part system device: X1D0E

2nd part system device: X1D2E

##### ---Setting range---

-99999.999 to 99999.999 (mm)

#### 【#7643】 PSW15 dog2 Imaginary dog position 2

When the machine enters the range between imaginary dog positions 1 and 2, a signal is output to the PLC.

1st part system device: X1D0E

2nd part system device: X1D2E

##### ---Setting range---

-99999.999 to 99999.999 (mm)

#### 【#7644】 PSW15 check Selection of area check method

When position switch area checking at high speed is selected, specify the mode of area checking, i.e., whether to use the command type machine position or detector feedback position, for each position switch point.

- 0: Use the command type machine position as the machine position for position switch area checking.
- 1: Use the detector feedback position as the machine position for position switch area checking.

(Note) This parameter is valid only when "1" set in "#7500 Pcheck".

#### 【#7651】 PSW16 axis Axis name

Specify the name of the axis for which a position switch is provided.

##### ---Setting range---

X, Y, Z, U, V, W, A, B, or C axis address

#### 【#7652】 PSW16 dog1 Imaginary dog position 1

When the machine enters the range between imaginary dog positions 1 and 2, a signal is output to the PLC.

1st part system device: X1D0F

2nd part system device: X1D2F

##### ---Setting range---

-99999.999 to 99999.999 (mm)

#### **【#7653】 PSW16 dog2 Imaginary dog position 2**

When the machine enters the range between imaginary dog positions 1 and 2, a signal is output to the PLC.

1st part system device: X1D0F  
2nd part system device: X1D2F

**---Setting range---**

-99999.999 to 99999.999 (mm)

#### **【#7654】 PSW16 check Selection of area check method**

When position switch area checking at high speed is selected, specify the mode of area checking, i.e., whether to use the command type machine position or detector feedback position, for each position switch point.

0: Use the command type machine position as the machine position for position switch area checking.

1: Use the detector feedback position as the machine position for position switch area checking.

(Note) This parameter is valid only when "1" set in "#7500 Pcheck".

#### **【#7661】 PSW17 axis Axis name**

Specify the name of the axis for which a position switch is provided.

**---Setting range---**

X, Y, Z, U, V, W, A, B, or C axis address

#### **【#7662】 PSW17 dog1 Imaginary dog position 1**

When the machine enters the range between imaginary dog positions 1 and 2, a signal is output to the PLC.

1st part system device: X1D10  
2nd part system device: X1D30

**---Setting range---**

-99999.999 to 99999.999 (mm)

#### **【#7663】 PSW17 dog2 Imaginary dog position 2**

When the machine enters the range between imaginary dog positions 1 and 2, a signal is output to the PLC.

1st part system device: X1D10  
2nd part system device: X1D30

**---Setting range---**

-99999.999 to 99999.999 (mm)

#### **【#7664】 PSW17 check Selection of area check method**

When position switch area checking at high speed is selected, specify the mode of area checking, i.e., whether to use the command type machine position or detector feedback position, for each position switch point.

0: Use the command type machine position as the machine position for position switch area checking.

1: Use the detector feedback position as the machine position for position switch area checking.

(Note) This parameter is valid only when "1" set in "#7500 Pcheck".

#### **【#7671】 PSW18 axis Axis name**

Specify the name of the axis for which a position switch is provided.

**---Setting range---**

X, Y, Z, U, V, W, A, B, or C axis address

**【#7672】 PSW18 dog1 Imaginary dog position 1**

When the machine enters the range between imaginary dog positions 1 and 2, a signal is output to the PLC.

1st part system device: X1D11

2nd part system device: X1D31

**---Setting range---**

-99999.999 to 99999.999 (mm)

**【#7673】 PSW18 dog2 Imaginary dog position 2**

When the machine enters the range between imaginary dog positions 1 and 2, a signal is output to the PLC.

1st part system device: X1D11

2nd part system device: X1D31

**---Setting range---**

-99999.999 to 99999.999 (mm)

**【#7674】 PSW18 check Selection of area check method**

When position switch area checking at high speed is selected, specify the mode of area checking, i.e., whether to use the command type machine position or detector feedback position, for each position switch point.

0: Use the command type machine position as the machine position for position switch area checking.

1: Use the detector feedback position as the machine position for position switch area checking.

(Note) This parameter is valid only when "1" set in "#7500 Pcheck".

**【#7681】 PSW19 axis Axis name**

Specify the name of the axis for which a position switch is provided.

**---Setting range---**

X, Y, Z, U, V, W, A, B, or C axis address

**【#7682】 PSW19 dog1 Imaginary dog position 1**

When the machine enters the range between imaginary dog positions 1 and 2, a signal is output to the PLC.

1st part system device: X1D12

2nd part system device: X1D32

**---Setting range---**

-99999.999 to 99999.999 (mm)

**【#7683】 PSW19 dog2 Imaginary dog position 2**

When the machine enters the range between imaginary dog positions 1 and 2, a signal is output to the PLC.

1st part system device: X1D12

2nd part system device: X1D32

**---Setting range---**

-99999.999 to 99999.999 (mm)

**【#7684】 PSW19 check Selection of area check method**

When position switch area checking at high speed is selected, specify the mode of area checking, i.e., whether to use the command type machine position or detector feedback position, for each position switch point.

0: Use the command type machine position as the machine position for position switch area checking.

1: Use the detector feedback position as the machine position for position switch area checking.

(Note) This parameter is valid only when "1" set in "#7500 Pcheck".

#### **【#7691】 PSW20 axis Axis name**

Specify the name of the axis for which a position switch is provided.

**---Setting range---**

X, Y, Z, U, V, W, A, B, or C axis address

#### **【#7692】 PSW20 dog1 Imaginary dog position 1**

When the machine enters the range between imaginary dog positions 1 and 2, a signal is output to the PLC.

1st part system device: X1D13

2nd part system device: X1D33

**---Setting range---**

-99999.999 to 99999.999 (mm)

#### **【#7693】 PSW20 dog2 Imaginary dog position 2**

When the machine enters the range between imaginary dog positions 1 and 2, a signal is output to the PLC.

1st part system device: X1D13

2nd part system device: X1D33

**---Setting range---**

-99999.999 to 99999.999 (mm)

#### **【#7694】 PSW20 check Selection of area check method**

When position switch area checking at high speed is selected, specify the mode of area checking, i.e., whether to use the command type machine position or detector feedback position, for each position switch point.

0: Use the command type machine position as the machine position for position switch area checking.

1: Use the detector feedback position as the machine position for position switch area checking.

(Note) This parameter is valid only when "1" set in "#7500 Pcheck".

#### **【#7701】 PSW21 axis Axis name**

Specify the name of the axis for which a position switch is provided.

**---Setting range---**

X, Y, Z, U, V, W, A, B, or C axis address

#### **【#7702】 PSW21 dog1 Imaginary dog position 1**

When the machine enters the range between imaginary dog positions 1 and 2, a signal is output to the PLC.

1st part system device: X1D14

2nd part system device: X1D34

**---Setting range---**

-99999.999 to 99999.999 (mm)

#### **【#7703】 PSW21 dog2 Imaginary dog position 2**

When the machine enters the range between imaginary dog positions 1 and 2, a signal is output to the PLC.

1st part system device: X1D14

2nd part system device: X1D34

**---Setting range---**

-99999.999 to 99999.999 (mm)

#### 【#7704】 PSW21 check Selection of area check method

When position switch area checking at high speed is selected, specify the mode of area checking, i.e., whether to use the command type machine position or detector feedback position, for each position switch point.

0: Use the command type machine position as the machine position for position switch area checking.

1: Use the detector feedback position as the machine position for position switch area checking.

(Note) This parameter is valid only when "1" set in "#7500 Pcheck".

#### 【#7711】 PSW22 axis Axis name

Specify the name of the axis for which a position switch is provided.

---Setting range---

X, Y, Z, U, V, W, A, B, or C axis address

#### 【#7712】 PSW22 dog1 Imaginary dog position 1

When the machine enters the range between imaginary dog positions 1 and 2, a signal is output to the PLC.

1st part system device: X1D15

2nd part system device: X1D35

---Setting range---

-99999.999 to 99999.999 (mm)

#### 【#7713】 PSW22 dog2 Imaginary dog position 2

When the machine enters the range between imaginary dog positions 1 and 2, a signal is output to the PLC.

1st part system device: X1D15

2nd part system device: X1D35

---Setting range---

-99999.999 to 99999.999 (mm)

#### 【#7714】 PSW22 check Selection of area check method

When position switch area checking at high speed is selected, specify the mode of area checking, i.e., whether to use the command type machine position or detector feedback position, for each position switch point.

0: Use the command type machine position as the machine position for position switch area checking.

1: Use the detector feedback position as the machine position for position switch area checking.

(Note) This parameter is valid only when "1" set in "#7500 Pcheck".

#### 【#7721】 PSW23 axis Axis name

Specify the name of the axis for which a position switch is provided.

---Setting range---

X, Y, Z, U, V, W, A, B, or C axis address

#### 【#7722】 PSW23 dog1 Imaginary dog position 1

When the machine enters the range between imaginary dog positions 1 and 2, a signal is output to the PLC.

1st part system device: X1D16

2nd part system device: X1D36

---Setting range---

-99999.999 to 99999.999 (mm)

### 【#7723】 PSW23 dog2 Imaginary dog position 2

When the machine enters the range between imaginary dog positions 1 and 2, a signal is output to the PLC.

1st part system device: X1D16

2nd part system device: X1D36

#### ---Setting range---

-99999.999 to 99999.999 (mm)

### 【#7724】 PSW23 check Selection of area check method

When position switch area checking at high speed is selected, specify the mode of area checking, i.e., whether to use the command type machine position or detector feedback position, for each position switch point.

0: Use the command type machine position as the machine position for position switch area checking.

1: Use the detector feedback position as the machine position for position switch area checking.

(Note) This parameter is valid only when "1" set in "#7500 Pcheck".

### 【#7731】 PSW24 axis Axis name

Specify the name of the axis for which a position switch is provided.

#### ---Setting range---

X, Y, Z, U, V, W, A, B, or C axis address

### 【#7732】 PSW24 dog1 Imaginary dog position 1

When the machine enters the range between imaginary dog positions 1 and 2, a signal is output to the PLC.

1st part system device: X1D17

2nd part system device: X1D37

#### ---Setting range---

-99999.999 to 99999.999 (mm)

### 【#7733】 PSW24 dog2 Imaginary dog position 2

When the machine enters the range between imaginary dog positions 1 and 2, a signal is output to the PLC.

1st part system device: X1D17

2nd part system device: X1D37

#### ---Setting range---

-99999.999 to 99999.999 (mm)

### 【#7734】 PSW24 check Selection of area check method

When position switch area checking at high speed is selected, specify the mode of area checking, i.e., whether to use the command type machine position or detector feedback position, for each position switch point.

0: Use the command type machine position as the machine position for position switch area checking.

1: Use the detector feedback position as the machine position for position switch area checking.

(Note) This parameter is valid only when "1" set in "#7500 Pcheck".



## Appendix 1.11 Open Parameters

### **【#29001】 Open param 1**

Set LONG data.

#29001 to #29896 are used as parameter range where C language modules can be used arbitrarily.

**---Setting range---**

-

### **【#29901】 Open param 2**

Set DOUBLE data.

#29901 to #29996 are used as parameter range where C language modules can be used arbitrarily.

**---Setting range---**

-

## Appendix 1.12 Device Open Parameters

### **【#40001-40100】 Device Open Parameters**

<Data typ>

Set the data format (BYTE, WORD, DWORD, WORD(BIT)) of the assignment area.

0:WORD

1:DWORD

2:BYTE

3:WORD(BIT)

<Data no>

Set the number of data in the assignment area. The number to be designated varies depending on the unit designated by the data format.

0 to 3000

(Depends on the device assignment and data format.)

<Disp typ>

Designate the status of data display format, display restrictions and input protection.

#### **bit0: Cancellation of protection for input**

Select whether to check the input protection for the data protection key 2 on the group details screen.

(Note) The name of data protection key differs between machine tool builders. Refer to manuals issued by each machine tool builder for details.

0: Check

1: Not check

#### **bit1: Cancellation of restriction on display**

Select whether to display the group details screen even when a machine tool builder password is not entered.

0: Not display

1: Display

#### **bit4: BCD format**

Display the data of the group details screen in BCD format.

0: Invalid

1: Valid

#### **bit5: BIT format**

Display the data of the group details screen in BIT format.

0: Invalid

1: Valid

#### **bit6: HEX format (Hexadecimal format)**

Display the data of the group details screen in HEX format.

0: Invalid

1: Valid

#### **bit7: Sign (Decimal format only)**

Select whether to display the data of the group details screen in a decimal format with/without a sign.

0: With sign

1: Without sign

## Appendix 1.13 SRAM Open Parameters

### 【#41001-41100】 SRAM Open Parameters

<Data typ>

Set the data type (CHAR, SHORT, LONG, DOUBLE) of the assignment area.

- 1: CHAR
- 2: SHORT
- 3: LONG
- 4: DOUBLE

<Data no>

Set the number of data in the assignment area. The number to be designated varies depending on the unit and free area designated by the data format.

0 to 9999999

(Depends on the data format and free area)

<Disp typ>

Designate the status of data display format, display restrictions and input protection.

#### bit0: Cancellation of protection for input

Select whether to check the input protection on data protection key 2 on the group details screen.

(Note) The name of data protection key differs between machine tool builders. Refer to manuals issued by each machine tool builder for details.

- 0: Check
- 1: Not check

#### bit1: Cancellation of restriction on display

Select whether to display the group details screen even when a machine tool builder password is not entered.

- 0: Not display
- 1: Display

#### bit4: BCD format

Display the data of the group details screen in BCD format.

- 0: Invalid
- 1: Valid

#### bit5: BIT format

Display the data of the group details screen in BIT format.

- 0: Invalid
- 1: Valid

#### bit6: HEX format (Hexadecimal format)

Display the data of the group details screen in HEX format.

- 0: Invalid
- 1: Valid

#### bit7: Sign (Decimal format only)

Select whether to display the data of the group details screen in a decimal format with/without a sign.

- 0: With sign
- 1: Without sign

## Appendix 1.14 CC-Link Parameters

### 【#24001+40(n-1)(PR)】 SLn station No. CC-Link station No.

Set the station No. of the CC-Link I/F unit.  
"n" represents the expansion slot No.(n=1 to 3)  
-1: Invalid  
0: Master station  
1 to 64: Slave station  
---Master station---  
Set a value within the setting range.  
---Local/standby master station---  
Set a value within the setting range.

---Setting range---  
-1 to 64

### 【#24002+40(n-1)(PR)】 SLn line-spd&Mode CC-Link transmission rate and mode

Select the transmission rate and operation mode of the CC-Link I/F unit.  
"n" represents the expansion slot No.(n=1 to 3)  
<Online mode>  
0 : 156Kbps  
1 : 625Kbps  
2 : 2.5Mbps  
3 : 5Mbps  
4 : 10M  
<Circuit test mode>  
5 : 156Kbps  
6 : 625Kbps  
7 : 2.5Mbps  
8 : 5Mbps  
9 : 10Mbps  
<Hardware test mode>  
10 : 156Kbps  
11 : 625Kbps  
12 : 2.5Mbps  
13 : 5Mbps  
14 : 10Mbps

(Note) Perform hardware test after removing the CC-Link cable.  
---Master station---  
Set a value within the setting range.  
---Local/standby master station---  
Set a value within the setting range.

---Setting range---  
0 to 14

### 【#24003+40(n-1)(PR)】 SLn set fault sta Setting of data link faulty station

Select whether to clear or hold the data input from the data link faulty station.  
"n" represents the expansion slot No.(n=1 to 3)  
0: Clear  
1: Hold

(Note) Refer to "CC-Link System Master/Local Module User's Manual (SH(NA)-080394E-E)" for the details of the functions.  
---Master station---  
Set to "0" or "1".  
---Local/standby master station---  
Set to "0" or "1".

## [#24004+40(n-1)] SLn PLC stop set Setting at PLC STOP

Set whether to refresh or compulsorily clear the slave stations at PLC STOP.

"n" represents the expansion slot No.(n=1 to 3)

0: Refresh

1: Compulsorily clear

(Note) Refer to "CC-Link System Master/Local Module User's Manual (SH(NA)-080394E-E)" for the details of the functions.

---Master station---

Set to "0" or "1".

---Local/standby master station---

Set to "0" or "1".

## [#24005+40(n-1)(PR)] SLn occ stations Number of occupied stations

Set the number of occupied local and standby master stations.

"n" represents the expansion slot No.(n=1 to 3)

---Master station---

Set to "0".

---Local/standby master station---

Set to either of "1" to "4".

---Setting range---

0 to 4

## [#24006+40(n-1)(PR)] SLn extended cyc Extended cyclic setting

Set the magnification for the extended cyclic operation of the local station whose type corresponds to Ver.2.

"n" represents the expansion slot No.(n=1 to 3)

Set "1" for the local station whose type corresponds to Ver.1.

This function is out of specifications when the protocol version is Ver.1. The setting for the local station is fixed to "1".

---Master station---

Set to "0".

---Local/standby master station---

Set to either of "1", "2", "4" or "8".

---Setting range---

0,1,2,4,8 (fold)

## [#24007+40(n-1)] SLn conn modules Number of connected modules

Set the total number of remote stations, local stations, intelligent device stations, standby master station and reserved stations connected to the master station.

"n" represents the expansion slot No.(n=1 to 3)

---Master station---

Set to either of "1" to "64".

---Local/standby master station---

Set to "0".

---Setting range---

0 to 64 (modules)

## [#24008+40(n-1)] SLn num of retries Number of retries

Set the number of retries for when a communication error occurs.

"n" represents the expansion slot No.(n=1 to 3)

---Master station---

Set to either of "1" or "7".

---Local/standby master station---

Set to "0".

---Setting range---

0 to 7 (times)

### 【#24009+40(n-1)】 SLn auto ret mdls Number of automatic return modules

Set the total number of remote stations, local stations, intelligent device stations and standby master station that can be returned to system operation by a single link scan.  
"n" represents the expansion slot No.(n=1 to 3)

(Note) Refer to "CC-Link System Master/Local Module User's Manual (SH(NA)-080394E-E)" for the details of the functions.

---Master station---  
Set to either of "1" or "10".  
---Local/standby master station---  
Set to "0".

---Setting range---  
0 to 10 (modules)

### 【#24010+40(n-1)(PR)】 SLn STBY master st Standby master station

Set the station No. of the standby master station.  
"n" represents the expansion slot No.(n=1 to 3)  
Set "0" when no standby master station is provided.

---Master station---  
Set a value within the setting range.  
---Local/standby master station---  
Set "0" (fixed) for the local station.  
Set "1" (fixed) for the standby station.

---Setting range---  
0 to 64

### 【#24011+40(n-1)】 SLn ope at NC down Operation at NC down

Set the data link status for when the master station failure occurs.  
"n" represents the expansion slot No.(n=1 to 3)  
0: Fixed to stop

(Note) Refer to "CC-Link System Master/Local Module User's Manual (SH(NA)-080394E-E)" for the details of the functions.

---Master station---  
Set to "0" (fixed).  
---Local/standby master station---  
Set to "0".

### 【#24012+40(n-1)】 SLn scan mode Scan mode

Select whether to synchronize the link scan with one ladder scan.  
"n" represents the expansion slot No.(n=1 to 3)  
0: Fixed to synchronize

---Master station---  
Set to "0" (fixed).  
---Local/standby master station---  
Set to "0".

### 【#24013+40(n-1)】 SLn delay time Delay time

Set the delay time.  
"n" represents the expansion slot No.(n=1 to 3)  
0: (Fixed value)

---Master station---  
Set to "0" (fixed).  
---Local/standby master station---  
Set to "0".

**【#24014+40(n-1)】 SLn RX dev name Remote input (RX) refresh device name**

Set the refresh device name of the remote input (RX) to be automatically refreshed.

(Example) X

"n" represents the expansion slot No.(n=1 to 3)

Set "0" when no setting is required.

---Master station---

Set a value within the setting range.

---Local/standby master station---

Set a value within the setting range.

---Setting range---

0,X,M,L,B,D,W,R

**【#24015+40(n-1)】 SLn RX dev No. Remote input (RX) refresh device No.**

Set the refresh device No. of the remote input (RX) to be automatically refreshed.

"n" represents the expansion slot No.(n=1 to 3)

(Note 1) When setting parameters in ALL.PRM with using the parameter input/output function, input the device No. of decimal digit.

(Example) When setting "X400" for the remote input (RX) refresh device No., input as follows;

#24014+40(n-1): "X"

#24015+40(n-1): "1024"

(Note 2) When the refresh device name has been set, the refresh device No. will be "0".Confirm the refresh device No. after changing the refresh device name.

When specifying a bit device, set the address in increments of 16 points.

The operation will not be guaranteed unless the address is set in increments of 16 points.

(Example) 1000

---Master station---

Set a value within the setting range.

---Local/standby master station---

Set a value within the setting range.

---Setting range---

X: 0 to 5FF

M: 0 to 10239

L: 0 to 511

B: 0 to 1FFF

D: 0 to 2047

W: 0 to 1FFF

R: 8300 to 9799, 9800 to 9899

**【#24016+40(n-1)(PR)】 SLn RY dev name Remote output (RY) refresh device name**

Set the refresh device name of the remote output (RY) to be automatically refreshed.

(Example) Y

"n" represents the expansion slot No.(n=1 to 3)

Set "0" when no setting is required.

---Master station---

Set a value within the setting range.

---Local/standby master station---

Set a value within the setting range.

---Setting range---

0,Y,M,L,B,D,W,R

**【#24017+40(n-1)】 SLn RY dev No. Remote output (RY) refresh device No.**

Set the refresh device No. of the remote output (RY) to be automatically refreshed.  
"n" represents the expansion slot No.(n=1 to 3)

(Note 1) When setting parameters in ALL.PRM with using the parameter input/output function, input the device No. of decimal digit.

(Example) When setting "X400" for the remote input (RX) refresh device No., input as follows;  
#24014+40(n-1): "X" #24015+40(n-1): "1024"

(Note 2) When the refresh device name has been set, the refresh device No. will be "0".Confirm the refresh device No. after changing the refresh device name.

When specifying a bit device, set the address in increments of 16 points.

The operation will not be guaranteed unless the address is set in increments of 16 points.

(Example) 1000

---Master station---

Set a value within the setting range.

---Local/standby master station---

Set a value within the setting range.

**---Setting range---**

Y: 0 to 5FF

M: 0 to 10239

L: 0 to 511

B: 0 to 1FFF

D: 0 to 2047

W: 0 to 1FFF

R: 8300 to 9799, 9800 to 9899

**【#24018+40(n-1)】 SLn RWr dev name Remote register (RWr) refresh device name**

Set the refresh device name of the remote register (RWr) to be automatically refreshed.

(Example) W

"n" represents the expansion slot No.(n=1 to 3)

Set "0" when no setting is required.

---Master station---

Set a value within the setting range.

---Local/standby master station---

Set a value within the setting range.

**---Setting range---**

0,M,L,B,D,W,R



**【#24019+40(n-1)】 SLn RWr dev No. Remote register (RWr) refresh device No.**

Set the refresh device No. of the remote register (RWr) to be automatically refreshed.  
 "n" represents the expansion slot No.(n=1 to 3)

(Note 1) When setting parameters in ALL.PRM with using the parameter input/output function, input the device No. of decimal digit.

(Example) When setting "X400" for the remote input (RX) refresh device No., input as follows;  
 #24014+40(n-1): "X" #24015+40(n-1): "1024"

(Note 2) When the refresh device name has been set, the refresh device No. will be "0". Confirm the refresh device No. after changing the refresh device name.

When specifying a bit device, set the address in increments of 16 points.

The operation will not be guaranteed unless the address is set in increments of 16 points.

(Example) 1FF0

---Master station---

Set a value within the setting range.

---Local/standby master station---

Set a value within the setting range.

**---Setting range---**

M: 0 to 10239

L: 0 to 511

B: 0 to 1FFF

D: 0 to 2047

W: 0 to 1FFF

R: 8300 to 9799, 9800 to 9899

**【#24020+40(n-1)】 SLn RWw dev name Remote register (RWw) refresh device name**

Set the refresh device name of the remote register (RWw) to be automatically refreshed.

(Example) W

"n" represents the expansion slot No.(n=1 to 3)

Set "0" when no setting is required.

---Master station---

Set a value within the setting range.

---Local/standby master station---

Set a value within the setting range.

**---Setting range---**

0,M,L,B,D,W,R

**【#24021+40(n-1)】 SLn RWw dev No. Remote register (RWw) refresh device No.**

Set the refresh device No. of the remote register (RWw) to be automatically refreshed.  
"n" represents the expansion slot No.(n=1 to 3)

(Note 1) When setting parameters in ALL.PRM with using the parameter input/output function, input the device No. of decimal digit.

(Example) When setting "X400" for the remote input (RX) refresh device No., input as follows;  
#24014+40(n-1): "X" #24015+40(n-1): "1024"

(Note 2) When the refresh device name has been set, the refresh device No. will be "0".Confirm the refresh device No. after changing the refresh device name.

When specifying a bit device, set the address in increments of 16 points.

The operation will not be guaranteed unless the address is set in increments of 16 points.

(Example) 1FF0

---Master station---

Set a value within the setting range.

---Local/standby master station---

Set a value within the setting range.

**---Setting range---**

M: 0 to 10239

L: 0 to 511

B: 0 to 1FFF

D: 0 to 2047

W: 0 to 1FFF

R: 8300 to 9799, 9800 to 9899

**【#24022+40(n-1)】 SLn SB dev name Special relay (SB) refresh device name**

Set the refresh device name of the special relay (SB) to be automatically refreshed.

(Example) SB

"n" represents the expansion slot No.(n=1 to 3)

Set "0" when no setting is required.

---Master station---

Set a value within the setting range.

---Local/standby master station---

Set a value within the setting range.

**---Setting range---**

0,M,L,B,D,W,R,SB

**【#24023+40(n-1)】 SLn SB dev No. Special relay (SB) refresh device No.**

Set the refresh device No. of the special relay (SB) to be automatically refreshed.  
 "n" represents the expansion slot No.(n=1 to 3)

(Note 1) When setting parameters in ALL.PRM with using the parameter input/output function, input the device No. of decimal digit.

(Example) When setting "X400" for the remote input (RX) refresh device No., input as follows;  
 #24014+40(n-1): "X" #24015+40(n-1): "1024"

(Note 2) When the refresh device name has been set, the refresh device No. will be "0". Confirm the refresh device No. after changing the refresh device name.

When specifying a bit device, set the address in increments of 16 points.  
 The operation will not be guaranteed unless the address is set in increments of 16 points.

(Example) 1F0

---Master station---

Set a value within the setting range.

---Local/standby master station---

Set a value within the setting range.

**---Setting range---**

M: 0 to 10239

L: 0 to 511

B: 0 to 1FFF

D: 0 to 2047

W: 0 to 1FFF

SB: 0 to 1FF

R: 8300 to 9799, 9800 to 9899

**【#24024+40(n-1)】 SLn SW dev name Special relay (SW) refresh device name**

Set the refresh device name of the special relay (SW) to be automatically refreshed.  
 "n" represents the expansion slot No.(n=1 to 3)

(Example) SW

Set "0" when no setting is required.

---Master station---

Set a value within the setting range.

---Local/standby master station---

Set a value within the setting range.

**---Setting range---**

0,M,L,B,D,W,R,SW

### 【#24025+40(n-1)】 S<sub>L</sub>n SW dev No. Special relay (SW) refresh device No.

Set the refresh device No. of the special relay (SW) to be automatically refreshed.  
"n" represents the expansion slot No.(n=1 to 3)

(Note 1) When setting parameters in ALL.PRM with using the parameter input/output function, input the device No. of decimal digit.

(Example) When setting "X400" for the remote input (RX) refresh device No., input as follows;

#24014+40(n-1): "X"

#24015+40(n-1): "1024"

(Note 2) When the refresh device name has been set, the refresh device No. will be "0".Confirm the refresh device No. after changing the refresh device name.

When specifying a bit device, set the address in increments of 16 points.

(Example) 1F0

---Master station---

Set a value within the setting range.

---Local/standby master station---

Set a value within the setting range.

#### ---Setting range---

M: 0 to 10239

L: 0 to 511

B: 0 to 1FFF

D: 0 to 2047

W: 0 to 1FFF

SW: 0 to 1FF

R: 8300 to 9799, 9800 to 9899

### 【#24026+40(n-1)(PR)】 S<sub>L</sub>n Protocol Ver Protocol version

Select the CC-Link version mode that has been set to the slide switch SW1-2 on the CC-Link unit (HN566/HN567).

"n" represents the expansion slot No.(n=1 to 3)

0: Ver.2

1: Ver.1

Ver.2 mode has been set to SW1-2 as default.

---Master station---

Set to "0" or "1".

---Local/standby master station---

Set to "0" or "1".

### 【#24121+15(m-1)】 C<sub>N</sub>m station type Station type

Set the type of the connected remote station, local station, intelligent device station and standby master station.

0: No setting

1: Ver.1 remote I/O station

2: Ver.1 remote device station

3: Ver.1 intelligent device station

4: Ver.2 remote device station

5: Ver.2 intelligent device station

"m" means the m-th connected station in ascending order of station No. (m= 1 to 64)

---Master station---

Set to either of "0" to "5".

---Local/standby master station---

Set to "0".

**【#24122+15(m-1)】 CNm extended cyc Extended cyclic setting**

Select the magnification for the extended cycling operation of the connected remote, local and intelligent stations.

Set "1" when the protocol version is Ver.1.

Set "0" when no setting is required.

"m" means the m-th connected station in ascending order of station No. (m=1 to 64)

---Master station---

Set a value within the setting range.

---Local/standby master station---

Set to "0".

**---Setting range---**

0,1,2,4,8 (times)

**【#24123+15(m-1)】 CNm occ stations Number of occupied stations**

Set the number of the occupied stations by the connected remote, local and intelligent stations.

Set 1 for 8 points I/O and 16 points I/O.

Set "0" when no setting is required.

"m" means the m-th connected station in ascending order of station No. (m= 1 to 64)

---Master station---

Set a value within the setting range.

---Local/standby master station---

Set to "0".

**---Setting range---**

0 to 4 (stations occupied)

**【#24124+15(m-1)】 CNm station No. Station No.**

Set the station No. of the connected remote, local and intelligent stations.

Set "0" when no setting is required.

"m" means the m-th connected station in ascending order of station No. (m= 1 to 64)

---Master station---

Set a value within the setting range.

---Local/standby master station---

Set to "0".

**---Setting range---**

0 to 64

### 【#24125+15(m-1)】 CNm remote sta pt Remote station points

Select the number of points of the connected remote station.

"m" means the m-th connected station in ascending order of station No. (m= 1 to 64)

The details of setting values differ with each protocol version and station type.

Protocol: Ver.2 (station type: Ver.1, remote I/O station)

- 0: 0 point (reserved station)
- 1: 8 points
- 2: 8 points + 8 points reserved
- 3: 16 points
- 4: 32 points
- Setting 0 is valid only for the reserved station. When 0 is set for the other stations, the number of points will be 32.
- Set the value so that the total number of points of remote I/O stations connected in series will be multiple of 16.
- (Example 1) 2 units of 8 points I/O: Set "1" for each
- (Example 2) 3 units of 8 points I/O: Set "1" for the first and the second I/O, "2" for the third.

Protocol: Ver.2 (station type: Ver.1 except remote I/O station)

- 0: 0 point (reserved station)
- 1 to 4: Automatically calculated
- 0 point is valid only for the reserved station. When 0 is set for the other stations, the number of points will be automatically calculated.
- Unless 0 is set, the number of points will be automatically calculated with the number of occupied stations and the setting value of the extended cycling.

Protocol: Ver.1 (for all station types)

- 0 to 4: Automatically calculated
- 0 cannot be set even for the reserved station.
- Automatically calculated with the setting value of the number of occupied stations.
- Master station---
- Set a value corresponding to the protocol version and the station type.
- Local/standby master station---
- Set to "0".

### 【#24126+15(m-1)】 CNm set rsvd sta Reserved station

Set the reserved/error invalid station.

"m" means the m-th connected station in ascending order of station No. (m= 1 to 64)

- 0: No setting
- 1: Reserved station
- 2: Error invalid station

(Note) Refer to "CC-Link System Master/Local Module User's Manual (SH(NA)-080394E-E)" for the details of the functions.

- Master station---
- Set either of "0" to "2".
- Local/standby master station---
- Set to "0".

### 【#24131+15(m-1)】 CNm send size Send buffer size

Set the allocation of the buffer memory size to the local station, standby master station and intelligent device station when in transient transmission.

"m" means the m-th connected station in ascending order of station No. (m= 1 to 64)

Set "0" when no setting is required.

(Note) The total size of the send/receive buffers must be 4096 (words) or less.

- Master station---
- Set a value within the setting range.
- Local/standby master station---
- Set to "0".
- Setting range---
- 0, 64 to 4096 (words)

**【#24132+15(m-1)】 CNm receive size Receive buffer size**

Set the allocation of the buffer memory size to the local station, standby master station and intelligent device station when in transient transmission.

"m" means the m-th connected station in ascending order of station No. (m= 1 to 64)

Set "0" when no setting is required.

(Note) The total size of the send/receive buffers must be 4096 (words) or less.

---Master station---

Set a value within the setting range.

---Local/standby master station---

Set to "0".

**---Setting range---**

0, 64 to 4096 (words)

**【#24133+15(m-1)】 CNm auto bfr size Automatic update buffer size**

Set the allocation of the buffer memory size to the local station, standby master station and intelligent device station when in transient transmission.

"m" means the m-th connected station in ascending order of station No. (m= 1 to 64)

Set "0" when no setting is required.

---Master station---

Set a value within the setting range.

---Local/standby master station---

Set to "0".

**---Setting range---**

0, 128 to 4096 (words)

## Appendix 1.15 Anshin-net Parameters 2/ MTB-net Parameters 2

### 【#10901(PR)】 Modem tel num

Set the PHS modem's registered No. (telephone No.).  
 This is used for the authentication by the host.  
 A hyphen "-" can be used as a delimiting character.  
 This parameter is used as both Anshin-net parameter 2 and MTB-net parameter 2.

---Setting range---  
 Within 28 characters

### 【#10902(PR)】 Num dispatch call

Set a call No. to Call Center.  
 Enter from the area code for domestic calls.  
 Enter from the communication company No. for international calls.  
 A hyphen "-" can be used as a delimiting character.

---Setting range---  
 Within 28 characters

### 【#10903(PR)】 Num arrival call 1

Set the caller's No.: the other party's telephone No. that is used for INIT authentication.  
 Enter from the area code for domestic calls.  
 Enter from the communication company No. for international calls.  
 This is used to distinguish between received calls from Call Center and those from machine tool builder.  
 A hyphen "-" can be used as a delimiting character.

---Setting range---  
 Within 28 characters

### 【#10904(PR)】 Num arrival call 2

Set the caller's No.: the other party's telephone No. that is used for INIT authentication.  
 Enter from the area code for domestic calls.  
 Enter from the communication company No. for international calls.  
 This is used to distinguish between received calls from Call Center and those from machine tool builder.  
 A hyphen "-" can be used as a delimiting character.

---Setting range---  
 Within 28 characters

### 【#10905(PR)】 Num arrival call 3

Set the caller's No.: the other party's telephone No. that is used for INIT authentication.  
 Enter from the area code for domestic calls.  
 Enter from the communication company No. for international calls.  
 This is used to distinguish between received calls from Call Center and those from machine tool builder.  
 A hyphen "-" can be used as a delimiting character.

---Setting range---  
 Within 28 characters

### 【#10906(PR)】 Num arrival call 4

Set the caller's No.: the other party's telephone No. that is used for INIT authentication.  
 Enter from the area code for domestic calls.  
 Enter from the communication company No. for international calls.  
 This is used to distinguish between received calls from Call Center and those from machine tool builder.  
 A hyphen "-" can be used as a delimiting character.

---Setting range---  
 Within 28 characters



**【#10907(PR)】 Num arrival call 5**

Set the caller's No.: the other party's telephone No. that is used for INIT authentication.  
 Enter from the area code for domestic calls.  
 Enter from the communication company No. for international calls.  
 This is used to distinguish between received calls from Call Center and those from machine tool builder.  
 A hyphen "-" can be used as a delimiting character.

**---Setting range---**  
 Within 28 characters

**【#10908(PR)】 Num dispatch call**

Set a call No. to a machine tool builder.  
 Enter from the area code for domestic calls.  
 Enter from the communication company No. for international calls.  
 A hyphen "-" can be used as a delimiting character.

**---Setting range---**  
 Within 28 characters

**【#10909(PR)】 Num arrival call 1**

Set the caller's No.: the other party's telephone No. that is used for INIT authentication.  
 Enter from the area code for domestic calls.  
 Enter from the communication company No. for international calls.  
 This is used to distinguish between received calls from Call Center and those from machine tool builder.  
 A hyphen "-" can be used as a delimiting character.

**---Setting range---**  
 Within 28 characters

**【#10910(PR)】 Num arrival call 2**

Set the caller's No.: the other party's telephone No. that is used for INIT authentication.  
 Enter from the area code for domestic calls.  
 Enter from the communication company No. for international calls.  
 This is used to distinguish between received calls from Call Center and those from machine tool builder.  
 A hyphen "-" can be used as a delimiting character.

**---Setting range---**  
 Within 28 characters

**【#10911(PR)】 Num arrival call 3**

Set the caller's No.: the other party's telephone No. that is used for INIT authentication.  
 Enter from the area code for domestic calls.  
 Enter from the communication company No. for international calls.  
 This is used to distinguish between received calls from Call Center and those from machine tool builder.  
 A hyphen "-" can be used as a delimiting character.

**---Setting range---**  
 Within 28 characters

**【#10912(PR)】 Num arrival call 4**

Set the caller's No.: the other party's telephone No. that is used for INIT authentication.  
 Enter from the area code for domestic calls.  
 Enter from the communication company No. for international calls.  
 This is used to distinguish between received calls from Call Center and those from machine tool builder.  
 A hyphen "-" can be used as a delimiting character.

**---Setting range---**  
 Within 28 characters

**【#10913(PR)】 Num arrival call 5**

Set the caller's No.: the other party's telephone No. that is used for INIT authentication.  
 Enter from the area code for domestic calls.  
 Enter from the communication company No. for international calls.  
 This is used to distinguish between received calls from Call Center and those from machine tool builder.  
 A hyphen "-" can be used as a delimiting character.

**---Setting range---**

Within 28 characters

**【#10914】 Auto select anet**

Set whether to change to the Anshin-net screen when a call is automatically dispatched from the NC.  
 (Currently not used.)  
 0: Not change  
 1: Change

**【#10915】 Num retry**

Set the number of times to retry when a control command transmission error occurs.  
 Standard setting: 3

**---Setting range---**

0 to 255

**【#10916】 Command time out**

Set the timeout time for reception command standby.  
 Standard setting: 30 (s)

**---Setting range---**

0 to 65535 (s)

**【#10917】 Frequ of redial**

Set the number of times to redial.  
 Standard setting: 3  
 This parameter is used as both Anshin-net parameter 2 and MTB-net parameter 2.

**---Setting range---**

0 to 255

**【#10918】 Interval of redial**

Set the redial interval.  
 Standard setting: 100 (s)  
 This parameter is used as both Anshin-net parameter 2 and MTB-net parameter 2.

**---Setting range---**

0 to 65535 (s)

**【#10919(PR)】 Modem connect port**

Select the modem connection port.  
 1: Port 1  
 2: Port 2  
 This parameter is used as both Anshin-net parameter 2 and MTB-net parameter 2.

**【#10920】 Dial mode select**

Select the dialing method.  
 0: Fixed by modem (default)  
 1: Dial with tone (push) method  
 2: Dial with pulse (dial) method  
 This parameter is used as both Anshin-net parameter 2 and MTB-net parameter 2.

### 【#10921】 Call wait time

Set the call back waiting time.

Default value: 0

This parameter is used as both Anshin-net parameter 2 and MTB-net parameter 2.

#### ---Setting range---

0 to 90 (s)

### 【#10922】 Machine Num

Set the machine's serial number as information for the machine tool builder to recognize the machine. This parameter is supposed to be input by the machine tool builder (when shipping or when starting the machine tool builder network). If this is set to blank, the system cannot connect with remote diagnosis tool kit.

#### ---Setting range---

Within 15 characters (one-byte alphanumeric characters)

### 【#10951(PR)】 Condition kind 1

Set the condition (alarm or PLC signal) for the automatic notification of alarms.  
Set the alarm type for alarm, device (register) name for PLC signal.

<Alarm>

Operation alarm (Mxx)

Stop code (Txx)

Servo alarm (Sxx)

Spindle servo alarm (Sxx)

System alarm (Zxx)

Absolute position detection alarm (Zxx)

Emergency stop (EMG)

Auxiliary axis servo alarm (Sxx)

Auxiliary axis absolute position detection alarm (Zxx)

Auxiliary axis OP error (Mxx)

Auxiliary axis MCP alarm (Yxx)

Computer link error (Lxx)

Operation error (Exx)

User PLC alarm (PLxx)

<Device (register)>

1-bit data ... X,Y,U,W

16-bit data ... R

(Note 1) Set "0" to cancel (set blank for) any setting of #10951 to #10970, "Condition kind" 1 to 10 and "Condition num" 1 to 10. Input "00" when setting "0" for "Condition num". When either of "Condition kind" or "Condition num" is canceled, the condition will not be available for the automatic notification of alarms.

#### ---Setting range---

Within 5 characters

### 【#10952(PR)】 Condition num 1

Set the condition (alarm or PLC signal) for the automatic notification of alarms.  
Set the alarm No. for alarm, status value for PLC signal.

(Note) Set "0" to cancel (set blank for) any setting of #10951 to #10970, "Condition kind" 1 to 10 and "Condition num" 1 to 10. Input "00" to set "Condition num" to "0". When either of "Condition kind" or "Condition num" is canceled, the condition will not be available for the automatic notification of alarms.

#### ---Setting range---

Within 4 characters

**【#10953(PR)】 Condition kind 2**

Set the condition (alarm or PLC signal) for the automatic notification of alarms.  
Set the alarm type for alarm, device (register) name for PLC signal.

<Alarm>

Operation alarm (Mxx)

Stop code (Txx)

Servo alarm (Sxx)

Spindle servo alarm (Sxx)

System alarm (Zxx)

Absolute position detection alarm (Zxx)

Emergency stop (EMG)

Auxiliary axis servo alarm (Sxx)

Auxiliary axis absolute position detection alarm (Zxx)

Auxiliary axis OP error (Mxx)

Auxiliary axis MCP alarm (Yxx)

Computer link error (Lxx)

Operation error (Exx)

User PLC alarm (PLxx)

<Device (resister)>

1-bit data ... X,Y,U,W

16-bit data ... R

(Note) Set "0" to cancel (set blank for) any setting of #10951 to #10970, "Condition kind" 1 to 10 and "Condition num" 1 to 10. Input "00" to set "Condition num" to "0". When either of "Condition kind" or "Condition num" is canceled, the condition will not be available for the automatic notification of alarms.

**---Setting range---**

Within 5 characters

**【#10954(PR)】 Condition num 2**

Set the condition (alarm or PLC signal) for the automatic notification of alarms.  
Set the alarm No. for alarm, status value for PLC signal.

(Note) Set "0" to cancel (set blank for) any setting of #10951 to #10970, "Condition kind" 1 to 10 and "Condition num" 1 to 10. Input "00" to set "Condition num" to "0". When either of "Condition kind" or "Condition num" is canceled, the condition will not be available for the automatic notification of alarms.

**---Setting range---**

Within 4 characters

**【#10955(PR) Condition kind 3**

Set the condition (alarm or PLC signal) for the automatic notification of alarms.  
Set the alarm type for alarm, device (register) name for PLC signal.

<Alarm>  
Operation alarm (Mxx)  
Stop code (Txx)  
Servo alarm (Sxx)  
Spindle servo alarm (Sxx)  
System alarm (Zxx)  
Absolute position detection alarm (Zxx)  
Emergency stop (EMG)  
Auxiliary axis servo alarm (Sxx)  
Auxiliary axis absolute position detection alarm (Zxx)  
Auxiliary axis OP error (Mxx)  
Auxiliary axis MCP alarm (Yxx)  
Computer link error (Lxx)  
Operation error (Exx)  
User PLC alarm (PLxx)

<Device (register)>  
1-bit data ... X,Y,U,W  
16-bit data ... R

(Note) Set "0" to cancel (set blank for) any setting of #10951 to #10970, "Condition kind" 1 to 10 and "Condition num" 1 to 10. Input "00" to set "Condition num" to "0". When either of "Condition kind" or "Condition num" is canceled, the condition will not be available for the automatic notification of alarms.

---Setting range---  
Within 5 characters

**【#10956(PR) Condition num 3**

Set the condition (alarm or PLC signal) for the automatic notification of alarms.  
Set the alarm No. for alarm, status value for PLC signal.

(Note) Set "0" to cancel (set blank for) any setting of #10951 to #10970, "Condition kind" 1 to 10 and "Condition num" 1 to 10. Input "00" to set "Condition num" to "0". When either of "Condition kind" or "Condition num" is canceled, the condition will not be available for the automatic notification of alarms.

---Setting range---  
Within 4 characters

**【#10957(PR)】 Condition kind 4**

Set the condition (alarm or PLC signal) for the automatic notification of alarms.  
Set the alarm type for alarm, device (register) name for PLC signal.

<Alarm>

Operation alarm (Mxx)

Stop code (Txx)

Servo alarm (Sxx)

Spindle servo alarm (Sxx)

System alarm (Zxx)

Absolute position detection alarm (Zxx)

Emergency stop (EMG)

Auxiliary axis servo alarm (Sxx)

Auxiliary axis absolute position detection alarm (Zxx)

Auxiliary axis OP error (Mxx)

Auxiliary axis MCP alarm (Yxx)

Computer link error (Lxx)

Operation error (Exx)

User PLC alarm (PLxx)

<Device (resister)>

1-bit data ... X,Y,U,W

16-bit data ... R

(Note) Set "0" to cancel (set blank for) any setting of #10951 to #10970, "Condition kind" 1 to 10 and "Condition num" 1 to 10. Input "00" to set "Condition num" to "0". When either of "Condition kind" or "Condition num" is canceled, the condition will not be available for the automatic notification of alarms.

**---Setting range---**

Within 5 characters

**【#10958(PR)】 Condition num 4**

Set the condition (alarm or PLC signal) for the automatic notification of alarms.  
Set the alarm No. for alarm, status value for PLC signal.

(Note) Set "0" to cancel (set blank for) any setting of #10951 to #10970, "Condition kind" 1 to 10 and "Condition num" 1 to 10. Input "00" to set "Condition num" to "0". When either of "Condition kind" or "Condition num" is canceled, the condition will not be available for the automatic notification of alarms.

**---Setting range---**

Within 4 characters

**【#10959(PR)】 Condition kind 5**

Set the condition (alarm or PLC signal) for the automatic notification of alarms.  
Set the alarm type for alarm, device (register) name for PLC signal.

<Alarm>

Operation alarm (Mxx)  
Stop code (Txx)  
Servo alarm (Sxx)  
Spindle servo alarm (Sxx)  
System alarm (Zxx)  
Absolute position detection alarm (Zxx)  
Emergency stop (EMG)  
Auxiliary axis servo alarm (Sxx)  
Auxiliary axis absolute position detection alarm (Zxx)  
Auxiliary axis OP error (Mxx)  
Auxiliary axis MCP alarm (Yxx)  
Computer link error (Lxx)  
Operation error (Exx)  
User PLC alarm (PLxx)

<Device (register)>

1-bit data ... X,Y,U,W  
16-bit data ... R

(Note) Set "0" to cancel (set blank for) any setting of #10951 to #10970, "Condition kind" 1 to 10 and "Condition num" 1 to 10. Input "00" to set "Condition num" to "0". When either of "Condition kind" or "Condition num" is canceled, the condition will not be available for the automatic notification of alarms.

---Setting range---

Within 5 characters

**【#10960(PR)】 Condition num 5**

Set the condition (alarm or PLC signal) for the automatic notification of alarms.  
Set the alarm No. for alarm, status value for PLC signal.

(Note) Set "0" to cancel (set blank for) any setting of #10951 to #10970, "Condition kind" 1 to 10 and "Condition num" 1 to 10. Input "00" to set "Condition num" to "0". When either of "Condition kind" or "Condition num" is canceled, the condition will not be available for the automatic notification of alarms.

---Setting range---

Within 4 characters

**【#10961(PR)】 Condition kind 6**

Set the condition (alarm or PLC signal) for the automatic notification of alarms.  
Set the alarm type for alarm, device (register) name for PLC signal.

## &lt;Alarm&gt;

Operation alarm (Mxx)  
Stop code (Txx)  
Servo alarm (Sxx)  
Spindle servo alarm (Sxx)  
System alarm (Zxx)  
Absolute position detection alarm (Zxx)  
Emergency stop (EMG)  
Auxiliary axis servo alarm (Sxx)  
Auxiliary axis absolute position detection alarm (Zxx)  
Auxiliary axis OP error (Mxx)  
Auxiliary axis MCP alarm (Yxx)  
Computer link error (Lxx)  
Operation error (Exx)  
User PLC alarm (PLxx)

## &lt;Device (resister)&gt;

1-bit data ... X,Y,U,W  
16-bit data ... R

(Note) Set "0" to cancel (set blank for) any setting of #10951 to #10970, "Condition kind" 1 to 10 and "Condition num" 1 to 10. Input "00" to set "Condition num" to "0". When either of "Condition kind" or "Condition num" is canceled, the condition will not be available for the automatic notification of alarms.

**---Setting range---**

Within 5 characters

**【#10962(PR)】 Condition num 6**

Set the condition (alarm or PLC signal) for the automatic notification of alarms.  
Set the alarm No. for alarm, status value for PLC signal.

(Note) Set "0" to cancel (set blank for) any setting of #10951 to #10970, "Condition kind" 1 to 10 and "Condition num" 1 to 10. Input "00" to set "Condition num" to "0". When either of "Condition kind" or "Condition num" is canceled, the condition will not be available for the automatic notification of alarms.

**---Setting range---**

Within 4 characters



**【#10963(PR)】 Condition kind 7**

Set the condition (alarm or PLC signal) for the automatic notification of alarms.  
Set the alarm type for alarm, device (register) name for PLC signal.

<Alarm>

Operation alarm (Mxx)  
Stop code (Txx)  
Servo alarm (Sxx)  
Spindle servo alarm (Sxx)  
System alarm (Zxx)  
Absolute position detection alarm (Zxx)  
Emergency stop (EMG)  
Auxiliary axis servo alarm (Sxx)  
Auxiliary axis absolute position detection alarm (Zxx)  
Auxiliary axis OP error (Mxx)  
Auxiliary axis MCP alarm (Yxx)  
Computer link error (Lxx)  
Operation error (Exx)  
User PLC alarm (PLxx)

<Device (register)>

1-bit data ... X,Y,U,W  
16-bit data ... R

(Note) Set "0" to cancel (set blank for) any setting of #10951 to #10970, "Condition kind" 1 to 10 and "Condition num" 1 to 10. Input "00" to set "Condition num" to "0". When either of "Condition kind" or "Condition num" is canceled, the condition will not be available for the automatic notification of alarms.

---Setting range---

Within 5 characters

**【#10964(PR)】 Condition num 7**

Set the condition (alarm or PLC signal) for the automatic notification of alarms.  
Set the alarm No. for alarm, status value for PLC signal.

(Note) Set "0" to cancel (set blank for) any setting of #10951 to #10970, "Condition kind" 1 to 10 and "Condition num" 1 to 10. Input "00" to set "Condition num" to "0". When either of "Condition kind" or "Condition num" is canceled, the condition will not be available for the automatic notification of alarms.

---Setting range---

Within 4 characters

**【#10965(PR)】 Condition kind 8**

Set the condition (alarm or PLC signal) for the automatic notification of alarms.  
Set the alarm type for alarm, device (register) name for PLC signal.

## &lt;Alarm&gt;

Operation alarm (Mxx)  
Stop code (Txx)  
Servo alarm (Sxx)  
Spindle servo alarm (Sxx)  
System alarm (Zxx)  
Absolute position detection alarm (Zxx)  
Emergency stop (EMG)  
Auxiliary axis servo alarm (Sxx)  
Auxiliary axis absolute position detection alarm (Zxx)  
Auxiliary axis OP error (Mxx)  
Auxiliary axis MCP alarm (Yxx)  
Computer link error (Lxx)  
Operation error (Exx)  
User PLC alarm (PLxx)

## &lt;Device (resister)&gt;

1-bit data ... X,Y,U,W  
16-bit data ... R

(Note) Set "0" to cancel (set blank for) any setting of #10951 to #10970, "Condition kind" 1 to 10 and "Condition num" 1 to 10. Input "00" to set "Condition num" to "0". When either of "Condition kind" or "Condition num" is canceled, the condition will not be available for the automatic notification of alarms.

**---Setting range---**

Within 5 characters

**【#10966(PR)】 Condition num 8**

Set the condition (alarm or PLC signal) for the automatic notification of alarms.  
Set the alarm No. for alarm, status value for PLC signal.

(Note) Set "0" to cancel (set blank for) any setting of #10951 to #10970, "Condition kind" 1 to 10 and "Condition num" 1 to 10. Input "00" to set "Condition num" to "0". When either of "Condition kind" or "Condition num" is canceled, the condition will not be available for the automatic notification of alarms.

**---Setting range---**

Within 4 characters

**【#10967(PR)】 Condition kind 9**

Set the condition (alarm or PLC signal) for the automatic notification of alarms.  
Set the alarm type for alarm, device (register) name for PLC signal.

<Alarm>  
Operation alarm (Mxx)  
Stop code (Txx)  
Servo alarm (Sxx)  
Spindle servo alarm (Sxx)  
System alarm (Zxx)  
Absolute position detection alarm (Zxx)  
Emergency stop (EMG)  
Auxiliary axis servo alarm (Sxx)  
Auxiliary axis absolute position detection alarm (Zxx)  
Auxiliary axis OP error (Mxx)  
Auxiliary axis MCP alarm (Yxx)  
Computer link error (Lxx)  
Operation error (Exx)  
User PLC alarm (PLxx)

<Device (register)>  
1-bit data ... X,Y,U,W  
16-bit data ... R

(Note 1) Set "0" to cancel (set blank for) any setting of #10951 to #10970, "Condition kind" 1 to 10 and "Condition num" 1 to 10. Input "00" when setting "0" for "Condition num". When either of "Condition kind" or "Condition num" is canceled, the condition will not be available for the automatic notification of alarms.

**---Setting range---**

Within 5 characters

**【#10968(PR)】 Condition num 9**

Set the condition (alarm or PLC signal) for the automatic notification of alarms.  
Set the alarm No. for alarm, status value for PLC signal.

(Note) Set "0" to cancel (set blank for) any setting of #10951 to #10970, "Condition kind" 1 to 10 and "Condition num" 1 to 10. Input "00" to set "Condition num" to "0". When either of "Condition kind" or "Condition num" is canceled, the condition will not be available for the automatic notification of alarms.

**---Setting range---**

Within 4 characters

**【#10969(PR)】 Condition kind 10**

Set the condition (alarm or PLC signal) for the automatic notification of alarms.  
Set the alarm type for alarm, device (register) name for PLC signal.

## &lt;Alarm&gt;

Operation alarm (Mxx)  
Stop code (Txx)  
Servo alarm (Sxx)  
Spindle servo alarm (Sxx)  
System alarm (Zxx)  
Absolute position detection alarm (Zxx)  
Emergency stop (EMG)  
Auxiliary axis servo alarm (Sxx)  
Auxiliary axis absolute position detection alarm (Zxx)  
Auxiliary axis OP error (Mxx)  
Auxiliary axis MCP alarm (Yxx)  
Computer link error (Lxx)  
Operation error (Exx)  
User PLC alarm (PLxx)

## &lt;Device (resister)&gt;

1-bit data ... X,Y,U,W  
16-bit data ... R

(Note) Set "0" to cancel (set blank for) any setting of #10951 to #10970, "Condition kind" 1 to 10 and "Condition num" 1 to 10. Input "00" to set "Condition num" to "0". When either of "Condition kind" or "Condition num" is canceled, the condition will not be available for the automatic notification of alarms.

**---Setting range---**

Within 5 characters

**【#10970(PR)】 Condition num 10**

Set the condition (alarm or PLC signal) for the automatic notification of alarms.  
Set the alarm No. for alarm, status value for PLC signal.

(Note) Set "0" to cancel (set blank for) any setting of #10951 to #10970, "Condition kind" 1 to 10 and "Condition num" 1 to 10. Input "00" to set "Condition num" to "0". When either of "Condition kind" or "Condition num" is canceled, the condition will not be available for the automatic notification of alarms.

**---Setting range---**

Within 4 characters

**【#10971】 Complete condition**

Set the of the PLC signal which will be the condition for completing the machining when "#10814 OP-notice condition" is set to "1".

## &lt;Device (Register)&gt;

1 bit data : X,Y,M,F,L,SM,T,C  
16 bit data : D,R  
\* T: Timer coil only / C: Counter coil only

**---Setting range---**

Within 6 alphanumeric characters

**【#10972】 Complete CND num**

Set the state values of PLC signal device which will be the condition for completing the machining when "#10814 OP-notice condition" is set to "1".

Use the device status set to "#10971 Complete condition". Set the conditions of 16 bit data in HEX format.

**---Setting range---**

Within 4 alphanumeric characters

## Appendix 1.16 PLC Axis Indexing Parameters

### [#12800(PR)] chgauxno Auxiliary axis number

Set the axis No. to be controlled as auxiliary axis using auxiliary axis interface.  
 When "0" is set, the axis will not operate as auxiliary axis.

#### ---Setting range---

M730/M750/M730VS/M750VS/M730VW/M750VW: 0 to 6  
 M720/M720VS/M720VW/M70 Series/M70V Series: 0 to 4

### [#12801(PR)] aux\_station Number of indexing stations

Set the number of stations.  
 For linear axis, this value is expressed by: number of divisions = number of stations -1.  
 Setting "0" or "1" sets the number of stations to 2.

#### ---Setting range---

0 to 360

### [#12802(PR)] aux\_Control1 Control parameter 1

The bits that are not explained here must be set to "0".

#### Bit3:

0: Automatic reach signal isn't interlocked with the start signal.  
 1: Automatic reach signal is interlocked with the start signal.

#### Bit4:

0: Automatic reach signal is turned ON again.  
 1: Automatic reach signal isn't turned ON again.

#### Bit5:

0: Station No. Output within fixed position.  
 1: Station No. Constantly output.

#### bit9:

0: Rotation direction determined by operation control signal (DIR)  
 1: Rotation direction in the shortcut direction

#### bitE:

0: Rotation direction in operation control signal (DIR) or in the shortcut direction  
 1: Rotation direction in the arbitrary position command sign direction

#### bitF:

0: Stopper direction is in the positioning direction.  
 1: Stopper direction is in the sign direction of the stopper amount.

### [#12803(PR)] aux\_Control2 Control parameter 2

The bits that are not explained here must be set to "0".

#### bit4:

0: Uniform assignment  
 1: Arbitrary coordinate assignment

### [#12804(PR)] aux\_tleng Linear axis stroke length

Set the movement stroke length for linear axes.  
 (Note 1) Setting "0.000" causes an MCP alarm at the power ON.  
 (Note 2) This parameter is meaningless at the arbitrary coordinate assignment or with the arbitrary coordinate designation method.

#### ---Setting range---

0.000 to 99999.999 (mm)

**【#12805】 aux\_ST.offset Station offset**

Set the distance (offset) from the reference position to station 1.

**---Setting range---**

-99999.999 to 99999.999 (° or mm)

**【#12810+10(n-1)】 aux\_Aspeedn Operation parameter group n Automatic operation speed**

Set the feedrate during automatic operation when "operation parameter group n" is selected. "#12810 aux\_Aspeed1" is regarded as the clamp value for the automatic operation speeds and manual operation speeds of all operation groups.

A speed exceeding "aux\_Aspeed1" cannot be commanded, even if it is set in a parameter.

(Note)Setting "0" causes an operation error at the "Operation start" signal's ON.

**---Setting range---**

0 to 100000 (°/min or mm/min)

**【#12811+10(n-1)】 aux\_Mspeedn Operation parameter group n Manual operation speed**

Set the feedrate during manual operation or JOG operation when "operation parameter group n" is selected.

(Note)Setting "0" causes an operation error at the "Operation start" signal's ON.

**---Setting range---**

0 to 100000 (°/min or mm/min)

**【#12812+10(n-1)】 aux\_timen.1 Operation parameter group n Acceleration/deceleration time constant 1**

Set the linear acceleration/deceleration time for "Operation parameter group 1 automatic operation speed" (clamp speed) when "operation parameter group n" is selected.

When this is set with "Acceleration/deceleration time constant 2", S-pattern acceleration/deceleration will be carried out. In this case, this parameter determines the acceleration/deceleration time of the linear part.

When operating at a speed less than the clamp speed, if "#1361 aux\_acc" is set to "0", the axis will accelerate/decelerate with the time constant set in this parameter. If "#1361 aux\_acc" is set to "1", the axis will accelerate/decelerate at the constant inclination determined by this parameter and "aux\_Aspeed1".

Setting "0" cancels acceleration/deceleration: The axis will move with the time constant "0".

**---Setting range---**

0 to 4000 (ms)

**【#12813+10(n-1)】 aux\_timen.2 Operation parameter group n Acceleration/deceleration time constant 2**

Set the total time of the non-linear parts in the S-pattern acceleration/deceleration.

In the handle feed operation mode, this setting value is regarded as time constant for the linear acceleration/deceleration.

(Note)If this parameter is set to "0" while "#12818 aux\_smgst1" is set to "F", an MCP alarm will occur.

**---Setting range---**

0 to 4000 (ms)

**【#12814+10(n-1)】 aux\_TLn Operation parameter group n Torque limit value**

Set the motor output torque limit value when "operation parameter group n" is selected.

At the default value, the torque is limited at the maximum torque of the motor specifications. Set the default value when torque limit is not especially required.

In the stopper positioning operation mode, this will be regarded as torque limit value when positioning to the stopper starting coordinates.

**---Setting range---**

0 to 500 (%)

# Appendix 1 Explanation of Parameters

## [#12815+10(n-1)] aux\_ODn Operation parameter group n Excessive error detection width

Set the excessive error detection width when "operation parameter group n" is selected.  
 The excessive error alarm (S03 0052) will be detected when the position droop becomes larger than this setting value.  
 In the stopper positioning operation mode, this will be regarded as excessive error detection width when positioning to the stopper starting coordinates.

### ---Setting range---

0 to 32767(° or mm)

## [#12816+10(n-1)] aux\_justn Operation parameter group n Set position output width

Set the tolerable value at which "set position reached" (JST) or "automatic set position reached" (JSTA) signal is output when "operation parameter group n" is selected.  
 "Set position reached" (JST) indicates that the machine position is at any station.  
 During automatic operation, "automatic set position reached" (JSTA) is also output under the same condition.  
 These signals will turn OFF when the machine position moves away from the station over this value.

### ---Setting range---

0.000 to 99999.999(° or mm)

## [#12817+10(n-1)] aux\_nearn Operation parameter group n Near set position output width

Set the tolerable value at which "near set position" (NEAR) signal is output when "operation parameter group n" is selected.  
 "Near set position" (NEAR) indicates that the machine position is near any station position.  
 This value is generally set wider than the set position output width. During operations, this is related to the special commands when the station selection is set to "0".

### ---Setting range---

0.000 to 99999.999(° or mm)

## [#12818+10(n-1)(PR)] aux\_smgstn Operation parameter group n Acceleration/Deceleration type

Select the acceleration/deceleration type when "operation parameter group n" is selected.  
 0, 1: Linear acceleration/deceleration  
 F: S-pattern acceleration/deceleration

## [#12850] aux\_stpos2 Station 2 coordinate

Set the station 2 coordinate value when arbitrary coordinate assignment is selected.  
 The station 1 coordinate value is fixed at "0.000" (machine coordinate zero point).

### ---Setting range---

-99999.999 to 99999.999(° or mm)

## [#12851] aux\_stpos3 Station 3 coordinate

Set the station 3 coordinate value when arbitrary coordinate assignment is selected.  
 The station 1 coordinate value is fixed at "0.000" (machine coordinate zero point).

### ---Setting range---

-99999.999 to 99999.999(° or mm)

## [#12852] aux\_stpos4 Station 4 coordinate

Set the station 4 coordinate value when arbitrary coordinate assignment is selected.  
 The station 1 coordinate value is fixed at "0.000" (machine coordinate zero point).

### ---Setting range---

-99999.999 to 99999.999(° or mm)

## [#12853] aux\_stpos5 Station 5 coordinate

Set the station 5 coordinate value when arbitrary coordinate assignment is selected.  
 The station 1 coordinate value is fixed at "0.000" (machine coordinate zero point).

### ---Setting range---

-99999.999 to 99999.999(° or mm)

**【#12854】 aux\_stpos6 Station 6 coordinate**

Set the station 6 coordinate value when arbitrary coordinate assignment is selected.  
The station 1 coordinate value is fixed at "0.000" (machine coordinate zero point).

**---Setting range---**

-99999.999 to 99999.999(° or mm)

**【#12855】 aux\_stpos7 Station 7 coordinate**

Set the station 7 coordinate value when arbitrary coordinate assignment is selected.  
The station 1 coordinate value is fixed at "0.000" (machine coordinate zero point).

**---Setting range---**

-99999.999 to 99999.999(° or mm)

**【#12856】 aux\_stpos8 Station 8 coordinate**

Set the station 8 coordinate value when arbitrary coordinate assignment is selected.  
The station 1 coordinate value is fixed at "0.000" (machine coordinate zero point).

**---Setting range---**

-99999.999 to 99999.999(° or mm)

**【#12857】 aux\_stpos9 Station 9 coordinate**

Set the coordinate of each station when arbitrary coordinate assignment is selected.  
The station 1 coordinate value is fixed at "0.000" (machine coordinate zero point).

**---Setting range---**

-99999.999 to 99999.999(° or mm)

**【#12858】 aux\_stpos10 Station 10 coordinate**

Set the station 10 coordinate value when arbitrary coordinate assignment is selected.  
The station 1 coordinate value is fixed at "0.000" (machine coordinate zero point).

**---Setting range---**

-99999.999 to 99999.999(° or mm)

**【#12859】 aux\_stpos11 Station 11 coordinate**

Set the station 11 coordinate value when arbitrary coordinate assignment is selected.  
The station 1 coordinate value is fixed at "0.000" (machine coordinate zero point).

**---Setting range---**

-99999.999 to 99999.999(° or mm)

**【#12860】 aux\_stpos12 Station 12 coordinate**

Set the station 12 coordinate value when arbitrary coordinate assignment is selected.  
The station 1 coordinate value is fixed at "0.000" (machine coordinate zero point).

**---Setting range---**

-99999.999 to 99999.999(° or mm)

**【#12861】 aux\_stpos13 Station 13 coordinate**

Set the station 13 coordinate value when arbitrary coordinate assignment is selected.  
The station 1 coordinate value is fixed at "0.000" (machine coordinate zero point).

**---Setting range---**

-99999.999 to 99999.999(° or mm)

**【#12862】 aux\_stpos14 Station 14 coordinate**

Set the station 14 coordinate value when arbitrary coordinate assignment is selected.  
The station 1 coordinate value is fixed at "0.000" (machine coordinate zero point).

**---Setting range---**

-99999.999 to 99999.999(° or mm)



**【#12863】 aux\_stpos15 Station 15 coordinate**

Set the station 15 coordinate value when arbitrary coordinate assignment is selected.  
The station 1 coordinate value is fixed at "0.000" (machine coordinate zero point).

**---Setting range---**

-99999.999 to 99999.999(° or mm)

**【#12864】 aux\_stpos16 Station 16 coordinate**

Set the station 16 coordinate value when arbitrary coordinate assignment is selected.  
The station 1 coordinate value is fixed at "0.000" (machine coordinate zero point).

**---Setting range---**

-99999.999 to 99999.999(° or mm)

**【#12865】 aux\_stpos17 Station 17 coordinate**

Set the station 17 coordinate value when arbitrary coordinate assignment is selected.  
The station 1 coordinate value is fixed at "0.000" (machine coordinate zero point).

**---Setting range---**

-99999.999 to 99999.999(° or mm)

**【#12866】 aux\_stpos18 Station 18 coordinate**

Set the station 18 coordinate value when arbitrary coordinate assignment is selected.  
The station 1 coordinate value is fixed at "0.000" (machine coordinate zero point).

**---Setting range---**

-99999.999 to 99999.999(° or mm)

**【#12867】 aux\_stpos19 Station 19 coordinate**

Set the station 19 coordinate value when arbitrary coordinate assignment is selected.  
The station 1 coordinate value is fixed at "0.000" (machine coordinate zero point).

**---Setting range---**

-99999.999 to 99999.999(° or mm)

**【#12868】 aux\_stpos20 Station 20 coordinate**

Set the station 20 coordinate value when arbitrary coordinate assignment is selected.  
The station 1 coordinate value is fixed at "0.000" (machine coordinate zero point).

**---Setting range---**

-99999.999 to 99999.999(° or mm)

**【#12870】 aux\_PSWcheck PSW detection method**

Select the criterion for the output of position switches 1 to 15.  
bit0 to E correspond to position switches 1 to 15.  
0: Judged by the machine position of the command system.  
1: Judged by the machine FB position (actual position).

(Note) The bits that are not explained here must be set to "0".

**【#12871】 aux\_PSW1dog1 PSW1 area setting 1**

Set "PSW1 area setting" 1 and 2 to specify the area where the position switch 1 will turn ON when the machine is positioned.  
Whether the value of setting 1 is larger than setting 2 (or vice versa) does not affect the position switch operation.  
For rotary axes, the output turns ON in the area excluding 0.000 degree.

**---Setting range---**

-99999.999 to 99999.999(° or mm)

**【#12872】 aux\_PSW1dog2 PSW1 area setting 2**

Set "PSW1 area setting" 1 and 2 to specify the area where the position switch 1 will turn ON when the machine is positioned.  
Whether the value of setting 1 is larger than setting 2 (or vice versa) does not affect the position switch operation.  
For rotary axes, the output turns ON in the area excluding 0.000 degree.

**---Setting range---**

-99999.999 to 99999.999(° or mm)

**【#12873】 aux\_PSW2dog1 PSW2 area setting 1**

Set "PSW2 area setting" 1 and 2 to specify the area where the position switch 2 will turn ON when the machine is positioned.  
Whether the value of setting 1 is larger than setting 2 (or vice versa) does not affect the position switch operation.  
For rotary axes, the output turns ON in the area excluding 0.000 degree.

**---Setting range---**

-99999.999 to 99999.999(° or mm)

**【#12874】 aux\_PSW2dog2 PSW2 area setting 2**

Set "PSW2 area setting" 1 and 2 to specify the area where the position switch 2 will turn ON when the machine is positioned.  
Whether the value of setting 1 is larger than setting 2 (or vice versa) does not affect the position switch operation.  
For rotary axes, the output turns ON in the area excluding 0.000 degree.

**---Setting range---**

-99999.999 to 99999.999(° or mm)

**【#12875】 aux\_PSW3dog1 PSW3 area setting 1**

Set "PSW3 area setting" 1 and 2 to specify the area where the position switch 3 will turn ON when the machine is positioned.  
Whether the value of setting 1 is larger than setting 2 (or vice versa) does not affect the position switch operation.  
For rotary axes, the output turns ON in the area excluding 0.000 degree.

**---Setting range---**

-99999.999 to 99999.999(° or mm)

**【#12876】 aux\_PSW3dog2 PSW3 area setting 2**

Set "PSW3 area setting" 1 and 2 to specify the area where the position switch 3 will turn ON when the machine is positioned.  
Whether the value of setting 1 is larger than setting 2 (or vice versa) does not affect the position switch operation.  
For rotary axes, the output turns ON in the area excluding 0.000 degree.

**---Setting range---**

-99999.999 to 99999.999(° or mm)

**【#12877】 aux\_PSW4dog1 PSW4 area setting 1**

Set "PSW4 area setting" 1 and 2 to specify the area where the position switch 4 will turn ON when the machine is positioned.  
Whether the value of setting 1 is larger than setting 2 (or vice versa) does not affect the position switch operation.  
For rotary axes, the output turns ON in the area excluding 0.000 degree.

**---Setting range---**

-99999.999 to 99999.999(° or mm)

**【#12878】 aux\_PSW4dog2 PSW4 area setting 2**

Set "PSW4 area setting" 1 and 2 to specify the area where the position switch 4 will turn ON when the machine is positioned.  
Whether the value of setting 1 is larger than setting 2 (or vice versa) does not affect the position switch operation.  
For rotary axes, the output turns ON in the area excluding 0.000 degree.

**---Setting range---**

-99999.999 to 99999.999(° or mm)

**【#12879】 aux\_PSW5dog1 PSW5 area setting 1**

Set "PSW5 area setting" 1 and 2 to specify the area where the position switch 5 will turn ON when the machine is positioned.  
Whether the value of setting 1 is larger than setting 2 (or vice versa) does not affect the position switch operation.  
For rotary axes, the output turns ON in the area excluding 0.000 degree.

**---Setting range---**

-99999.999 to 99999.999(° or mm)

**【#12880】 aux\_PSW5dog2 PSW5 area setting 2**

Set "PSW5 area setting" 1 and 2 to specify the area where the position switch 5 will turn ON when the machine is positioned.  
Whether the value of setting 1 is larger than setting 2 (or vice versa) does not affect the position switch operation.  
For rotary axes, the output turns ON in the area excluding 0.000 degree.

**---Setting range---**

-99999.999 to 99999.999(° or mm)

**【#12881】 aux\_PSW6dog1 PSW6 area setting 1**

Set "PSW6 area setting" 1 and 2 to specify the area where the position switch 6 will turn ON when the machine is positioned.  
Whether the value of setting 1 is larger than setting 2 (or vice versa) does not affect the position switch operation.  
For rotary axes, the output turns ON in the area excluding 0.000 degree.

**---Setting range---**

-99999.999 to 99999.999(° or mm)

**【#12882】 aux\_PSW6dog2 PSW6 area setting 2**

Set "PSW6 area setting" 1 and 2 to specify the area where the position switch 6 will turn ON when the machine is positioned.  
Whether the value of setting 1 is larger than setting 2 (or vice versa) does not affect the position switch operation.  
For rotary axes, the output turns ON in the area excluding 0.000 degree.

**---Setting range---**

-99999.999 to 99999.999(° or mm)

**【#12883】 aux\_PSW7dog1 PSW7 area setting 1**

Set "PSW7 area setting" 1 and 2 to specify the area where the position switch 7 will turn ON when the machine is positioned.  
Whether the value of setting 1 is larger than setting 2 (or vice versa) does not affect the position switch operation.  
For rotary axes, the output turns ON in the area excluding 0.000 degree.

**---Setting range---**

-99999.999 to 99999.999(° or mm)

**【#12884】 aux\_PSW7dog2 PSW7 area setting 2**

Set "PSW7 area setting" 1 and 2 to specify the area where the position switch 7 will turn ON when the machine is positioned.  
Whether the value of setting 1 is larger than setting 2 (or vice versa) does not affect the position switch operation.  
For rotary axes, the output turns ON in the area excluding 0.000 degree.

**---Setting range---**

-99999.999 to 99999.999(° or mm)

**【#12885】 aux\_PSW8dog1 PSW8 area setting 1**

Set "PSW8 area setting" 1 and 2 to specify the area where the position switch 8 will turn ON when the machine is positioned.  
Whether the value of setting 1 is larger than setting 2 (or vice versa) does not affect the position switch operation.  
For rotary axes, the output turns ON in the area excluding 0.000 degree.

**---Setting range---**

-99999.999 to 99999.999(° or mm)

**【#12886】 aux\_PSW8dog2 PSW8 area setting 2**

Set "PSW8 area setting" 1 and 2 to specify the area where the position switch 8 will turn ON when the machine is positioned.  
Whether the value of setting 1 is larger than setting 2 (or vice versa) does not affect the position switch operation.  
For rotary axes, the output turns ON in the area excluding 0.000 degree.

**---Setting range---**

-99999.999 to 99999.999(° or mm)

**【#12887】 aux\_PSW9dog1 PSW9 area setting 1**

Set "PSW9 area setting" 1 and 2 to specify the area where the position switch 9 will turn ON when the machine is positioned.  
Whether the value of setting 1 is larger than setting 2 (or vice versa) does not affect the position switch operation.  
For rotary axes, the output turns ON in the area excluding 0.000 degree.

**---Setting range---**

-99999.999 to 99999.999(° or mm)

**【#12888】 aux\_PSW9dog2 PSW9 area setting 2**

Set "PSW9 area setting" 1 and 2 to specify the area where the position switch 9 will turn ON when the machine is positioned.  
Whether the value of setting 1 is larger than setting 2 (or vice versa) does not affect the position switch operation.  
For rotary axes, the output turns ON in the area excluding 0.000 degree.

**---Setting range---**

-99999.999 to 99999.999(° or mm)

**【#12889】 aux\_PSW10dog1 PSW10 area setting 1**

Set "PSW10 area setting" 1 and 2 to specify the area where the position switch 10 will turn ON when the machine is positioned.  
Whether the value of setting 1 is larger than setting 2 (or vice versa) does not affect the position switch operation.  
For rotary axes, the output turns ON in the area excluding 0.000 degree.

**---Setting range---**

-99999.999 to 99999.999(° or mm)

**【#12890】 aux\_PSW10dog2 PSW10 area setting 2**

Set "PSW10 area setting" 1 and 2 to specify the area where the position switch 10 will turn ON when the machine is positioned.  
Whether the value of setting 1 is larger than setting 2 (or vice versa) does not affect the position switch operation.  
For rotary axes, the output turns ON in the area excluding 0.000 degree.

**---Setting range---**

-99999.999 to 99999.999(° or mm)

**【#12891】 aux\_PSW11dog1 PSW11 area setting 1**

Set "PSW11 area setting" 1 and 2 to specify the area where the position switch 11 will turn ON when the machine is positioned.  
Whether the value of setting 1 is larger than setting 2 (or vice versa) does not affect the position switch operation.  
For rotary axes, the output turns ON in the area excluding 0.000 degree.

**---Setting range---**

-99999.999 to 99999.999(° or mm)

**【#12892】 aux\_PSW11dog2 PSW11 area setting 2**

Set "PSW11 area setting" 1 and 2 to specify the area where the position switch 11 will turn ON when the machine is positioned.  
Whether the value of setting 1 is larger than setting 2 (or vice versa) does not affect the position switch operation.  
For rotary axes, the output turns ON in the area excluding 0.000 degree.

**---Setting range---**

-99999.999 to 99999.999(° or mm)

**【#12893】 aux\_PSW12dog1 PSW12 area setting 1**

Set "PSW12 area setting" 1 and 2 to specify the area where the position switch 12 will turn ON when the machine is positioned.  
Whether the value of setting 1 is larger than setting 2 (or vice versa) does not affect the position switch operation.  
For rotary axes, the output turns ON in the area excluding 0.000 degree.

**---Setting range---**

-99999.999 to 99999.999(° or mm)

**【#12894】 aux\_PSW12dog2 PSW12 area setting 2**

Set "PSW12 area setting" 1 and 2 to specify the area where the position switch 12 will turn ON when the machine is positioned.  
Whether the value of setting 1 is larger than setting 2 (or vice versa) does not affect the position switch operation.  
For rotary axes, the output turns ON in the area excluding 0.000 degree.

**---Setting range---**

-99999.999 to 99999.999(° or mm)

**【#12895】 aux\_PSW13dog1 PSW13 area setting 1**

Set "PSW13 area setting" 1 and 2 to specify the area where the position switch 13 will turn ON when the machine is positioned.  
Whether the value of setting 1 is larger than setting 2 (or vice versa) does not affect the position switch operation.  
For rotary axes, the output turns ON in the area excluding 0.000 degree.

**---Setting range---**

-99999.999 to 99999.999(° or mm)

**【#12896】 aux\_PSW13dog2 PSW13 area setting 2**

Set "PSW13 area setting" 1 and 2 to specify the area where the position switch 13 will turn ON when the machine is positioned.  
Whether the value of setting 1 is larger than setting 2 (or vice versa) does not affect the position switch operation.  
For rotary axes, the output turns ON in the area excluding 0.000 degree.

**---Setting range---**

-99999.999 to 99999.999(° or mm)

**【#12897】 aux\_PSW14dog1 PSW14 area setting 1**

Set "PSW14 area setting" 1 and 2 to specify the area where the position switch 14 will turn ON when the machine is positioned.  
Whether the value of setting 1 is larger than setting 2 (or vice versa) does not affect the position switch operation.  
For rotary axes, the output turns ON in the area excluding 0.000 degree.

**---Setting range---**

-99999.999 to 99999.999(° or mm)

**【#12898】 aux\_PSW14dog2 PSW14 area setting 2**

Set "PSW14 area setting" 1 and 2 to specify the area where the position switch 14 will turn ON when the machine is positioned.  
Whether the value of setting 1 is larger than setting 2 (or vice versa) does not affect the position switch operation.  
For rotary axes, the output turns ON in the area excluding 0.000 degree.

**---Setting range---**

-99999.999 to 99999.999(° or mm)

**【#12899】 aux\_PSW15dog1 PSW15 area setting 1**

Set "PSW15 area setting" 1 and 2 to specify the area where the position switch 15 will turn ON when the machine is positioned.  
Whether the value of setting 1 is larger than setting 2 (or vice versa) does not affect the position switch operation.  
For rotary axes, the output turns ON in the area excluding 0.000 degree.

**---Setting range---**

-99999.999 to 99999.999(° or mm)

**【#12900】 aux\_PSW15dog2 PSW15 area setting 2**

Set "PSW15 area setting" 1 and 2 to specify the area where the position switch 15 will turn ON when the machine is positioned.  
Whether the value of setting 1 is larger than setting 2 (or vice versa) does not affect the position switch operation.  
For rotary axes, the output turns ON in the area excluding 0.000 degree.

**---Setting range---**

-99999.999 to 99999.999(° or mm)

**【#12910】 aux\_push Stopper amount**

Set the command stroke of the stopper operation in the stopper positioning.

**---Setting range---**

0.000 to 359.999(° or mm)

**【#12911】 aux\_pusht1 Stopper standby time**

Set the standby time from the stopper starting coordinate positioning to the stopper operation start in the stopper positioning.

**---Setting range---**

0 to 9999(ms)

### 【#12912】 aux\_pusht2 Stopper torque release time

Set the time from the completion of the stopper operation to the changeover of the stopper torque in the stopper positioning.

---Setting range---

0 to 9999(ms)

### 【#12913】 aux\_pusht3 Set position signal output delay time


Set the time from the completion of the stopper operation to the output of the “automatic set position reached” (JSTA), “set position reached” (JST) or “near set position” (NEAR) signal in the stopper positioning.

---Setting range---

0 to 9999(ms)

## Appendix 1.17 Screen Transition Chart

The menus for screens related to maintenance appear when the function key [MAINT] is pressed.  
The parameter menu appears when the menu key [Param] is pressed.



(Note) There are user parameter dedicated menus in the screens related to setup. The menu configuration differs slightly from the above configuration. Refer to the Instruction Manual for details.



## Appendix 1.18 Unit

### (1) Input setting unit and number of decimal digits

The number of digits in the decimal section of the parameters related to length is determined by the input setting unit.

The input setting unit is set with parameter "#1003 iunit".

Input setting unit	Number of digits in decimal section	Example of setting range
B	3	0 to 999.999 (mm)
C	4	0 to 999.9999 (mm)
D	5	0 to 999.99999 (mm)
E	6	0 to 999.999999 (mm)

The setting ranges indicated in this manual use the input setting unit "B".

## Appendix 1.19 Inputting the Machine Parameters

A password input is required to set the machine parameters.

### Inputting the machine parameter password

#### (1) Press the function key [MAINT].

The menu for the maintenance related screen will appear.

#### (2) Press the menu [Param].

The parameter menu will appear.

#### (3) Press the machine parameter selection menu.

(Example) Menu [Base sys param]

A message prompting input of the password will appear.

If the password has been input once after the power was turned ON, the cursor will appear at the machine parameter screen.

#### (4) Enter the password and press the [INPUT] key. (Password: MPARA)

The cursor will appear at the machine parameter screen, and the machine parameters can be set.

(Note 1) Refer to the section of "Base Specifications Parameters" and the following for the details of the machine parameters.

(Note 2) Always turn the power OFF after setting the machine parameters.

(Note 3) To enter the character "A", press the shift key and then "A" key. Do not press both keys at the same time.

## Appendix 1.20 Machine Error Compensation (Function Details)

### Appendix 1.20.1 Outline

#### (1) Memorized pitch error compensation

According to the specified parameters, this method compensates an axis feed error caused by a ball screw pitch error, etc.

With the reference position defined as the base, set the compensation amount in the division points obtained by equally dividing the machine coordinates. (See Fig. 1.1)

The compensation amount can be set by either the absolute or incremental system. Select the desired method with "#4000 Pinc".

Machine position between division points  $n$  and  $n+1$  is smoothly compensated by the linear approximation of the compensation amount.




Fig. 1.1 Relationship between the compensation amount and machine position

## (2) Two-way pitch error compensation

Two different compensation amounts can be set for plus and minus movements respectively: compensation in each direction is allowed. This method will reduce the difference between the path in the positive direction and that in the negative direction.

With the reference position defined as the base, set the compensation amount in the division points obtained by equally dividing the machine coordinates. (See Fig. 1.2)

The compensation amount can be set by either the absolute or incremental system. Select the desired method with "#4000 Pinc".

Machine position between division points  $n$  and  $n+1$  is smoothly compensated by the linear approximation of the compensation amount.




Fig. 1.2 Relationship between the compensation amount and machine position

**(3) Memorized relative position compensation**

This method, according to the parameters specified in advance, compensates the relative position error between two orthogonal axes caused by deflection of the moving stand.

For this, as shown in Fig. 1.3, specify the compensation amount in the compensation axis direction in the division points obtained by equally dividing the machine coordinates of the base axis.

Machine position between division points  $n$  and  $n+1$  is smoothly compensated by the linear approximation of the compensation amount.

The base axis is one of the two orthogonal axes to which relative position compensation applies. This axis is used as the criterion for relative-error measurement. The compensation axis is the coordinate axis that is orthogonal to the base axis. The compensation is actually made for this coordinate axis.




Fig. 1.3 Relationship between the compensation amount and machine position

## Appendix 1.20.2 Setting Compensation Data

There are two systems for setting the compensation data: absolute system and increment system.

"#4000 Pinc" 0: Absolute system

1: Incremental system

### (1) Absolute system

In feeding from the reference position to each division point as in Fig. 2.1,

the difference between a commanded position and an actual machine position is multiplied by 2, and the result (in unit of output) will be a compensation amount.

For example, when the machine is actually positioned at 99.990mm while commanded to +100mm, the difference between 100000 and 99990 is multiplied by 2, then the result, 20 pulses, will be set as a compensation amount at the +100mm position.

When the machine is actually positioned at -99.990mm while commanded to -100mm, the difference between -100000 and -99990 is multiplied by 2, then the result, -20 pulses, will be set as a compensation amount at the -100mm position.




Fig. 2.1

### (2) Incremental system

In feeding from division n-1 to n when the machine is in the positive direction from the reference position, as shown in Fig. 2.2,

"division interval - actual movement amount" is multiplied by 2, and the result (in unit of output) will be set as a compensation amount.

(3) In feeding from division n+1 to n when the machine is in the negative direction from the reference position, as shown in Fig. 2.3,

"division interval + actual movement amount" is multiplied by 2, and the result (in unit of output) will be set as a compensation amount.




Fig. 2.2

Unit : Unit of output  
Range : -128 to 127





Fig. 2.3

n: Division point  
compensation number  
I: Division interval

(Note) The unit of output is used as the unit of setting.  
The actual unit of compensation pulses depends on the compensation

### Appendix 1.20.3 Example in Using a Linear Axis as Base Axis


#### (1) When "mdvno" or "pdvno" exists at both ends of "rdvno"



Division point number	#4101	#4102	#4103	#4104	#4105	#4106	rdvno	4103
Specified machine position	-300.000	-200.000	-100.000	100.000	200.000	300.000	mdvno	4101
Real machine position	-299.999	-200.000	-100.003	100.002	200.002	299.999	pdvno	4106
Compensation amount	Incremental	2	6	-6	-4	0	6	
	Absolute	-2	0	6	-4	-4	2	

The compensation beyond the setting range ("mdvno" to "pdvno") will be based on the compensation amount at "mdvno" or "pdvno".


(2) When the range compensated is only the positive range



Division point number		#4113	#4114	#4115	#4116	#4117		
Compensation amount	Incremental	-4	2	0	6	2	rdvno	4112
	Absolute	-4	-2	-2	4	6	mdvno	4113
							pdvno	4117

When the machine has been positioned beyond "pdvno", the compensation will be based on the compensation amount at "pdvno". If the machine is positioned on the negative side in this case, no compensation will be executed.

## (3) When the range compensated is only the negative range




Division point number		#4125	#4126	#4127	#4128	#4129	#4130		
Compensation amount	Incremental	-2	2	6	2	0	-6	rdvno	4130
	Absolute	-2	-4	-2	4	6	6	mdvno	4125
								pdvno	4130

When the machine has been positioned beyond "mdvno", the compensation will be based on the compensation amount at "mdvno".



(4) When compensation is executed in a range that contains no reference position




Division point number		#4135	#4136	#4137	#4138	#4139	#4140		
Compensation amount	Incremental			-2	-2	6	2	rdvno	4134
	Absolute			-2	-4	2	4	mdvno	4136
								pdvno	4140

In this case, the compensation is executed in the range from "mdvno" to "pdvno".

This setting rule is also applied when the compensation is executed in a range which contains negative machine positions and no reference position.

## Appendix 1.20.4 Example in Using a Rotary Axis as Base Axis



Division point number		#4123	#4124	#4125	#4126	#4127	#4128		
Compensation amount	Incremental	-4	2	0	6	2	-6	rdvno	4122
	Absolute	-4	-2	-2	4	6	0	mdvno	4123
								pdvno	4128

The sum of the compensation amounts set out with the incremental system is always "0".

In the absolute system, the compensation amount at the terminal point (360 degrees) is always "0".

# Appendix 1.21 Position Switch (Function Details)

## Appendix 1.21.1 Outline

Position switches (PSW) are used as alternatives for the dog switches provided on the machine axis. Imaginary dog switches, with axis names and imaginary dog coordinates preset by parameters, output a signal to the PLC interface when the machine reaches the switch area. The imaginary dog switches are called position switches (PSW).

Position switch Nos. of PSW1 to PSW24 and signal devices

	<axis>	<dog1>	<dog2>	<check>	Part system 1	Part system 2
PSW1	#7501	#7502	#7503	#7504	X1D00	X1D20
PSW2	#7511	#7512	#7513	#7514	X1D01	X1D21
PSW3	#7521	#7522	#7523	#7524	X1D02	X1D22
PSW4	#7531	#7532	#7533	#7534	X1D03	X1D23
:	:	:	:	:	:	:
PSW24	#7731	#7732	#7733	#7734	X1D17	X1D37





Position switches (PSW1 - PSW24) are used to set imaginary dog coordinates (dog1 and dog2) on the coordinate axes, whose names are preset with <axis>, as alternatives for the dog switches provided on the machine axis.

When the machine reaches the switch area, a signal is output to the corresponding device of the PLC interface.

## Appendix 1.21.2 Setting and Operation Examples of dog1 and dog2

Settings of dog1 and dog2	Positions of dog1 and dog2	Description	
dog1 < dog2		A signal is output when the machine reaches between dog1 and dog2.	
dog1 > dog2		A signal is output when the machine reaches between dog2 and dog1.	
dog1 = dog2		A signal is output when the machine reaches dog1 or dog2.	

For rotary axis

Settings of dog1 and dog2	Positions of dog1 and dog2	Description
dog1 < dog2	 <p>(Example) dog1 = 30.000 dog2 = 330.000</p>	A signal is output when the machine reaches between dog1 and dog2.
	 <p>(Example) dog1 = -30.000 dog2 = 30.000</p>	Signal output is the same when dog1 is negative.
dog1 > dog2	 <p>(Example) dog1 = 330.000 dog2 = 30.000</p>	A signal is output when the machine reaches between dog2 and dog1.
dog1 ≤ 0 and 360 ≤ dog2	 <p>(Example) dog1 = -30.000 dog2 = 390.000</p>	When the range of dog1 and dog2 include 0 to 360 degrees, a signal is output whenever and wherever the machine reaches.



### Appendix 1.21.3 Canceling the Position Switch

Enter the position switch number to cancel (#75\*1) in # ( ) and a slash "/" in DATA ( ) on the setting field, and then press the INPUT key. This deletes the axis name for the specified position switch, thus invalidating the position switch. The data in <dog1> and <dog2> are still stored in memory. To validate the position switch again, therefore, it is enough to specify the axis name only.


## Appendix 1.22 Bit Selection Parameters #6449 to #6496

	Symbol name	7	6	5	4	3	2	1		0
0	#6449 R7824 L	Control unit thermal alarm on	Setting and display unit thermal mgmt on ■	-		Counter C retention	Integrated timer ST retention	PLC counter program on		PLC timer program on
1	#6450 R7824 H	-	External alarm message display ■	Alarm/operator change ■	Full screen display of message ■	-	Operator message on	R method	F method	Alarm message on
2	#6451 R7825 L	-	-	GX Developer serial communication on			Onboard editing not possible ■	Onboard simple operation mode on		Onboard on
3	#6452 R7825 H	-	Branch destination label check valid		Serial handy terminal comm. on	-	-	Extended PLC instruction mode valid		-
4	#6453 R7826 L	Integrated timer ST Variable/fixed Number of points setting					Message language change code			
5	#6454 R7826 H	Counter C Variable/fixed Number of points setting				Timer T Variable/fixed Number of points setting				
6	#6455 R7827 L	Enable ladder program writing during RUN	Enable ladder program writing during RUN (in high-speed processing)	-	-	-	R device access variables decimal point valid region			
7	#6456 R7827 H	-	-	-	-	-	-	-	-	-
8	#6457 R7828 L	High-speed input specification 1								
9	#6458 R7828 H									
A	#6459 R7829 L	High-speed input specification 2								
B	#6460 R7829 H									
C	#6461 R7830 L	High-speed output specification 1								
D	#6462 R7830 H									
E	#6463 R7831 L	High-speed output specification 2								
F	#6464 R7831 H									

	Symbol name	7	6	5	4	3	2	1	0
0	#6465 R7832 L	High-speed input specification 3							
1	#6466 R7832 H								
2	#6467 R7833 L	High-speed input specification 4							
3	#6468 R7833 H								
4	#6469 R7834 L	-	-	-	-	-	-	-	-
5	#6470 R7834 H	-	-	-	-	-	-	-	-
6	#6471 R7835 L	-	-	-	-	-	-	-	-
7	#6472 R7835 H	-	-	-	-	-	-	-	-
8	#6473 R7836 L	High-speed output specification 3							
9	#6474 R7836 H								
A	#6475 R7837 L	High-speed output specification 4							
B	#6476 R7837 H								
C	#6477 R7838 L	-	-	-	-	-	-	-	-
D	#6478 R7838 H	-	-	-	-	-	-	-	-
E	#6479 R7839 L	-	-	-	-	-	-	-	-
F	#6480 R7839 H	-	-	-	-	-	-	-	-

(Note 1) Be sure to set "0" for the bits indicated by "-" or blank.

(Note 2) Parameters #6481 to #6496 are reserved for debugging by Mitsubishi.

(Note 3) Functions marked with  may not be available for some machine types.

# Appendix 2

---

## Explanation of Alarms



## Appendix 2.1 Operation Errors (M)

### M01 Dog overrun 0001

#### Details

When returning to the reference position, the near-point detection limit switch did not stop over the dog, but overran the dog.

#### Remedy

- Increase the length of the near-point dog.
- Reduce the reference position return speed.

### M01 Some ax does not pass Z phase 0002

#### Details

One of the axes did not pass the Z-phase during the initial reference position return after the power was turned ON.

#### Remedy

- Move the detector one rotation or more in the opposite direction of the reference position, and repeat reference position return.

### M01 R-pnt direction illegal 0003

#### Details

When manually returning to the reference position, the return direction differs from the axis movement direction selected with the AXIS SELECTION key.

#### Remedy

- The selection of the AXIS SELECTION key's +/- direction is incorrect. The error is canceled by feeding the axis in the correct direction.

### M01 External interlock axis exists 0004

#### Details

The external interlock function has activated (the input signal is "OFF") and one of the axes has entered the interlock state.

#### Remedy

- As the interlock function has activated, release it before resuming operation.
- Correct the sequence on the machine side.
- Check for any broken wires in the "interlock" signal line.

### M01 Internal interlock axis exists 0005

#### Details

The internal interlock state has been entered.  
 The absolute position detector axis has been removed.  
 A command for the manual/automatic simultaneous valid axis was issued from the automatic mode.  
 The manual speed command was issued while the "tool length measurement 1" signal is ON.  
 A travel command has been issued to an inclined axis whose base axis is in control axis synchronization across part systems.

#### Remedy

- The servo OFF function is valid, so release it first.
- An axis that can be removed has been issued, so perform the correct operations.
- The command is issued in the same direction as the direction where manual skip turned ON, so perform the correct operations.
- During the manual/automatic simultaneous mode, the axis commanded in the automatic mode became the manual operation axis. Turn OFF the "manual/automatic valid" signal for the commanded axis.
- Turn ON the power again, and perform absolute position initialization.
- Turn OFF the "tool length measurement 1" signal to start the program by the manual speed command.
- Cancel the control axis synchronization across part systems, then issue a travel command to the inclined axis.

#### M01 H/W stroke end axis exists 0006

##### Details

The stroke end function has activated (the input signal is "OFF") and one of the axes is in the stroke end status.

##### Remedy

- Move the machine manually.
- Check for any broken wires in the "stroke end" signal line.
- Check for any limit switch failure.

#### M01 S/W stroke end axis exists 0007

##### Details

The stored stroke limit I, II, IIB or IB function has activated.

##### Remedy

- Move the machine manually.
- Correct any setting error of the parameters for the stored stroke limit.

#### M01 Chuck/tailstock stroke end ax 0008

##### Details

The chuck/tail-stock barrier function turned ON, and an axis entered the stroke end state.

##### Remedy

- Reset the alarm with reset, and move the machine in the reverse direction.

#### M01 Ref point return No. invalid 0009

##### Details

2nd reference position return was performed before 1st reference position return has been completed.

##### Remedy

- Execute 1st reference position return.

#### M01 Sensor signal illegal ON 0019

##### Details

The sensor signal was already ON when the "tool length measurement 1" signal was validated.

The sensor signal turned ON when there was no axis movement after the "tool length measurement 1" signal was validated.

The sensor signal turned ON at a position within 100  $\mu$  m from the final entry start position.

##### Remedy

- Disable the "tool length measurement 1" signal and move the axis in a safe direction.
- Disabling the sensor signal also clears the operation alarm.

(Note) When the "tool length measurement 1" signal is disabled, the axis can be moved in either direction. Pay attention to the movement direction.

#### M01 Ref point retract invalid 0020

##### Details

Reference position retract was performed while the coordinates had not been established.

##### Remedy

- Execute reference position return.

#### M01 Tool ofs invld after R-pnt 0021

##### Details

Reference position return had been performed during the tool escape and return, which invalidated the tool compensation amount after the reference position return.

##### Remedy

- The error is cleared if the operation mode is changed to other than reference position return before the axis performs reference position return.
- The error is cleared when the tool return is completed.
- The error is cleared if reset 1 is input or the emergency stop button is pushed.

## **Appendix 2 Explanation of Alarms**

### **M01 R-pnt ret invld at abs pos alm 0024**

#### **Details**

A reference position return signal was enabled during an absolute position detection alarm.

#### **Remedy**

- Reset the absolute position detection alarm, and then perform the reference position return.

### **M01 R-pnt ret invld at zero pt ini 0025**

#### **Details**

A reference position return signal was input during zero point initialization of the absolute position detection system.

#### **Remedy**

- Complete the zero point initialization, and then perform reference position return.

### **M01 High-accuracy skip disabled 0028**

#### **Details**

The drive unit's hardware or software does not conform to the high-accuracy skip.

#### **Remedy**

- The software or hardware does not conform to the function. Contact service center.

### **M01 Hi-ac skip coord retrieval err 0029**

#### **Details**

Failed to retrieve the skip coordinate value from the drive unit.

#### **Remedy**

- Check the wiring.
- Check the parameters.

### **M01 Now skip on 0030**

#### **Details**

The "skip input" signal remains enabled when the operation has shifted from skip retract to measurement.

#### **Remedy**

- Increase the skip retract amount.

### **M01 No skip 0031**

#### **Details**

Even though the 1st skip was to the correct position, the 2nd skip could not be found.

#### **Remedy**

- Check whether the measurement target has moved.

### **M01 Rtn dir err in manual measure 0033**

#### **Details**

Return direction in manual measurement is the opposite of the parameter setting.

#### **Remedy**

- Check and correct the "#2169 Man meas rtn dir (Return direction in manual measurement)" setting.
- Move the axis manually to a safe position in the direction set by "#2169 Man meas rtn dir (Return direction in manual measurement)", then reset.

### **M01 Movement prohibited during tool retract 0035**

#### **Details**

An axis movement was attempted from the tool retract position.

The movement was attempted by a manual command in the tool return.

#### **Remedy**

It is not allowed to move an axis arbitrarily from the tool retract position. Take the following steps to move the axis.

- Cancel the program execution by reset.
- Use the tool escape and retract function and let the axis escape from the tool retract position.

The interruption by a manual command is not allowed in a tool return. Take the following step to move the axis.

- Cancel the program execution by reset.

#### M01 Chopping axis R-pnt incomplete 0050

##### Details

Chopping mode has been entered while the chopping axis has not completed reference position return.  
All axes interlock has been applied.

##### Remedy

- Reset the NC or disable the "chopping" signal, and then carry out the reference position return.

#### M01 Synchronous error excessive 0051

##### Details

The synchronization error of the primary and secondary axes exceeded the allowable value under synchronous control. A deviation exceeding the synchronization error limit value was found with the synchronization deviation detection.

##### Remedy

- Select the correction mode and move one of the axes in the direction in which the errors are reduced.
- Increase "#2024 synerr(allowable value)" or set "0" to disable error check.
- When using simple C-axis synchronous control, set "0" for "synchronous control operation method".

#### M01 No spindle select signal 0053

##### Details

Synchronous tapping command was issued when the "spindle selection" signals for all spindles were OFF in the multiple-spindle control II.

##### Remedy

- Turn ON the "spindle selection" signal for the tapping spindle before performing the synchronous tapping command.

#### M01 No spindle serial connection 0054

##### Details

Synchronous tapping command was issued in the multiple-spindle control II, while the spindle with the "spindle selection" signal ON was not serially connected.

##### Remedy

- Make sure the "spindle selection" signal for the spindle is ON.
- Consider the machine construction when issuing the command.

#### M01 Spindle fwd/rvs run para err 0055

##### Details

Asynchronous tapping command was issued when M code of the spindle forward/reverse run command, set by "#3028 sprcmm", was one of the followings in the multiple-spindle control II.

- M0, M1, M2, M30, M98, M99, or M198
- M code No. that commands to enable/disable the "macro interrupt" signal

##### Remedy

- Correct the "#3028 sprcmm (Tap cycle spindle forward run/reverse run M command)" setting.

#### M01 Tap pitch/thread number error 0056

##### Details

The command for the pitch or the number of threads is not correct in the synchronous tapping command of the multiple-spindle control II.

The pitch is too small for the spindle rotation speed.

Thread number is too large for the spindle rotation speed.

##### Remedy

- Correct the pitch, number of threads or rotation speed of the tapping spindle.

#### M01 Wait for tap retract 0057

##### Details

The axis travel command is interlocked in the part system where the "Tap retract possible" signal is ON.

##### Remedy

- If tap retract is necessary, perform it before issuing an axis travel command.
- If tap retract is not necessary, cancel the tap retract enabled state.

### M01 Handle ratio too large 0060

#### Details

- The handle ratio is too large for the handle feed clamp speed.  
(The handle feed clamp speed changes according to the rapid traverse rate, external feedrate, maximum speed outside the soft limit range and etc. (or external deceleration speed when external deceleration is valid))

#### Remedy

- Change the settings of the handle feed clamp speed or the handle ratio.

### M01 R-pos offset value illegal 0065

#### Details

At the start of reference position initial setting, "#2034 rfpos (Distance-coded reference position detection offset) is not set to "0".

#### Remedy

- Set "#2034 rfpos" to "0", then turn the power ON again to perform the reference position initial setting.

### M01 R-pos scan distance exceeded 0066

#### Details

Reference position could not be established within the maximum scan distance.

#### Remedy

- Check the scale to see if it has dirt or damage.
- Check if the servo drive unit supports this function.

### M01 Illegal op in wk instl err cmp 0070

#### Details

One of the following operations was attempted during workpiece installation error compensation.

- Manual interruption
- Automatic operation handle interruption
- MDI interruption
- PLC interruption

#### Remedy

- Return the operation mode to the original mode to remove the cause.

### M01 No operation mode 0101

#### Details

No operation mode

#### Remedy

- Check for any broken wires in the input mode signal line.
- Check for any failure of the MODE SELECT switch.
- Correct the sequence program.

### M01 Cutting override zero 0102

#### Details

The "cutting feed override" switch on the machine operation panel is set to "0".  
The override was set to "0" during a single block stop.

#### Remedy

- Set the "cutting feed override" switch to a value other than "0" to clear the error.
- If the "cutting feed override" switch has been set to a value other than "0", check for any short circuit in the signal line.
- Correct the sequence program.

#### M01 External feed rate zero 0103

##### Details

MANUAL FEEDRATE switch on the machine operation panel is set to "0" when the machine is in the JOG or automatic dry run mode.

"Manual feedrate B" is set to "0" during the JOG mode when manual feedrate B is valid.

"Each axis manual feedrate B" is set to "0" during the JOG mode when each axis manual feedrate B is valid.

##### Remedy

- Set the MANUAL FEEDRATE switch to a value other than "0" to release the error.
- If the MANUAL FEEDRATE switch has been set to a value other than "0" check for any short circuit in the signal line.
- Correct the sequence program.

#### M01 F 1-digit feed rate zero 0104

##### Details

The F1-digit feedrate has been set to "0" when the F1-digit feed command was executed.

##### Remedy

- Set the F1-digit feedrate (from "#1185 spd\_F1 (F1 digit feedrate F1)" to "#1189 spd\_F5 (F1 digit feedrate F5)").

#### M01 Spindle stop 0105

##### Details

The spindle stopped during the synchronous feed/thread cutting command.

##### Remedy

- Rotate the spindle.
- If the workpiece is not being cut, start dry run.
- Check for any broken wire in the spindle encoder cable.
- Check the connections for the spindle encoder connectors.
- Check the spindle encoder pulse.
- Correct the program. (commands and addresses)

#### M01 Handle feed ax No. illegal 0106

##### Details

The axis, designated at handle feed, is out of specifications.  
No axis has been selected for handle feed.

##### Remedy

- Check for any broken wires in the handle feed axis selection signal line.
- Correct the sequence program.
- Check the number of axes in the specifications.

#### M01 Spindle rotation speed over 0107

##### Details

Spindle rotation speed exceeded the axis clamp speed during the thread cutting command.

##### Remedy

- Lower the commanded rotation speed.

#### M01 Fixed pnt mode feed ax illegal 0108

##### Details

The axis, designated in the manual arbitrary feed, is out of specifications.  
The feedrate in manual arbitrary feed mode is illegal.

##### Remedy

- Check for any broken wires in the axis selection signal line or the feedrate line for the manual arbitrary feed mode.
- Check the specifications for the manual arbitrary feed mode.

#### M01 Block start interlock 0109

##### Details

An interlock signal has been input to lock the block start.

##### Remedy

- Correct the sequence program.

## M01 Cutting block start interlock 0110

### Details

An interlock signal has been input to lock the cutting block start.

### Remedy

- Correct the sequence program.

## M01 Restart switch ON 0111

### Details

Restart switch has been turned ON and manual mode has been selected before the restart search is completed.

### Remedy

- Search the block to restart.
- Turn the restart switch OFF.

## M01 Program check mode 0112

### Details

The automatic start button was pressed during program check or in program check mode.

### Remedy

- Press the reset button to cancel the program check mode.

## M01 Auto start in buffer correct 0113

### Details

The automatic start button was pressed during buffer correction.

### Remedy

- Press the automatic start button after the buffer correction is completed.

## M01 In reset process 0115

### Details

The automatic start button was pressed during resetting or tape rewinding.

### Remedy

- When rewinding the tape, wait for the winding to end, or press the reset button to stop the winding, and then press the automatic start button.
- During resetting, wait for the resetting to end, and then press the automatic start button.

## M01 Playback not possible 0117

### Details

The playback switch was turned ON during editing.

### Remedy

- Cancel the editing by pressing the input or previous screen key before turning ON the playback switch.

## M01 Turn stop in normal line cntrl 0118

### Details

The turning angle at the block joint exceeded the limit during normal line control.

In normal line control type I:

"#1523 C\_feed (Normal line control axis turning speed)" has not been set.

In normal line control type II:

When turning in the inside of the arc, the set value for "#8041 C-rot. R" is larger than the arc radius.

### Remedy

- Correct the program.
- Correct the "#1523 C\_feed (Normal line control axis turning speed)" setting.
- Correct the "#8041 C rot. R" setting.

#### M01 Reverse run impossible 0119

##### Details

Either of the following conditions occurred:

- there is no block to run backward.
- eight blocks has been continued without any travel command.

##### Remedy

- Execute forward run to clear the alarm.
- Reset to clear the alarm.

#### M01 In synchronous correction mode 0120

##### Details

The synchronous correction mode switch was pressed in non-handle mode.

##### Remedy

- Select the handle or manual arbitrary feed mode.
- Turn OFF the correction mode switch.

#### M01 No synchronous control option 0121

##### Details

The synchronous control operation method was set (with R2589) while no synchronous control option was provided.

##### Remedy

- Set "0" for "synchronous control operation method".

#### M01 Computer link B not possible 0123

##### Details

Cycle start was attempted before resetting was completed.

Computer link B operation was attempted at the 2nd or further part system in a multi-part system.

##### Remedy

- Perform the cycle start after resetting has been completed.
- Set "#8109 HOST LINK" to "0" and then set to "1" before performing the cycle start.
- Computer link B operation cannot be performed at the 2nd or further part system in a multi-part system.

#### M01 X/Z axes simultaneous prohibit 0124

##### Details

The basic axis corresponding to the inclined axis was started simultaneously in the manual mode while the inclined axis control was valid.

##### Remedy

- Turn the inclined axis and basic axis start OFF for both axes. (This is also applied for manual/automatic simultaneous start.)
- Disable the basic axis compensation, or command it to axes one by one.

#### M01 Rapid override zero 0125

##### Details

The RAPID TRAVERSE OVERRIDE switch on the machine operation panel is set to "0".

##### Remedy

- Set the RAPID TRAVERSE OVERRIDE switch to a value other than "0" to clear the error.
- If the RAPID TRAVERSE OVERRIDE switch has been set to a value other than "0", check for any short circuit in the signal line.
- Correct the sequence program.

#### M01 Program restart machine lock 0126

##### Details

Machine lock was applied on the return axis being manually returned to the restart position.

##### Remedy

- Cancel the machine lock and resume the operation.



### M01 Rot axis parameter error 0127

#### Details

Orthogonal coordinate axis name does not exist.  
 Rotary axis name does not exist.  
 A duplicate name is used for the designated orthogonal coordinate axis.  
 The number of axes that were selected to change tool length compensation along the tool axis amount exceeds the maximum number of axes.  
 The designated orthogonal coordinate axis name is the same as the rotary axis name.

#### Remedy

- Correct the rotary axis configuration parameters.

### M01 Restart pos return incomplete 0128

#### Details

Automatic return was performed with an axis whose return to the restart position was not complete.

#### Remedy

- Perform restart position return manually.
- Enable "#1302 AutoRP (Automatic return by program restart)" before executing the automatic start.

### M01 PLC interruption impossible 0129

#### Details

After the automatic startup, the "PLC interrupt" signal was turned ON during buffer correction, program restart, arbitrary reverse run, tool escape and return, high-speed high-accuracy control II, or NURBS interpolation.

#### Remedy

- By turning OFF the "PLC interrupt" signal, or by resetting the NC the error can be cancelled.

### M01 Restart posn return disabled 0130

#### Details

Restart position return was attempted in a mode where the return is disabled.

#### Remedy

- Correct the program restart position.

### M01 Chopping override zero 0150

#### Details

The override became "0" in the chopping operation.

#### Remedy

- Correct the setting of "chopping override" (R2503).
- Correct the setting of "rapid traverse override" (R2502).

### M01 Command axis chopping axis 0151

#### Details

A chopping axis movement command was issued from the program during the chopping mode. (This alarm will not occur for the command with the movement amount "0".)  
 (All axes interlock state will be applied.)

#### Remedy

- Press the reset button or turn OFF the "chopping" signal. When the "chopping" signal is turned OFF, the axis returns to the reference position and performs the movement command in the program.

### M01 Bottom dead center pos. zero 0153

#### Details

The bottom dead center position is set to the same position as the upper dead center position.

#### Remedy

- Correct the bottom dead center position.

#### M01 Chopping disable for handle ax 0154

##### Details

Chopping has been attempted while the chopping axis is selected as the handle axis.

##### Remedy

- Select an axis other than the chopping axis as the handle axis, or start chopping after changing the mode to the other mode.

#### M01 No speed set out of soft limit 0160

##### Details

The axis, without any maximum speed outside of the soft limit range set, was returned from the outside of the soft limit range.

##### Remedy

- Correct the "#2021 out\_f (Maximum speed outside soft limit range)" setting.
- Correct the soft limit range (with "#2013 OT- (Soft limit I-)" and "#2014 OT+ (Soft limit I+)").

#### M01 Aux axis changeover error 0166

##### Details

One of the following attempts was made on an axis that can be switched to NC/auxiliary axis.

- A command was issued to an auxiliary axis from machining program.
- When there were more than one NC axis having a same name, a command was issued to those axes from machining program.
- "NC axis control selection" signal was turned OFF while the NC axis was in motion.
- "NC axis control selection" signal was turned ON while the auxiliary axis was in motion.

##### Remedy

- Turn ON the "NC axis control selection" signal to set the auxiliary axis to NC axis when issuing a command to the axis from machining program.
- When more than one axis have a same name, let only one of the axes work as an NC axis.
- Do not change the "NC axis control selection" signal while the axis is in motion.

#### M01 Ill. op during T tip control 0170

##### Details

Illegal operation was attempted during tool tip center control.

##### Remedy

- Change the operation mode to the previous one and restart.

#### M01 Illegal OP in tilted face cut 0185

##### Details

Any of the following illegal operations was attempted during inclined surface machining mode.

- Manual interrupt
- Handle interrupt in automatic operation
- MDI interrupt
- PLC interrupt
- Arbitrary reverse run

##### Remedy

- Switch the operation mode back to the previous to remove the cause of this failure.

#### M01 Interference check invalidated 0200

##### Details

The 3D machine interference check is invalidated. This alarm is output to NC alarm 5.

##### Remedy

- Validate all the interference check settings.
- If there is any axis which has not completed zero point return, establish the zero point first.

### M01 Machine interference 1 0201

#### Details

It was judged that an interference occurred in the No.1 step interference check and caused a deceleration stop.

When machine interference is detected, the interfered part is highlighted (yellow/red) and the part's name is displayed on the 3D monitor's model display.

#### Remedy

- Move the axis in a direction which does not cause interference.
- Press RESET to cancel the alarm.
- You can move the axis in the same travel direction as before the interference.  
But the axis movement is done using the 2nd step interference check distance.  
(In manual operation)

### M01 Machine interference 2 0202

#### Details

It was judged that an interference occurred in the No.2 step interference check and caused a deceleration stop.

When machine interference is detected, the interfered part is highlighted (red) and the part's name is displayed on the 3D monitor's model display.

#### Remedy

- Move the axis in a direction which doesn't cause interference.
- Press RESET to cancel the alarm.

### M01 Manual feed for 5-axis machining/Simultaneous command to multiple axes 0230

#### Details

More than one axis was designated simultaneously in manual mode while the manual feed for 5-axis machining was valid.

#### Remedy

- Command the manual feed to each axis one by one.

### M01 Manual feed for 5-axis machining/Selecting coordinate system illegal 0231

#### Details

- More than one of the three bits for selecting hypothetical coordinate system was turned ON.
- Hypothetical coordinate system was selected while the manual feed for 5-axis machining was invalidated by the parameter setting.

#### Remedy

- Check the sequence program.
- Validate the manual feed for 5-axis machining (parameter "#7912 NO\_MANUAL").

### M01 Illegal op in 5 ax tool R comp 0232

#### Details

An illegal operation (such as manual interrupt) was attempted during tool radius compensation for 5-axis machining.

#### Remedy

- Operations such as manual interrupt are disabled while the tool radius compensation for 5-axis machining is being performed.

### M01 Machining surface operation disabled 0250

#### Details

Machining surface operation (selection, indexing or cancel) was attempted while the operation is disabled.

#### Remedy

- Cancel the other modes so that the inclined surface machining command (G68.2), tool axis direction control (G53.1) and the inclined surface machining cancel command (G69) can be issued.
- Wait until the axes stop completely (until the smoothing for all axes reaches zero).
- Perform operation search for machining programs.

#### M01 APLC password mismatch 0280

##### Details

The APLC authentication password is inconsistent.

##### Remedy

- Contact the machine tool builder.

#### M01 Illegal movement command during superimposition 1003

##### Details

- A machine command was issued to the superimposing axis.
- Reference position return was attempted on the superimposing axis.
- Skip command was issued to the master or superimposing axis.
- Dog-type reference position return was attempted on the master axis.

##### Remedy

- Correct the program.

#### M01 Superimposition command illegal 1004

##### Details

- Superimposition command (G126) was issued to the axis which is executing the following functions.  
Synchronization control  
Milling interpolation
- Superimposition start command was issued to the axis which was under superimposition control.
- The superimposition command was issued to an axis that belongs to the same part system as a basic or synchronous axis of synchronization across part systems.

##### Remedy

- Correct the program.

#### M01 G114.n command illegal 1005

##### Details

G114.n has been commanded during the execution of G114.n.  
G51.2 has been commanded when G51.2 spindle-spindle polygon machining mode has been already entered at another part system.

##### Remedy

- Command G113 to cancel the operation.
- Turn ON the "spindle synchronization cancel" signal to cancel the operation.
- Command G50.2 to cancel the operation.
- Turn ON the "spindle-spindle polygon cancel" signal to cancel the operation.

#### M01 Spindle in-use by synchro tap 1007

##### Details

The spindle is being used in synchronized tapping.

##### Remedy

- Cancel the synchronized tapping.

#### M01 SP-C ax ctrl runs independntly 1026

##### Details

C axis mode command has been issued for polygon machining spindle.  
C axis mode command has been issued for synchronized tapping spindle.  
Polygon command has been issued for synchronized tapping spindle.  
Spindle is being used as spindle/C axis.

##### Remedy

- Cancel the C axis command.
- Cancel the polygon machining command.
- Cancel the C axis with servo OFF.

### M01 Synchronization mismatch 1030

#### Details

Different M codes were each commanded as synchronization M code in each of the two part systems. Synchronization with the "I" code was commanded in another part system during M code synchronization.  
Synchronization with the M code was commanded in another part system during synchronization with the "I" code.

#### Remedy

- Correct the program so that the M codes match.
- Correct the program so that the same synchronization codes are commanded.

### M01 Multiple C axes select invalid 1031

#### Details

The "C axis selection" signal has been changed when the multiple C axes selection is not available. The selected axis by the "C axis selection" signal cannot be controlled for the multiple C axes selection.

#### Remedy

- Correct the parameter settings and program.

### M01 Tap retract Sp select illegal 1032

#### Details

Tap retract has been executed with a different spindle selected. Cutting feed is in wait state until synchronization is completed.

#### Remedy

- Select the spindle for which tap cycle was halted before turning ON the "tap retract" signal.

### M01 Sp-Sp polygon cut interlock 1033

#### Details

Cutting feed is in wait state until synchronization is completed.

#### Remedy

- Wait for the synchronization to end.

### M01 Mixed sync ctrl prmtr illegal 1034

#### Details

There is a mistake in the settings of mixed control axis parameters (crsax [1] to [8]). Mixed control was attempted within one and the same part system. Any of the parameter settings is disabling mixed control.

#### Remedy

- Correct the parameter settings for the mixed control (cross axis control).

#### M01 Mixed sync ctrl disable modal 1035

##### Details

Mixed control (cross axis control) was commanded for a part system in which the mixed control (cross axis control) is disabled as shown below.

- During nose R compensation mode
- During pole coordinate interpolation mode
- During cylindrical interpolation mode
- During balance cut mode
- During fixed cycle machining mode
- During facing turret mirror image
- During constant surface speed control mode
- During hobbing mode
- During axis name switch

An axis was transferred to another part system, and mixed control was attempted with the part system's maximum number of control axes exceeded.

An axis was removed from the part system, and mixed control was attempted with the part system's number of axes zero.

Another axis exchange was attempted to the axis which was already transferred to another part system for mixed control.

##### Remedy

- Correct the program.

#### M01 Synchro ctrl setting disable 1036

##### Details

"Synchronous control operation method" was set (with R2589) when the mode was not the C axis mode.

"Synchronous control operation method" was set (with R2589) in the zero point not set state.

Mirror image is disabled.

External mirror image or parameter mirror image was commanded during facing turret mirror image.

##### Remedy

- Set the contents of the R2589 register to "0".
- Correct the program and parameters.

#### M01 Synchro start/cancel disable 1037

##### Details

Synchronous control start/cancel command was issued when the start/cancel is disabled.

##### Remedy

- Correct the program and parameters.

#### M01 Move cmdnd invld to synchro ax 1038

##### Details

A travel command was issued to a synchronous axis in synchronous control.

##### Remedy

- Correct the program.

#### M01 No spindle speed clamp 1043

##### Details

The constant surface speed command (G96) was issued to the spindle which is not selected for the spindle speed clamp command (G92/G50) under Multiple spindle control II.

##### Remedy

Press the reset key and carry out the remedy below.

- Select the spindle before commanding G92/G50.

#### M01 Sp synchro phase calc illegal 1106

##### Details

Spindle synchronization phase alignment command was issued while the "phase shift calculation request" signal was ON.

##### Remedy

- Correct the program.
- Correct the sequence program.

## M80 POSITION ERROR

### Details

An axis position is illegal.  
An alarm is displayed (AL4 is output) and a block stop is applied on the machining program.  
When the block stop is not allowed in the thread cutting cycle and the like, the stop is applied at the next position where allowed.

### Remedy

Carry out reset. Then confirm that the system starts the operation. If the alarm is displayed again, turn ON the emergency stop switch and turn the NC power OFF and ON.

## M90 Parameter set mode

### Details

The lock for setup parameters has been released. Setting the setup parameters is enabled while automatic start is disabled.

### Remedy

Refer to the manual issued by the machine tool builder.

## M91 INVALID MEASUR. 0002

### Details

Data is over the range  
The measurement result exceeds the tool data setting range.

### Remedy

Correct the settings of "#2015 tlmI- (Negative direction sensor of tool setter)" and "#2016 tlmI+ (Positive direction sensor of tool setter or TLM standard length)".

## M91 INVALID MEASUR. 0003

### Details

No corresponding No.  
No measurement tool No. has been set.  
The registered No. is out of the specifications.

### Remedy

Correct the measurement tool No.

## M91 INVALID MEASUR. 0045

### Details

Measurement axis illegal  
Sensor has been turned ON while two or more axes are moving.

### Remedy

Move a single axis when the sensor is contacted.

## M91 INVALID MEASUR. 0046

### Details

Measurement axis has not returned to reference position  
Reference position return has not been executed on a measurement axis in an incremental system.

### Remedy

Carry out the reference position return on the measurement axis before measuring the tool.

## M91 INVALID MEASUR. 0089

### Details

Sensor signal illegal ON  
Sensor has already been ON when TLM mode is turned ON. The travel amount was so small that the tool contacted the sensor.

### Remedy

All axes are interlocked when this alarm has occurred.  
Turn the TLM mode OFF or use the interlock cancel signal to move the tool off the sensor.  
Ensure at least 0.1mm for the movement to the sensor.

#### M91 INVALID MEASUR. 9000

##### Details

Speed at contact is below minimum  
The tool has contacted the sensor at the lower speed than set in "#1508 TLM\_Fmin (Minimum speed toward tool setter)".

##### Remedy

Correct the feed rate to move the tool to the sensor.

#### M91 INVALID MEASUR. 9001

##### Details

Speed at contact is over maximum  
The tool has contacted the sensor at the higher speed than set in "#1509 TLM\_Fmax (Maximum speed toward tool setter)".

##### Remedy

Correct the feed rate to move the tool to the sensor.

#### M91 INVALID MEASUR. 9002

##### Details

Change of compensation No. or sub-side selection during measurement  
A compensation No. or sub-side valid signal state has been changed while a sensor signal is ON or a compensation amount is being written.

##### Remedy

Carry out the measurement again.

#### M91 INVALID MEASUR. 9003

##### Details

Error on response timing of sensor signal  
A compensation No. has been changed at the same time as a sensor's response.

##### Remedy

Carry out the measurement again.

#### M92 IGNORE INT.LOCK

##### Details

Manual tool length measurement Interlock temporally canceled  
"M01 Operation error 0005" and "M01 Operation error 0019", which occur at manual tool length measurement, are temporally canceled. When a tool has contacted a sensor and "M01 Operation error 0019" has occurred, tool escape is enabled by temporarily turning ON the interlock cancel request. This alarm notifies that the interlock is disabled in the meantime.

##### Remedy

After carrying out the tool escape from the sensor, turn OFF the interlock temporary cancel signal for manual tool length measurement.



## Appendix 2.2 Stop Codes (T)

### T01 Axis in motion 0101

#### Details

Automatic start is not possible as one of the axes is moving.

#### Remedy

- Try automatic start again after all axes have stopped.

### T01 NC not ready 0102

#### Details

Automatic start is not possible as the NC is not ready.

#### Remedy

- Another alarm has occurred. Check the details and remedy.

### T01 Reset signal ON 0103

#### Details

Automatic start is not possible as the "reset" signal has been input.

#### Remedy

- Turn OFF the "reset" signal.
- Check for any failure of the reset switch which has caused the switch's continuous ON.
- Correct the sequence program.

### T01 Auto operation pause signal ON 0104

#### Details

The feed hold switch on the machine operation panel is ON (valid).

#### Remedy

- Correct the feed hold switch setting.
- The feed hold switch is B contact switch.
- Fix any broken wires in the feed hold signal line.
- Correct the sequence program.

### T01 H/W stroke end axis exists 0105

#### Details

Automatic start is not possible as one of the axes is at the stroke end.

#### Remedy

- Manually move any axis whose end is at the stroke end.
- Check for any broken wires in the stroke end signal line.
- Check for any failure in the stroke end limit switch.

### T01 S/W stroke end axis exists 0106

#### Details

Automatic start is not possible as one of the axes is at the stored stroke limit.

#### Remedy

- Move the axis manually.
- If the axis's end is not at the stroke end, check the parameters.

### T01 No operation mode 0107

#### Details

The operation mode has not been selected.

#### Remedy

- Select automatic operation mode.
- Check for any broken wires in the signal line for automatic operation mode (memory, tape, MDI).

#### T01 Operation mode duplicated 0108

##### Details

Two or more automatic operation modes have been selected.

##### Remedy

- Check for any short circuit in the mode (memory, tape, MDI) selection signal line.
- Check for any failure in the switch.
- Correct the sequence program.

#### T01 Operation mode changed 0109

##### Details

The automatic operation mode has changed to another automatic operation mode.

##### Remedy

- Return to the original automatic operation mode, and execute automatic start.

#### T01 Tape search execution 0110

##### Details

Automatic start is not possible as tape search is being executed.

##### Remedy

- Wait for the tape search to be completed and then execute the automatic start.

#### T01 Cycle start prohibit 0111

##### Details

Automatic start is disabled because restart search is in execution.

##### Remedy

- Execute automatic start after the restart search is completed.

#### T01 CNC overhear 0113

##### Details

Automatic start is not possible because a thermal alarm (Z53 CNC overheat) has occurred.

##### Remedy

- Temperature of the control unit has exceeded the specified temperature.
- Take appropriate measures to cool the unit.

#### T01 Cycle st. prohibit(Host comm.) 0115

##### Details

Automatic start cannot is not possible because the NC is communicating with the host computer.

##### Remedy

- Wait for the communication with host computer to be ended and then execute the automatic start.

#### T01 Cycle st prohibit(Battery alm) 0116

##### Details

Automatic start is not possible because the voltage of the battery in the NC control unit has dropped.

##### Remedy

- Replace the battery of the NC control unit.
- Contact the service center.

#### T01 R-pnt offset value not set 0117

##### Details

Automatic operation is not possible because no reference position offset value has been set.

##### Remedy

- Perform the reference position initialization setting, then set "#2034 rfpofs(Distance-coded reference position detection offset)".

**T01 Cycle start prohibit 0118**

**Details**

Tool retract position signal OFF

The axis was moved from the tool retract position. Tool retract position reached signal is OFF.

**Remedy**

Once the axis has been moved off the tool retract position, resuming the program is not possible. Cancel the program by reset and then execute it from the start.

**T01 In absolute position alarm 0138**

**Details**

A start signal was input during an absolute position detection alarm.

**Remedy**

- Clear the absolute position detection alarm, and then input the start signal.

**T01 In abs posn initial setting 0139**

**Details**

A start signal was input during zero point initialization in the absolute position detection system.

**Remedy**

- Complete zero point initialization before inputting the start signal.

**T01 Start during MDI operation at other part system disable 0141**

**Details**

In multi-part system, a start signal was input for MDI mode while the MDI operation was being carried out in another part system.

**Remedy**

- End the other part system's operation before starting.

**T01 Cycle start prohibit 0142**

**Details**

In manual coordinate system setting

Automatic start is not allowed during the manual coordinate system setting.

**Remedy**

The system restarts after either of the manual coordinate system setting completion signal or the error end signal has been turned ON.

**T01 In manual measurement 0143**

**Details**

Automatic start is disabled because manual measurement is in execution.

**Remedy**

- Execute automatic start after the manual measurement is completed.

**T01 APLC password mismatch 0160**

**Details**

The APLC authentication password is inconsistent.

**Remedy**

- Contact the machine tool builder.

**T01 Cycle start prohibit 0180**

**Details**

Automatic start became disabled while servo auto turning is enabled.

**Remedy**

- Set "#1164 ATS" to "0" when the servo auto turning is not executed.

**T01 Cycle start prohibit 0190**

**Details**

Automatic start is not possible because the setting of setup parameters is enabled.

**Remedy**

- Refer to the manual issued by the machine tool builder.

#### T01 Cycle start prohibit 0191

##### Details

Automatic start was attempted while a file was being deleted/written.

##### Remedy

- Wait for the file to be deleted/written and then execute the automatic start.

#### T01 Cycle st. prohibit (Term exp'd) 0193

##### Details

Automatic start is not possible because the valid term has been expired.

##### Remedy

- Enter the decryption code and turn the power ON again.

#### T02 H/W stroke end axis exists 0201

##### Details

An axis is at the stroke end.

##### Remedy

- Manually move the axis away from the stroke end limit switch.
- Correct the machining program.

#### T02 S/W stroke end axis exists 0202

##### Details

An axis is at the stored stroke limit.

##### Remedy

- Manually move the axis.
- Correct the machining program.

#### T02 Reset signal ON 0203

##### Details

The reset has been entered.

##### Remedy

- The program execution position has returned to the start of the program. Execute automatic operation from the start of the machining program.

#### T02 Auto operation pause signal ON 0204

##### Details

The "feed hold" switch is ON.

##### Remedy

- Press the CYCLE START switch to resume the automatic operation.

#### T02 Operation mode changed 0205

##### Details

The operation mode has changed to another mode during automatic operation.

##### Remedy

- Return to the original automatic operation mode, and press the CYCLE START switch to resume the automatic operation.

#### T02 Acc/dec time cnst too large 0206

##### Details

The acceleration and deceleration time constants are too large. (This alarm occurs with the system alarm Z59.)

##### Remedy

- Set a larger value for "#1206 G1bF(Maximum speed)".
- Set a smaller value for "#1207 G1btL(Time constant)".
- Set a lower cutting speed.

**T02 Abs posn detect alarm occurred 0215**

**Details**

An absolute position detection alarm occurred.

**Remedy**

- Clear the absolute position detection alarm.

**T02 Aux axis changeover error 0220**

**Details**

A travel command was issued to an auxiliary axis.

**Remedy**

- Turn ON the "NC axis control selection" signal and press the CYCLE START switch to restart the automatic operation with.

**T03 Single block stop signal ON 0301**

**Details**

The SINGLE BLOCK switch on the machine operation panel is ON.

The SINGLE BLOCK or MACHINE LOCK switch changed.

**Remedy**

- Press the CYCLE START switch to resume the automatic operation.

**T03 Block stop cmnd in user macro 0302**

**Details**

A block stop command was issued in the user macro program.

**Remedy**

- Press the CYCLE START switch to resume the automatic operation.

**T03 Operation mode changed 0303**

**Details**

Automatic mode changed to another automatic mode.

**Remedy**

- Return to the original automatic operation mode, and press the CYCLE START switch to resume the automatic operation.

**T03 MDI completed 0304**

**Details**

MDI operation has ended the last block.

**Remedy**

- Set the MDI operation again, and press the CYCLE START switch to start the MDI operation.

**T03 Block start interlock 0305**

**Details**

The interlock signal, which locks the block start, is ON.

**Remedy**

- Correct the sequence program.

**T03 Cutting blk start interlock 0306**

**Details**

The interlock signal, which locks the block cutting start, is ON.

**Remedy**

- Correct the sequence program.

**T03 Inclined Z offset change 0310**

**Details**

The "inclined axis control: No Z axis compensation" signal has turned ON or OFF during the program operation.

**Remedy**

- Press the CYCLE START switch to resume the automatic operation.

### T03 Aux axis changeover error 0330

#### Details

The "NC axis control selection" signal was turned OFF while a NC axis was traveling.

#### Remedy

- Turn the "NC axis control selection" signal ON and press the CYCLE START switch to resume the automatic operation.

### T04 Collation stop 0401

#### Details

Collation stop occurred.

#### Remedy

- Execute the automatic start to resume the automatic operation.

### T10 Fin wait (Factors for waiting completion)

#### Details

The following Nos. are shown during the operation of the corresponding completion wait factor. The numbers will disappear when the operation is completed.  
The completion wait factor is indicated with four digits (in hexadecimal).

Display format of completion wait factor

0 \_ \_ \_  
(a)(b)(c)

Each of the hexadecimal numbers (a), (b) and (c) indicates the following details.

(a)

bit0: In dwell execution

bit3: Unclamp signal wait (Note 1)

(b)

bit0: Waiting for spindle position to be looped

bit3: Door open (Note 2)

(c)

bit0: Waiting for MSTB completion

bit1: Waiting for rapid traverse deceleration

bit2: Waiting for cutting speed deceleration

bit3: Waiting for spindle orientation completion

(Note 1) This shows the wait state for the unclamp signal's ON/OFF for the index table indexing.

(Note 2) This shows the door open state caused by the door interlock function.

### T11 Fin wait 0010(Factors for waiting completion)

#### Details

The following Nos. are shown during the operation of the corresponding completion wait factor. The numbers will disappear when the operation is completed.  
The completion wait factor is indicated with four digits (in hexadecimal).

Display format of completion wait factor

0 \_ \_ \_  
(a)(b)(c)

Each of the hexadecimal numbers (a), (b) and (c) indicates the following details.

bit0: Operation alarm display being postponed

#### Remedy

The parameter "#1342 AlmDly" may be able to postpone displaying a part of an operation alarm, depending on the setting.


This stop code will remain displayed while any alarm is being postponed.

And it will disappear if the postponed alarm is displayed or canceled.

## Appendix 2.3 Servo/Spindle Alarms (S)

### Appendix 2.3.1 Servo Errors (S01/S03/S04)

Servo alarm is displayed in the following format.



Alarm class	Message	Reset method	Resetting methods
S01	Servo alarm	PR	After removing the cause of the alarm, reset the alarm by turning the NC power ON again.
S03	Servo alarm	NR	After removing the cause of the alarm, reset the alarm by inputting the NC RESET key.
S04	Servo alarm	AR	After removing the cause of the alarm, reset the alarm by turning the drive unit power ON again.

Error No. consists of four digits (0010 to). Servo alarms are explained in ascending order of the error No. The four digits on the left part of each alarm indicate the error No.

(Note) For the details of servo alarms, refer to your drive unit's instruction manual.

#### Drive unit alarms

##### 0010 Insufficient voltage

###### Details

- A drop of bus voltage was detected in main circuit.
- Servo stop method: Dynamic stop
- Spindle stop method: Coast to a stop

##### 0011 Axis selection error

###### Details

- The axis selection rotary switch has been incorrectly set.
- Servo stop method: Initial error
- Spindle stop method: Initial error

##### 0012 Memory error 1

###### Details

- A hardware error was detected during the power ON self-check.
- Servo stop method: Initial error
- Spindle stop method: Initial error

##### 0013 Software processing error 1

###### Details

- An error was detected for the software execution state.
- Servo stop method: Dynamic stop
- Spindle stop method: Coast to a stop

##### 0016 Init mag pole pos detect err

###### Details

- In the built-in motor which uses the absolute position detector, the servo ON has been set before the magnetic pole shift amount is set.
- The magnetic pole position, detected in the initial magnetic pole position detection control, is not correctly set.
- Servo stop method: Dynamic stop
- Spindle stop method: Coast to a stop

#### 0017 A/D converter error

##### Details

- A current feedback error was detected.
- Servo stop method: Dynamic stop
- Spindle stop method: Coast to a stop

#### 0018 Motor side dtc: Init commu err

##### Details

- An error was detected in the initial communication with the motor side detector.
- Servo stop method: Initial error
- Spindle stop method: Initial error

#### 0019 Detector commu err in syn cont

##### Details

- An error of the shared detector on the machine side was detected on the secondary axis of the speed command synchronization control.
- Servo stop method: Dynamic stop

#### 001A Machine side dtc: Init comu er

##### Details

- An error was detected in the initial communication with the machine side detector.
- Servo stop method: Initial error
- Spindle stop method: Initial error

#### 001B Machine side dtc: Error 1

##### Details

- An error was detected by the detector connected to the machine side.
- The error details are different according to the detector type.
- Servo stop method: Dynamic stop
- Spindle stop method: Coast to a stop
- [Detector alarm (Servo drive unit)]
- OSA105, OSA105-ET2, OSA166, OSA166-ET2(MITSUBISHI) Memory alarm
- OSA18() CPU alarm
- MDS-B-HR() Memory error
- AT343, AT543, AT545(Mitsutoyo) Initialization error
- LC193M, LC493M, RCN223M, RCN227M, RCN727M, RCN827M, EIB Series(HEIDENHAIN) Initialization error
- MPRZ Series(MHI) Installation accuracy fault
- SR75, SR85, SR77, SR87, RU77(Magnescale) Laser diode error
- [Detector alarm (Spindle drive unit)]
- TS5690, TS5691(MITSUBISHI) Memory error
- MDS-B-HR() Initialization error
- OSA18() CPU error
- EIB Series(HEIDENHAIN) Initialization error
- MPC1 scale(MHI) Installation accuracy fault
- (Note) A driver processes all reset types of alarms as "PR". However, "AR" will be applied according to the detector.

#### 001C Machine side dtc: Error 2

##### Details

- An error was detected by the detector connected to the machine side.
- The error details are different according to the detector type.
- Servo stop method: Dynamic stop
- Spindle stop method: Coast to a stop
- [Detector alarm (Servo drive unit)]
- OSA105, OSA105-ET2, OSA166, OSA166-ET2(MITSUBISHI) LED alarm
- AT343, AT543, AT545(Mitsutoyo) EEPROM error
- LC193M, LC493M, RCN223M, RCN227M, RCN727M, RCN827M, EIB Series(HEIDENHAIN) EEPROM error
- SR75, SR85, SR77, SR87, RU77(Magnescale) System memory error
- [Detector alarm (Spindle drive unit)]
- TS5690, TS5691(MITSUBISHI) Waveform error
- EIB Series(HEIDENHAIN) EEPROM error
- (Note) A driver processes all reset types of alarms as "PR". However, "AR" will be applied according to the detector.



**001D Machine side dtc: Error 3**

**Details**

An error was detected by the detector connected to the machine side.  
The error details are different according to the detector type.

- Servo stop method: Dynamic stop
- Spindle stop method: Coast to a stop
- [Detector alarm (Servo drive unit)]
- OSA105, OSA105-ET2, OSA166, OSA166-ET2(MITSUBISHI) Data alarm
- OSA18() Data alarm
- MDS-B-HR() Data error
- AT343, AT543, AT545(Mitsutoyo) Photoelectric type, static capacity type data mismatch
- LC193M, LC493M, RCN223M, RCN227M, RCN727M, RCN827M, EIB Series(HEIDENHAIN)

Relative/ absolute position data mismatch

- MPRZ Series(MHI) Detection position deviance
- SR75, SR85, SR77, SR87, RU77(Magnescape) Encoder mismatch error
- SAM/SVAM/GAM/LAN Series (FAGOR) Absolute position detection error

[Detector alarm (Spindle drive unit)]

- MDS-B-HR() Data error
- OSA18() Data error
- MPC1 scale(MHI) Detection position deviance

(Note) A driver processes all reset types of alarms as "PR". However, "AR" will be applied according to the detector.

**001E Machine side dtc: Error 4**

**Details**

An error was detected by the detector connected to the machine side.  
The error details are different according to the detector type.

- Servo stop method: Dynamic stop
- Spindle stop method: Coast to a stop
- [Detector alarm (Servo drive unit)]
- AT343, AT543, AT545(Mitsutoyo) ROM/RAM error
- LC193M, LC493M, RCN223M, RCN227M, RCN727M, RCN827M, EIB Series(HEIDENHAIN) ROM/ RAM error

- MPRZ Series(MHI) Scale breaking
- SAM/SVAM/GAM/LAM Series (FAGOR) H/W error

[Detector alarm (Spindle drive unit)]

- MPC1 scale(MHI) Scale breaking

(Note) A driver processes all reset types of alarms as "PR". However, "AR" will be applied according to the detector.

**001F Machine side dtc: Commu error**

**Details**

An error was detected in the communication with the machine side detector.

- Servo stop method: Dynamic stop
- Spindle stop method: Coast to a stop

**0021 Machine side dtc: No signal**

**Details**

In the machine side detector, ABZ-phase feedback cannot be returned even when the motor moves.

- Servo stop method: Dynamic stop
- Spindle stop method: Coast to a stop

**0022 Detector data error**

**Details**

An error was detected in the feedback data from the position detector.

- Servo stop method: Dynamic stop

**0023 Excessive speed error**

**Details**

The state that there is a difference between the actual speed and command speed continued for longer than the excessive speed deviation timer setting.

- Spindle stop method: Coast to a stop

## 0024 Grounding

### Details

- The motor power cable is in contact with FG (Frame Ground).
- Servo stop method: Dynamic stop
  - Spindle stop method: Coast to a stop

## 0025 Absolute position data lost

### Details

- The absolute position data was lost in the detector.
- Servo stop method: Initial error

## 0026 Unused axis error

### Details

- In the multi-axis drive unit, there is an axis set to free, and the other axis detected a power module error.
- Servo stop method: Dynamic stop
  - Spindle stop method: Coast to a stop

## 0027 Machine side dtc: Error 5

### Details

- An error was detected by the detector connected to the machine side.  
The error details are different according to the detector type.
- Servo stop method: Dynamic stop
  - Spindle stop method: Coast to a stop
- [Detector alarm (Servo drive unit)]
- MDS-B-HR() Scale not connected
  - AT343, AT543, AT545(Mitsutoyo) CPU error
  - LC193M, LC493M, RCN223M, RCN227M, RCN727M, RCN827M, EIB Series(HEIDENHAIN) CPU error
  - MPRZ Series(MHI) Absolute value detection fault
  - SAM/SVAM/GAM/LAN Series (FAGOR) CPU error
- [Detector alarm (Spindle drive unit)]
- MDS-B-HR() Connection error
  - EIB Series(HEIDENHAIN) CPU error
- (Note) A driver processes all reset types of alarms as "PR". However, "AR" will be applied according to the detector.

## 0028 Machine side dtc: Error 6

### Details

- An error was detected by the detector connected to the machine side.  
The error details are different according to the detector type.
- Servo stop method: Dynamic stop
  - Spindle stop method: Coast to a stop
- [Detector alarm (Servo drive unit)]
- AT343, AT543, AT545(Mitsutoyo) Photoelectric type overspeed
  - LC193M, LC493M, RCN223M, RCN227M, RCN727M, RCN827M, EIB Series(HEIDENHAIN) Overspeed
  - SR75, SR85, SR77, SR87, RU77(Magnescape) Over speed
- [Detector alarm (Spindle drive unit)]
- TS5690, TS5691(MITSUBISHI) Overspeed
  - EIB Series(HEIDENHAIN) Overspeed
- (Note) A driver processes all reset types of alarms as "PR". However, "AR" will be applied according to the detector.

## Appendix 2 Explanation of Alarms

### 0029 Machine side dtc: Error 7

#### Details

An error was detected by the detector connected to the machine side.  
The error details are different according to the detector type.

- Servo stop method: Dynamic stop
- Spindle stop method: Coast to a stop
- [Detector alarm (Servo drive unit)]
- AT343, AT543, AT545(Mitsutoyo) Static capacity type error
- LC193M, LC493M, RCN223M, RCN227M, RCN727M, RCN827M, EIB Series(HEIDENHAIN)

Absolute position data error

- MPRZ Series(MHI) Gain fault
- SR75, SR85, SR77, SR87, RU77(Magnescale) Absolute position data error
- [Detector alarm (Spindle drive unit)]
- MPC1 scale(MHI) Gain fault

(Note) A driver processes all reset types of alarms as "PR". However, "AR" will be applied according to the detector.

### 002A Machine side dtc: Error 8

#### Details

An error was detected by the detector connected to the machine side.  
The error details are different according to the detector type.

- Servo stop method: Dynamic stop
- Spindle stop method: Coast to a stop
- [Detector alarm (Servo drive unit)]
- AT343, AT543, AT545(Mitsutoyo) Photoelectric type error
- LC193M, LC493M, RCN223M, RCN227M, RCN727M, RCN827M, EIB Series(HEIDENHAIN)

Relative position data error

- MPRZ Series(MHI) Phase fault
- SR75, SR85, SR77, SR87, RU77(Magnescale) Relative position data error
- [Detector alarm (Spindle drive unit)]
- TS5690, TS5691(MITSUBISHI) Relative position data error
- EIB Series(HEIDENHAIN) Relative position data error

- MPC1 scale(MHI) Phase fault

(Note) A driver processes all reset types of alarms as "PR". However, "AR" will be applied according to the detector.

### 002B Motor side dtc: Error 1

#### Details

An error was detected by the detector connected to the motor side.  
The error details are different according to the detector type.

- Servo stop method: Dynamic stop
- Spindle stop method: Coast to a stop
- [Detector alarm (Servo drive unit)]
- OSA105, OSA105-ET2, OSA166, OSA166-ET2(MITSUBISHI) Memory alarm
- OSA18() CPU alarm
- MDS-B-HR() Memory error
- AT343, AT543, AT545(Mitsutoyo) Initialization error
- LC193M, LC493M, RCN223M, RCN227M, RCN727M, RCN827M, EIB Series(HEIDENHAIN)

Initialization error

- MPRZ Series(MHI) Installation accuracy fault
- SR75, SR85, SR77, SR87, RU77(Magnescale) Laser diode error
- [Detector alarm (Spindle drive unit)]
- TS5690, TS5691(MITSUBISHI) Memory error
- MDS-B-HR() Initialization error
- OSA18() CPU error
- EIB Series(HEIDENHAIN) Initialization error
- MPC1 scale(MHI) Installation accuracy fault

(Note) A driver processes all reset types of alarms as "PR". However, "AR" will be applied according to the detector.

## 002C Motor side dtc: Error 2

### Details

An error was detected by the detector connected to the motor side.

The error details are different according to the detector type.

- Servo stop method: Dynamic stop
- Spindle stop method: Coast to a stop
- [Detector alarm (Servo drive unit)]
- OSA105, OSA105-ET2, OSA166, OSA166-ET2(MITSUBISHI) LED alarm
- AT343, AT543, AT545(Mitsutoyo) EEPROM error
- LC193M, LC493M, RCN223M, RCN227M, RCN727M, RCN827M, EIB Series(HEIDENHAIN) EEPROM error

- SR75, SR85, SR77, SR87, RU77(Magnescale) System memory error

[Detector alarm (Spindle drive unit)]

- TS5690, TS5691(MITSUBISHI) Waveform error
- EIB Series(HEIDENHAIN) EEPROM error

(Note) A driver processes all reset types of alarms as "PR". However, "AR" will be applied according to the detector.

## 002D Motor side dtc: Error 3

### Details

An error was detected by the detector connected to the motor side.

The error details are different according to the detector type.

- Servo stop method: Dynamic stop
- Spindle stop method: Coast to a stop
- [Detector alarm (Servo drive unit)]
- OSA105, OSA105-ET2, OSA166, OSA166-ET2(MITSUBISHI) Data alarm
- OSA18() Data alarm
- MDS-B-HR() Data error
- AT343, AT543, AT545(Mitsutoyo) Photoelectric type, static capacity type data mismatch
- LC193M, LC493M, RCN223M, RCN227M, RCN727M, RCN827M, EIB Series(HEIDENHAIN) Relative/ absolute position data mismatch

- MPRZ Series(MHI) Detection position deviance
- SR75, SR85, SR77, SR87, RU77(Magnescale) Encoder mismatch error
- SAM/SVAM/GAM/LAN Series (FAGOR) Absolute position detection error

[Detector alarm (Spindle drive unit)]

- MDS-B-HR() Data error
- OSA18() Data error
- MPC1 scale(MHI) Detection position deviance

(Note) A driver processes all reset types of alarms as "PR". However, "AR" will be applied according to the detector.

## 002E Motor side dtc: Error 4

### Details

An error was detected by the detector connected to the motor side.

The error details are different according to the detector type.

- Servo stop method: Dynamic stop
- Spindle stop method: Coast to a stop
- [Detector alarm (Servo drive unit)]
- AT343, AT543, AT545(Mitsutoyo) ROM/RAM error
- LC193M, LC493M, RCN223M, RCN227M, RCN727M, RCN827M, EIB Series(HEIDENHAIN) ROM/RAM error

- MPRZ Series(MHI) Scale breaking
- SAM/SVAM/GAM/LAM Series (FAGOR) H/W error

[Detector alarm (Spindle drive unit)]

- MPC1 scale(MHI) Scale breaking

(Note) A driver processes all reset types of alarms as "PR". However, "AR" will be applied according to the detector.

## 002F Motor side dtc: Commu error

### Details

An error was detected in the communication with the motor side detector.

- Servo stop method: Dynamic stop
- Spindle stop method: Coast to a stop

### 0030 Over regeneration

#### Details

- Over-regeneration level exceeded 100%. The regenerative resistor is overloaded.
- Servo stop method: Dynamic stop
  - Spindle stop method: Coast to a stop

### 0031 Overspeed

#### Details

- The motor speed exceeded the allowable speed.
- Servo stop method: Deceleration stop enabled
  - Spindle stop method: Deceleration stop enabled

### 0032 Power module overcurrent

#### Details

- The power module detected the overcurrent.
- Servo stop method: Dynamic stop
  - Spindle stop method: Coast to a stop

### 0033 Overvoltage

#### Details

- The bus voltage in main circuit exceeded the allowable value.
- Servo stop method: Dynamic stop
  - Spindle stop method: Coast to a stop

### 0034 NC-DRV commu: CRC error

#### Details

- The data received from the NC was outside the setting range.
- Servo stop method: Deceleration stop enabled
  - Spindle stop method: Deceleration stop enabled

### 0035 NC command error

#### Details

- The travel command data received from the NC was excessive.
- Servo stop method: Deceleration stop enabled
  - Spindle stop method: Deceleration stop enabled

### 0036 NC-DRV commu: Commu error

#### Details

- The communication with the NC was interrupted.
- Servo stop method: Deceleration stop enabled
  - Spindle stop method: Deceleration stop enabled

### 0037 Initial parameter error

#### Details

- An incorrect set value was detected among the parameters send from the NC at the power ON.  
In the safety observation function, an error was detected in the relation between the safety speed and safety rotation number in the speed observation mode.
- Servo stop method: Initial error
  - Spindle stop method: Initial error

### 0038 NC-DRV commu: Protocol error 1

#### Details

- An error was detected in the communication frames received from the NC.  
Or, removing an axis or changing an axis was performed in the synchronous control.
- Servo stop method: Deceleration stop enabled
  - Spindle stop method: Deceleration stop enabled

#### 0039 NC-DRV commu: Protocol error 2

##### Details

An error was detected in the axis data received from the NC.

Or, in changing an axis, the parameter setting of the synchronous control was applied when the axis was installed.

- Servo stop method: Deceleration stop enabled
- Spindle stop method: Deceleration stop enabled

#### 003A Overcurrent

##### Details

Excessive motor drive current was detected.

- Servo stop method: Dynamic stop
- Spindle stop method: Coast to a stop

#### 003B Power module overheat

##### Details

The power module detected an overheat.

- Servo stop method: Dynamic stop
- Spindle stop method: Coast to a stop

#### 003C Regeneration circuit error

##### Details

An error was detected in the regenerative transistor or in the regenerative resistor.

- Servo stop method: Dynamic stop

#### 003D Pw sply volt err acc/dec

##### Details

A motor control error during acceleration/deceleration, due to a power voltage failure, was detected.

- Servo stop method: Dynamic stop

#### 003E Magnet pole pos detect err

##### Details

The magnetic pole position, detected in the magnetic pole position detection control, is not correctly detected.

- Servo stop method: Dynamic stop
- Spindle stop method: Coast to a stop

#### 0041 Feedback error 3

##### Details

Either a missed feedback pulse in the motor side detector or an error in the Z-phase was detected in the full closed loop system.

- Servo stop method: Dynamic stop
- Spindle stop method: Coast to a stop

#### 0042 Feedback error 1

##### Details

Either a missed feedback pulse in the position detection or an error in the Z-phase was detected. Or the distance-coded reference check error exceeded the allowable value when the distance-coded reference scale was used.

- Servo stop method: Dynamic stop
- Spindle stop method: Coast to a stop

#### 0043 Feedback error 2

##### Details

An excessive difference in feedback was detected between the machine side detector and the motor side detector.

- Servo stop method: Dynamic stop
- Spindle stop method: Coast to a stop

## Appendix 2 Explanation of Alarms

### 0045 Fan stop

#### Details

- An overheat of the power module was detected during the cooling fan stopping.
- Servo stop method: Dynamic stop
  - Spindle stop method: Coast to a stop

### 0046 Motor overheat

#### Details

- Either the motor or the motor side detector detected an overheat.  
 Or, the thermistor signal receiving circuit of the linear motor or DD motor was disconnected.  
 Or, the thermistor signal receiving circuit was short-circuited.
- Servo stop method: Deceleration stop enabled
  - Spindle stop method: Deceleration stop enabled

### 0048 Motor side dtc: Error 5

#### Details

- An error was detected by the detector connected to the main side.  
 The error details are different according to the connected detector.
- Servo stop method: Dynamic stop
  - Spindle stop method: Coast to a stop
- [Detector alarm (Servo drive unit)]
- MDS-B-HR() Scale not connected
  - AT343, AT543, AT545(Mitsutoyo) CPU error
  - LC193M, LC493M, RCN223M, RCN227M, RCN727M, RCN827M, EIB Series(HEIDENHAIN) CPU error
  - MPRZ Series(MHI) Absolute value detection fault
  - SAM/SVAM/GAM/LAM Series (FAGOR) CPU error
- [Detector alarm (Spindle drive unit)]
- MDS-B-HR() Connection error
  - EIB Series(HEIDENHAIN) CPU error
- (Note) A driver processes all reset types of alarms as "PR". However, "AR" will be applied according to the detector.

### 0049 Motor side dtc: Error 6

#### Details

- An error was detected by the detector connected to the main side.  
 The error details are different according to the connected detector.
- Servo stop method: Dynamic stop
  - Spindle stop method: Coast to a stop
- [Detector alarm (Servo drive unit)]
- AT343, AT543, AT545(Mitsutoyo) Photoelectric type overspeed
  - LC193M, LC493M, RCN223M, RCN227M, RCN727M, RCN827M, EIB Series(HEIDENHAIN) Overspeed
  - SR75, SR85, SR77, SR87, RU77(Magnescale) Over speed
- [Detector alarm (Spindle drive unit)]
- TS5690, TS5691(MITSUBISHI) Overspeed
  - EIB Series(HEIDENHAIN) Overspeed
- (Note) A driver processes all reset types of alarms as "PR". However, "AR" will be applied according to the detector.

### 004A Motor side dtc: Error 7

#### Details

- An error was detected by the detector connected to the main side.  
 The error details are different according to the connected detector.
- Servo stop method: Dynamic stop
  - Spindle stop method: Coast to a stop
- [Detector alarm (Servo drive unit)]
- AT343, AT543, AT545(Mitsutoyo) Static capacity type error
  - LC193M, LC493M, RCN223M, RCN227M, RCN727M, RCN827M, EIB Series(HEIDENHAIN) Absolute position data error
  - MPRZ Series(MHI) Gain fault
  - SR75, SR85, SR77, SR87, RU77(Magnescale) Absolute position data error
- [Detector alarm (Spindle drive unit)]
- MPC1 scale(MHI) Gain fault
- (Note) A driver processes all reset types of alarms as "PR". However, "AR" will be applied according to the detector.

#### 004B Motor side dtc: Error 8

##### Details

An error was detected by the detector connected to the main side.  
The error details are different according to the connected detector.

- Servo stop method: Dynamic stop
- Spindle stop method: Coast to a stop
- [Detector alarm (Servo drive unit)]
- AT343, AT543, AT545(Mitsutoyo) Photoelectric type error
- LC193M, LC493M, RCN223M, RCN227M, RCN727M, RCN827M, EIB Series(HEIDENHAIN) Relative position data error
- MPRZ Series(MHI) Phase fault
- SR75, SR85, SR77, SR87, RU77(Magnescale) Relative position data error
- [Detector alarm (Spindle drive unit)]
- TS5690, TS5691(MITSUBISHI) Relative position data error
- EIB Series(HEIDENHAIN) Relative position data error
- MPC1 scale(MHI) Phase fault

(Note) A driver processes all reset types of alarms as "PR". However, "AR" will be applied according to the detector.

#### 004C Current err mag pole estim

##### Details

Current detection failed at the initial magnetic pole estimation.

- Servo stop method: Dynamic stop
- Spindle stop method: Coast to a stop

#### 004E NC command mode error

##### Details

An error was detected in the control mode send from the NC.

- Servo stop method: Deceleration stop enabled
- Spindle stop method: Deceleration stop enabled

#### 004F Instantaneous power interrupt

##### Details

The control power supply has been shut down for 50ms or more.

- Servo stop method: Deceleration stop enabled
- Spindle stop method: Deceleration stop enabled

#### 0050 Overload 1

##### Details

Overload detection level became 100% or more. The motor or the drive unit is overloaded.

- Servo stop method: Deceleration stop enabled
- Spindle stop method: Deceleration stop enabled

#### 0051 Overload 2

##### Details

In a servo system, current command of 95% or more of the unit's max. current was given continuously for 1 second or longer. In a spindle system, current command of 95% or more of the motor's max. current was given continuously for 1 second or longer.

- Servo stop method: Deceleration stop enabled
- Spindle stop method: Deceleration stop enabled

#### 0052 Excessive error 1

##### Details

A position tracking error during servo ON was excessive.

- Servo stop method: Deceleration stop enabled
- Spindle stop method: Deceleration stop enabled

#### 0053 Excessive error 2

##### Details

A position tracking error during servo OFF was excessive.

- Servo stop method: Dynamic stop



## Appendix 2 Explanation of Alarms

### 0054 Excessive error 3

#### Details

- There was no motor current feedback when the alarm "Excessive error 1" was detected.
- Servo stop method: Dynamic stop
  - Spindle stop method: Coast to a stop

### 0056 Commanded speed error

#### Details

- In the C-axis control mode, excessive speed error was detected.
- Spindle stop method: Deceleration stop enabled

### 0058 Collision detection 1: G0

#### Details

- A disturbance torque exceeded the allowable value in rapid traverse modal (G0).
- Servo stop method: Maximum capacity deceleration stop

### 0059 Collision detection 1: G1

#### Details

- A disturbance torque exceeded the allowable value in the cutting feed modal (G1).
- Servo stop method: Maximum capacity deceleration stop

### 005A Collision detection 2

#### Details

- A current command with the maximum drive unit current value was detected.
- Servo stop method: Maximum capacity deceleration stop

### 005B Sfty obsrvation: Cmd spd err

#### Details

- A commanded speed exceeding the safe speed was detected in the safety observation mode.
- Servo stop method: Deceleration stop enabled
  - Spindle stop method: Deceleration stop enabled

### 005D Sfty obsrvation: Door stat err

#### Details

- The door state signal input in the NC does not coincide with the door state signal input in the drive unit in the safety observation mode. Otherwise, door open state was detected in normal mode.
- Servo stop method: Deceleration stop enabled
  - Spindle stop method: Deceleration stop enabled

### 005E Sfty obsrvation: FB speed err

#### Details

- A motor speed exceeding the safe speed was detected in the safety observation mode.
- Servo stop method: Deceleration stop enabled
  - Spindle stop method: Deceleration stop enabled

### 005F External contactor error

#### Details

- A contact of the external contactor is welding.
- Servo stop method: Deceleration stop enabled
  - Spindle stop method: Deceleration stop enabled

### 0080 Motor side dtc: cable err

#### Details

- The cable type of the motor side detector cable is for rectangular wave signal.
- Servo stop method: Initial error

### 0081 Machine side dtc: cable err

#### Details

- The cable type of the machine side detector cable does not coincide with the detector type which is set by the parameter.
- Servo stop method: Initial error

#### 0087 Drive unit communication error

##### Details

- The communication frame between drive units was aborted.
- Servo stop method: Dynamic stop
  - Spindle stop method: Coast to a stop

#### 0088 Watchdog

##### Details

- The drive unit does not operate correctly.
- Servo stop method: Dynamic stop
  - Spindle stop method: Coast to a stop

#### 008A Drivers commu data error 1

##### Details

- The communication data 1 between drivers exceeded the tolerable value in the communication between drive units.
- Servo stop method: Dynamic stop
  - Spindle stop method: Coast to a stop

#### 008B Drivers commu data error 2

##### Details

- The communication data 2 between drivers exceeded the tolerable value in the communication between drive units.
- Servo stop method: Dynamic stop
  - Spindle stop method: Coast to a stop

Power supply alarms

**0061 Pw sply: Pwr module overcurrnt**

**Details**

Overcurrent protection function in the power module has started its operation.  
- LED display: 1

**0062 Pw sply: Frequency error**

**Details**

The input power supply frequency increased above the specification range.  
- LED display: 2

**0066 Process error**

**Details**

An error occurred in the process cycle.  
- LED display: 6

**0067 Pw sply: Phase interruption**

**Details**

An open-phase condition was detected in input power supply circuit.  
- LED display: 7

**0068 Pw sply: Watchdog**

**Details**

The system does not operate correctly.  
- LED display: 8

**0069 Pw sply: Grounding**

**Details**

The motor power cable is in contact with FG (Frame Ground).  
- LED display: 9

**006A Pw sply: Ext contactor weld**

**Details**

A contact of the external contactor is welding.  
- LED display: A

**006B Pw sply: Rush relay welding**

**Details**

An error was detected in the rush circuit.  
- LED display: b

**006C Pw sply: Main circuit error**

**Details**

An error was detected in charging operation of the main circuit capacitor.  
- LED display: C

**006D Pw sply: Parameter error**

**Details**

An error was detected in the parameter sent from the drive unit.  
- LED display: d

**006E Pw sply: Memory error**

**Details**

An error was detected in the internal memory.  
An error was detected in the A/D converter.  
An error was detected in the unit identification.  
- LED display: E

#### 006F Power supply error

##### Details

No power supply is connected to the drive unit, or a communication error was detected.  
- LED display: F

#### 0070 Pw sply: External EMG stop err

##### Details

A mismatch of the external emergency stop input and NC emergency stop input continued for 30 seconds.  
- LED display: G

#### 0071 Pw sply: Instant pwr interrupt

##### Details

The power was momentarily interrupted.  
- LED display: H

#### 0072 Pw sply: Fan stop

##### Details

A cooling fan built in the power supply unit stopped, and overheat occurred in the power module.  
- LED display: I

#### 0073 Pw sply: Over regeneration

##### Details

Over-regeneration detection level became over 100%. The regenerative resistor is overloaded. This alarm cannot be reset for 15 min from the occurrence to protect the regeneration resistor. Leave the drive system energized for more than 15 min, then turn the power ON to reset the alarm.  
- LED display: J

#### 0075 Pw sply: Overvoltage

##### Details

L+ and L- bus voltage in main circuit exceeded the allowable value. As the voltage between L+ and L- is high immediately after this alarm, another alarm may occur if this alarm is reset in a short time. Wait more than 5 min before resetting so that the voltage drops.  
- LED display: L

#### 0076 Pw sply: Ext EMG stop set err

##### Details

The rotary switch setting of external emergency stop is not correct, or a wrong external emergency stop signal is input.  
- LED display: M

#### 0077 Pw sply: Power module overheat

##### Details

Thermal protection function in the power module has started its operation.  
- LED display: n

### Appendix 2.3.2 Initial Parameter Errors (S02)

#### S02 Initial parameter error : PR 2201-2264 (Axis name)

##### Details

The servo parameter setting data is illegal.  
The alarm No. is the No. of the servo parameter where the error occurred.

##### Remedy

Check the descriptions for the appropriate servo parameters and correct them.

#### S02 Initial parameter error : PR 2301 (Axis name)

##### Details

The number of constants to be used in the following functions is too large:

- Electronic gears
- Position loop gain
- Speed feedback conversion

##### Remedy

Check that all the related parameters are specified correctly.  
sv001:PC1, sv002:PC2, sv003:PGN1  
sv018:PIT, sv019:RNG1, sv020:RNG2

#### S02 Initial parameter error : PR 2302 (Axis name)

##### Details

When high-speed serial incremental detector (OSE104, OSE105) is connected, parameters for absolute position are set to ON.

Set the parameters for absolute position detection to OFF.

To detect an absolute position, replace the incremental specification detector with an absolute position detector.

##### Remedy

Check that all the related parameters are specified correctly.  
sv017:SPEC, sv025:MTYP

#### S02 Initial parameter error : PR 2303 (Axis name)

##### Details

No servo option is found.

The closed loop (including the ball screw-end detector) or dual feedback control is an optional function.

##### Remedy

Check that all the related parameters are specified correctly.  
sv025:MTYP/pen  
sv017:SPEC/dfbx

#### S02 Initial parameter error : PR 2304 (Axis name)

##### Details

No servo option is found.

The SHG control is an optional function.

##### Remedy

Check that all the related parameters are specified correctly.  
sv057:SHGC  
sv058:SHGCsp

#### S02 Initial parameter error : PR 2305 (Axis name)

##### Details

No servo option is found.

The adaptive filtering is an optional function.

##### Remedy

Check that all the related parameters are specified correctly.  
sv027:SSF1/aflt

**S02 Initial parameter error : PR 13001-13256 (Axis name)**

**Details**

Parameter error

The spindle parameter setting data is illegal.

The alarm No. is the No. of the spindle parameter where the error occurred.

**Remedy**

Check the descriptions for the appropriate spindle parameters and correct them.

Refer to Alarm No.37 in Spindle Drive Maintenance Manual.

### Appendix 2.3.3 Parameter Errors (S51)

#### S51 Parameter error 2201-2264 (Axis name)

##### Details

Servo parameter setting data is illegal.

The alarm No. is the No. of the servo parameter where the warning occurred.

##### Remedy

Check the descriptions for the appropriate servo parameters and correct them.

#### S51 Parameter error 13001-13256 (Axis name)

##### Details

Spindle parameter setting data is illegal.

The alarm No. is the No. of the spindle parameter where the warning occurred.


##### Remedy

Check the descriptions for the appropriate spindle parameters and correct them.

Refer to Spindle Drive Maintenance Manual.

### Appendix 2.3.4 Servo Warnings (S52)

Servo warning is displayed in the following format.



Alarm class	Message
S52	Servo warning

Error No. consists of four digits (0096 to). Servo warnings are explained in ascending order of the error No. The four digits on the left part of each warning indicate the error No.

(Note) For the details of servo warnings, refer to your drive unit's instruction manual.

#### Drive unit warnings

##### 0096 Scale feedback error

###### Details

An excessive difference in feedback amount was detected between the main side detector and the MPI scale in MPI scale absolute position detection system.  
- Reset method: Automatically reset once the cause of the warning is removed.

##### 0097 Scale offset error

###### Details

An error was detected in the offset data that is read at the NC power-ON in MPI scale absolute position detection system.

##### 009B Detec cnv: Mag pole shift warn

###### Details

The difference between the magnetic pole position after the phase Z has been passed (magnetic pole shift amount:SV028) and the initially detected position is excessive in the built-in motor's incremental control system. The magnetic pole is controlled by the initial detection value.  
- Reset method: Automatically reset once the cause of the warning is removed.

##### 009E Abs pos dtc: Rev count error

###### Details

An error was detected in the revolution counter data of the absolute position detector. The accuracy of absolute position is not guaranteed.  
- Reset method: Automatically reset once the cause of the warning is removed.

##### 009F Battery voltage drop

###### Details

The battery voltage to be supplied to the absolute position detector is dropping.  
- Reset method: Automatically reset once the cause of the warning is removed.

##### 00A3 DisCode ref chk: init s-up war

###### Details

This warning is detected until the axis reaches the reference position during the initial setup of the distance-coded reference check function. This warning turns OFF after the axis has reached the position, thus set the value displayed on the drive monitor to the parameter.  
- Reset method: Automatically reset once the cause of the warning is removed.

##### 00A6 Fan stop warning

###### Details

A cooling fan in the drive unit stopped.  
- Reset method: Automatically reset once the cause of the warning is removed.



#### 00E0 Over regeneration warning

##### Details

- Over-regeneration detection level exceeded 80%.  
 - Reset method: Automatically reset once the cause of the warning is removed.

#### 00E1 Overload warning

##### Details

- A level of 80% of the Overload 1 alarm state was detected.  
 - Reset method: Automatically reset once the cause of the warning is removed.

#### 00E4 Set parameter warning

##### Details

- An incorrect set value was detected among the parameters send from the NC in the normal operation.  
 - Reset method: Automatically reset once the cause of the warning is removed.

#### 00E6 Control axis detach warning

##### Details

- A control axis is being detached. (State display)  
 - Reset method: Automatically reset once the cause of the warning is removed.

#### 00E7 In NC emergency stop state

##### Details

- In NC emergency stop. (State display)  
 - Stop method: Deceleration stop enabled  
 - Reset method: Automatically reset once the cause of the warning is removed.

#### 00E8-00EF Power supply warning

##### Details

- The power supply unit detected a warning. The error details are different according to the connected power supply unit.  
 Refer to "Power supply warning".  
 - Stop method: - (EA: Deceleration stop enabled)  
 - Reset method: Automatically reset once the cause of the warning is removed.

## Power supply warnings

### 00E9 Instant pwr interrupt warning

#### Details

- The power was momentarily interrupted.
- LED display: P

### 00EA In external EMG stop state

#### Details

- External emergency stop signal was input.
- Reset method: Automatically reset once the cause of the warning is removed.
  - LED display: q

### 00EB Pw sply: Over regenerat warn

#### Details

- Over-regeneration detection level exceeded 80%.
- Reset method: Automatically reset once the cause of the warning is removed.
  - LED display: r

### 00EE Power supply: Fan stop warning

#### Details

- A cooling fan built in the power supply unit stopped.
- Reset method: Automatically reset once the cause of the warning is removed.
  - LED display: u

## Appendix 2.4 MCP Alarms (Y)

### Y02 System alm: Process time over 0050

#### Details

System alarm: Process time is over.

#### Remedy

The software or hardware may be damaged.  
Contact the service center.

(Note) When two or more "Y02 System alarms" occur at the same time, only the alarm which has occurred first is displayed.

### Y02 SV commu er: CRC error 1 0051 0000

#### Details

A communication error has occurred between controller and drive unit.

#### Remedy

- Take measures against noise.
- Check for any failure of the communication cable connectors between controller and drive unit or between two drive units.
- Check for any failure of the communication cables between controller and drive unit or between two drive units.
- A drive unit may be faulty. Take a note of the 7-segment LED contents of each drive unit and contact the Service Center.
- Update the drive unit software version.

(Note) When two or more "Y02 System alarms" occur at the same time, only the alarm which has occurred first is displayed.

### Y02 SV commu er: CRC error 2 0051 0001

#### Details

A communication error has occurred between controller and drive unit.

#### Remedy

- Take measures against noise.
- Check for any failure of the communication cable connectors between controller and drive unit or between two drive units.
- Check for any failure of the communication cables between controller and drive unit or between two drive units.
- A drive unit may be faulty. Take a note of the 7-segment LED contents of each drive unit and contact the Service Center.
- Update the drive unit software version.

(Note) When two or more "Y02 System alarms" occur at the same time, only the alarm which has occurred first is displayed.

### Y02 SV commu er: Recv timing err 0051 0002

#### Details

A communication error has occurred between controller and drive unit.

#### Remedy

- Take measures against noise.
- Check for any failure of the communication cable connectors between controller and drive unit or between two drive units.
- Check for any failure of the communication cables between controller and drive unit or between two drive units.
- A drive unit may be faulty. Take a note of the 7-segment LED contents of each drive unit and contact the Service Center.
- Update the drive unit software version.

(Note) When two or more "Y02 System alarms" occur at the same time, only the alarm which has occurred first is displayed.

#### Y02 SV commu er: Data ID error 0051 xy03

##### Details

A communication error has occurred between controller and drive unit.

x: Channel No. (0 to)

y: Drive unit rotary switch No. (0 to)

##### Remedy

- Take measures against noise.
- Check for any failure of the communication cable connectors between controller and drive unit or between two drive units.
- Check for any failure of the communication cables between controller and drive unit or between two drive units.
- A drive unit may be faulty. Take a note of the 7-segment LED contents of each drive unit and contact the Service Center.
- Update the drive unit software version.

(Note) When two or more "Y02 System alarms" occur at the same time, only the alarm which has occurred first is displayed.

#### Y02 SV commu er: Recv frame No. 0051 xy04

##### Details

A communication error has occurred between controller and drive unit.

x: Channel No. (from 0)

y: Drive unit rotary switch No. (from 0)

##### Remedy

- Take measures against noise.
- Check for any failure of the communication cable connectors between controller and drive unit or between two drive units.
- Check for any failure of the communication cables between controller and drive unit or between two drive units.
- A drive unit may be faulty. Take a note of the 7-segment LED contents of each drive unit and contact the Service Center.
- Update the drive unit software version.

(Note) When two or more "Y02 System alarms" occur at the same time, only the alarm which has occurred first is displayed.

#### Y02 SV commu er: Commu error 0051 x005

##### Details

A communication error has occurred between controller and drive unit.

x: Channel No. (from 0)

##### Remedy

- Take measures against noise.
- Check for any failure of the communication cable connectors between controller and drive unit or between two drive units.
- Check for any failure of the communication cables between controller and drive unit or between two drive units.
- A drive unit may be faulty. Take a note of the 7-segment LED contents of each drive unit and contact the Service Center.
- Update the drive unit software version.

(Note) When two or more "Y02 System alarms" occur at the same time, only the alarm which has occurred first is displayed.

#### Y02 SV commu er: Connect error 0051 x006

##### Details

A communication error has occurred between controller and drive unit.

x: Channel No. (from 0)

##### Remedy

- Take measures against noise.
- Check for any failure of the communication cable connectors between controller and drive unit or between two drive units.
- Check for any failure of the communication cables between controller and drive unit or between two drive units.
- A drive unit may be faulty. Take a note of the 7-segment LED contents of each drive unit and contact the Service Center.
- Update the drive unit software version.

(Note) When two or more "Y02 System alarms" occur at the same time, only the alarm which has occurred first is displayed.

## Appendix 2 Explanation of Alarms

### Y02 SV commu er : Init commu error 0051 xy20

#### Details

A communication error has occurred between controller and drive unit.  
 A drive unit stopped due to transition failure from initial communication to runtime.  
 x: Channel No. (from 0)  
 y: Drive unit rotary switch No. (from 0)

#### Remedy

- Take measures against noise.
- Check for any failure of the communication cable connectors between controller and drive unit or between two drive units.
- Check for any failure of the communication cables between controller and drive unit or between two drive units.
- A drive unit may be faulty. Take a note of the 7-segment LED contents of each drive unit and contact the Service Center.
- Update the drive unit software version.

(Note) When two or more "Y02 System alarms" occur at the same time, only the alarm which has occurred first is displayed.

### Y02 SV commu er: Node detect error 0051 xy30

#### Details

A communication error has occurred between controller and drive unit.  
 No response from drive unit to the request from NC when setting network configuration.  
 x: Channel No. (from 0)  
 y: Station No. (from 0)

#### Remedy

- Take measures against noise.
- Check for any failure of the communication cable connectors between controller and drive unit or between two drive units.
- Check for any failure of the communication cables between controller and drive unit or between two drive units.
- A drive unit may be faulty. Take a note of the 7-segment LED contents of each drive unit and contact the Service Center.
- Update the drive unit software version.

(Note) When two or more "Y02 System alarms" occur at the same time, only the alarm which has occurred first is displayed.

### Y02 SV commu er: Commu not support 0051 xy31

#### Details

A communication error has occurred between controller and drive unit.  
 Drive unit's software version doesn't support the communication mode that the controller requires.  
 x: Channel No. (from 0)  
 y: Station No. (from 0)

#### Remedy

- Take measures against noise.
- Check for any failure of the communication cable connectors between controller and drive unit or between two drive units.
- Check for any failure of the communication cables between controller and drive unit or between two drive units.
- A drive unit may be faulty. Take a note of the 7-segment LED contents of each drive unit and contact the Service Center.
- Update the drive unit software version.

(Note) When two or more "Y02 System alarms" occur at the same time, only the alarm which has occurred first is displayed.

### Y02 System alarm 0052 0001

#### Details

Transfer to buffer is not properly done in servo communication.

#### Remedy

Software/ hardware may have a fault.  
 Contact service center.

(Note) When two or more "Y02 System alarms 0051" alarms occur at the same time, only the alarm which occurs first is displayed.

### Y03 Drive unit unequipped axis name

#### Details

The drive unit is not correctly connected.  
Alphabet (axis name): Servo axis drive unit not mounted  
1 to 4: PLC axis drive unit not mounted  
S: No.1 spindle drive unit not mounted  
T: No.2 spindle drive unit not mounted  
M: No.3 spindle drive unit not mounted  
N: No.4 spindle drive unit not mounted

#### Remedy

Check the drive unit mounting state.  
- Check the end of the cable wiring.  
- Check for any broken wires.  
- Check the connector insertion.  
- The drive unit input power has not been ON.  
- The drive unit axis No. switch is illegal.

### Y05 Initial parameter error

#### Details

There is a problem in the value set for the number of axes or the number of part systems.

#### Remedy

Correct the value set for the following corresponding parameters:  
"#1001 SYS\_ON (System validation setup)",  
"#1002 axisno (Number of axes)",  
"#1039 spinno (Number of spindles)", etc.

### Y06 mcp\_no setting error 0001

#### Details

There is a skipped number in the channels.

#### Remedy

Check the values set for the following parameters.  
"#1021 mcp\_no (Drive unit I/F channel No. (servo))"  
"#3031 smcp\_no (Drive unit I/F channel No. (spindle))"

### Y06 mcp\_no setting error 0002

#### Details

There is a duplicate setting for random layout.

#### Remedy

Check the values set for the following parameters.  
"#1021 mcp\_no (Drive unit I/F channel No. (servo))"  
"#3031 smcp\_no (Drive unit I/F channel No. (spindle))"

### Y06 mcp\_no setting error 0003

#### Details

The drive unit fixed setting "0000" and random layout setting "\*\*\*\*\*" are both set.

#### Remedy

Check the values set for the following parameters.  
"#1021 mcp\_no (Drive unit I/F channel No. (servo))"  
"#3031 smcp\_no (Drive unit I/F channel No. (spindle))"

### Y06 mcp\_no setting error 0004

#### Details

The spindle/C axis "#1021 mcp\_no (Drive unit I/F channel No. (servo))" and "#3031 smcp\_no (Drive unit I/F channel No. (spindle))" are not set to the same values.

#### Remedy

Check the values set for the following parameters.  
"#1021 mcp\_no (Drive unit I/F channel No. (servo))"  
"#3031 smcp\_no (Drive unit I/F channel No. (spindle))"

### Y06 mcp\_no setting error 0005

#### Details

A random layout has been set while "#1154 pdoor" has been set to "1" in two-part system.

#### Remedy

Check the values set for the following parameters.  
 "#1021 mcp\_no (Drive unit I/F channel No. (servo))"  
 "#3031 smcp\_no (Drive unit I/F channel No. (spindle))"

### Y06 mcp\_no setting error 0006

#### Details

The channel No. parameter is not within the setting range.

#### Remedy

Check the values set for the following parameters.  
 "#1021 mcp\_no (Drive unit I/F channel No. (servo))"  
 "#3031 smcp\_no (Drive unit I/F channel No. (spindle))"

### Y07 Too many axes connected 00xy

#### Details

The number of axes connected to each channel exceeds the maximum number of connectable axes.  
 The exceeded number of axes per channel is displayed as alarm No.

x: Exceeded number of axes at drive unit interface channel 2 (0 to F)

y: Exceeded number of axes at drive unit interface channel 1 (0 to F)

This alarm also occurs when the drive unit is connected only with the 2nd channel without connecting with the 1st channel.

#### Remedy

Remove connected axes from the channel whose alarm No. is other than '0' for the number displayed as the alarm No. Keep the number of connected axes to or less than the maximum that can be connected.

(Note 1) The number of axes is limited per each drive unit interface channel.

(Note 2) Maximum number of axes that can be connected differs depending on whether or not an expansion unit is available or the setting of '#11012 16 axes for 1ch (Connecting 16 axes for 1ch)'.

With the expansion unit, up to eight axes can be connected to a channel. Without the expansion unit, up to eight axes are allowed when '#11012 16 axes for 1ch (Connecting 16 axes for 1ch)' is set to '0', sixteen axes when set to '1'.

(Note 3) If this alarm occurs, the alarm 'Y03 Message: Drive unit unequipped' will not occur.

(Note 4) This alarm is displayed taking precedence over the alarm 'Y08 Too many drive units connected' and 'Y09 Too many axisno connected'.

### Y08 Too many drive units connected 00xy

#### Details

The number of drive units connected to each channel exceeds 8.  
 The exceeded number of drive units per channel is displayed as alarm No.

x: Exceeded number of drive units at drive unit interface channel 2 (0 to F)

y: Exceeded number of drive units at drive unit interface channel 1 (0 to F)

#### Remedy

Remove drive units from the channel whose alarm No. is other than "0" for the number displayed as the alarm No. Keep the number of connected drive units to 8 or less.

(Note 1) The drive unit is not counted when all the axes connected to it are invalid.

(Note 2) If this alarm occurs, the alarm "Y03 Message: Drive unit unequipped" will not occur.

(Note 3) The alarm "Y07 Too many axes connected" and "Y09 Too many axisno connected" are displayed taking precedence over this alarm.

### Y09 Too many axisno connected 00xy

#### Details

The No. of the axis (drive unit's rotary switch No.) connected to each channel is bigger than the No. allowed.

If the axis No. of each channel is bigger than the No. allowed, "1" is displayed for the alarm No.

x: "1" when the axis No. at drive unit interface channel 2 is too big

y: "1" when the axis No. at drive unit interface channel 1 is too big

#### Remedy

For the channel whose alarm No. is "1", keep the axis No. (drive unit's rotary switch No.) not bigger than the No. allowed.

(Note 1) The axis No. is limited per each drive unit interface channel.

(Note 2) The biggest allowed connected axis No. differs depending on whether or not an expansion unit is available or the setting of "#11012 16 axes for 1ch (Connecting 16 axes for 1ch)". The biggest connectable axis No. is as shown below.

With the expansion unit, axes No. '0' to '7' can be connected.

Without the expansion unit, axes No. '0' to '7' are allowed when '#11012 16 axes for 1ch (Connecting 16 axes for 1ch)' is set to '0', axes No. '0' to 'F' when set to '1'.

(Note 3) If this alarm occurs, the alarm "Y03 Message: Drive unit unequipped" will not occur.

(Note 4) This alarm is displayed taking precedence over the alarm "Y08 Too many drive units connected".

(Note 5) The alarm "Y07 Too many axes connected" is displayed taking precedence over this alarm.

### Y11 Node Detect Err 8002-8300 xy00

#### Details

Drive unit does not respond to the request from NC when the NC is turned ON.

Error No. shows the No. of communication phase at which the response stopped.

x: Channel No. (0 or later)

y: Station No. with the error (0 or later)

#### Remedy

The communication error may be caused by the drive unit software version that does not correspond to the NC software version. Check the drive unit software version.

This alarm is canceled after the NC restarts.

When the alarm is not canceled, write down the alarm No. and contact service center.

### Y12 No commu. with axis drv unit

#### Details

Although the high-speed synchronous tapping option is valid, the connected drive unit doesn't support the option.

#### Remedy

Replace the drive unit with that supports the option.

### Y13 No commu. with sp drv unit

#### Details

Although the high-speed synchronous tapping option is valid, the connected drive unit doesn't support the option.

#### Remedy

Replace the drive unit with that supports the option.

### Y14 Comm btwn drives not ready

#### Details

Communication between drive units failed to be ready within a specified time.

#### Remedy

- There may be a faulty connection of drive units.
- Check if any of drive units is broken.



## Y20 Parameter compare error 0001 (Axis name)

### Details

The speed monitoring parameter in the NC does not correspond to the parameter transmitted to the drive unit.  
The name of the axis with an error is displayed.

### Remedy

The NC or the servo drive unit may be damaged.  
Contact the service center.

## Y20 Sfty obsrvation: Cmd spd err 0002 (Axis name)

### Details

The speed exceeding the speed set with the parameter was commanded during the speed monitoring mode.  
The name of the axis with an error is displayed.

### Remedy

Check the speed monitoring parameter and the sequence program.  
Restart the NC.

## Y20 Sfty obsrvation: FB pos err 0003 (Axis name)

### Details

The commanded position, transmitted to the servo drive unit from NC, is totally different from the feedback position received from the servo drive unit during the speed monitoring mode.  
The name of the axis with an error is displayed.

### Remedy

The NC or the servo drive unit may be damaged.  
Contact the service center.

## Y20 Sfty obsrvation: FB speed err 0004 (Axis name)

### Details

Actual rotation speed of the motor is exceeding the speed that has been set with speed monitoring parameter during the speed monitoring mode.  
The name of the axis with an error is displayed.

### Remedy

Correct the speed observation parameter and the sequence program.  
Restart the NC.

## Y20 Door signal: Input mismatch 0005 Door No.

### Details

Door state signals on the NC side and the drive side do not match. It may be caused by the followings:  
- Cable disconnection  
- Damaged door switch  
- Damaged NC or servo drive unit

### Remedy

Check the cable.  
Check the door switch.  
Restart the NC.

## Y20 No speed observation mode in door open 0006 Door No.

### Details

The door open state was detected when the speed monitoring mode was invalid.  
The causes may be same as the ones for 0005 (Door signal: Input mismatch). Also the sequence program may not be correct.

### Remedy

Correct the sequence program.  
Restart the NC.

## Y20 Speed obsv: Para incompatible 0007 (Axis name)

### Details

Two speed monitoring parameters are not matched at the rising edge of the "speed monitor mode" signal.  
The name of the axis with an error is displayed.

### Remedy

Correct the relevant parameters so that the two speed monitoring parameters match.  
Restart the NC.

## Y20 Contactor welding detected 0008 Contactor No.

### Details

Contactor welding was detected.  
Displays the bit corresponding to the No. of the abnormal contactor.  
Some contactors take a while to be shutdown after the servo ready is turned OFF, and the servo ready was turned ON in the meantime.

### Remedy

- Make sure that contactor's auxiliary B contact signal is output correctly to the device set on "#1330 MC\_dp1(Contactor weld detection device 1)" and "#1331 MC\_dp2(Contactor weld detection device 2)".
- If welding, replace the contactor.
- Restart the NC.

## Y20 No spec: Safety observation 0009

### Details

"#2313 SV113 SSF8/bitF (Servo function selection 8)" and "#13229 SP229 SFNC9/bitF (Spindle function 9)" are set for a system with no safety observation option.

### Remedy

Disable "#2313 SV113 SSF8/bitF (Servo function selection 8)" and "#13229 SP229 SFNC9/bitF (Spindle function 9)".  
Then, restart the NC.

## Y20 SDIO connector input volt err 0010

### Details

24VDC power is not supplied to SDIO connector correctly. (SDIO 4A pin supply voltage was dropped to 16V or less, or 1ms or more instant power interrupt was detected.)  
In this case, "Pw sply:Inst pw interpt(DC24V)" alarm occurs because the contactor control output signal cannot be controlled.  
This state remains until restarting the NC even if the cause of the alarm has been removed.

### Remedy

Check the wiring. Supply 24VDC power to the SDIO connector.  
Restart the NC.

## Y20 Device setting illegal 0011

### Details

- The device set in "#1353 MC\_ct1 (Contactor shutoff output 1 device)" does not exist.
- The device set in "#1353 MC\_ct1 (Contactor shutoff output 1 device)" is used as an output device in PLC program.

### Remedy

- In "#1353 MC\_ct1 (Contactor shutoff output 1 device)", set the device to which a remote I/O is connected. Use the device to control the contactor.
- Confirm that the devices set by "#1353 MC\_ct1 (Contactor shutoff output 1 device)" are not used as an output device in PLC program.

## Y20 Contactor operation abnormal 0012 Contactor No.

### Details

Contactor's operation is not following the NC's commands.  
Displays the No. of the abnormal contactor.

### Remedy

- Check and correct "#1353 MC\_ct1 (Contactor shutoff output 1 device)" setting.
- Check the wiring for contactor shutoff.
- Check for contactor's welding.

#### Y20 Dual signal: parameter setting error 0027

##### Details

A setting of #2118 SscDrSel, #3071 SscDrSelSp, #2180 S\_DIN, or #3140 S\_DINSp is not correct.

##### Remedy

- Correct the parameter setting.

#### Y20 Safety observation: parameter memory error 0031 (Parameter No.)

##### Details

The following parameters are not consistent with the check data.  
#2180 S\_DIN, #3140 S\_DINSp

##### Remedy

- Correct the parameter setting.
- Restore the backup data, as the parameter or check data may be corrupted.

#### Y21 Speed obsv signal: Speed over 0001 (Axis name)

##### Details

The speed exceeds the safety speed limit when the "speed monitor mode" signal is ON.  
The name of the axis with an error is displayed.

##### Remedy

- Decelerate the speed to reset the warning and start the speed monitor.

#### Y51 Parameter G0tL illegal 0001

##### Details

The time constant has not been set or exceeded the setting range.

##### Remedy

- Correct "#2004 G0tL (G0 time constant (linear))".

#### Y51 Parameter G1tL illegal 0002

##### Details

The time constant has not been set or exceeded the setting range.

##### Remedy

- Correct "#2007 G1tL (G1 time constant (linear))".

#### Y51 Parameter G0t1 illegal 0003

##### Details

The time constant has not been set or exceeded the setting range.

##### Remedy

- Correct "#2005 G0t1 (G0 time constant (primary delay) / Second-step time constant for soft acceleration/deceleration)".

#### Y51 Parameter G1t1 illegal 0004

##### Details

The time constant has not been set or exceeded the setting range.

##### Remedy

- Correct "#2008 G1t1 (G1 time constant (primary delay)/Second-step time constant for soft acceleration/deceleration)".

#### Y51 Parameter grid space illegal 0009

##### Details

The grid space is illegal.

##### Remedy

- Correct "#2029 grspc(Grid interval)".

#### Y51 Parameter stapt1-4 illegal 0012

##### Details

The time constant has not been set or exceeded the setting range.

##### Remedy

Correct the parameters from "#3017 stapt1(Tap time constant (Gear: 00))" to "#3020 stapt4(Tap time constant (Gear: 11))".

#### Y51 Slave axis No. illegal 0014

##### Details

In the axis synchronization, parameter settings for slave axis have been attempted in different part system from that of master axis.

##### Remedy

- Correct the "#1068 slavno (Slave axis number)" setting.

#### Y51 Parameter skip\_tL illegal 0015

##### Details

The time constant has exceeded the setting range.

##### Remedy

Correct "#2102 skip\_tL (Skip time constant linear)".

#### Y51 Parameter skip\_t1 illegal 0016

##### Details

The time constant has exceeded the setting range.

##### Remedy

Correct "#2103 skip\_t1 (Skip time constant primary delay / Second-step time constant for soft acceleration/deceleration)".

#### Y51 Parameter G0bdcc illegal 0017

##### Details

"#1205 G0bdcc (Acceleration and deceleration before G0 interpolation)" for the 2nd part system is set to acceleration/deceleration before G0 interpolation.

##### Remedy

Correct "#1205 G0bdcc (Acceleration and deceleration before G0 interpolation)".

#### Y51 OMR-II parameter error 0018

##### Details

An illegal setting was found in the OMR-II-related parameters. OMR-II has been disabled.

##### Remedy

Correct the related parameter settings.

#### Y51 PLC indexing stroke length err 0019

##### Details

"#12804 aux\_tleng (Linear axis stroke length)" has not been set or exceeded the setting range while the linear axis equal indexing is enabled for the PLC indexing axis.

##### Remedy

Correct "#12804 aux\_tleng (Linear axis stroke length)".

#### Y51 No hi-accu acc/dec t-const ext 0020

##### Details

There is no expansion option for the high-accuracy acceleration/deceleration time constant.

##### Remedy

Set "#1207 G1btL (Time constant)" to a value within the setting range with no expansion specification for the extended high-accuracy time constant.

**Y51 Values of PC1/PC2 too large 0101**

**Details**

The PC1 and PC2 settings for the rotary axis are too large.

**Remedy**

Correct "#2201 SV001 PC1 (Motor side gear ratio)" and "#2202 SV002 PC2 (Machine side gear ratio)".

**Y90 No spindle signal 0001-0007**

**Details**

There is an error in the spindle encoder signal.

The data transmission to the drive unit is stopped when this error occurs.

**Remedy**

Check the spindle encoder's feedback cable and the encoder.

## Appendix 2.5 System Alarms (Z)

### Z02 System error

#### Details

The operation result is illegal.

#### Remedy

- Contact the service center.

### Z31 Socket open error(socket) 0001

#### Details

Socket open error (socket)

#### Remedy

Set the parameter then turn the power OFF and ON again.

### Z31 Socket bind error(bind) 0002

#### Details

Socket bind error (bind)

#### Remedy

Set the parameter then turn the power OFF and ON again.

### Z31 Connection wait queue error(listen) 0003

#### Details

Connection wait queue error (listen)

#### Remedy

Set the parameter then turn the power OFF and ON again.

### Z31 Connection request error(accept) 0004

#### Details

Connection request error (accept)

### Z31 Data rcv error(socket error) 0005

#### Details

Data receive error (socket error)

### Z31 Data rcv error(data error) 0006

#### Details

Data receive error (data error)

### Z31 Data send error(socket error) 0007

#### Details

Data send error (socket error)

### Z31 Data send error(data error) 0008

#### Details

Data send error (data error)

### Z31 Socket close error(close) 000A

#### Details

Socket close error (close)

#### Remedy

Set the parameter then turn the power OFF and ON again.

### Z34 DeviceNet error

#### Details

Any of the following errors has occurred in the DeviceNet unit.

- Master function error (X03 is ON)
- Slave function error (X08 is ON)
- Message communication error (X05 is ON)

If the errors have occurred in more than one unit, the error No. of the unit with the smallest slot No. is displayed.

If the master function, slave function and message communication errors have occurred at the same time, the error is displayed in the following priority order.

1. Master function error
2. Slave function error
3. Message communication error

#### Remedy

- Select the [Ext. PLC link control] menu on the maintenance screen to open the unit confirmation screen, and check the unit in error and details to cancel the error.
- For the details of the DeviceNet unit errors, refer to "External PLC Link II (Bus connection) MELSEC-Q Series Appendix 2 (DeviceNet)"BNP-C3039-276 (Appendix 2).

### Z40 Format mismatch

#### Details

"#1052 MemVal (No. of common variables shared in part system designation)", formatted at "0", was set to "1".

#### Remedy

- Reset "#1052 MemVal (No. of common variables shared in part system designation)" to "0" or format and restart.

### Z51 EEPROM ERROR

#### Details

The data read from EEPROM does not coincide with the data that has been written into it.

#### Remedy

- If the same alarm occurs with the same operation, a hardware fault may be the cause. Contact the service center.

### Z52 Battery fault 000x

#### Details

The voltage of the battery in the NC control unit has dropped. (The battery used to save the internal data.)

- 0001: Battery warning
- 0002: Battery detecting circuit error
- 0003: Battery alarm

(Note)The display of "Z52 battery fault 0001" can be removed by resetting. However, the warning state will not be cleared until the battery is replaced.

#### Remedy

- Replace the battery of the NC control unit.
- Check for any disconnection of the battery cable.
- After fixing the battery's fault, check the machining program.

## Z53 CNC overheat

### Details

The controller or operation board temperature has risen above the designated value.

(Note) Temperature warning

When an overheating alarm is detected, the alarm is displayed and the overheating signal is output simultaneously. Automatic operation will be continued, while restarting after resetting or stopping with M02/M30 is not possible. (Restarting after block stop or feed hold is possible.) The alarm will be cleared and the overheating signal will turn OFF when the temperature drops below the specified temperature.

Z53 CNC overheating 000x

[000x]

(For all models)

0001: The temperature in the control unit is high.

(For M700VS only)

0004: The temperature in the control unit is high.

0005: The temperature in the control unit 2 is high.

The ambient temperature must be lowered immediately when a "Z53 CNC overheating" alarm occurs. However, if the machining needs to be continued, set "#6449/bit7 Control unit temperature alarm ON" to "0". Then the alarm will be invalidated.

### Remedy

- Cooling measures are required.
- Turn OFF the controller power, or lower the temperature with a cooler, etc.

## Z55 RIO communication stop

### Details

An error occurs in the communication between the control unit and remote I/O unit.

Disconnection of a cable

Fault in remote I/O unit

Fault of power supply to remote I/O unit

The alarm and the I/O unit No. is displayed when an error occurs in the communication between the control unit and remote I/O unit.

The remote I/O unit No. is displayed in eight digits. Two digits (in hexadecimal) are used for each board and part system.

[Display format of remote I/O unit No. ]

Z55 RIO communication stop

(a) (b) (c) (d) (e) (f) (g) (h)

(a)(b): Remote I/O 2nd part system communication interrupted station

(c)(d): Remote I/O 1st part system communication interrupted station

(e)(f): Remote I/O 3rd part system communication interrupted station

(g)(h): Board connection remote I/O communication interrupted station

(a)(b) indicates the following station in hexadecimal.

bit0: RIO (0th station)

bit1: RIO (first station)

bit2: RIO (second station)

bit3: RIO (third station)

bit4: RIO (fourth station)

bit5: RIO (fifth station)

bit6: RIO (sixth station)

bit7: RIO (seventh station)

This also applies for the remote I/O 1st part system communication interrupted station, remote I/O 3rd part system communication interrupted station and board connection remote I/O communication interrupted station.

### Remedy

- Check and replace the cables.
- Replace the remote I/O unit.
- Check the power supply (existence of supply and voltage).



### Z57 System warning

#### Details

Program memory capacity has been set over the value that can be formatted.  
An expansion device/expansion cassette has not mounted after formatting.  
The mounted expansion device/expansion cassette is different from the one that was mounted at formatting.

#### Remedy

- Check the followings.
- Program memory capacity
  - Mounting of an expansion device/expansion cassette
  - APLC release option

### Z58 ROM write not completed

#### Details

A machine tool builder macro program has not been written to FROM after being registered/ edited/ copied/ condensed/ merged/ the number changed/ deleted.

#### Remedy

- Write the machine tool builder macro program to FROM.
- The program does not need to be written to FROM unless the editing operations and so on need to be valid after the NC power OFF.

### Z59 Acc/dec time cnst too large

#### Details

Acceleration and deceleration time constants are too large.  
(This alarm is output at the same time as "T02 0206".)

#### Remedy

- Set the larger value for "#1206 G1bF(Maximum speed)".
- Set the smaller value for "#1207 G1btL(Time constant)".
- Set the lower feedrate.

## Z60 Fieldbus communication error n1 n2 n3 n4

### Details

A communication error has occurred on the Fieldbus communication with HN571/HN573/HN575.

[n1 :Shows state of the master channel (shown in hexadecimal number)]

00 :Offline In initializing

40 :Stop Cutting I/O communication

80 :Clear Resetting output data of each slave by sending 0 data.

C0 :In operation I/O In I/O communication

[n2 :Shows error state (shown in hexadecimal number)]

bit0 :Control error Parameter error

bit1 :Auto clear error Communication with all the slave channels was cut because a communication with one slave channel had an error.

bit2 :Non exchange error Slave channel with communication error is found.

bit3 :Fatal error The communication cannot be continued because severe network failure exists.

bit4 :Event error Short-circuit was found on the network.

bit5 :Not ready CNC communication is not ready.

bit6 :Time out error Time out was detected in communication with each channel.

bit7 :Not used

[n3 :Shows error No. (shown in hexadecimal number)]

- Error in master channel (when remote address with an error is FF (hexadecimal number))

0 :No error Operating normally

32 :No USR\_INT Damage in HN571. Replace HN571.

33 :No global data field

34 :No FDL-task

35 :No PLC-task

37 :Master parameter incorrect

39 :Slave parameter incorrect

3C :Data offset exceeding allowable set value received. Check the configuration setting.

3D :Slave data send range overlap

3E :Slave data receive range overlap

3F :Not set data hand shake Damage in HN571. Replace HN571.

40 :RAM range exceeded

41 :Slave parameter data set illegal

CA :No segment

D4 :Data base read illegal Download the configuration data again.

D5 :Operating system illegal Damage in HN571. Replace HN571.

DC :Watch dog error

DD :Hand shake mode No data communication by 0

DE :Master auto clear mode When setting auto clear mode, the auto clear mode was performed because one slave was not able to connect in run time.

- Error in slave channel (when remote address with an error is other than FF (hexadecimal number))  
Check the configuration of slave channel in which error has occurred. Check if there is any short-circuit in wire to bus.

2 :Station overflow reported

3 :Station stopped responding to master command

9 :No slave required responding data

11 :No station respond

12 :No master to logical token ring

15 :Illegal parameter requested

[n4 : Shows slave No. where communication error has occurred. (shown in hexadecimal number)]

'FF' means an error in master channel.

## Z64 Valid term soon to be expired xx

### Details

The valid term will be expired in less than a week. Remaining valid term is xx days.

### Remedy

- Obtain a decryption code by making a payment. Enter the decryption code.

## Z65 Valid term has been expired

### Details

The valid term has been expired with no decryption code input.

### Remedy

- Obtain a decryption code by making a payment. Enter the decryption code.

### Z67 CC-Link communication error

#### Details

A communication error occurred during CC-Link communication using CC-Link unit.

#### Remedy

- Refer to "List of Messages" in CC-Link (Master/Slave) Specification manual (BNP-C3039-214).

### Z68 CC-Link unconnected

#### Details

A cable between CC-Link unit and a device is disconnected or broken.

#### Remedy

- Connect the cable.
- Check for any broken cables.

### Z69 External link error 2

#### Details

A FROM/TO instruction was used while the MELSEC-Q interface expansion module is not installed.

#### Remedy

Install the MELSEC-Q interface expansion module.

### Z69 External link error 3

#### Details

A negative value was set for an I/O No. in the FROM/TO instruction.

#### Remedy

Correct the I/O No.

### Z69 External link error 4

#### Details

A negative value was set for transfer size in the FROM/TO instruction.

#### Remedy

Correct the transfer size.

### Z69 External link error 5

#### Details

The number of FROM/TO instructions within one scan has exceeded 50.

#### Remedy

Correct the user PLC (ladder sequence) so that the number of FROM/TO instructions per scan is 50 or less.

### Z69 External link error 6

#### Details

The access to the buffer memory by the FROM/TO instruction has exceeded 12K words per scan.

#### Remedy

Correct the user PLC (ladder sequence) so that the buffer memory access by the FROM/TO instruction won't exceed 12K words per scan. (The total size of FROM/TO is up to 12K words.)

### Z69 External link error 7

#### Details

A FROM/TO instruction was used in high-speed processing.

#### Remedy

Delete the FROM/TO instruction from high-speed processing.

### Z69 External link error 8

#### Details

The bit device number designated in the FROM/TO instruction is not a multiple of 16.

#### Remedy

Correct the bit device number designated in the FROM/TO instruction to be a multiple of 16.

#### Z69 External link error 9

##### Details

With a FROM/TO instruction, a value out of the address range (negative value, or 0x8000 or over) was set as the head address of the buffer memory.

##### Remedy

Correct the head address of the buffer memory.

#### Z69 External link error 10

##### Details

An alarm occurred in the MELSEC module mounted on the extension base.

##### Remedy

Check for any disconnection of the MELSEC module and the cables on the extension base. Then turn the CNC's power ON again.

#### Z69 External link error 11

##### Details

The I/O No. designated in the FROM/TO instruction is different from the mounted location of the intelligent function module on the extension base (the module's I/O No.).

##### Remedy

Correct the I/O No. Then turn the CNC's power ON again.

#### Z82 3D machine interference/No machine model 0001

##### Details

Machine model is not registered.

##### Remedy

- Press RESET to cancel the alarm.  
Movement can be resumed after the cancellation. However, the 3D machine interference check will become invalid.
- Inform the machine tool builder if an alarm occurs.

#### Z82 3D machine interference/Machine model illegal 0002

##### Details

Machine model is illegal.

##### Remedy

- Press RESET to cancel the alarm.  
Movement can be resumed after the cancellation. However, the 3D machine interference check will become invalid.
- Inform the machine tool builder if an alarm occurs.

#### Z82 3D machine Interference check load excess 003

##### Details

The calculation of the interference check took time and caused a deceleration.

##### Remedy

- Inform the machine tool builder.
- Restart the axis in case of a manual operation.
- In case of an automatic operation, the operation will automatically resume when the processing load of the interference check decreases.

#### Z82 3D machine Interference check error 004

##### Details

The interference check failed.

##### Remedy

- Take a note of the failed status and contact the service center.
- Press RESET to cancel the alarm. Invalidate the 3D machine interference check to continue the operation.

**Z83 NC started during SP rotation 0001**

**Details**

The NC was started while the spindle was rotating.

**Remedy**

Turn the power OFF and confirm that the spindle is not rotating, then turn the power ON again.

## Appendix 2.6 Absolute Position Detection System Alarms (Z7\*)

### Z70 Abs posn base set incomplete 0001 (Axis name)

#### Details

Zero point initialization is incomplete. Otherwise, the spindle was removed.

#### Remedy

Complete zero point initialization.

(Note) To release alarm "Z70 Abs data error", enter the parameter data output when establishing the absolute position and turn ON the power again. For the rotary axis, however, the alarm cannot be released by entering the parameter data.

- Zero point initialization: Required

### Z70 Absolute position lost 0002 (Axis name)

#### Details

The absolute position basic point data saved in the NC has been damaged.

#### Remedy

Set the parameters. If the basic point data is not restored by setting the parameters, perform zero point initialization.

(Note) To release alarm "Z70 Abs data error", enter the parameter data output when establishing the absolute position and turn ON the power again. For the rotary axis, however, the alarm cannot be released by entering the parameter data.

- Zero point initialization: (Required)

### Z70 Abs posn param changed 0003 (Axis name)

#### Details

Any of the parameters for absolute position detection has been changed.

#1003 iunit

#1016 iout

#1017 rot

#1018 ccw

#1040 M\_inch

#2049 type

#### Remedy

Correct the parameter settings. Then turn the power ON again and perform zero point initialization.

(Note) To release alarm "Z70 Abs data error", enter the parameter data output when establishing the absolute position and turn ON the power again. For the rotary axis, however, the alarm cannot be released by entering the parameter data.

- Zero point initialization: Required

### Z70 Abs posn initial set illegal 0004 (Axis name)

#### Details

The zero point initialization point is not at the grid position.

#### Remedy

Perform the zero point initialization again.

(Note) To release alarm "Z70 Abs data error", enter the parameter data output when establishing the absolute position and turn ON the power again. For the rotary axis, however, the alarm cannot be released by entering the parameter data.

- Zero point initialization: Required

### Z70 Abs posn param restored 0005 (Axis name)

#### Details

The data has been restored by inputting the parameters during the alarm No.0002.

#### Remedy

Turn the power ON again to start the operation.

(Note) To release alarm "Z70 Abs data error", enter the parameter data output when establishing the absolute position and turn ON the power again. For the rotary axis, however, the alarm cannot be released by entering the parameter data.

- Zero point initialization: Not required

### Z70 Abs data error 0006

#### Details

Deviation of the servo axis with scale when the power is OFF exceeds the set value in "#2051 check (Check)".

#### Remedy

Search for the factor which led the deviation of the servo axis at the power OFF.

- Zero point initialization: Not required
- Alarm reset when power is turned OFF: -
- Servo alarm No.: -

### Z70 Abs posn data lost 0080 (Axis name)

#### Details

The absolute position data has been lost. An error of the multi-rotation counter data in the detector and so on may be the cause.

#### Remedy

Replace the detector and complete zero point initialization.

(Note) To release alarm "Z70 Abs data error", enter the parameter data output when establishing the absolute position and turn ON the power again. For the rotary axis, however, the alarm cannot be released by entering the parameter data.

- Zero point initialization: Required
- Servo alarm No.: (9E)etc.

### Z70 Abs posn error(servo alm 25) 0101 (Axis name)

#### Details

The servo alarm No. 25 was displayed and the power was turned ON again.

#### Remedy

Perform zero point initialization again.

(Note) To release alarm "Z70 Abs data error", enter the parameter data output when establishing the absolute position and turn ON the power again. For the rotary axis, however, the alarm cannot be released by entering the parameter data.

- Zero point initialization: Required
- Servo alarm No.: -25

### Z70 Abs posn error(servo alm E3) 0106 (Axis name)

#### Details

The servo alarm No. E3 was displayed and the power was turned ON again.

#### Remedy

Perform zero point initialization again.

(Note) To release alarm "Z70 Abs data error", enter the parameter data output when establishing the absolute position and turn ON the power again. For the rotary axis, however, the alarm cannot be released by entering the parameter data.

- Zero point initialization: Required
- Servo alarm No.: (E3)

### Z71 AbsEncoder:Backup voltage drop 0001 (Axis name)

#### Details

Backup voltage in the absolute position detector dropped.

#### Remedy

Replace the battery, check the cable connections, and check the detector. Turn the power ON again and perform zero point initialization.

- Zero point initialization: Required
- Alarm reset when power is turned OFF: -(Z70-0101 is displayed after the power is turned ON again.)
- Servo alarm No.: 25

**Z71 AbsEncoder: Commu error 0003 (Axis name)****Details**

Communication with the absolute position detector has been disabled.

**Remedy**

Check and replace the cables, card or detector. Turn the power ON again and perform zero point initialization.

- Zero point initialization: (Required) only when the detector has been replaced.
- Alarm reset when power is turned OFF: Reset
- Servo alarm No.: 91

**Z71 AbsEncoder: Abs data changed 0004 (Axis name)****Details**

Absolute position data has been changed at the absolute position establishment.

**Remedy**

Check and replace the cables, card or detector. Turn the power ON again and perform zero point initialization.

- Zero point initialization: (Required) only when the detector has been replaced.
- Alarm reset when power is turned OFF: Reset
- Servo alarm No.: 93

**Z71 AbsEncoder: Serial data error 0005 (Axis name)****Details**

An error of the serial data was found in the absolute position detector.

**Remedy**

Check and replace the cables, card or detector. Turn the power ON again and perform zero point initialization.

- Zero point initialization: (Required) only when the detector has been replaced.
- Alarm reset when power is turned OFF: Reset
- Servo alarm No.: 92

**Z71 AbsEncoder: Abs/inc posn diffr 0006 (Axis name)****Details**

Servo alarm E3  
Absolute position counter warning

**Remedy**

Operation is possible until the power is turned OFF.

- Zero point initialization: (Required) after the power is turned ON again.
- Alarm reset when power is turned OFF: Reset (Z70-0106 is displayed after the power is turned ON again.)
- Servo alarm No.: E3

**Z71 AbsEncoder: Initial commu er 0007 (Axis name)****Details**

Initial communication with the absolute position detector is not possible.

**Remedy**

Check and replace the cables, card or detector. Turn the power ON again and perform zero point initialization.

- Zero point initialization: (Required) only when the detector has been replaced.
- Alarm reset when power is turned OFF: Reset
- Servo alarm No.: 18

**Z72 Message: Position check error (Axis name)****Details**

An error is detected at the comparison of detector's absolute position and controller coordinate values in the absolute position detection system.

**Remedy**



## Z73 Battery for abs data fault 0001

### Details

Low backup battery  
Servo alarm 9F  
Low battery voltage

### Remedy

This is displayed when the battery voltage is 0 low or the cable has been damaged.  
The absolute position initialization is not required.

(Note) When this alarm has occurred, do not turn OFF the drive unit power in order to protect the absolute position data. Replace the battery with the drive unit power ON.

## Appendix 2.7 Distance-coded Reference Scale Errors (Z8\*)

### Z80 Basic position lost 0001

#### Details

The basic point data saved in the NC has been damaged.

#### Remedy

- Set the parameters. If the basic point data is not restored by setting the parameters, perform zero point initialization.

### Z80 Basic position restore 0002

#### Details

The basic point data has been restored by setting the parameters.

#### Remedy

- Turn the power ON again to start the operation.

### Z80 No spec: Distance-coded scale 0003

#### Details

The distance-coded reference scale has been set available although this function is out of the specifications.

#### Remedy

- Check the specifications.
- If you do not use this function, correct the detector type with the servo parameter.

### Z81 R-pos adjustment data lost 0001

#### Details

Reference position adjustment value data saved in the NC has been damaged.

#### Remedy

- Set the parameter. If the data is not restored by setting the parameter, establish the reference position again.

### Z81 R-pos adjustment data restored 0002

#### Details

After the 'Z81 R-pos adjustment data lost 0001', the data has been recovered by setting the parameter.

#### Remedy

- Establish the reference position to start the operation.

## Appendix 2.8 Emergency Stop Alarms (EMG)

### EMG Emergency stop PLC

#### Details

The user PLC has entered the emergency stop state during the sequence process.

#### Remedy

- Investigate and remove the cause of the user PLC emergency stop.

### EMG Emergency stop EXIN

#### Details

The "emergency stop" signal is significant (open).

#### Remedy

- Cancel the "emergency stop" signal.
- Check for any broken wires.

### EMG Emergency stop SRV

#### Details

An alarm occurred in the servo system causing an emergency stop.

#### Remedy

- Investigate and remove the cause of the servo alarm.

### EMG Emergency stop STOP

#### Details

The user PLC (ladder sequence) is not running.

#### Remedy

- Check the setting of the control unit rotary switch CS2. Correct it if set to "1".
- Check the [RUN/SP] (run/stop) switch on the PLC edit file save screen (onboard function). Turn it OFF if ON.

### EMG Emergency stop SPIN

#### Details

Spindle drive unit is not mounted.

#### Remedy

- Cancel the causes of the other emergency stop.
- Check the "emergency stop" signal input in the spindle drive unit.

### EMG Emergency stop PC\_H

#### Details

Failure in the high-speed PC processing abnormal

#### Remedy

- Correct the sequence program. (To stop monitoring the high-speed PC processing temporarily, set "1" in "#1219 aux03/bit1 (Stop high-speed PC monitoring function)". Disable the monitoring function only as a temporary measure.)

### EMG Emergency stop PARA

#### Details

Setting of the door open II fixed device is illegal.

Setting of the parameters for dog signal random assignment is illegal.

#### Remedy

- Correct the "#1155 DOOR\_m" and "#1156 DOOR\_s" settings. (When the door open II fixed device is not used, set "#1155 DOOR\_m" and "#1156 DOOR\_s" to "100".)
- Correct the "#2073 zrn\_dog (Origin dog Random assignment device)", "#2074 H/W\_OT+ (H/W OT+ Random assignment device)", "#2075 H/W\_OT- (H/W OT- Random assignment device)" and "#1226 aux10/bit5 (Arbitrary allocation of dog signal)" settings.

## EMG Emergency stop LINK

### Details

An emergency stop occurs when the FROM/TO instruction is not executed within 500ms.

### Remedy

- Execute the FROM/TO instruction one or more times every 500ms.
- The time in which no interrupt request is issued from MELSEC is measured and stored in the following R registers:
- R10190: Current timeout counter
  - R10191: Maximum timeout counter after power ON
  - R10192: Maximum timeout counter after system is started up (this is backed up)

### Details

MELSEC is in error and reset states.

### Remedy

- Check the MELSEC states.

### Details

The contents of MELSEC-specific code area in buffer memory have been damaged.

### Remedy

- Check the MELSEC states.

### Details

PLC serial link communication has stopped.

(Note) When "WAIT" is entered in the PLC serial link, only the preparation sequence has been established before the communication stops. It is supposed that the settings of the serial link parameters "#1902 Din size" and "#1903 Dout size" are incorrect or the "#1909 Tout (ini)" set-time is too short in basic specification parameters.

### Remedy

- Check the CC-Link card wiring and the external sequencer transmission.
- Check the link communication errors shown on the diagnostic screen.
- Correct the settings of the serial link parameters in basic specification parameters.

## EMG Emergency stop WAIT

### Details

The preparation sequence is not sent from the master station. Otherwise, the contents of the received preparation sequence are inconsistent with those of the parameters, so that the usual sequence cannot be started.

(Note) When "LINK" is also entered for the PLC serial link, refer to "Note" in the section, "LINK".

### Remedy

- Check that the CC-Link card switch setting and wiring as well as the external sequencer transmission are normal.
- Check the diagnostic screen for link communication errors.

## EMG Emergency stop XTEN

### Details

The CC-Link card is operating incorrectly.  
Switch/parameter settings for the CC-Link card are incorrect.

### Remedy

- Replace the CC-Link card.
- Correct the switch/parameter settings for the CC-Link card.

## EMG Emergency stop LAD

### Details

The sequence program has an illegal code.

### Remedy

- Correct any illegal device Nos. or constants in the sequence program.

### EMG Emergency stop CVIN

#### Details

The "emergency stop" signal for power supply is significant (open) because the external emergency stop function for power supply is enabled.

#### Remedy

- Cancel the "emergency stop" signal.
- Check for any broken wires.

### EMG Emergency stop MCT

#### Details

The contactor shutoff test is being executed.

#### Remedy

- The emergency stop is reset automatically after the contactor shutoff is confirmed.
- If the contactor shutoff is not confirmed within 5 seconds after the "contactor shutoff test" signal has been input, the "contactor welding detected" alarm occurs and the emergency stop status remains.
- Make sure that the contactor's auxiliary B contact signal is correctly output to the device that is set in "#1330 MC\_dp1" and "#1331 MC\_dp2" (Contactor weld detection device 1 and 2), and then turn the power ON again.

### EMG Emergency stop IPWD

#### Details

The data backup for power failure might not have been executed successfully at the previous power failure.

#### Remedy

- If this message appears frequently, the power supply may be deteriorated. Contact the service center.

### EMG Emergency stop SUIN

#### Details

The emergency stop input signal (M0) is OFF in the NC/PLC safety circuit.

#### Remedy

- Check the conditions for turning ON the emergency stop input signal.
- Check for any broken wires.

### EMG Emergency stop STP2

#### Details

Sequence programs stopped in CNC.

#### Remedy

- Correct the rotary switch 1 (on the right) of the control unit if set to "1".

### EMG Emergency stop MULT

#### Details

An error related to Q bus or Qr bus occurred.

#### Remedy

- Refer to the error No. that follows the message "A01 Multi CPU error" to take a remedy.

### EMG Emergency stop LINE

#### Details

An error was detected when communicating with the drive unit.

#### Remedy

- Check the wiring.

## Appendix 2.9 Computer Link Errors (L)

### L01 Serial port being used -2

#### Details

Serial port has already been opened or cannot be used.

#### Remedy

- Set the port not to shared by Anshin-net and so on.
- Correct the parameter settings for tape operation port.

### L01 Timeout error -4

#### Details

Communication ended with timeout.  
(CNC has a 248-byte receive buffer. The time during which CNC receives 248 bytes exceeds the 'TIME-OUT' value set in the I/O device parameter.

#### Remedy

- Set a greater timeout value in the input/output device parameter.
- Check the software in HOST and make sure that the HOST transmits data in response to DC1(data request) from CNC.
- Set '#9614 START CODE' to '0'.

### L01 Host ER signal OFF -10

#### Details

ER signal in HOST (or DR signal in CNC) is not turned ON.

#### Remedy

- Check for any disconnected cable.
- Check for any broke wire.
- Make sure that the HOST power is turned ON.

### L01 Parity H error -15

#### Details

Communication ended with parity H.

#### Remedy

- Check the software in HOST and make sure that the data to be transmitted to CNC is ISO code.

### L01 Parity V error -16

#### Details

Communication ended with parity V.

#### Remedy

- Correct the data to transmit to CNC.

### L01 Overrun error -17

#### Details

CNC received 10 bytes or more data from HOST in spite of DC3 (request to stop data transfer) transmission from CNC to the HOST, which terminated the communication.  
CNC received 10 bytes or more data from HOST during the data transmission from CNC to the HOST.

#### Remedy

- Check the software in HOST and make sure that the HOST stops transmitting data within 10 bytes after receiving DC3.
- Correct the software in HOST not to transmit data such as a command or header to CNC during receiving a machining program.

## Appendix 2.10 User PLC Alarms (U)

### U01 No user PLC - -

#### Details

PLC program is not input.

(Note 1) The number of PLC program steps displayed on the screen may not match the actual number of error occurrence steps because of the PLC program timing. Use this as a guideline of the occurrence place.

(Note 2) Emergency stop (EMG) will be applied.

#### Remedy

Download the PLC program with the format selected by the PLC environment selection parameters (bit selection "#51/bit4").

### U10 Illegal PLC 0x0010 -

#### Details

PLC scan time error

The scan time is 1 second or longer.

(Note) The number of PLC program steps displayed on the screen may not match the actual number of error occurrence steps because of the PLC program timing. Use this as a guideline of the occurrence place.

#### Remedy

Edit the PLC program to make the size smaller.

### U10 Illegal PLC 0x0040 -

#### Details

PLC program operation mode illegal

The downloaded PLC program is compatible with the designated mode.

(Note 1) The number of PLC program steps displayed on the screen may not match the actual number of error occurrence steps because of the PLC program timing. Use this as a guideline of the occurrence place.

(Note 2) Emergency stop (EMG) will be applied.

#### Remedy

Turn the power ON again or download the PLC program with the same format as at the power ON.

### U10 Illegal PLC 0x0080 -

#### Details

GPPW ladder code error

(Note 1) The number of PLC program steps displayed on the screen may not match the actual number of error occurrence steps because of the PLC program timing. Use this as a guideline of the occurrence place.

(Note 2) Emergency stop (EMG) will be applied.

#### Remedy

Download the PLC program with a correct GPPW format.

### U10 Illegal PLC 0x008x -

#### Details

PLC4B ladder code error

An illegal circuit was found in the PLC4B ladder.

bit1: PC medium-speed circuit illegal

bit2: PC high-speed circuit illegal

(Note 1) The number of PLC program steps displayed on the screen may not match the actual number of error occurrence steps because of the PLC program timing. Use this as a guideline of the occurrence place.

(Note 2) Emergency stop (EMG) will be applied.

#### Remedy

Download the correct PLC4B format PLC program.

#### U10 Illegal PLC 0x0400 Number of ladder steps

##### Details

Software illegal interrupt

An abnormal stop occurred in the PLC program process due to an illegal code for software command.

(Note 1) The number of PLC program steps displayed on the screen may not match the actual number of error occurrence steps because of the PLC program timing. Use this as a guideline of the occurrence place.

(Note 2) Emergency stop (EMG) will be applied.

##### Remedy

Turn the power ON again.

If the error is not reset, download the correct PLC program.

#### U10 Illegal PLC 0x800x Number of PLC program steps

##### Details

Software exception

An abnormal stop occurred in PLC program process due to a bus error, etc.

bit0: BIN command operation error

bit1: BCD command operation error

(Note) The number of PLC program steps displayed on the screen may not match the actual number of error occurrence steps because of the PLC program timing. Use this as a guideline of the occurrence place.

##### Remedy

Refer to the methods for using the BCD and BIN function commands.

##### Details

Software exception

An abnormal stop occurred in PLC program process due to a bus error, etc.

bit6: CALL/CALLS/RET command error

bit7: IRET command execution error

(Note 1) The number of PLC program steps displayed on the screen may not match the actual number of error occurrence steps because of the PLC program timing. Use this as a guideline of the occurrence place.

(Note 2) Emergency stop (EMG) is applied for bit6/7.

##### Remedy

Turn the power ON again.

If the error is not reset, download the correct PLC program.

#### U50 PLC stopped

##### Details

The PLC program is stopped.

(Note) The number of PLC program steps displayed on the screen may not match the actual number of error occurrence steps because of the PLC program timing. Use this as a guideline of the occurrence place.

##### Remedy

Start the PLC program.

#### U55 PLC stopped / is not saved

##### Details

The PLC program is stopped and not written into ROM.

(Note) The number of PLC program steps displayed on the screen may not match the actual number of error occurrence steps because of the PLC program timing. Use this as a guideline of the occurrence place.

##### Remedy

Write the PLC program into ROM.



**U60 Ladder is not saved****Details**

The PLC program is not written into ROM.

(Note) The number of PLC program steps displayed on the screen may not match the actual number of error occurrence steps because of the PLC program timing. Use this as a guideline of the occurrence place.

**Remedy**

Write the PLC program into ROM.

## Appendix 2.11 Network Service Errors (N)

### N001 Modem initial error

#### Details

An error occurred in the modem connection at the power ON.

#### Remedy

- Check the connection between the NC and modem, connection port and power supply to modem.

### N002 Redial over

#### Details

- The number of redials exceeded due to the dial transmission failure.

#### Remedy

- Wait a while, and then dial again.

### N003 TEL unconnect

#### Details

- The phone line is not connected.

#### Remedy

- Check for any disconnection in the modem's phone line.

### N004 Net communication error

#### Details

- An error other than the above occurred during communication.

#### Remedy

- Note down how the error occurred and contact the service center.

### N005 Invalid net communication

#### Details

- The modem connection port is being used for another function such as input/output.
- The modem connection port settings are incorrect.

#### Remedy

- Stop using the modem connection port with the other function, and then turn the power ON again.
- Correct the settings of the modem connection port.

### N006 Received result of diagnosis

#### Details

- A diagnosis data file has been received.

#### Remedy

- Clear the message.

### N007 Send data size over

#### Details

- A file larger than Anshin-net server capacity (64Kbyte) has been transmitted in machining data sharing.

#### Remedy

- Reduce the size of machining program file so that it won't exceed the capacity of Anshin-net server.

### N008 No file on server

#### Details

- The file reception failed in machining data sharing because no file exists on Anshin-net server.

#### Remedy

- Confirm that a machining program file exists on Anshin-net server before receiving it.

### N009 Password error

#### Details

- The file reception failed in machining data sharing due to a wrong password.

#### Remedy

- Input the password again.

### N010 Customer number error

#### Details

- The file reception failed in machining data sharing due to a wrong customer number.

#### Remedy

- Input the customer number again.

### N011 Storage capacity over

#### Details

- The file reception failed in machining data sharing because the size of the file to be received is bigger than free space in the NC.

#### Remedy

- Ensure sufficient free space in the NC.

### N012 File deletion error

#### Details

- A file on Anshin-net server cannot be deleted in machining data sharing.

#### Remedy

- Confirm that the file exists on Anshin-net server.
- Note down how the error occurred and contact the service center.

## Appendix 2.12 Program Errors (P)

### P10 No. of simultaneous axes over

#### Details

The number of axis addresses commanded in a block exceeds the specifications.

#### Remedy

- Divide the alarm block command into two.
- Check the specifications.

### P11 Illegal axis address

#### Details

The axis address commanded by the program does not match any of the ones set by the parameter.

#### Remedy

- Correct the axis names in the program.

### P20 Division error

#### Details

The issued axis command cannot be divided by the command unit.

#### Remedy

- Correct the program.

### P29 Not accept command

#### Details

The command has been issued when it is impossible.

- The normal line control command (G40.1, G41.1, G42.1) has been issued during the modal in which the normal line control is not acceptable.
- The command has been issued during the modal in which the 2-part system synchronous thread cutting is not acceptable.

#### Remedy

- Correct the program.

### P30 Parity H error

#### Details

The number of holes per character on the paper tape is even for EIA code and odd for ISO code.

#### Remedy

- Check the paper tape.
- Check the tape puncher and tape reader.

### P31 Parity V error

#### Details

The number of characters per block on the paper tape is odd.

#### Remedy

- Make the number of characters per block on the paper tape even.
- Set the parameter parity V selection OFF.

### P32 Illegal address

#### Details

An address not listed in the specifications has been used.

#### Remedy

- Correct the program address.
- Correct the parameter settings.
- Check the specifications.

### P33 Format error

#### Details

The command format in the program is not correct.

#### Remedy

- Correct the program.

### P34 Illegal G code

#### Details

The commanded G code is not in the specifications.  
An illegal G code was commanded during the coordinate rotation command.

#### Remedy

- Correct the G code address in the program.

#### Details

G51.2 or G50.2 was commanded when "#1501 polyax (Rotational tool axis number)" was set to "0".  
G51.2 or G50.2 was commanded when the tool axis was set to the linear axis ("#1017 rot (Rotational axis)" is set to "0").

#### Remedy

- Correct the parameter settings.

### P35 Setting value range over

#### Details

The setting range for the addresses has been exceeded.

#### Remedy

- Correct the program.

### P36 Program end error

#### Details

"EOR" has been read during tape and memory mode.

#### Remedy

- Enter the M02 and M30 command at the end of the program.
- Enter the M99 command at the end of the subprogram.

### P37 O, N number zero

#### Details

"0" has been specified for program or sequence No.

#### Remedy

- Designate program Nos. within a range from 1 to 99999999.
- Designate sequence Nos. within a range from 1 to 99999.

### P38 No spec: Add. Op block skip

#### Details

"/n" has been issued while the optional block skip addition is not in the specifications.

#### Remedy

- Check the specifications.

### P39 No specifications

#### Details

- A non-specified G code was commanded.
- The selected operation mode is out of specifications.

#### Remedy

- Check the specifications.

### P45 G-CODE COMB.

#### Details

The combination of G codes in a block is inappropriate.  
A part of unmodal G codes and modal G codes cannot be commanded in a same block.

#### Remedy

Correct the combination of G codes.  
Separate the incompatible G codes into different blocks.

#### P48 Restart pos return incomplete

##### Details

A travel command was issued before the execution of the block that had been restart-searched.

##### Remedy

- Carry out program restart again.  
Travel command cannot be executed before the execution of the block that has been restart-searched.

#### P49 Invalid restart search

##### Details

- Restart search was attempted for the 3-dimensional circular interpolation.
- Restart search was attempted for the mixed control (cross axis control) command (G110).
- Restart search was attempted during the cylindrical interpolation, polar coordinate interpolation, or tool tip center control.
- Restart search was attempted from a block (G68.2) during the inclined surface machining mode or from the inclined surface machining mode cancel command block (G69).

##### Remedy

- Correct the program.
- Correct the restart search position.

#### P50 No spec: Inch/Metric change

##### Details

Inch/Metric changeover (G20/G21) command was issued while the function is out of specifications.

##### Remedy

- Check the specifications.

#### P60 Compensation length over

##### Details

The commanded movement distance is excessive (over  $2^{31}$ ).

##### Remedy

- Correct the command range for the axis address.

#### P61 No spec: Unidirectional posit.

##### Details

Unidirectional positioning (G60) was commanded while the function is out of specifications.

##### Remedy

- Check the specifications.

#### P62 No F command

##### Details

- No feed rate command has been issued.
- There is no F command in the cylindrical interpolation or polar coordinate interpolation immediately after the G95 mode is commanded.

##### Remedy

- The default movement modal command at power ON is G01. This causes the machine to move without a G01 command if a movement command is issued in the program, and an alarm results. Use an F command to specify the feed rate.
- Specify F with a thread lead command.

#### P63 No spec: High-speed machining

##### Details

High-speed machining cancel (G5P0) was commanded while the high-speed machining is out of specifications.

##### Remedy

- Check the specifications.

### P65 No spec: High speed mode 3

#### Details

#### Remedy

- Check whether the specifications are provided for the high-speed mode III.

### P70 Arc end point deviation large

#### Details

- There is an error in the arc start and end points as well as in the arc center.
- The difference of the involute curve through the start point and the end point is large.
- When arc was commanded, one of the two axes configuring the arc plane was a scaling valid axis.

#### Remedy

- Correct the numerical values of the addresses that specify the start and end points, arc center as well as the radius in the program.
- Correct the "+" and "-" directions of the address numerical values.
- Check for the scaling valid axis.

### P71 Arc center error

#### Details

- An arc center cannot be obtained in R-specified circular interpolation.
- A curvature center of the involute curve cannot be obtained.

#### Remedy

- Correct the numerical values of the addresses in the program.
- Correct the start and end points if they are inside of the base circle for involute interpolation. When carrying out tool radius compensation, make sure that the start and end points after compensation will not be inside of the base circle for involute interpolation.
- Correct the start and end points if they are at an even distance from the center of the base circle for involute interpolation.

### P72 No spec: Helical cutting

#### Details

A helical command has been issued though it is out of specifications.

#### Remedy

- Check whether the specifications are provided for the helical cutting.
- An Axis 3 command has been issued by the circular interpolation command. If there is no helical specification, move the linear axis to the next block.

### P73 No spec: Spiral cutting

#### Details

A spiral command was issued though it is out of specifications.

#### Remedy

- Issue the G02.1 and G03.1 commands for circular interpolation.
- Check whether the specifications are provided for the spiral cutting.

### P74 Can't calculate 3DIM arc

#### Details

The 3-dimension circular cannot be obtained because the end block was not specified during 3-dimension circular interpolation supplementary modal.

The 3-dimension circular cannot be obtained due to an interruption during 3-dimension circular interpolation supplementary modal.

#### Remedy

- Correct the program.

### P75 3DIM arc illegal

#### Details

An illegal G code was issued during 3-dimension circular interpolation modal. Otherwise, 3-dimension circular interpolation command was issued during a modal for which a 3-dimension circular interpolation command cannot be issued.

#### Remedy

- Correct the program.

#### **P76 No spec: 3DIM arc interpolat**

##### **Details**

G02.4/G03.4 was commanded though there is no 3-dimension circular interpolation specification.

##### **Remedy**

- Check the specifications.

#### **P80 No spec: Hypoth ax interpolat**

##### **Details**

Hypothetical axis interpolation (G07) was commanded though it is out of specifications.

##### **Remedy**

- Check the specifications.

#### **P90 No spec: Thread cutting**

##### **Details**

A thread cutting command was issued though it is out of specifications.

##### **Remedy**

- Check the specifications.

#### **P91 No spec: Var lead threading**

##### **Details**

Variable lead thread cutting (G34) was commanded though it is out of specifications.

##### **Remedy**

- Check the specifications.

#### **P93 Illegal pitch vaule**

##### **Details**

An illegal thread lead (thread pitch) was specified at the thread cutting command.

##### **Remedy**

- Correct the thread lead for the thread cutting command.

#### **P100 No spec: Cylindric interpolat**

##### **Details**

A cylindrical interpolation command was issued though it is out of specifications.

##### **Remedy**

- Check the specifications.

#### **P110 Plane select during figure rot**

##### **Details**

Plane selection (G17/G18/G19) was commanded during figure rotation.

##### **Remedy**

- Correct the machining program.

#### **P111 Plane selected while coord rot**

##### **Details**

Plane selection commands (G17, G18, G19) were issued during a coordinate rotation was being commanded.

##### **Remedy**

- Always command coordinate rotation cancel after the coordinate rotation command, and then issue a plane selection command.



#### P112 Plane selected while R compen

##### Details

- Plane selection commands (G17, G18, G19) were issued while tool radius compensation (G41, G42) and nose R compensation (G41, G42, G46) commands were being issued.
- Plane selection commands were issued after completing nose R compensation commands when there were no further axis movement commands after G40, and compensation has not been cancelled.

##### Remedy

- Issue plane selection commands after completing (axis movement commands issued after G40 cancel command) tool radius compensation and nose R compensation commands.

#### P113 Illegal plane select

##### Details

The circular command axis does not correspond to the selected plane.

##### Remedy

- Select a correct plane before issuing a circular command.

#### P120 No spec: Feed per rotation

##### Details

Feed per rotation (G95) was commanded though it is out of specifications.

##### Remedy

- Check the specifications.

#### P121 F0 command during arc modal

##### Details

F0 (F 1-digit feed) was commanded during the arc modal (G02/G03).

##### Remedy

- Correct the machining program.

#### P122 No spec: Auto corner override

##### Details

An auto corner override command (G62) was issued though it is out of specifications.

##### Remedy

- Check the specifications.
- Delete the G62 command from the program.

#### P123 No spec: High-accuracy control

##### Details

High-accuracy control command was issued though it is out of specifications.

##### Remedy

- Check the specifications.

#### P124 No spec: Inverse time feed

##### Details

- The inverse time option is not provided.

##### Remedy

- Check the specifications.

#### P125 G93 mode error

##### Details

- The issued G code command is illegal during G93 mode.
- G93 command was issued during a modal for which inverse time feed cannot be performed.

##### Remedy

- Correct the program.

#### P126 Invalid cmdnd in high-accuracy

##### Details

An illegal command was issued during the high-accuracy control mode.

- A G code group 13 command was issued during the high-accuracy control mode.
- Milling, cylindrical interpolation or pole coordinate interpolation was commanded during the high-accuracy control mode.

##### Remedy

- Correct the program.

#### P127 No spec: SSS Control

##### Details

The SSS control valid parameter has been set although there is no SSS control specification.

##### Remedy

- Check the specifications. Set "#8090 SSS ON" to "0" when there is no SSS control specification.

#### P128 Machin condtn select I disable

##### Details

Machining condition selection I was commanded during the mode where the selection command is unavailable.

##### Remedy

- Check the program and see whether any unavailable mode is included during machining condition selection I. If any, cancel that mode.

#### P130 2nd M function code illegal

##### Details

The 2nd miscellaneous function address, commanded in the program, differs from the address set in the parameters.

##### Remedy

- Correct the 2nd miscellaneous function address in the program.

#### P131 No spec: Cnst surface ctrl G96

##### Details

A constant surface speed control command (G96) was issued though it is out of specifications.

##### Remedy

- Check the specifications.
- Issue a rotation speed command (G97) instead of the constant surface speed control command (G96).

#### P132 Spindle rotation speed S=0

##### Details

No spindle rotation speed command has been issued.

##### Remedy

- Correct the program.

#### P133 Illegal P-No. G96

##### Details

The illegal No. was specified for the constant surface speed control axis.

##### Remedy

- Correct the parameter settings and program that specify the constant surface speed control axis.

#### P134 G96 Clamp Err.

##### Details

The constant surface speed control command (G96) was issued without commanding the spindle speed clamp (G92/G50).

##### Remedy

Press the reset key and carry out the remedy below.

- Check the program.
- Issue the G92/G50 command before the G96 command.
- Command the constant surface speed cancel (G97) to switch to the rotation speed command.

**P140 No spec: Pos compen cmd**

**Details**

The position compensation command (G45 to G48) is out of specifications.

**Remedy**

- Check the specifications.

**P141 Pos compen during rotation**

**Details**

Position compensation was commanded during the figure rotation or coordinate rotation command.

**Remedy**

- Correct the program.

**P142 Pos compen invalid arc**

**Details**

Position compensation cannot be executed with the issued arc command.

**Remedy**

- Correct the program.

**P150 No spec: Nose R compensation**

**Details**

- Tool radius compensation commands (G41 and G42) were issued though they are out of specifications.
- Nose R compensation commands (G41, G42, and G46) were issued though they are out of specifications.

**Remedy**

- Check the specifications.

**P151 Radius compen during arc mode**

**Details**

A compensation command (G40, G41, G42, G43, G44, or G46) has been issued in the arc modal (G02 or G03).

**Remedy**

- Issue the linear command (G01) or rapid traverse command (G00) in the compensation command block or cancel block.  
(Set the modal to linear interpolation.)

**P152 No intersection**

**Details**

- In interference block processing during execution of a tool radius compensation (G41 or G42) or nose R compensation (G41, G42, or G46) command, the intersection point after one block is skipped cannot be determined.
- The compensation amount cannot be calculated during the tool radius compensation for 5-axis machining (G41.2,G42.2).

**Remedy**

- Correct the program.

**P153 Compensation interference**

**Details**

An interference error has occurred while the tool radius compensation command (G41 or G42) or nose R compensation command (G41, G42 or G46) was being executed.

**Remedy**

- Correct the program.

**P154 No spec: 3D compensation**

**Details**

A three-dimensional compensation command was issued though it is out of specifications.

**Remedy**

- Check the specifications.

#### P155 Fixed cyc exec during compen

##### Details

A fixed cycle command has been issued in the radius compensation mode.

##### Remedy

- Issue a radius compensation cancel command (G40) to cancel the radius compensation mode that has been applied since the fixed cycle command was issued.

#### P156 R compen direction not defined

##### Details

A shift vector with undefined compensation direction was found at the start of G46 nose R compensation.

##### Remedy

- Change the vector to that which has the defined compensation direction.
- Change the tool to that which has a different tip point No.

#### P157 R compen direction changed

##### Details

During G46 nose R compensation, the compensation direction is reversed.

##### Remedy

- Change the G command to that which allows the reversed compensation direction (G00, G28, G30, G33, or G53).
- Change the tool to that which has a different tip point No.
- Enable "#8106 G46 NO REV-ERR".

#### P158 Illegal tip point

##### Details

An illegal tip point No. (other than 1 to 8) was found during G46 nose R compensation.

##### Remedy

- Correct the tip point No.

#### P159 C-CMP REMAINS

##### Details

One of the followings was commanded while the compensation has not been canceled (the compensation amount remained).

- (1) Automatic tool nose R compensation (G143)
- (2) Radius compensation (G145)
- (3) Plane selection (G17 to G19)
- (4) Skip (G31 or G31.1/G31.2/G31.3)
- (5) Fixed cycle for drilling (G81 to G89)
- (6) Compound type fixed cycle II (G74 to G76)

##### Remedy

- Cancel the compensation (with compensation amount "0") before commanding.
- Command the G00 move block before the block with a command among (1) to (6).

#### P160 G53 CMP. ERR

##### Details

- G53 was commanded during nose R compensation (by G41/G42/G46).
- G53 was commanded to the block where the nose R compensation mode is changed (with G40/G41/G42/G46).
- G53 was commanded while nose R compensation amount has not been cleared.

##### Remedy

- Correct the program.
- When issuing G53 after G40 command, move the compensation plane axis by G00/G01/G02/G03 command before issuing G53.

#### P161 No spec: 5ax tool R compensate

##### Details

Tool radius compensation for 5-axis machining is not included in the specifications.

##### Remedy

- Check the specifications.

#### P162 Disable Cmd in 5ax tool R comp

##### Details

A command (G or T command, etc) was issued during tool radius compensation for 5-axis machining, although it is disabled during the compensation.

##### Remedy

- Cancel the tool radius compensation for 5-axis machining.

#### P163 5 ax tool R comp is disable

##### Details

Tool radius compensation for 5-axis machining was commanded in a mode where the command is disabled.

##### Remedy

- Cancel the mode that disables the command.

#### P170 No offset number

##### Details

No compensation No. (DOO, TOO or HOO) command was given when the radius compensation (G41, G42, G43 or G46) command was issued. Otherwise, the compensation No. is larger than the number of sets in the specifications.

##### Remedy

- Add the compensation No. command to the compensation command block.
- Check the number of sets for the tool compensation Nos. and correct the compensation No. command to be within the number of sets.

#### P171 No spec:Comp input by prog G10

##### Details

Compensation data input by program (G10) was commanded though it is out of specifications.

##### Remedy

- Check the specifications.

#### P172 G10 L number error

##### Details

An address of G10 command is not correct.

##### Remedy

- Correct the address L No. of the G10 command.

#### P173 G10 P number error

##### Details

The compensation No. at the G10 command is not within the permitted number of sets in the specifications.

##### Remedy

- Check the number of sets for the tool compensation Nos. and correct the address P designation to be within the number of sets.

#### P174 No spec:Comp input by prog G11

##### Details

Compensation data input by program cancel (G11) was commanded though there is no specification of compensation data input by program.

##### Remedy

- Check the specifications.

#### P177 Tool life count active

##### Details

Registration of tool life management data with G10 was attempted when the "usage data count valid" signal was ON.

##### Remedy

- The tool life management data cannot be registered during the usage data count. Turn the "usage data count valid" signal OFF.

#### P178 Tool life data entry over

##### Details

The number of registration groups, total number of registered tools or the number of registrations per group exceeded the range in the specifications.

##### Remedy

- Correct the number of registrations.

#### P179 Illegal group No.

##### Details

- A duplicate group No. was found at the registration of the tool life management data with G10.
- A group No. that was not registered was designated during the T\*\*\*\*99 command.
- An M code command, which must be issued as a single command, coexists in the same block as that of another M code command.
- The M code commands set in the same group exist in the same block.

##### Remedy

- Register the tool life data once for one group: commanding with a duplicate group No. is not allowed.
- Correct to the group No.

#### P180 No spec: Drilling cycle

##### Details

A fixed cycle command (G72 - G89) was issued though it is out of specifications.

##### Remedy

- Check the specifications.
- Correct the program.

#### P181 No spindle command (Tap cycle)

##### Details

Spindle rotation speed (S) has not been commanded in synchronous tapping.

##### Remedy

- Command the spindle rotation speed (S) in synchronous tapping.
- When "#8125 Check Scode in G84" is set to "1", enter the S command in the same block where the synchronous tapping command is issued.

#### P182 Synchronous tap error

##### Details

- Connection to the main spindle unit was not established.
- The synchronous tapping was attempted with the spindle not serially connected under the multiple-spindle control I.

##### Remedy

- Check connection to the main spindle.
- Check that the main spindle encoder exists.
- Set 1 to the parameter #3024 (sout).

#### P183 No pitch/thread number

##### Details

The pitch or number of threads has not been commanded in the tap cycle of a fixed cycle for drilling command.

##### Remedy

- Specify the pitch data and the number of threads by F or E command.

#### P184 Pitch/thread number error

##### Details

- The pitch or the number of threads per inch is illegal in the tap cycle of the fixed cycle for drilling command.
- The pitch is too small for the spindle rotation speed.
- The thread number is too large for the spindle rotation speed.

##### Remedy

- Correct the pitch or the number of threads per inch.

#### P185 No spec: Sync tapping cycle

##### Details

Synchronous tapping cycle (G84/G74) was commanded though it is out of specifications.

##### Remedy

- Check the specifications.

#### P186 Illegal S cmdnd in synchro tap

##### Details

S command was issued during synchronous tapping modal.

##### Remedy

- Cancel the synchronous tapping before issuing the S command.

#### P190 No spec: Turning cycle

##### Details

A lathe cutting cycle command was issued though it is out of specifications.

##### Remedy

- Check the specification.
- Delete the lathe cutting cycle command.

#### P191 Taper length error

##### Details

In the lathe cutting cycle, the specified length of taper section is illegal.

##### Remedy

- Set the smaller radius value than the axis travel amount in the lathe cycle command.

#### P192 Chamfering error

##### Details

Chamfering in the thread cutting cycle is illegal.

##### Remedy

- Set a chamfering amount not exceeding the cycle.

#### P200 No spec: MRC cycle

##### Details

The compound type fixed cycle for turning machining I (G70 to G73) was commanded though it is out of specifications.

##### Remedy

- Check the specifications.

### P201 Program error (MRC)

#### Details

- The subprogram, called with a compound type fixed cycle for turning machining I command, has at least one of the following commands: reference position return command (G27, G28, G29, G30); thread cutting (G33, G34); fixed cycle skip-function (G31, G31.n).
- An arc command was found in the first movement block of the finished shape program in compound type fixed cycle for turning machining I.

#### Remedy

- Delete G27, G28, G29, G30, G31, G33, G34, and fixed cycle G codes from the subprogram called with the compound type fixed cycle for turning machining I commands (G70 to G73).
- Delete G02 and G03 from the first movement block of the finished shape program in compound type fixed cycle for turning machining I.

### P202 Block over (MRC)

#### Details

The number of blocks in the shape program of the compound type fixed cycle for turning machining I is over 50 or 200 (the maximum number differs according to the model).

#### Remedy

- Set a 50/200 or less value for the number of blocks in the shape program called by the compound type fixed cycle for turning machining I commands (G70 to G73). (The maximum number differs according to the model).

### P203 D cmd figure error (MRC)

#### Details

A proper shape will not be obtained by executing the shape program for the compound type fixed cycle for turning machining I (G70 to G73).

#### Remedy

- Correct the shape program for the compound type fixed cycle for turning machining I (G70 to G73).

### P204 E cmd fixed cycle error

#### Details

A command value of the compound type fixed cycle for turning machining (G70 to G76) is illegal.

#### Remedy

- Correct the command value of the compound type fixed cycle for turning machining (G70 to G76).

### P210 No spec: Pattern cycle

#### Details

A compound type fixed cycle for turning machining II (G74 to G76) command was commanded though it is out of specifications.

#### Remedy

- Check the specifications.

### P220 No spec: Special fixed cycle

#### Details

There are no special fixed cycle specifications.

#### Remedy

- Check the specifications.

### P221 No. of special fixed holes = 0

#### Details

"0" has been specified for the number of holes in special fixed cycle mode.

#### Remedy

- Correct the program.

### P222 G36 angle error

#### Details

A G36 command specifies "0" for angle intervals.

#### Remedy

- Correct the program.



### P223 G12/G13 radius error

#### Details

The radius value specified with a G12 or G13 command is below the compensation amount.

#### Remedy

- Correct the program.

### P224 No spec: Circular (G12/G13)

#### Details

There are no circular cutting specifications.

#### Remedy

- Check the specifications.

### P230 Subprogram nesting over

#### Details

Over 8 times of subprogram calls have been done in succession from a subprogram.

- A M198 command was found in the program in the data server.
- The program in the IC card has been called more than once (the program in the IC card can be called only once during nested).

#### Remedy

- Correct the program so that the number of subprogram calls does not exceed 8 times.

### P231 No sequence No.

#### Details

The sequence No., commanded at the return from the subprogram or by GOTO in the subprogram call, was not set.

#### Remedy

- Specify the sequence Nos. in the call block of the subprogram.

### P232 No program No.

#### Details

- The machining program has not been found when the machining program is called.
- The file name of the program registered in IC card is not corresponding to O No.

#### Remedy

- Enter the machining program.
- Check the subprogram storage destination parameters.
- Ensure that the external device (including IC card) that contains the file is mounted.

### P235 Program editing

#### Details

Operation was attempted for the file under program editing.

#### Remedy

- Execute the program again after completion of program editing.

### P240 No spec: Variable commands

#### Details

A variable command (with #) was issued though it is out of specifications.

#### Remedy

- Check the specifications.

### P241 No variable No.

#### Details

The variable No. commanded is out of the range specified in the specifications.

#### Remedy

- Check the specifications.
- Correct the program variable No.

#### **P242 = not defined at vrble set**

##### **Details**

The "=" sign has not been commanded when a variable is defined.

##### **Remedy**

- Designate the "=" sign in the variable definition of the program.

#### **P243 Can't use variables**

##### **Details**

An invalid variable has been specified in the left or right side of an operation expression.

##### **Remedy**

- Correct the program.

#### **P244 Invalid set date or time**

##### **Details**

Date or time was set earlier than current date or time in the system variables (#3011, #3012) when the credit system was valid.

##### **Remedy**

- Date or time cannot be changed.
- Correct the program.

#### **P250 No spec: Figure rotation**

##### **Details**

Figure rotation (M98 I\_J\_P\_H\_L\_) was commanded though it is out of specifications.

##### **Remedy**

- Check the specifications.

#### **P251 Figure rotation overlapped**

##### **Details**

Figure rotation command was issued during figure rotation.

##### **Remedy**

- Correct the program.

#### **P252 Coord rotate in fig. rotation**

##### **Details**

A coordinate rotation related command (G68, G69) was issued during figure rotation.

##### **Remedy**

- Correct the program.

#### **P260 No spec: Coordinates rotation**

##### **Details**

A coordinate rotation command was issued though it is out of specifications.

##### **Remedy**

- Check the specifications.

#### **P261 G code illegal (Coord rot)**

##### **Details**

Another G code or a T command has been issued in the block of coordinate rotation command.

##### **Remedy**

- Correct the program.

#### **P262 Illegal modal (Coord rot)**

##### **Details**

A coordinate rotation command has been issued during modal in which coordinate rotation is not allowed.

##### **Remedy**

- Correct the program.

#### P270 No spec: User macro

##### Details

A macro specification was commanded though it is out of specifications.

##### Remedy

- Check the specifications.

#### P271 No spec: Macro interrupt

##### Details

A macro interruption command has been issued though it is out of specifications.

##### Remedy

- Check the specifications.

#### P272 NC and macro texts in a block

##### Details

An executable statement and a macro statement exist together in the same block.

##### Remedy

- Place the executable statement and macro statement in separate blocks in the program.

#### P273 Macro call nesting over

##### Details

The number of macro call nests exceeded the limit imposed by the specifications.

##### Remedy

- Correct the program so that the macro calls do not exceed the limit imposed by the specifications.

#### P275 Macro argument over

##### Details

The number of argument sets in the macro call argument type II has exceeded the limit.

##### Remedy

- Correct the program.

#### P276 Illegal G67 command

##### Details

A G67 command was issued though it was not during the G66 command modal.

##### Remedy

- Correct the program.
- Issue G66 command before G67 command, which is a call cancel command.

#### P277 Macro alarm message

##### Details

An alarm command has been issued in #3000.

##### Remedy

- Refer to the operator messages on the diagnosis screen.
- Refer to the instruction manual issued by the machine tool builder.

#### P280 Brackets [ ] nesting over

##### Details

Over five times have the parentheses "[" or "]" been used in a single block.

##### Remedy

- Correct the program so that the number of "[" or "]" is five or less.

#### P281 Brackets [ ] not paired

##### Details

A single block does not have the same number of commanded parentheses "[" as that of "]".

##### Remedy

- Correct the program so that "[" and "]" parentheses are paired up properly.

#### P282 Calculation impossible

##### Details

The arithmetic formula is incorrect.

##### Remedy

- Correct the formula in the program.

#### P283 Divided by zero

##### Details

The denominator of the division is zero.

##### Remedy

- Correct the program so that the denominator for division in the formula is not zero.

#### P288 IF EXCESS

##### Details

Over ten times of IF statement nesting have been done.

##### Remedy

Correct the program so that the number of IF statement nesting does not exceed ten.

#### P289 IF-ENDIF MMC.

##### Details

An IF statement is not ended with ENDIF.  
THEN/ELSE has been commanded while there is no IF command.

##### Remedy

- Correct the program so that IF statements are ended with ENDIFs.
- Put IF[condition] before THEN/ELSE command.

#### P290 IF sentence error

##### Details

There is an error in the "IF[<conditional>]GOTO(" statement.

##### Remedy

- Correct the program.

#### P291 WHILE sentence error

##### Details

There is an error in the "WHILE[<conditional>]DO(-END(" statement.

##### Remedy

- Correct the program.

#### P292 SETVN sentence error

##### Details

There is an error in the "SETVN(" statement when the variable name setting was made.

##### Remedy

- Correct the program.
- The number of characters in the variable name of the SETVN statement must be 7 or less.

#### P293 DO-END nesting over

##### Details

The number of DO-END nesting levels in the "WHILE[<conditional>]DO(-END(" statement has exceeded 27.

##### Remedy

- Correct the program so that the nesting levels of the DO-END statement does not exceed 27.

#### P294 DO and END not paired

##### Details

The DOs and ENDs are not paired off properly.

##### Remedy

- Correct the program so that the DOs and ENDs are paired off properly.

### P295 WHILE/GOTO in tape

#### Details

There is a WHILE or GOTO statement on the tape during tape operation.

#### Remedy

- Apply memory mode operation instead of tape mode that does not allow the execution of the program with a WHILE or GOTO statement.

### P296 No address (macro)

#### Details

A required address has not been specified in the user macro.

#### Remedy

- Correct the program.

### P297 Address-A error

#### Details

The user macro does not use address A as a variable.

#### Remedy

- Correct the program.

### P298 G200-G202 cmd in tape

#### Details

User macro G200, G201, or G202 was specified during tape or MDI mode.

#### Remedy

- Correct the program.

### P300 Variable name illegal

#### Details

The variable names have not been commanded properly.

#### Remedy

- Correct the variable names in the program.

### P301 Variable name duplicated

#### Details

A duplicate variable name was found.

#### Remedy

- Correct the program so that no duplicate name exists.

### P310 Not use GMSTB macro code

#### Details

G, M, S, T, or B macro code was called during fixed cycle.

#### Remedy

- Correct the program.
- Correct the parameter settings.

### P350 No spec: Scaling command

#### Details

The scaling command (G50, G51) was issued though it is out of specifications.

#### Remedy

- Check the specifications.

### P360 No spec: Program mirror

#### Details

A mirror image (G50.1 or G51.1) command has been issued though the programmable mirror image specifications are not provided.

#### Remedy

- Check the specifications.

#### P370 No spec: Facing t-post MR

##### Details

The facing turret mirror image specifications are not provided.

##### Remedy

- Check the specifications.

#### P371 Facing t-post MR illegal

##### Details

- Mirror image for facing tool posts was commanded to an axis in external mirror image or parameter mirror image.
- The commanded mirror image for facing tool posts enables the mirror image for a rotary axis.

##### Remedy

- Correct the program.
- Correct the parameter settings.

#### P380 No spec: Corner R/C

##### Details

The corner R/C was issued though it is out of specifications.

##### Remedy

- Check the specifications.
- Delete the corner chamfering/corner rounding command in the program.

#### P381 No spec: Arc R/C

##### Details

Corner chamfering II or corner rounding II was commanded in the arc interpolation block though it is out of specifications.

##### Remedy

- Check the specifications.

#### P382 No corner movement

##### Details

The block next to corner chamfering/ corner rounding is not a travel command.

##### Remedy

- Replace the block succeeding the corner chamfering/ corner rounding command by G01 command.

#### P383 Corner movement short

##### Details

The travel distance in the corner chamfering/corner rounding command was shorter than the value in the corner chamfering/corner rounding command.

##### Remedy

- Set the smaller value for the corner chamfering/corner rounding than the travel distance.

#### P384 Corner next movement short

##### Details

The travel distance in the following block in the corner chamfering/corner rounding command was shorter than the value in the corner chamfering/corner rounding command.

##### Remedy

- Set the smaller value for the corner chamfering/corner rounding than the travel distance in the following block.

#### P385 Corner during G00/G33

##### Details

A block with corner chamfering/corner rounding was given during G00 or G33 modal.

##### Remedy

- Correct the program.

### P390 No spec: Geometric

#### Details

A geometric command was issued though it is out of specifications.

#### Remedy

- Check the specifications.

### P391 No spec: Geometric arc

#### Details

There are no geometric IB specifications.

#### Remedy

- Check the specifications.

### P392 Angle < 1 degree (GEOMT)

#### Details

The angular difference between the geometric line and line is 1° or less.

#### Remedy

- Correct the geometric angle.

### P393 Inc value in 2nd block (GEOMT)

#### Details

The second geometric block has a command with an incremental value.

#### Remedy

- Issue a command with an absolute value in the second geometric block.

### P394 No linear move command (GEOMT)

#### Details

The second geometric block contains no linear command.

#### Remedy

- Issue the G01 command.

### P395 Illegal address (GEOMT)

#### Details

The geometric format is invalid.

#### Remedy

- Correct the program.

### P396 Plane selected in GEOMT ctrl

#### Details

A plane switching command was issued during geometric command processing.

#### Remedy

- Complete the plane switching command before geometric command processing.

### P397 Arc error (GEOMT)

#### Details

In geometric IB, the circular arc end point does not contact or cross the next block start point.

#### Remedy

- Correct the geometric circular arc command and the preceding and following commands.

### P398 No spec: Geometric1B

#### Details

A geometric command was issued though the geometric IB specifications are not provided.

#### Remedy

- Check the specifications.

#### P411 Illegal modal G111

##### Details

- G111 was issued during milling mode.
- G111 was issued during nose R compensation mode.
- G111 was issued during constant surface speed.
- G111 was issued during mixed control (cross axis control).
- G111 was issued during fixed cycle.
- G111 was issued during polar coordinate interpolation.
- G111 was issued during cylindrical interpolation mode.

##### Remedy

- Before commanding G111, cancel the following commands.
- Milling mode
- Nose R compensation
- Constant surface speed
- Mixed control (cross axis control)
- Fixed cycle
- Polar coordinate interpolation
- Cylindrical interpolation

#### P412 No spec: Axis name switch

##### Details

Axis name switch (G111) was issued though it is out of specifications.

##### Remedy

- Check the specifications.

#### P420 No spec: Para input by program

##### Details

Parameter input by program (G10) was commanded though it is out of specifications.

##### Remedy

- Check the specifications.

#### P421 Parameter input error

##### Details

- The specified parameter No. or set data is illegal.
- An illegal G command address was input in parameter input mode.
- A parameter input command was issued during fixed cycle modal or nose R compensation.
- G10L50, G10L70, G11 were not commanded in independent blocks.

##### Remedy

- Correct the program.

#### P430 R-pnt return incomplete

##### Details

- A command was issued to move an axis, which has not returned to the reference position, away from that reference position.
- A command was issued to an axis removal axis.

##### Remedy

- Execute reference position return manually.
- Disable the axis removal on the axis for which the command was issued.

#### P431 No spec: 2,3,4th R-point ret

##### Details

A command for second, third or fourth reference position return was issued though there are no such command specifications.

##### Remedy

- Check the specifications.



**P432 No spec: Start position return**

**Details**

Start position return (G29) was commanded though it is out of specifications.

**Remedy**

- Check the specifications.

**P433 No spec: R-position check**

**Details**

Reference position check (G27) was commanded though it is out of specifications.

**Remedy**

- Check the specifications.

**P434 Compare error**

**Details**

One of the axes did not return to the reference position when the reference position check command (G27) was executed.

**Remedy**

- Correct the program.

**P435 G27 and M commands in a block**

**Details**

An M command was issued simultaneously in the G27 command block.

**Remedy**

- Place the M code command, which cannot be issued in a G27 command block, in separate block from G27 command block.

**P436 G29 and M commands in a block**

**Details**

An M command was issued simultaneously in the G29 command block.

**Remedy**

- Place the M code command, which cannot be issued in a G29 command block, in separate block from G29 command block.

**P438 G52 invalid during G54.1**

**Details**

A local coordinate system command was issued during execution of the G54.1 command.

**Remedy**

- Correct the program.

**P450 No spec: Chuck barrier**

**Details**

The chuck barrier on command (G22) was specified although the chuck barrier is out of specifications.

**Remedy**

- Check the specifications.

**P451 No spec: Stroke chk bef travel**

**Details**

Stroke check before travel (G22/G23) was commanded though it is out of specifications.

**Remedy**

- Check the specifications.

**P452 Limit before travel exists**

**Details**

An illegal command, which places the axis travel start/end point in the prohibited area or moves the axis through the prohibited area, was detected when Stroke check before travel (G22) was commanded.

**Remedy**

- Correct the coordinate values of the axis address commanded in the program.

#### P460 Tape I/O error

##### Details

An error has occurred in the tape reader. Otherwise an error has occurred in the printer during macro printing.

##### Remedy

- Check the power and cable of the connected devices.
- Correct the I/O device parameters.

#### P461 File I/O error

##### Details

- A file of the machining program cannot be read.
- IC card has not been inserted.

##### Remedy

- In memory mode, the programs stored in memory may have been destroyed. Output all of the programs and tool data and then format the system.
- Ensure that the external device (including an IC card, etc) that contains the file is mounted.
- Correct the parameter settings for HD operation or IC card operation.

#### P462 Computer link commu error

##### Details

A communication error occurred during the BTR operation.

##### Remedy

- "L01 Computer link error" is displayed simultaneously. Take the remedy corresponding to the error No.

#### P480 No spec: Milling

##### Details

- Milling was commanded though it is out of specifications.
- Polar coordinate interpolation was commanded though it is out of specifications.

##### Remedy

- Check the specifications.

#### P481 Illegal G code (mill)

##### Details

- An illegal G code was used during the milling mode.
- An illegal G code was used during cylindrical interpolation or polar coordinate interpolation.
- The G07.1 command was issued during the tool radius compensation.

##### Remedy

- Correct the program.

#### P482 Illegal axis (mill)

##### Details

- A rotary axis was commanded during the milling mode.
- Milling was executed though an illegal value was set for the milling axis No.
- Cylindrical interpolation or polar coordinate interpolation was commanded during mirror image.
- Cylindrical interpolation or polar coordinate interpolation was commanded before the tool compensation was completed after the T command.
- G07.1 was commanded when cylindrical interpolation was not possible (there is no rotary axis, or external mirror image is ON).
- An axis other than a cylindrical coordinate system axis was commanded during cylindrical interpolation.

##### Remedy

- Correct the machining program, parameters and PLC interface signals.

#### P484 R-pnt ret incomplete (mill)

##### Details

- Movement was commanded to an axis that had not completed reference position return during the milling mode.
- Movement was commanded to an axis that had not completed reference position return during cylindrical interpolation or polar coordinate interpolation.

##### Remedy

- Carry out manual reference position return.

#### P485 Illegal modal (mill)

##### Details

- The milling mode was turned ON during nose R compensation or constant surface speed control.
- A T command was issued during the milling mode.
- The mode was switched from milling to cutting during tool compensation.
- Cylindrical interpolation or polar coordinate interpolation was commanded during the constant surface speed control mode (G96).
- The command unacceptable in the cylindrical interpolation was issued.
- A T command was issued during the cylindrical interpolation or polar coordinate interpolation mode.
- A movement command was issued when the plane was not selected just before or after the G07.1 command.
- A plane selection command was issued during the polar coordinate interpolation mode.
- Cylindrical interpolation or polar coordinate interpolation was commanded during tool radius compensation.
- The G16 plane in which the radius value of a cylinder is "0" was specified.
- A cylindrical interpolation or polar coordinate interpolation command was issued during coordinate rotation by program.

##### Remedy

- Correct the program.
- Issue G40 or G97 before issuing G12.1.
- Issue a T command before issuing G12.1.
- Issue G40 before issuing G13.1.
- Specify the radius value of a cylinder other than "0", or specify the X axis's current value other than "0" before issuing G12.1/G16.

#### P486 Milling error

##### Details

- The milling command was issued during the mirror image (when parameter or external input is turned ON).
- Polar coordinate interpolation, cylindrical interpolation or milling interpolation was commanded during mirror image for facing tool posts.
- The start command of the cylindrical interpolation or polar coordinate interpolation was issued during the normal line control.

##### Remedy

- Correct the program.

#### P501 Cross (G110) impossible

##### Details

Mixed control (cross axis control) command (G110) was issued in the following modes.

- During nose R compensation mode
- During pole coordinate interpolation mode
- During cylindrical interpolation mode
- During balance cut mode
- During fixed cycle machining mode
- During facing turret mirror image
- During constant surface speed control mode
- During hobbing mode
- During axis name switch

##### Remedy

- Correct the program.

#### P503 Illegal G110 axis

##### Details

- The commanded axis does not exist.
- The mixed control (cross axis control) (G110) was commanded to the axis for which the mixed control (cross axis control) is disabled.
- The number of axes included in the mixed control (cross axis control) (G110) command is exceeding the maximum number of axes per part system.

##### Remedy

- Correct the program.

#### P511 Synchronization M code error

##### Details

- Two or more synchronization M codes were commanded in the same block.
- The synchronization M code and "!" code were commanded in the same block.
- Synchronization with the M code was commanded in 3rd part system or more. (Synchronization with the M code is valid only in 1st part system or 2nd part system.)

##### Remedy

- Correct the program.

#### P520 Control axis superimposition/Designated axis illegal

##### Details

An axis which was impossible to superimpose was designated as a master axis or superimposing axis.

##### Remedy

Correct the program.

#### P521 Illegal synchronization axis

##### Details

The axis specified as a basic or synchronous axis of synchronization across part systems cannot be synchronized.

##### Remedy

- Correct the program.

#### P530 DEC. POINT ERR

##### Details

A decimal point was added to the address where the decimal point command is not allowed. ("#1274 ext10/bit0 (Type of address enabling/disabling decimal point command)")

##### Remedy

Do not add any decimal point to the addresses where the decimal point is not allowed.

#### P544 No spec: Wk instl err cmp

##### Details

The workpiece installation error compensation function is out of the specifications.

##### Remedy

- Check the specifications.

#### P545 Invlid cmd in wk instl err cmp

##### Details

During workpiece installation error compensation, a command impossible to issue (such as G command) was issued.

##### Remedy

- Check the program. If you wish to issue a command impossible to issue (such as G command) during workpiece installation error compensation, cancel workpiece installation error compensation once.

### P546 Wk instl err cmp cmd invalid

#### Details

- Workpiece installation error compensation was commanded in a G modal in which commanding it is not allowed.
- An illegal G command was issued in the block that has a workpiece installation error compensation command.

#### Remedy

- Check the program. Also check the G modals which were issued at commanding the workpiece installation error compensation, and cancel illegal ones.
- Issue the G command in a separate block.

### P547 Illegal wk instl err cmp cmd

#### Details

A command in which the rotary axis's travel distance exceeds 180 degrees was issued.

#### Remedy

- Divide the travel command so that the rotary axis's travel distance per block is less than 180 degrees.

### P550 No spec: G06.2(NURBS)

#### Details

There is no NURBS interpolation option.

#### Remedy

- Check the specifications.

### P551 G06.2 knot error

#### Details

The knot (k) command value is smaller than the value for the previous block.

#### Remedy

- Correct the program.
- Specify the knot by monotone increment.

### P552 Start point of 1st G06.2 err

#### Details

The block end point immediately before the G06.2 command and the G06.2 first block command value do not match.

#### Remedy

- Match the G06.2 first block coordinate command value with the previous block end point.

### P554 Invld manual interrupt in G6.2

#### Details

Manual interruption was executed in a block that applies the G06.2 mode.

#### Remedy

- Execute the manual interruption in the block that does not apply the G06.2 mode.

### P555 Invalid restart during G06.2

#### Details

Restart was attempted from the block that applies G06.2 mode.

#### Remedy

- Restart from the block that does not apply the G06.2 mode.

### P600 No spec: Auto TLM

#### Details

An automatic tool length measurement command (G37) was issued though it is out of specifications.

#### Remedy

- Check the specifications.

#### **P601 No spec: Skip**

##### **Details**

A skip command (G31) was issued though it is out of specifications.

##### **Remedy**

- Check the specifications.

#### **P602 No spec: Multi skip**

##### **Details**

A multiple skip command (G31.1, G31.2, G31.3 or G31 Pn) was issued though it is out of specifications.

##### **Remedy**

- Check the specifications.

#### **P603 Skip speed 0**

##### **Details**

The skip speed is "0".

##### **Remedy**

- Specify the skip speed.

#### **P604 TLM illegal axis**

##### **Details**

No axis was specified in the automatic tool length measurement block. Otherwise, two or more axes were specified.

##### **Remedy**

- Specify only one axis.

#### **P605 T & TLM command in a block**

##### **Details**

The T code is in the same block as the automatic tool length measurement block.

##### **Remedy**

- Specify the T code before the automatic tool length measurement block.

#### **P606 T cmnd not found before TLM**

##### **Details**

The T code was not yet specified in automatic tool length measurement.

##### **Remedy**

- Specify the T code before the automatic tool length measurement block.

#### **P607 TLM illegal signal**

##### **Details**

The measurement position arrival signal turned ON before the area specified by the D command or "#8006 ZONE d". Otherwise, the signal remained OFF to the end.

##### **Remedy**

- Correct the program.

#### **P608 Skip during radius compen**

##### **Details**

A skip command was issued during radius compensation processing.

##### **Remedy**

- Issue a radius compensation cancel (G40) command or remove the skip command.

### P610 Illegal parameter

#### Details

- The parameter setting is not correct.
- G114.1 was commanded while the spindle synchronization was selected with the PLC interface signal.
- G113 was commanded while the spindle-spindle polygon machining option was OFF and the spindle synchronization was selected with the PLC interface signal.
- G110 was commanded while the mixed control (cross axis control) was selected with the PLC interface signal.
- G125 was commanded while the control axis synchronization across part systems was selected with the PLC interface signal.

#### Remedy

- Check whether the values are set in descending order (from the largest value) for "#1549 lv0vR1" to "#1553 lv0vR5".
- Check whether the values are set in descending order for "#1554 lv0rd2" to "#1557 lv0rd5".
- Correct the settings of "#1514 expLinax (Exponential function interpolation linear axis)" and "#1515 expRotax (Exponential function interpolation rotary axis)".
- Correct the program.
- Correct the parameter settings.

### P611 No spec: Exponential function

#### Details

There is no specification for the exponential interpolation.

#### Remedy

- Check the specifications.

### P612 Exponential function error

#### Details

A travel command for exponential interpolation was issued during mirror image for facing tool posts.

#### Remedy

- Correct the program.

### P700 Illegal command value

#### Details

Spindle synchronization was commanded to a spindle that is not connected serially.

#### Remedy

- Correct the program.
- Correct the parameter settings.

### P900 No spec: Normal line control

#### Details

A normal line control command (G40.1, G41.1, or G42.1) was issued though it is out of specifications.

#### Remedy

- Check the specifications.

### P901 Normal line control axis G92

#### Details

A coordinate system preset command (G92) was issued to a normal line control axis during normal line control.

#### Remedy

- Correct the program.

#### P902 Normal line control axis error

##### Details

- The normal line control axis was set to a linear axis.
- The normal line control axis was set to the linear type rotary axis II axis.
- The normal line control axis has not been set.
- The normal line control axis is the same as the plane selection axis.

##### Remedy

- Correct the normal line control axis setting.

#### P903 Plane chg in Normal line ctrl

##### Details

The plane selection command (G17, G18, or G19) was issued during normal line control.

##### Remedy

- Delete the plane selection command (G17, G18, or G19) from the program of the normal line control.

#### P920 No spec: 3D coord conv

##### Details

There is no specification for 3-dimensional coordinate conversion.

##### Remedy

- Check the specifications.

#### P921 Illegal G code at 3D coord

##### Details

The commanded G code cannot be performed during 3-dimensional coordinate conversion modal.

##### Remedy

- Refer to "MITSUBISHI CNC 700/70 Series Programming Manual (Machining Center System)" for usable G commands.
- When the basic specification parameter "#1229 set01/bit3 (Initial constant surface speed)" is enabled, disable the parameter or issue the constant surface speed control cancel (G97) command.

#### P922 Illegal mode at 3D coord

##### Details

A 3-dimensional coordinate conversion command was issued during a modal for which 3-dimensional coordinate conversion cannot be performed.

##### Remedy

- Refer to "MITSUBISHI CNC 700/70 Series Programming Manual (Machining Center System)" for usable G commands.

#### P923 Illegal addr in 3D coord blk

##### Details

A G code and G68 was commanded in a block though the G code cannot be commanded with G68.

##### Remedy

- Refer to "MITSUBISHI CNC 700/70 Series Programming Manual (Machining Center System)" for usable G commands.

#### P930 No spec: Tool axis compen

##### Details

A tool length compensation along the tool axis command was issued though it is out of specifications.

##### Remedy

- Check the specifications.

#### P931 Executing tool axis compen

##### Details

There is a G code that cannot be commanded during tool length compensation along the tool axis.

##### Remedy

- Correct the program.



**P932 Rot axis parameter error**

**Details**

There is an illegal linear axis name or rotary axis name set in the rotary axis configuration parameters. There is an illegal setting in the parameter concerning the configuration of the inclined surface machining axis.

**Remedy**

- Set the correct value and turn the power ON again.

**P940 No spec: Tool tip control**

**Details**

There is no specification for tool tip center control.

**Remedy**

- Check the specifications.

**P941 Invalid T tip control command**

**Details**

A tool tip center control command was issued during a modal for which a tool tip center control command cannot be issued.

**Remedy**

- Correct the program.

**P942 Invalid cmd during T tip ctrl**

**Details**

A G code that cannot be commanded was issued during tool tip center control.

**Remedy**

- Correct the program.

**P943 Tool posture command illegal**

**Details**

In tool tip center control type 1, if the signs at the tool-side rotary axis or table base-side rotary axis start and finish points differ, a tool base-side rotary axis or table workpiece-side rotary axis rotation exists for the same block, and does not pass a singular point.

In tool tip center control type 2, the posture vector command is incorrect.

**Remedy**

- Correct the program.

**P950 No spec: Tilt face machining**

**Details**

Inclined surface machining option is not supported.

**Remedy**

- Check the specifications.

**P951 III cmd in tilt face machining**

**Details**

A forbidden command (G command, etc) was issued during inclined surface machining.

**Remedy**

- Check the program. If you want to execute a command (G command, etc) that is unavailable during inclined surface machining, cancel the inclined surface machining.

**P952 Inclined face cut prohibited**

**Details**

Inclined surface machining was commanded during the mode where the machining is unavailable. Inclined surface machining was commanded during interruption.

**Remedy**

- Check the program and see whether any unavailable mode is included during inclined surface machining command. If any, cancel that mode.

#### P953 Tool axis dir cntrl prohibited

##### Details

Tool axis direction control was commanded during the mode where the control is unavailable.

##### Remedy

- Check the program and see whether any unavailable mode is included during tool axis direction control. If any, cancel that mode.

#### P954 Inclined face command error

##### Details

The address to issue the inclined surface machining command is incorrect.

##### Remedy

- Check the program.

#### P955 Inclined face coord illegal

##### Details

Impossible to define an inclined surface with the values you specified.

##### Remedy

- Check the program.

#### P957 Tool axis dir ctrl cmp amt 0

##### Details

When the tool axis direction control type 2 (G53.6) was commanded, a tool length compensation No. whose compensation amount is 0 was commanded.

##### Remedy

- Correct the program. Set the tool length compensation amount, or command a tool length compensation No. whose compensation amount is not 0.

#### P990 PREPRO error

##### Details

Combining commands that required pre-reading (nose R offset, corner chamfering/corner rounding, geometric I, geometric IB, and compound type fixed cycle for turning machining) resulted in eight or more pre-read blocks.

##### Remedy

- Delete some or all of the combinations of commands that require pre-reading.


## Appendix 2.13 Troubleshooting

### Appendix 2.13.1 Troubleshooting for NC

In case of the error during startup, the 7-segment LED change as follows.

Using two 7-segment LED, it displays sub-CPU on left side, and main CPU on the right side.

Take a note of the 7-segment LED contents and contact the Service Center.



LED display	Cause
E	Undefined interruption signal
F	Bus error, Address error or Interrupt exception (ASIC)
A	Checksum check error in Boot ROM (Flash ROM)
C	Checksum check error in DOSFS (Flash ROM)
d	Memory test error in DRAM
b	Time out error in ASIC
G	Initialization error in Graphic controller
U	Unsupported H/W
.(period)	No correct boot data in Flash ROM

(cf) In case of SRAM clear, 7-segment LED change as follows (RSW2'C')

LED display	Result
y	Memory test pass in SRAM
c	Memory test error in SRAM

### Appendix 2.13.2 Troubleshooting for drive system


Follow this section to troubleshoot the alarms that occur during start up or while the machine is operating. If the state is not improved with the following investigations, the drive unit may be faulty. Exchange the unit with another unit of the same capacity, and check whether the state is improved.

#### Appendix 2.13.2.1 Troubleshooting at power ON

If the NC system does not start up correctly and a system error occurs when the NC power is turned ON, the drive unit may not have been started up properly. Check the LED display on the drive unit, and take measures according to this section.

LED display	Symptom	Cause of occurrence	Investigation method	Remedy
AA	Initial communication with the CNC was not completed correctly.	The drive unit axis No. setting is incorrect.	Is there any other drive unit that has the same axis No. set?	Set correctly.
		The CNC setting is incorrect.	Is the No. of CNC controlled axes correct?	Set correctly.
		Communication with CNC is incorrect.	Is the connector (CN1A, CN1B) connected?	Connect correctly.
			Is the cable broken?	Replace the cable.
Ab	Initial communication with the CNC was not carried out.	The axis is not used, the setting is for use inhibiting.	Is the DIP switch set correctly?	Set correctly.
		Communication with CNC is incorrect.	Is the connector (CN1A, CN1B) connected?	Connect correctly.
			Is the cable broken?	Replace the cable.
12	An error was detected in the unit's memory and IC during the self-diagnosis at power ON.	The CPU peripheral circuit is abnormal.	Check the repeatability.	Replace the unit.
			Check whether there is any abnormality with the unit's surrounding environment, etc.	Improve the surrounding environment.

The drive unit has started up normally if the following type of emergency stop (E7) is displayed on the display unit's LED display.



Normal drive unit LED display at NC power ON (for 1st axis)

## Appendix 2 Explanation of Alarms

### Appendix 2.13.2.2 Troubleshooting for each alarm No.

Alarm No. 10		Insufficient voltage			
		Insufficient bus voltage was detected in main circuit.			
	Investigation details	Investigation results	Remedies	SV	SP
1	Check the timing when the alarm occurs.	The moment of READY ON	Check the investigation item No. 2.	○	○
		During operation	Increase the power supply capacity (KVA).		
2	Did the external contactor turn ON at the READY ON?	The external contactor did not turn ON.	Check the investigation item No. 3.	○	○
		The external contactor turned ON, but the alarm occurred immediately.	Check the investigation item No. 4.		
3	Check the wiring of contactor excitation circuit.	The wiring is correct.	Replace the contactor.	○	○
		The wiring is not correct.	Rewire.		
4	Check the input voltage of the drive unit by a tester. (Voltage between L1 and L2, L2 and L3, L1 and L3)	The input voltage is normal.	Replace the drive unit.	○	○
		The input voltage is abnormal. The measured voltage fluctuates.	Increase the power supply capacity (KVA). Replace the power supply.		

Alarm No. 11		Axis selection error			
		The axis selection rotary switch is incorrectly set.			
	Investigation details	Investigation results	Remedies	SV	SP
1	Check the setting of the axis selection switch (rotary switch) on the top of the unit.	The same axis No. is set for the L and M axes.	Correctly set the axis No. 0 = No. 1 axis, 1 = No. 2 axis, ...	○	○
		The value is duplicated with other axis.	Correctly set the axis No. 0 = No. 1 axis, 1 = No. 2 axis, ...		
		The axis No. is correctly set.	Replace the drive unit.		

Alarm No. 12		Memory error 1			
		Hardware error (a CPU or an internal memory error was detected during the power ON self-check.			
	Investigation details	Investigation results	Remedies	SV	SP
1	Check the repeatability.	The error is always repeated.	Replace the drive unit.	○	○
		The state returns to normal once, but occurs sometimes thereafter.	Check the investigation item No. 2.		
2	Check if there is any abnormality in the unit's ambient environment. (Ex. Ambient temperature, noise, grounding)	Take remedies according to the causes of the abnormality in the ambient environment.		○	○

Alarm No. 13		Software processing error 1			
		An error was detected in the software execution state. Software processing has not finished within the specified time.			
	Investigation details	Investigation results	Remedies	SV	SP
1	Check the repeatability.	The error is always repeated.	Replace the drive unit.	○	○
		The state returns to normal once, but occurs sometimes thereafter.	Check the investigation item No. 2.		
2	Check if there is any abnormality in the unit's ambient environment. (Ex. Ambient temperature, noise, grounding)	Take remedies according to the causes of the abnormality in the ambient environment. [1] Machine grounding check		○	○

Alarm No. 16		Initial magnetic pole position detection error			
		In linear motor or IPM spindle motor using absolute position detector, the servo ON has been set before the magnetic pole shift amount(servo:SV028,spindle:SP118) is set. In the initial magnetic pole position detection control, the pole position was not correctly set.			
	Investigation details	Investigation results	Remedies	SV	SP
1	Check the parameters, SV028 (for the servo) and SP118(for the spindle).	The parameters have not been set.	Set the magnetic shift pole amount(SP118).	○	○
		The parameters have been set, but the alarm occurs.	Carry out the magnetic pole estimation again, as the setting value is wrong.		
		The setting parameter value is the same even when initial magnetic pole function was executed again.	Check the investigation item No. 2.		
2	Check the repeatability.	The error is always repeated.	Replace the drive unit.	○	○
		The state returns to normal once, but occurs sometimes thereafter.	Check the investigation item No. 3.		
3	Check if there is any abnormality in the unit's ambient environment. (Ex. Ambient temperature, noise, grounding)	Take remedies according to the causes of the abnormality in the ambient environment. [1] Machine grounding check [2] Shield connection of the cable		○	○

Alarm No. 17		A/D converter error			
		An error was detected in the current FB.			
	Investigation details	Investigation results	Remedies	SV	SP
1	Check the repeatability.	The error is always repeated.	Replace the drive unit.	○	○
		The state returns to normal, but occurs thereafter.	Check the investigation item No. 2.		
2	Check if there is any abnormality in the unit's ambient environment. (Ex. Ambient temperature, noise, grounding)	Take remedies according to the causes of the abnormality in the ambient environment.		○	○

Alarm No. 18		Main side detector: Initial communication error			
		An error was detected in the initial communication with the motor side detector.			
	Investigation details	Investigation results	Remedies	SV	SP
1	Check the servo parameter (SV025.ent) setting value. Check the spindle parameter(SP020) setting value.	The value is not set correctly.	Correctly set SV025 for the servo, and SP020 for the spindle.	○	○
		The value is set correctly.	Check the investigation item No. 3.		
2	Check the detector. Check if a pulse detector is used for serial detector specifications.	The pulse detector is used.	Replace the detector to the serial.	○	○
		The serial detector is used.	Check the investigation item No. 3.		
3	Jiggle the detector connectors (drive unit side and detector side) and check if they are disconnected.	The connector is disconnected (or loose).	Correctly install.	○	○
		The connector is not disconnected.	Check the investigation item No. 4.		
4	Turn the power OFF, and check the detector cable connection with a tester.	The connection is faulty.	Replace the detector cable.	○	○
		The connection is normal.	Check the investigation item No. 5.		
5	Replace with another unit, and check whether the fault is on the unit side or detector side.	The alarm is on the drive unit side.	Replace the drive unit.	○	○
		The alarm is on the detector side.	Check the investigation item No. 6.		
6	Check if there is any abnormality in the detector's ambient environment. (Ex. Ambient temperature, noise, grounding)	Take remedies according to the causes of the abnormality in the ambient environment. [1] Machine grounding check [2] Shield connection of the cable		○	○

## Appendix 2 Explanation of Alarms

Alarm No. 19	Detector communication error in synchronous control:				
	An error was detected in the machine side detector of the secondary axis at the speed command synchronization control.				
	Investigation details	Investigation results	Remedies	SV	SP
1	Check the servo parameter value of secondary axis (SV025.pen:position detector).	The value is not set correctly.	Correctly set.	○	
		The value is set correctly.	Check the investigation item No. 2.		
2	Check if there are no problems in the connection between the detector (linear scale) and MDS-B-HR.	The screw connected to MDS-B-HR is winded down.	Tighten up the screw.	○	
		No problems found in the connector connection.	Check the investigation item No. 3.		
3	Jiggle the detector connectors (drive unit side and detector side) and check if they are disconnected.	The connector is disconnected (or loose).	Correctly install.	○	
		The connector is not disconnected.	Check the investigation item No. 3.		
4	Turn the power OFF, and check the detector cable connection with a tester.	The connection is faulty.	Replace the detector cable.	○	
		The connection is normal.	Check the investigation item No. 4.		
5	Replace with another unit, and check whether the fault is on the unit side or detector side.	The alarm is on the drive unit side.	Replace the drive unit.	○	
		The alarm is on the detector side.	Check the investigation item No. 5.		
6	Check if there is any abnormality in the detector's ambient environment. (Ex. Ambient temperature, noise, grounding)	Take remedies according to the causes of the abnormality in the ambient environment. [1] Machine grounding check [2] Shield connection of the cable		○	

Alarm No. 1A	Sub side detector: Initial communication error				
	Initial communication with the machine side detector failed.				
	Investigation details	Investigation results	Remedies	SV	SP
1	Check the servo parameter (SV025.pen:position detector) setting value. Check the spindle parameter(SP019) setting value. Are the serial communication type detector parameters set for the pulse type detector?	The value is not set correctly.	Correctly set SV025.	○	
		The value is set correctly.	Check the investigation item No. 2.		
2	Check the detector. Check if the pulse detector is used for the detector specified to be serial.	The pulse detector is used.	Replace the detector.	○	○
		The serial detector is used.	Check the investigation item No. 3.		
3	Jiggle the detector connectors (drive unit side and detector side) and check if they are disconnected.	The connector is disconnected (or loose).	Correctly install.	○	
		The connector is not disconnected.	Check the investigation item No. 4.		
4	Turn the power OFF, and check the detector cable connection with a tester.	The connection is faulty.	Replace the detector cable.	○	
		The connection is normal.	Check the investigation item No. 5.		
5	Replace with another unit, and check whether the fault is on the unit side or detector side.	The alarm is on the drive unit side.	Replace the drive unit.	○	
		The alarm is on the detector side.	Check the investigation item No. 6.		
6	Check if there is any abnormality in the detector's ambient environment. (Ex. Ambient temperature, noise, grounding)	Take remedies according to the causes of the abnormality in the ambient environment.		○	

Alarm No. 1B		Sub side detector: Error 1			
		The machine side detector (CN3 side) detected an error. As details differ for each detector, refer to "Detector alarm" in 6-2-1.			
	Investigation details	Investigation results	Remedies	SV	SP
1	Check whether the servo axis has moved and the spindle has rotated when an alarm occurred.	The axis has operated.	Check the investigation item No. 3.	○	○
		The axis has not operated.	Check the investigation item No. 2.		
2	Check whether the operation at low speed is normal.	The operation is normal.	Check the investigation item No. 3.	○	○
		The operation is not normal.	Check the cautions at power ON. [1] Wiring check [2] Parameter check		
3	Jiggle the detector connectors (drive unit side and detector side) and check if they are disconnected.	The connector is disconnected (or loose).	Correctly install.	○	○
		The connector is not disconnected.	Check the investigation item No. 4.		
4	Turn the power OFF, and check the detector cable connection with a tester.	The connection is faulty.	Replace the detector cable.	○	○
		The connection is normal.	Check the investigation item No. 5.		
5	Replace with another unit, and check whether the fault is on the unit side or detector side.	The alarm is on the drive unit side.	Replace the drive unit.	○	○
		The alarm is on the detector side.	Check the investigation item No. 6.		
6	Check if there is any abnormality in the detector's ambient environment. (Ex. Ambient temperature, noise, grounding)	Take remedies according to the causes of the abnormality in the ambient environment.		○	○

Alarm No. 1C		Sub side detector: Error 2			
		The machine side detector (CN3 side) detected an error. As details differ for each detector, refer to "Detector alarm" in 6-2-1.			
	Investigation details	Investigation results	Remedies	SV	SP
1	Check the alarm No. "1B" items.			○	

Alarm No. 1D		Sub side detector: Error 3			
		The machine side detector (CN3 side) detected an error. As details differ for each detector, refer to "Detector alarm" in 6-2-1.			
	Investigation details	Investigation results	Remedies	SV	SP
1	Check the alarm No. "1B" items.			○	

Alarm No. 1E		Sub side detector: Error 4			
		The machine side detector (CN3 side) detected an error. As details differ for each detector, refer to "Detector alarm" in 6-2-1.			
	Investigation details	Investigation results	Remedies	SV	SP
1	Check the alarm No. "1B" items.			○	



# Appendix 2 Explanation of Alarms

Alarm No. 1F	Sub side detector: Communication error				
	An error was detected in communication data with the linear scale or the ball screw side detector. Or the communication was interrupted.				
	Investigation details	Investigation results	Remedies	SV	SP
1	Jiggle the detector connectors (drive unit side and detector side) and check if they are disconnected.	The connector is disconnected (or loose).	Correctly install.	○	
		The connector is not disconnected.	Check the investigation item No. 2.		
2	Is the detector cable wired in the same conduit as the motor's power cable, or are the two cables laid in parallel near each other?	The cables are wired near each other. (Noise is entering from the power cable.)	Wire the detector cable away from the power cable. Shield the power cable.	○	
		The wires are sufficiently separated.	Check the investigation item No. 3.		
3	Is the motor FG wire connected only to the drive unit which drives it? (Is the motor grounded to one point?)	The motor FG wire is grounded on the motor side.	Ground the motor to one point, connecting the wires together on the drive unit side.	○	
		The motor is grounded to one point.	Check the investigation item No. 4.		
4	Turn the power OFF, and check the detector cable connection with a tester. (Is the cable shielded?)	The connection is faulty.	Replace the detector cable.	○	
		The connection is normal.	Check the investigation item No. 5.		
5	Replace with another unit, and check whether the fault is on the unit side or detector side.	The alarm is on the drive unit side.	Replace the drive unit.	○	
		The alarm is on the detector side.	Check the investigation item No. 6.		
6	Check if there is any abnormality in the detector's ambient environment. (Ex. Ambient temperature, noise, grounding)	Take remedies according to the causes of the abnormality in the ambient environment.		○	

Alarm No. 21	Sub side detector: No signal2				
	When an excessive error alarm occurred, no signal from the machine side detector was detected. An error was detected in the ABZ-phase in the full closed loop control system.				
	Investigation details	Investigation results	Remedies	SV	SP
1	Check the servo parameter (SV025. pen:machine side detector), and spindle parameter (SP019) setting value. Are the pulse type detector parameters set for a serial communication type detector?	The value is not set correctly.	Correctly set SV025.pen for the servo and SP019 for the spindle (including SP097 for pulse type).	○	
		The value is set correctly.	Check the investigation item No. 3.		
2	Jiggle the detector connectors (drive unit side and detector side) and check if they are disconnected.	The connector is disconnected (or loose).	Correctly install.	○	
		The connector is not disconnected.	Check the investigation item No. 4.		
3	Turn the power OFF, and check the detector cable connection with a tester.	The connection is faulty.	Replace the detector cable.	○	
		The connection is normal.	Check the investigation item No. 5.		
4	Replace with another unit, and check whether the fault is on the unit side or detector side.	The alarm is on the drive unit side.	Replace the drive unit.	○	
		The alarm is on the detector side.	Replace the detector.		
5	Check if there is any abnormality in the detector's ambient environment. (Ex. Ambient temperature, noise, grounding)	Take remedies according to the causes of the abnormality in the ambient environment.		○	

Alarm No. 22		Detector data error: Drive unit received a wrong feedback data (scattered data) from the detector and position deviation occurred.			
	Investigation details	Investigation results	Remedies	SV	SP
1	Check if the installation of the detector is loosened.	It is loosened.	Tightly install the detector.	○	
		It is not loosened.	Check the investigation item No. 2.		
2	Check if an excessive vibration is occurring during machining.	An excessive vibration is occurring.	Check the installation of the machine.	○	
		An excessive vibration is not occurring.	Check the investigation item No. 3.		
3	Check the investigation item No.2 or subsequent items in Alarm No.21.			○	

Alarm No. 23		Excessive speed error A difference between the speed command and speed feedback was continuously exceeding 50 r/min for longer than the setting time.			
	Investigation details	Investigation results	Remedies	SV	SP
1	Check the U, V and W wiring connected to the spindle drive unit.	The wires are not correctly connected.	Correctly connect.		○
		The wires are correctly connected.	Check the investigation item No. 2.		
2	Check the spindle parameter SP020, SP026, SP027, from SP057 to SP064 and spindle specification parameters from slimit1 to slimit4 setting value.	The correct values are not set.	Correctly set.		○
		The correct values are set.	Check the investigation item No. 3.		
3	Measure the acceleration/ deceleration time from 0 to the point where the spindle speed reaches its maximum. If the alarm occurs when forward run is changed to reverse run, measure the acceleration/ deceleration time from the forward to reverse. Also measure it from the reverse to forward.	12sec or more. (SP117 setting value or more.)	Increase the spindle acceleration/ deceleration time constant setting value(sp_t1 to sp_t4). Reduce the load inertia.		○
		Less than 12sec.	Check the investigation item No. 4.		
4	Check the load amount when the alarm occurred during cutting.	The speed deterioration due to load amount has exceeded the tolerable range which is determined by the parameter SP096. -If SP096 is set to 0, it is regarded as 85%. Thus a speed of 85% of the machining speed or faster will be the tolerable speed.	Reduce the cutting load to mitigate the speed deterioration. Replace the tool.		○
		The load amount is within the SP096 setting value.	Check the investigation item No. 5.		
5	Check the fluctuation of the input voltage into the power supply unit with a tester.	Voltage drop during acceleration is 200V or less	Review the power supply capacity.		○
		Voltage drop during acceleration is 200V or more	Check the investigation item No.6.		
6	Check the capacity of the drive unit.	The capacity does not satisfy the motor output.	Change the capacity to the selected one.		○
		The capacity satisfies the motor output.	Replace the unit.		

## Appendix 2 Explanation of Alarms

Alarm No. 24		Grounding			
		The motor power cable is in contact with FG (Frame Ground).			
	Investigation details	Investigation results	Remedies	SV	SP
1	Measure the insulation across the power cables (U,V,W) for connected motors and the ground. (Carry out a megger test.) (Note) When the insulation is measured, disconnect wires from the drive unit.	Less than 1MΩ.	The motor or power cable may be ground faulted.	○	○
		1MΩ or more.	Check the investigation item No. 2.		
2	Has oil come in contact with the motor or power cable?	Oil has come in contact.	Take measures so that oil does not come in contact. Check the motor's cannon connector and the inside of the terminal box, and clean as necessary.	○	○
		Oil has not come in contact.	Check the investigation item No. 3.		
3	Measure the insulation again.	Less than 1MΩ.	Replace the motor or cable.	○	○
		1MΩ or more.	Check the investigation item No. 4.		
4	Measure the resistance across the U, V, W phase terminals of the servo/ spindle drive unit and the ground with a tester. (Note) Do not measure the insulation as the unit is damaged.	Less than 100kΩ.	Replace the drive unit.	○	○
		100kΩ or more.	Replace the power supply unit.		

Alarm No. 25		Absolute position data lost			
		The absolute position was lost, as the backup battery voltage dropped in the absolute position detector.			
	Investigation details	Investigation results	Remedies	SV	SP
1	Is warning 9F occurring at the same time?	The warning is occurring.	Check the investigation item No. 2.	○	
		The warning is not occurring.	Check the investigation item No. 3.		
2	Measure the battery voltage with a tester at the DC range.	Less than 3V.	Replace the battery, and establish the zero point.	○	
		3V or more.	Check the NC bus cable connection.		
3	Did alarm No.18 occur when the power was turned ON the last time?	Alarm No.18 occurred.	Turn the drive unit control power ON again, and establish the zero point.	○	
		Alarm No.18 did not occur.	Check the investigation item No. 4.		
4	Was the detector cable or battery cable left disconnected from the unit for a long time?	The unit was left disconnected for a long time. Guide at delivery: 20 hours or more After 5 years: 10 hours or more	Turn the drive unit control power ON again, and establish the zero point.	○	
		The cables were not left disconnected.	Check the investigation item No. 5.		
5	Check the detector cable or battery cable connection with a tester.	The connection is faulty.	Replace the cable.	○	
		The connection is normal.	Replace the drive unit.		

Alarm No. 26		Unused axis error			
		A power module error occurred in the axis whose axis No. selection switch was set to "F" (free axis).			
	Investigation details	Investigation results	Remedies	SV	SP
1	Check the repeatability.	The error is always repeated.	Replace the drive unit.	○	○
		The state returns to normal once, but occurs sometimes thereafter.	Check the investigation item No. 2.		
2	Check if there is any abnormality in the unit's ambient environment. (Ex. Ambient temperature, noise, grounding)	Take remedies according to the causes of the abnormality in the ambient environment.		○	○

Alarm No. 27		Sub side detector: Error 5			
		The machine side detector (CN3 side) detected an error. As details differ for each detector, refer to "Detector alarm" in 6-2-1.			
Investigation details		Investigation results	Remedies	SV	SP
1	Check the alarm No. "1B" items.			○	

Alarm No. 28		Sub side detector: Error 6			
		The machine side detector (CN3 side) detected an error. As details differ for each detector, refer to "Detector alarm" in 6-2-1.			
Investigation details		Investigation results	Remedies	SV	SP
1	Check the alarm No. "1B" items.			○	

Alarm No. 29		Sub side detector: Error 7			
		The machine side detector (CN3 side) detected an error. As details differ for each detector, refer to "Detector alarm" in 6-2-1.			
Investigation details		Investigation results	Remedies	SV	SP
1	Check the alarm No. "1B" items.			○	

Alarm No. 2A		Sub side detector: Error 8			
		The machine side detector (CN3 side) detected an error. As details differ for each detector, refer to "Detector alarm" in 6-2-1.			
Investigation details		Investigation results	Remedies	SV	SP
1	Check the alarm No. "1B" items.			○	

Alarm No. 2B		Main side detector: Error 1			
		The motor side detector (CN2 side) detected an error. (Note) It includes the linear scale in the case of linear motor. As details differ for each detector, refer to "Detector alarm" in 6-2-1.			
Investigation details		Investigation results	Remedies	SV	SP
1	Check the alarm No. "1B" items.			○	○

Alarm No. 2C		Main side detector: Error 2			
		The motor side detector (CN2 side) detected an error. (Note) It includes the linear scale in the case of linear motor. As details differ for each detector, refer to "Detector alarm" in 6-2-1.			
Investigation details		Investigation results	Remedies	SV	SP
1	Check the alarm No. "1B" items.			○	○

Alarm No. 2D		Main side detector: Error 3			
		The motor side detector (CN2 side) detected an error. (Note) It includes the linear scale in the case of linear motor. As details differ for each detector, refer to "Detector alarm" in 6-2-1.			
Investigation details		Investigation results	Remedies	SV	SP
1	Check the alarm No. "1B" items.			○	○

Alarm No. 2E		Main side detector: Error 4			
		The motor side detector (CN2 side) detected an error. (Note) It includes the linear scale in the case of linear motor. As details differ for each detector, refer to "Detector alarm" in 6-2-1.			
Investigation details		Investigation results	Remedies	SV	SP
1	Check the alarm No. "1B" items.			○	○

# Appendix 2 Explanation of Alarms

Alarm No. 2F	Main side detector: Communication error				
	An error was detected in communication data with the motor side detector or with the linear scale of a linear servo system. Or the communication was interrupted.				
	Investigation details	Investigation results	Remedies	SV	SP
1	Jiggle the detector connectors (drive unit side and detector side) and check if they are disconnected.	The connector is disconnected (or loose).	Correctly install.	○	○
		The connector is not disconnected.	Check the investigation item No. 2.		
2	Is the detector cable wired in the same conduit as the motor's power cable, or are the two cables laid in parallel near each other?	The cables are wired near each other. (Noise is entering from the power cable.)	Improve the cable wiring.	○	○
		The wires are sufficiently separated.	Check the investigation item No. 3.		
3	Is the motor FG wire connected only to the drive unit which drives it? (Is the motor grounded to one point?)	The motor FG wire is grounded on the motor side.	Ground the motor to one point, connecting the wires together on the drive unit side.	○	○
		The motor is grounded to one point.	Check the investigation item No. 4.		
4	Turn the power OFF, and check the detector cable connection with a tester. (Is the cable shielded?)	The connection is faulty.	Replace the detector cable.	○	○
		The connection is normal.	Check the investigation item No. 5.		
5	Replace with another unit, and check whether the fault is on the unit side or detector side.	The alarm is on the drive unit side.	Replace the drive unit.	○	○
		The alarm is on the detector side.	Check the investigation item No. 6.		
6	Check if there is any abnormality in the detector's ambient environment. (Ex. Ambient temperature, noise, grounding)	Take remedies according to the causes of the abnormality in the ambient environment.		○	○

Alarm No. 30	Over regeneration:				
	Over-regeneration detection level became over 100%. The regenerative resistor is overloaded.				
	Investigation details	Investigation results	Remedies	SV	SP
1	Check if the regenerative capacity exceeds the regenerative resistor tolerable capacity.	The regenerative capacity exceeds the regenerative resistor tolerable capacity.	Add the option regenerative resistor or replace it.	○	○
		The regenerative resistor selection is appropriate.	Check the investigation item No. 2.		
2	Check if the parameter is set incorrectly, and check the values of sv036 and sp032.	The parameters are set incorrectly.	Change the parameters.	○	○
		The parameters are correct.	Check the investigation item No. 3.		
3	Is an external regenerative resistor used?	An external regenerative resistor is used.	Check the investigation item No. 5.	○	
		A built-in regenerative resistor is used.	Check the investigation item No. 4.		
4	Is the short wire connected between P and D terminal? Are there any problems with the connection condition?	The wire is not connected.	Connect the wire.	○	
		The connector is disconnected. The connector has a contact fault.	Reconnect the connector. Replace the connector.		
5	Is the connection of the regenerative resistor or regeneration resistor cable correct?	The connection is incorrect.	Rewire.	○	○
		The connection is correct.	Check the investigation item No. 6.		
6	Is the regeneration resistor or the regeneration resistor cable broken? Disconnect the regenerative resistor terminal and check the resistance value with a tester.	The regeneration resistor is broken. Or the resistance value is large.	Replace the regenerative resistor.	○	○
		The regeneration resistor cable is broken.	Replace the cable.		
		The resistance value is normal.	Check the investigation item No. 7.		
7	Check if the power supply voltage is too high.	The power supply voltage exceeded 253V.	Review the power supply.	○	○
		The power supply voltage is normal.	Replace the drive unit.		

Alarm No. 31	Overspeed				
	The motor was detected to rotate at a speed exceeding the allowable speed (In the case of linear motor, it was detected to move at a speed exceeding the allowable speed).				
	Investigation details	Investigation results	Remedies	SV	SP
1	Check if the unit in which the alarm was detected is servo or spindle.	The alarm was detected in servo.	Check the investigation item No. 2.	○	○
		The alarm was detected in spindle.	Check the investigation item No. 3.		
2	Check the servo parameters SV001 (PC1), SV002 (PC2), SV018 (PIT) and SV025 (MTYP) settings.	The settings are incorrect.	Correctly set.	○	
		Correctly set.	Check the investigation item No. 5.		
3	Check the spindle parameter SP026 (TSP) setting.	The setting is incorrect. The alarm is detected at 115% of SP026.	Correctly set.		○
		Correctly set.	Check the investigation item No. 4.		
4	Check the PLG output waveform.	There is a problem.	Adjust the PLG output waveform.	○	○
		Normal.	Check the investigation item No. 5.		
5	Check whether the speed waveform is overshooting.	The waveform is overshooting.	Increase the acceleration/ deceleration time constant. Lower the load inertia.	○	○
		The waveform is not overshooting.	Check if there is any abnormality in the unit's ambient environment. (Ex.: Ambient temperature, noise, grounding)		
			Check the investigation item No. 6.		
6	Check the repeatability.	[1] The alarm occurs when the motor is stopped. [2] The rotation speed displayed on the drive monitor varies when the motor is stopped.	Replace the detector or detector cable.	○	○
		The alarm occurs at all time.	Replace the drive unit.		

## Appendix 2 Explanation of Alarms

Alarm No. 32		Power module overcurrent			
		Overcurrent protection function in the power module has started its operation.			
	Investigation details	Investigation results	Remedies	SV	SP
1	Disconnect the power cable (U, V, W) from the unit's terminal block and motor, and check whether a short-circuit between the power cable or whether conduction at both end of wiring occurs with a tester.	[1] Before disconnecting the power cable, the cable connector or screw has been loosened. [2] The short-circuit condition persists even after disconnecting the cable from the unit and motor.	[1] Tighten it. [2] Check the motor wiring. [3] Replace the power cable.	○	○
		There is no problem.	Check the investigation item No. 2.		
	Check the motor insulation with a (megger) tester. -Between motor power and ground earth	Less than 1MΩ. (Grounding)	Replace the motor.	○	○
		1MΩ or more. (Normal)	Check the investigation item No. 3.		
2	Check the unit capacity. [1] The same size but smaller than the selected capacity. [2] The combination of the motor and axis is alternated in a 2-axis unit.	The capacity is small. The smaller capacity side was used in 2-axis unit.	Replace to the unit of the selected capacity or change the axis.	○	○
		The motor meets the selected capacity.	Check the investigation item No. 3.		
3	Check the current loop gain parameters.	Different from the standard parameter settings.	Adjust the value to the standard setting.	○	○
		Equivalent to the standard parameter settings.	Check the investigation item No. 4.		
4	Jiggle the detector connectors (drive unit side and detector side) and check if they are disconnected.	The connector is disconnected (or loose).	Correctly install.	○	○
		The connector is not disconnected.	Check the investigation item No. 5.		
5	Turn the power OFF, and check the detector cable connection with a tester.	Connection is faulty.	Replace the detector cable.	○	○
		Connection is normal.	Check the investigation item No. 6.		
6	Check the repeatability.	The state returns to normal once, but occurs sometimes thereafter.	Check the investigation item No. 8.	○	○
		The error is always repeated.	Check the investigation item No. 7.		
7	Replace with another unit, and check whether the fault is on the drive unit side or detector side.	The alarm is on the drive unit side.	Replace the drive unit.	○	○
		The alarm is on the detector side.	Replace the detector.		
8	Check for any abnormalities in the unit's ambient environment. (Ex.: Ambient temperature, noise, grounding)	Take remedies according to the causes of the abnormality in the ambient environment.		○	○

Alarm No. 33		Overvoltage: The main circuit bus voltage exceeded the tolerable value.			
	Investigation details	Investigation results	Remedies	SV	SP
1	Is an external regenerative resistor used?	An external regenerative resistor is used.	Check the investigation item No. 3.	○	
		A built-in regenerative resistor is used.	Check the investigation item No. 2.		
2	Is the short wire connected between P and D terminal? Are there any problems with the connection condition?	The wire is not connected.	Connect the wire.	○	
		The connector is disconnected. The connector has a contact fault.	Reconnect the connector. Replace the connector.		
		The connection is correct.	Check the investigation item No.6.		
3	Is the combination of the used regenerative resistor and drive unit appropriate?	The combination is incorrect.	Replace the correct regenerative resistor.	○	○
		The combination is normal.	Check the investigation item No. 4.		
4	Is the connection of the regenerative resistor or regeneration resistor cable correct?	The connection is incorrect.	Rewire.	○	○
		The connection is correct.	Check the investigation item No. 5.		
5	Is the regeneration resistor or the regeneration resistor cable broken? Disconnect the regenerative resistor terminal and check the resistance value with a tester.	The regeneration resistor is broken. Or the resistance value is large.	Replace the regenerative resistor.	○	○
		The regeneration resistor cable is broken.	Replace the cable.		
		The resistance value is normal.	Check the investigation item No. 6.		
6	The acceleration/deceleration time constant is too short. At acceleration/deceleration, has the speed overshoot reached to the current limit?	Reached to the current limit. The speed overshoot is applied.	Increase the acceleration/deceleration time constant.	○	○
		The connection is normal.	Replace the drive unit.		

Alarm No. 34		NC-DRV communication: CRC error An error was detected in the data received from the CNC.			
	Investigation details	Investigation results	Remedies	SV	SP
1	Gently shake the connectors of the optical cables by hand that link between NC and drive unit or between drive units to check for loosening and disconnection. Also check if an excessive force is not applied on them.	The connector is loose or nearly disconnected. The tab of the connector is damaged.	Correctly install. Replace the cable.	○	○
		The connector is not disconnected.	Check the investigation item No. 2.		
2	Check for damages at the ends of the optical communication cable. Replace the cable.	The damage is found at the end of the cable.	Replace the communication cable.	○	○
		The connection is normal.	Check the investigation item No. 3.		
3	Check whether the NC or drive unit software version was changed recently.	The version was changed.	Change software version back to the original.	○	○
		The version was not changed.	Check the investigation item No. 4.		
4	Replace with another drive unit, and check whether the fault is on the NC side or drive unit side.	The alarm is on the drive unit side.	Replace the drive unit.	○	○
		The alarm is on the unit connections.	Check the investigation item No. 5.		
5	Check if there is any abnormality in the unit's ambient environment. (Ex. Ambient temperature, noise, grounding)	Take remedies according to the causes of the abnormality in the ambient environment.		○	○



# Appendix 2 Explanation of Alarms

Alarm No.		NC command error			
35		The travel command data that was received from the CNC was excessive.			
	Investigation details	Investigation results	Remedies	SV	SP
1	Check the alarm No. "34" items.			○	○

Alarm No.		NC-DRV communication: Communication error			
36		The communication with the CNC was interrupted.			
	Investigation details	Investigation results	Remedies	SV	SP
1	Check the alarm No. "34" items.			○	○

Alarm No.		Initial parameter error			
37		An incorrect parameter was detected among the parameters received from the CNC at the power ON.			
	Investigation details	Investigation results	Remedies	SV	SP
1	Check if the unit in which the alarm was detected is servo axis or spindle.	The alarm was detected in servo axis.	Check the investigation item No. 2.	○	○
		The alarm was detected in spindle.	Check the investigation item No. 3.		
2	Check the error parameters displayed on the NC diagnosis screen. Servo parameters: SV001 to SV065, SV082	Wrong parameters were set.	Correct the parameter setting. Set the value within the designated setting range.	○	
		The electronic gears are overflowing.	Set SV001, SV002 and SV018 so that they meet the machine specifications.		
		The absolute position detection parameter is valid when OSE104 and OSE105 are connected. (Absolute position control cannot be used.)	In order to use the absolute position control function, an absolute position option is required.		
		SV082/bitC to F are the same setting in one unit.	Correct the setting of SV082/bit0 to B.		
		SV082/bitC to F are not the same setting in one unit.	Correct to the same setting.		
		Correct parameters were set.	Check the investigation item No. 4.		
3	Check the error parameters displayed on the NC diagnosis screen. Spindle parameters: SP001 to SP240	The setting is wrong.	Correct the parameter setting. Set the value within the designated setting range.		
		The set parameters are correct.	Check the investigation item No. 4.		
		The set parameter value is different from that of the machine specified detector.	Change the setting to meet the machine specifications.		○
4	Check the alarm No. "34" items.			○	○

Alarm No.		NC-DRV communication: Protocol error 1			
38		An error was detected in the communication frames received from the CNC.			
	Investigation details	Investigation results	Remedies	SV	SP
1	Check the alarm No. "34" items.			○	○

Alarm No.		NC-DRV communication: Protocol error 2			
39		An error was detected in the axis information data received from the CNC.			
	Investigation details	Investigation results	Remedies	SV	SP
1	Check the alarm No. "34" items.			○	○

Alarm No. 3A		Overcurrent			
		Excessive current was detected in the motor drive current.			
	Investigation details	Investigation results	Remedies	SV	SP
1	[1] Check whether vibration is occurring at the table or spindle. [2] Check if the vibration caused by the load fluctuation is occurring.	Vibration is occurring.	[1] Set a filter. [2] Lower the speed loop gain (SV005/SP005).	○	○
		There is no vibration.	Check the investigation item No. 2.		
2	Check the repeatability of the alarm at the rapid traverse feed for the servo and at acceleration/deceleration for the spindle. (Note) Check the phenomenon caused by the load fluctuation.	The alarm occurs.	Lower the speed loop gain (SV005/SP005) to the level at which the alarm does not occur.	○	○
		The alarm does not occur.	Check the investigation item No. 3.		
3	For the servo, perform the rapid traverse feed repeatedly and check if the max. current value is within the tolerable value. For the spindle, check the load meter value at the unloaded max. rotation speed.	The displayed value is high.	Increase the current loop gain. Servo: SV009 to 012 Spindle: SP077 to 080 and SP081 to 084	○	○
		The displayed value is appropriate.	Check the investigation item No. 4.		
4	Disconnect the power cable (U,V,W) from the terminal block and the cannon plug from the motor. Check the insulation of the cable and motor with a tester.	The resistance value of the power cable for each phase is not "∞".	Replace the motor power cable.	○	○
		The resistance value of the motor terminal and unit (shaft) is 1MΩ or less.	Replace the motor.(Note) For the motors equipped with the absolute position detector, the zero point must be established.		
		The values below are met when measured with a tester. Cable : ∞ Motor terminal - unit:1MΩ or more	Check the investigation item No. 5.		
5	Check the insulation between the motor power cable and FG.	There is a ground fault at the power cable.	Replace the motor power cable.	○	○
		There is no problem.	Check the investigation item No. 6.		
6	Check if there is any abnormality in the motor's ambient environment. (Ex. Ambient temperature, cutting water)	Take remedies according to the causes of the abnormality in the ambient environment.		○	○

Alarm No. 3B		Power module overheat			
		Thermal protection function in the power module has started its operation.			
	Investigation details	Investigation results	Remedies	SV	SP
1	Check that the fan of the drive unit is rotating correctly.	Large amounts of cutting oil or cutting chips, etc., are adhered to the fan, or the rotation is slow.	Clean or replace the fan.	○	○
		The fan is rotating properly.	Check the investigation item No. 2.		
2	Check whether the heat dissipating fins are dirty.	Cutting oil or cutting chips, etc., are adhered, and the fins are clogged.	Clean the fins.	○	○
		Cutting chips etc. are not adhered to the fins.	Check the investigation item No. 3.		
3	Measure the drive unit's ambient temperature.	55° C or more.	Improve the efficiency cooling for the power distribution panel.	○	○
		Less than 55° C.	Check the investigation item No. 4.		
4	Check if there is any abnormality in the unit's ambient environment. (Ex. Ambient temperature, noise, grounding)	Take remedies according to the causes of the abnormality in the ambient environment.		○	○

## Appendix 2 Explanation of Alarms

Alarm No. 3C		Regeneration circuit error: An error was detected in the regenerative transistor or in the regenerative resistor.			
	Investigation details	Investigation results	Remedies	SV	SP
1	Check if an external regenerative resistor is used.	An external regenerative resistor is used.	Check the investigation item No. 3.	○	
		A built-in regenerative resistor is used.	Check the investigation item No. 2.		
2	Is the short wire connected between P and D terminal? Are there any problems with the connection condition? (looseness of the screw)	The wire is not connected.	Connect the wire.	○	
		The connector is disconnected. The connector has a contact fault.	Reconnect the connector. Replace the connector.		
		The connection is correct.	Replace the drive unit.		
3	Is the connection of the regenerative resistor or regeneration resistor cable correct?	The wire is not connected.	Connect the wire.	○	○
		The connection is correct.	Check the investigation item No. 4.		
4	Is the regeneration resistor or the regeneration resistor cable broken? Disconnect the regenerative resistor terminal and check the resistance value with a tester.	The regeneration resistor is broken. Or the resistance value is different from the specified value.	Replace the regenerative resistor.	○	○
		The regeneration resistor cable is broken.	Replace the cable.		
		The resistance value is normal.	Replace the drive unit.		

Alarm No. 3D		Power supply voltage error at acceleration/deceleration: A motor control error was detected at acceleration/deceleration due to an input voltage drop.			
	Investigation details	Investigation results	Remedies	SV	SP
1	Measure the input voltage during operations with a tester.	During operations, the voltage fluctuates widely.	Increase the power capacity (KVA).	○	-
		During operations, the voltage is stable.	Check the investigation item No. 2.		
2	Check the load inertia.	The load inertia (workpiece etc.) is excessive.	[1] Lower the load inertia. [2] Extend the rapid traverse time constant for G0/G1.	○	-
		The load inertia is normal.	Replace the drive unit.		

Alarm No. 3E		Magnetic pole position detection error: The magnetic pole position is not reliable in the magnetic pole position detection control. This alarm occurs at the detection level which is set in SV094.			
	Investigation details	Investigation results	Remedies	SV	SP
1	Adjust the setting value of the servo parameter SV094 and detect the magnetic pole position.	Set SV094.	Set SV094. The standard value for a rotary motor is 100. The standard value for a linear motor is 10.	○	-
		SV094 is set.	Set the optimal value allowing for the coasting distance (Increase the value).		

Alarm No. 41		Feedback error 3 Either a missed feedback pulse in the main side incremental detector or an error in the Z-phase was detected in the full closed loop system. In the servo, Z-phase was not detected by a rotary detector within 2 rotations.			
	Investigation details	Investigation results	Remedies	SV	SP
1	Check the connection condition of the cable and detector. - Check if the cable is disconnected.	The cable is disconnected.	Replace the cable.	○	○
		The cable is normal.	Check for dirt on the connector terminal and reconnect it.		
		The alarm occurs even after it is reconnected.	Replace the detector.		

Alarm No. 42		Feedback error 1			
		An error was detected in the sub side detector ( feedback signals of the position detector in a servo system, or PLG's feedback signals in a spindle system).			
	Investigation details	Investigation results	Remedies	SV	SP
1	Check SP019 and SP020.	Parameter is set incorrectly.	Correctly set.		○
		Parameter is set correctly.	Check the investigation item No. 2.		
2	Check the alarm No. "2C" items.				○

Alarm No. 43		Feedback error 2			
		Excessive difference was detected in position data between the motor side detector and the machine side detector.			
	Investigation details	Investigation results	Remedies	SV	SP
1	Check if the connecting pulley ratio of the spindle end to ABZ pulse encoder meets the machine specifications.	The pulley ratio of the spindle end to encoder is 1:1.	Check the parameter setting.		○
		The spindle end and encoder are not equal in the pulley ratio.	Check the parameter setting.		
			When the encoder is smaller than the spindle end in the pulley ratio, replace the pulley.		
		No problem.	Check the investigation item No. 2.		
2	Check the setting value of the spindle parameter from SP057 to SP064.	The correct values are not set.	Correctly set.		○
		The correct values are set.	Check the investigation item No. 3.		
3	Check the spindle parameter SP054 setting value.	V-belt is used for the spindle end driving.	Set "-1" to the spindle parameter "SP054".		○
		Other than V-belt(gears or timing belt) is used for the spindle end driving.	Set "360" to the spindle parameter "SP054".		
		SP054 is set corresponding to the machine specifications.	Check the investigation item No. 4.		
4	Jiggle the detector connectors (drive unit side and detector side) and check if they are disconnected.	The connector is disconnected (or loose).	Correctly install.	○	○
		The connector is not disconnected.	Check the investigation item No. 5.		
5	Is the detector cable wired in the same conduit as the motor's power cable, or are the two cables laid in parallel near each other?	The cables are wired near each other. Noise is entering from the power cable.	Improve the cable wiring. Divide it by a FG shield.	○	○
		The wires are sufficiently separated.	Check the investigation item No. 6.		
6	Is the motor FG wire connected only to the drive unit which drives it? (Is the motor grounded to one point?)	The motor FG wire is grounded on the motor side.	Ground the motor to one point, connecting the wires together on the drive unit side.	○	○
		The motor is grounded to one point.	Check the investigation item No. 7.		
7	Turn the power OFF, and check the detector cable connection with a tester. (Is the cable shielded?)	The connection is faulty.	Replace the detector cable.	○	○
		The connection is normal.	Check the investigation item No. 8.		
8	Replace with another unit, and check whether the fault is on the unit side or detector side.	The alarm is on the drive unit side.	Replace the drive unit.	○	○
		The alarm is on the detector side.	Check the investigation item No. 9.		
9	Check if there is any abnormality in the detector's ambient environment. (Ex. Ambient temperature, noise, grounding)	Take remedies according to the causes of the abnormality in the ambient environment.		○	○
10	Check SP019, SP020, SV019, and SV020.	Parameter is set incorrectly.	Correctly set.	○	○
		Parameter is set correctly.	Check the investigation item No. 11.		
11	Check the alarm No. "1B" items.			○	

# Appendix 2 Explanation of Alarms

Alarm No.		Fan stop			
45		A cooling fan built in the drive unit stopped, and overheat occurred in the power module.			
	Investigation details	Investigation results	Remedies	SV	SP
1	Turn the unit power ON again, and confirm the rotation of the fan. Note) Assure more than 10 seconds for the time from when the power is turned OFF till when it is turned ON. For the fan used for the drive unit, assuring more than 10 seconds for the time from when the power is turned OFF till when it is turned ON is required.	The fan is rotating, and an alarm did not occur again.	Continue to use. The power may be turned ON without assuring more than 10 seconds for the time from when the power is turned OFF till when it is turned ON. Leave for more than 10 seconds, and turn the power ON again.	○	○
		The fan did not rotate. Or, an alarm occurred again.	Check the investigation item No. 2.		
2	Check if the connector connected to a fan is loosened or disconnected in the unit.	[1]The connector is loosened. [2]The connector is disconnected.	Correctly connect the connector. Replace the fan.	○	○
		[1]The connector is not loosened. [2]The connector is not disconnected.	Check the investigation item No. 3.		
3	Check if oil or cutting chips are adhered to the fan.	Oil or cutting chips are adhered.	Improve the use environment and replace the drive unit.	○	○
		Oil or cutting chips are not adhered. The cable may be broken.	Replace the fan. Replace the drive unit.		

Alarm No. 46		Motor overheat / Thermal error			
		Thermal protection function of the motor or in the detector, has started its operation.			
	Investigation details	Investigation results	Remedies	SV	SP
1	Check the repeatability. (Note) For the spindle, check the "temperature" of the "spindle unit" displayed on the drive monitor screen.	[1] The alarm occurs before operation. [2] The "temperature" displayed on the drive monitor screen is different from ambient temperature.	Check the investigation item No. 2.	○	○
		[1] The alarm occurs after the operation continues for a while. [2] The "temperature" displayed on the drive monitor screen rises drastically during the spindle operation.	Check the investigation item No. 5.		
2	Jiggle the detector connectors (drive unit side and detector side) and check if they are disconnected.	The connector is disconnected (or loose).	Correctly install.	○	○
		The connector is not disconnected.	Check the investigation item No. 3.		
3	Turn the power OFF, and check the detector cable connection with a tester.	The connection is faulty.	Replace the cable.	○	○
		The connection is normal.	Check the investigation item No. 4.		
4	When using MDS-B-HR, check if the motor is validated even if a motor thermal is not provided?	SV034/bit2 = 0	Set SP034/bit2 to 1.	○	
		SV034/bit2 = 1	Check the investigation item No. 5.		
5	Check the overload % (servo) or load meter (spindle).	The load is large.	Servo: Check the investigation item No. 6. Spindle: Check the investigation item No. 8.	○	○
		The load is not large.	Check the investigation item No. 9.		
6	Is the unbalance torque high?	The constant load torque (friction + unbalance) is 60% or more.	Select the motor so that the constant load torque is 60% or less.	○	
		The constant load torque is less than 60%.	Check the investigation item No. 7.		
7	Was the overload alarm (50) forcibly reset by turning the drive unit power OFF?	The alarm was forcibly reset.	Do not turn the drive unit's power OFF when an overload alarm occurs. (The NC power can be turned OFF.)	○	○
		The alarm was not forcibly reset.	Check the investigation item No. 9.		
8	Check the parameter settings.	The parameter is not set correctly.	Correctly set.		○
		The parameter is set correctly.	Check the investigation item No. 9.		
9	Measure the motor temperature when the alarm occurs. (Note) For the spindle motor, check the "temperature" of the "spindle unit" shown on the drive monitor screen.	The motor unit is hot.	Check the investigation item No. 10.	○	○
		The motor is not hot.	Check the investigation item No. 12.		
10	When using a motor with fan, check whether the fan is stopped, or it is clogged with dust, etc.	The motor fan was stopped.	Check the investigation item No. 11.	○	○
		The motor fan wind flow is poor.	Clean the fan and ventilation holes inside of the motor.		
		The direction of the ventilation is opposite.	Change the connected phase sequence.		
11	Check the fan wiring.	There is no problem.	Check the investigation item No. 12.	○	○
		The cable is broken.	Replace the cable.		
		The cable is not broken.	Replace the fan.		
12	Replace the drive unit or motor with another drive unit or motor, and check whether the fault is on the drive unit side or motor side	The alarm is on the drive unit side.	Replace the drive unit.	○	○
		The alarm is on the motor side.	Replace the motor.		
13	Check if there is any abnormality in the unit's ambient environment. (Ex. Ambient temperature, noise, grounding)	Take remedies according to the causes of the abnormality in the ambient environment.		○	○

## Appendix 2 Explanation of Alarms

Alarm No. 48		Motor side detector: Error 5			
		The motor side detector (linear scale in the case of linear motor) detected an error. As details differ for each detector, refer to "Detector alarm" in 6-2-1.			
Investigation details		Investigation results	Remedies	SV	SP
1	Check the alarm No. "1B" items.			○	○

Alarm No. 49		Motor side detector: Error 6			
		The motor side detector (linear scale in the case of linear motor) detected an error. As details differ for each detector, refer to "Detector alarm" in 6-2-1.			
Investigation details		Investigation results	Remedies	SV	SP
1	Check the alarm No. "1B" items.			○	

Alarm No. 4A		Motor side detector: Error 7			
		The motor side detector (linear scale in the case of linear motor) detected an error. As details differ for each detector, refer to "Detector alarm" in 6-2-1.			
Investigation details		Investigation results	Remedies	SV	SP
1	Check the alarm No. "1B" items.			○	○

Alarm No. 4B		Motor side detector: Error 8			
		The motor side detector (linear scale in the case of linear motor) detected an error. As details differ for each detector, refer to "Detector alarm" in 6-2-1.			
Investigation details		Investigation results	Remedies	SV	SP
1	Check the alarm No. "1B" items.			○	○

Alarm No. 4C		Current error at magnetic pole estimate			
		Current detection failed at the pulse-applied magnetic pole estimation by IPM spindle motor.			
Investigation details		Investigation results	Remedies	SV	SP
1	Check the pulse-applied time.	The pulse-applied time can be short.	Set the pulse-applied time longer. Setting parameter:SP142 1) The pulse-applied time (0 to 350) 2) For low-speed coil:1)+1000 3) The polarity of magnetic pole estimate: Reverse polarity is "-" After the adjustment, perform the magnetic pole detection control again.	-	○
		The alarm also occurs after the pulse-applied time is set.	Replace the unit.		

Alarm No. 4E		NC command mode error			
		The mode outside the specification was input in spindle control mode selection.			
Investigation details		Investigation results	Remedies	SV	SP
1	Check the wiring and setting environment. 1) Correctly grounded? 2) Any noise generating devices around the unit? 3) Are the speed/position detector cables correctly shielded?	1) The grounding is incomplete.	Correctly ground.		○
		2) The alarm occurs easily when a specific device operates.	Use noise measures on the device described on the left.		
		3) The cable is not correctly shielded.	Correctly shield the cable.		
		No abnormality is found in particular.	Replace the drive unit.		

Alarm No. 4F		Instantaneous power interrupt			
		The control power supply has been shut down for 50ms or more.			
Investigation details		Investigation results	Remedies	SV	SP
1	Check the repeatability.	The alarm occurs occasionally.	Check the power facilities.	-	○
			Check the wiring of the control power.		

Alarm No. 50		Overload 1			
		Overload detection level became over 100%. The motor or the drive unit is overloaded.			
	Investigation details	Investigation results	Remedies	SV	SP
1	Check the overload parameters. Servo : SV021, SV022 Spindle : SP021,SP022	The standard values (below) are not set. Servo : SV021 = 60, SV022 = 150 Spindle : SP021=60,SP022=120 IPM : SP021=300,SP022=100	Set the standard values.	○	○
		The standard values are set.	Investigate item 2.		
2	Check the items below displayed on the drive monitor screen during operation. <Servo> Max.current 3 (%) Overload(%) <Spindle> Load meter(%)	Perform the machining such as rapid traverse, where an alarm occurs. The examples are below. <Servo> [1] Max.current 3 constantly displays the maximum value. [2] Overload increases at a rapid speed. <Spindle> [1] The time to display 120% lasts long. [2] The value is higher than normal.	Servo [1] Mount a smaller workpiece. [2] Increase the time constant. [3] Check the investigation item No.6.		
		The value is within the supposed level and there is no problem.	Spindle [1] Lower the cutting amount. [2] Extend the cycle time.	○	○
			Investigate item 3.		
3	Check whether machine resonance is occurring. Check for vibration and abnormal noise at the spindle and table.	Resonance is occurring when a tool or workpiece is mounted or during machining. (The load inertia changes)	Adjust the parameters. [1] Set the optimal notch filter. [2] Lower VGN1 (SV005,SP005).	○	
		Resonance is not occurring.	Investigate item 4.		
4	Check whether the shaft sways when the motor is stopped. "Hunting" of the spindle "Vibration" of the table	The motor is hunting.	Adjust the parameters. [1] Increase VGN1 (SV005, SP005). [2] Lower VIA (SV008, SP008).	○	
		The motor is not hunting.	Servo: Investigate item 5 Spindle: Investigate item 7		
5	Check the brake operation. [1] Check the brake relay. [2] Check the connector (CN20) connection.	The motor brakes are not released.	Correct the faulty section.	○	
		The motor brake operation is normal.	Investigate item 6.		
6	Check the load current with the NC Servo Monitor, and investigate the machine load.	The cutting load is large.	Lower the cutting load.	○	
		There is interference with the positioning pin.	When using the positioning pin, turn the servo OFF when stopped.		
		An excessive force is applied from the machine.	Check whether the ball screw is bent, or whether there is a fault in the guide.		
		The machine load is not large.	Investigate item 8.		
7	Check the PLG output waveform. TS5690 cannot be checked.	There is a problem.	Adjust the PLG output waveform. For TS5690, reinstall.		○
		Normal	Investigate item 8.		
8	Confirm the motor capacity selection again.	The motor performance is insufficient.	Lower the acceleration/deceleration rate or cutting load.	○	○
		The motor performance is sufficient.	Check the tool mounted on the spindle. - The service life is reached. Increase the number of teeth (chips) of the milling cutter, etc. Investigate item 9.		
9	Try replacing the drive unit.	Improved.	Use as it is.	○	○
		Not improved.	Replace the motor.		

(Note) NR and PR resetting are not possible when the overload level is 50% or more. Do not forcibly reset (AR) by turning the unit power OFF. If AR resetting is used at 50% or higher, the level is set to 80% when the power is turned ON next. (Servo)



## Appendix 2 Explanation of Alarms

Alarm No. 51	Overload 2				
	Current command of more than 95% of the unit's max. current was being continuously given for longer than 1 second in a servo system. In a spindle system, current command of more than 95% of the motor's max. current was being continuously given for longer than 1 second.				
	Investigation details	Investigation results	Remedies	SV	SP
1	Did the alarm occur immediately after READY ON?	The alarm occurred after ready ON before operation starts.	Investigate item 2.	○	
		The alarm occurred after normal operation.	Investigate item 5.		
2	Check that the PN voltage is supplied to the drive unit. MDS-D-SVJ3 Series is not connected to the power supply unit, so investigate item 3 for MDS-D-SVJ3. [1] Is the CHARGE lamp ON?	The CHARGE lamp becomes dark. L+ or L- screw was loosened.	Increase the capacity of power supply. Tighten the L+ and L- screws.	○	
		Approx. 300V is correctly supplied.	Investigate item 3.		
3	Check the motor power cable (U, V, W phases). [1] The power cable is not connected. [2] Is the cable connected to the motor for another axis?	The connections are incorrect. Connected to the incorrect axis.	Connect correctly.	○	
		The connections are correct.	Investigate item 4.		
4	Check the detector cable connection. [1] Is the cable connected to the motor for another axis?	The connections are incorrect.	Connect correctly.	○	
		The connections are correct.	Investigate item 5.		
5	Check whether the machine has collided.	The machine has collided.	Check the machining program and soft limit settings.	○	
		The machine has not collided.	Investigate item 6.		
6	Check whether the current value on the NC Servo Monitor screen is saturated during acceleration/ deceleration.	The current is saturated during acceleration/ deceleration.	Increase the acceleration/ deceleration time constant.	○	
		The current value during acceleration/ deceleration is appropriate.	Investigate item 7.		
7	Check the detector Feedback.	The Feedback signal is abnormal. - The droop does not stabilize.	Replace the detector. (With the absolute position system, the zero point must be established.)	○	
		The Feedback signal is normal.	Replace the drive unit.		
8	Check the load meter value.	The value is large.	Lower the load.		○
		The value is normal.	Investigate item 9.		
9	Check the PLG output waveform. For TS5690, waveform cannot be checked.	There is a problem.	Adjust the PLG output waveform.		○
		Normal	Replace the drive unit.		


Alarm No. 52		Excessive error 1			
		A difference between the actual and theoretical motor positions during servo ON exceeded the setting value.			
	Investigation details	Investigation results	Remedies	SV	SP
1	The load inertia is large. The unbalance torque in the Z (gravity) direction is high. An excessive workpiece or tool is mounted on the spindle.	The load inertia is excessive.	[1] Lower the machine weight applied to the servo motors (by the unbalance torque). [2] Lower the weight of the workpiece.	○	○
		The load inertia is normal.	Investigate item 2.		
2	Check the excessive error detection width. Servo SV053 Spindle SP023 (Interpolation, spindle synchronization)SP053 (Non-interpolation)	The excessive error detection width is too small. Servo standard value: $SV053 = \{RAPID / (60 \times PGN1)\} / 2$ Spindle standard value: No alarm is set at SP023 = 120:0 SP053 = motor max. speed $\times 6 / PGV / 2$	Set appropriate values.	○	○
		Appropriate values are set.	Investigate item 3.		
3	Check the position detector polarity. SV017/bit4 (Servo) SP017/bit4 (Spindle: position FB) SP017/bit0 (Spindle: speed FB) #3106/bit7 (Synchronous tap control)	The polarity is reversed.	Correctly set the parameters.	○	○
		Normal.	Investigate item 4.		
4	Check the alarm No. "51" items.			○	○

Alarm No. 53		Excessive error 2			
		A difference between the actual and theoretical motor positions during servo OFF exceeded the setting value.			
	Investigation details	Investigation results	Remedies	SV	SP
1	Check the follow-up function while the NC is in the servo OFF state.	The axis detachment function (NC parameter) is invalid. (Note) For the axis detachment function, refer to the NC manual.	Check the investigation item No. 2.	○	
		The axis detachment function (NC parameter) is valid. (Note) For the axis detachment function, refer to the NC manual.	Check the investigation item No. 3.		
2	Check whether the axis has moved during servo OFF (either by visual inspection or monitor the position droop waveform). [1] Check if the motor brake is released in the middle. [2] Check if the axis moves because the servo OFF is applied during the C axis mode.	[1] The axis has moved. [2] The servo OFF is applied during the mode.	[1] Adjust the brakes, etc. so that the axis does not move. [2] Avoid the servo OFF from being applied during position control.	○	
		The axis has not moved.	Check the investigation item No. 3.		
3	Check the excessive error detection width. SV026 (Servo) (Note) Set the same value to SV023.	The excessive error detection width is too small. $SV026 = \{RAPID / (60 \times PGN1)\} / 2$	Set an appropriate value.	○	
		An appropriate value is set.	Check for problems on the NC side, such as the position FB follow-up control.		

Alarm No.		Excessive error 3			
54		When an excessive error 1 occurred, detection of the motor current failed.			
	Investigation details	Investigation results	Remedies	SV	SP
1	Check that the PN voltage is supplied to the drive unit.	The voltage is not supplied.	Correctly supply the PN voltage.	○	○
	[1] Is the CHARGE lamp ON?	It is correctly supplied (DC300V).	Investigate item 2.		
2	Check the motor power cable (U, V, W phases).	The connections are incorrect.	Connect correctly.	○	○
	[1] The power cable is not connected. [2] Is the cable connected to the motor for another axis?	The connections are correct.	Replace the drive unit.		

### Supplement (servo)

Depending on the ideal machine position in respect to the command position, the actual machine position could enter the actual shaded section shown below, which is separated more than the distance set in OD1.



Alarm No. 56		Commanded speed error			
		In C axis control mode, excessive NC commanded speed was detected.(In C axis control mode)			
	Investigation details	Investigation results	Remedies	SV	SP
1	Check the rotation speed displayed on the spindle drive monitor to see if the C axis rotation speed exceeds 1.15 times of the set speed during rapid traverse.	Exceed.	Increase the rapid traverse time constant.	○	○
		Not exceed.			

Alarm No. 58		Collision detection 1: G0			
		When collision detection function (set to SV060) was valid, the disturbance torque in rapid traverse (G0) exceeded the collision detection level.			
	Investigation details	Investigation results	Remedies	SV	SP
1	Check whether the machine has collided during G0 operation.	A collision has occurred at the table, turret or spindle head in the machine during movement.	Check the machining program and soft limit settings.	○	
		There is no collision at the table, turret and spindle head in the machine during movement	Adjust the tolerable disturbance torque SV060. (Note) Set the detection level to be 1.5 times or more of the maximum torque.		

Alarm No. 59		Collision detection 1: G1			
		When collision detection function was valid (SV035.c1G1 was set), the disturbance torque in cutting feed (G1) exceeded the collision detection level.			
	Investigation details	Investigation results	Remedies	SV	SP
1	Check whether the machine has collided during G0 operation.	The machine has collided during movement.	Check the machining program and soft limit settings.	○	
		The machine has not collided.	Increase the detection level (SV035.c1G1). G1 collision detection level =SV060 × c1G1(001 to 111) (Note) Set the detection level larger than the maximum cutting load.		

Alarm No. 5A		Collision detection 2			
		When collision detection function was valid, the command torque reached the max. motor torque.			
	Investigation details	Investigation results	Remedies	SV	SP
1	Check whether the machine has collided.	The machine has collided.	Check the machining program and soft limit settings.	○	
		The machine has not collided.	Check the investigation item No. 2.		
2	Check whether the current value on the NC Servo Monitor screen is saturated during acceleration/ deceleration.	The current is saturated during acceleration/deceleration.	Check the investigation item No. 3.	○	
		The current value during acceleration/ deceleration is appropriate.	Investigate the cause of the load fluctuation.		
3	Can the acceleration/deceleration time constant be changed?	The constant can be changed.	Increase the acceleration/ deceleration time constant.	○	
		The constant cannot be changed.	Set to ignore collision detection method 2.		

Alarm No. 5B		Safety observation: Commanded speed error			
		In safety monitoring mode, the commanded speed was detected to exceed the safe speed.			
	Investigation details	Investigation results	Remedies	SV	SP
1	Check the commanded speed on the NC side.	The commanded speed and safe speed limit value are the same.	Reduce the commanded speed on the NC side or increase the safe speed limit value.	○	○
		The commanded speed is slower than the safe speed.	Replace the drive unit.		

## Appendix 2 Explanation of Alarms

Alarm No. 5D		Safety observation: Door state error			
		In safety monitoring mode, the door state signal from the NC and the same signal from the drive unit don't match. Otherwise, door open state was detected in normal mode.			
	Investigation details	Investigation results	Remedies	SV	SP
1	Check the DI input timing.	Both NC side and drive unit side input timings match one another within 500ms.	Review the DI input sequence. Check if the cable for the DI input signal is broken.	○	○
		NC side and drive unit side inputs do not match one another within 500ms.	Investigate the wiring and connection environment.		

Alarm No. 5E		Safety observation: Feedback speed error			
		In safety monitoring mode, the motor speed was detected to exceed the safe speed.			
	Investigation details	Investigation results	Remedies	SV	SP
1	Check the DI input timing.	The feedback speed and safe speed limit value are the same.	Reduce the commanded speed on the NC side or increase the safe speed limit value.	○	○
		The feedback speed is slower than the safe speed.	Replace the drive unit.		
2	Check the wiring and setting environment. 1) Correctly grounded? 2) Any noise generating devices around the unit? 3) Are the speed/position detector cables correctly shielded?	1) The grounding is incomplete.	Correctly ground.	○	○
		2) The alarm occurs easily when a specific device operates.	Use noise measures on the device described on the left.		
		3) The cable is not correctly shielded.	Correctly shield the cable.		
		No abnormality is found in particular.	Replace the drive unit.		

Alarm No. 5F		External contactor error			
		A contact of the external contactor is welding.			
	Investigation details	Investigation results	Remedies	SV	SP
1	Check whether the contactor's contact has melted.	The contactor is melted.	Replace the contactor.	○	○
		The contactor is not melted.	Check the investigation item No. 2.		
2	Check whether the axis where an alarm occurred was a contactor control axis.	The alarm occurred at the axis where the contactor control is not executed.	Check the parameter.(SVJ3/SPJ3) With contactor control Servo:SV082, Spindle :SP227 0800h is added to the setting value. Without contactor control Change "Bit A,B" to "00" in the parameter above.	○	○
		The alarm occurred at the axis where the contactor control is executed.	Replace the drive unit.		

Alarm No. 80		Main side detector cable error			
		A pulse type cable is used for the motor side detector.			
	Investigation details	Investigation results	Remedies	SV	SP
1	Check the parameters. Servo:SV025 = "x200" Spindle:SP031 = "x200" And then, check the connected cable and the detector.	The cable type is pulse.	Replace the cable to the serial type.	○	○
		There is no problem with the selection of the detector and cable.	Replace the detector or cable.		

Alarm No. 81		Sub side detector cable error			
		The cable type of machine side detector does not match the detector specifications set by the parameter.			
	Investigation details	Investigation results	Remedies	SV	SP

Alarm No. 81		Sub side detector cable error			
		The cable type of machine side detector does not match the detector specifications set by the parameter.			
1	Check if the below parameters match the connected detector and cable. Servo: SV025 Spindle: SP031	The detector does not match the specifications.	Replace the detector.	○	○
		The parameter is not correct.	Set the parameters so that they meet the machine side detector. <Servo:SV025> - Rotary Pulse 2xxx Serial 6xxx - Scale Pulse 8xxx Serial Axxx <Spindle:SP031> Pulse 4200 Serial 6200		
		There is no problem with the selection of the detector and cable.	Replace the detector or cable.		

Alarm No. 87		Drive unit communication error			
		The communication frame between drive units was aborted.			
	Investigation details	Investigation results	Remedies	SV	SP
1	Check the connection of the optical communication cable between drive units.	The cable and connector were loose.	Connect again so as not to be loosened.	○	○
		The cable and connector were not loose.	Replace the cable. Check the investigation item No. 2.		
2	Check the repeatability.	The error is always repeated (in high-speed synchronous tapping).	Replace the servo drive or spindle drive unit that is used for high-speed synchronous tapping.	○	○

Alarm No. 88		Watchdog			
		The system does not operate correctly.			
	Investigation details	Investigation results	Remedies	SV	SP
1	Check whether the servo or spindle software version was changed recently.	The version was changed.	Change software version back to the original.	○	○
		The version was not changed.	Check the investigation item No. 2.		
2	Check the repeatability.	The error is always repeated.	Replace the drive unit.	○	○
		The state returns to normal once, but occurs sometimes thereafter.	Check the investigation item No. 3.		
3	Check if there is any abnormality in the unit's ambient environment. (Ex. Ambient temperature, noise, grounding)	Take remedies according to the causes of the abnormality in the ambient environment.		○	○

(Note) For MDS-D-SVJ3/SPJ3 Series, "888" is displayed.

## Appendix 2 Explanation of Alarms

Alarm No. 8A		Drive unit communication data error 1			
		The communication data 1 between drive units exceeded the tolerable value in the communication between drive units.			
	Investigation details	Investigation results	Remedies	SV	SP
1	Check if the error has occurred during high-speed synchronous tapping.	The error occurs during the synchronous tapping.	[1]Check the tool. [2]Adjust the tapping.	○	○
		The error does not occur during the synchronous tapping.	Check the investigation item No. 2.		
2	Check the repeatability.	The error is always repeated.	Replace the drive unit.	○	○
		The state returns to normal once, but occurs sometimes thereafter.	Check the investigation item No. 3.		
3	Check if there is any abnormality in the unit's ambient environment. (Ex. Ambient temperature, noise, grounding)	Take remedies according to the causes of the abnormality in the ambient environment.		○	○

Alarm No. 8B		Drive unit communication data error 2			
		The communication data 2 between drive units exceeded the tolerable value in the communication between drive units.			
	Investigation details	Investigation results	Remedies	SV	SP
1	Check if the error was occurred during the synchronous tapping.	The error occurs during the synchronous tapping.	[1]Check the tool. [2]Adjust the tapping.	○	○
		Check if the error has occurred during high-speed synchronous tapping.	Check the investigation item No. 2.		
2	Check the repeatability.	The error is always repeated.	Replace the drive unit.	○	○
		The state returns to normal once, but occurs sometimes thereafter.	Check the investigation item No. 3.		
3	Check if there is any abnormality in the unit's ambient environment. (Ex. Ambient temperature, noise, grounding)	Take remedies according to the causes of the abnormality in the ambient environment.		○	○

### Appendix 2.13.2.3 Troubleshooting for each warning No.

Warning No. 96		Scale feedback error			
		An excessive difference in feedback amount was detected between the main side detector and the MPI scale in MPI scale absolute position detection system.			
	Investigation details	Investigation results	Remedies	SV	SP
1	Check if there is any abnormality in the detector's ambient environment. (Ex. Ambient temperature, noise, grounding)	Take remedies according to the causes of the abnormality in the ambient environment.		○	
2	Check the repeatability.	Occurs frequently.	Replace the detector.	○	○
		Is not repeated.	Check the investigation item No. 1.		

Warning No. 97		Scale offset error			
		An error was detected in the offset data that is read at the NC power-ON in MPI scale absolute position detection system.			
	Investigation details	Investigation results	Remedies	SV	SP
1	Check if there is any abnormality in the detector's ambient environment. (Ex. Ambient temperature, noise, grounding)	Take remedies according to the causes of the abnormality in the ambient environment.		○	
2	Check the repeatability.	Occurs frequently.	Replace the detector.	○	○
		Is not repeated.	Check the investigation item No. 1.		

Warning No. 9B		Incremental detector/magnetic pole shift warning			
		For the incremental detector, an error was detected in the magnetic pole shift amount set in the magnetic pole shift amount parameter "SV028".			
	Investigation details	Investigation results	Remedies	SV	SP
1	Check if there is any abnormality in the detector's ambient environment. (Ex. Ambient temperature, noise, grounding)	Take remedies according to the causes of the abnormality in the ambient environment.		○	
2	Check the repeatability.	Occurs occasionally.	Execute magnetic pole detection control again and reset SV028.	○	○
		Is not repeated.	Check the investigation item No. 1.		

Warning No. 9E		Absolute position detector: Revolution counter error			
		An error was detected in the revolution counter of the absolute position detector. The absolute position data cannot be compensated.			
	Investigation details	Investigation results	Remedies	SV	SP
1	Check if there is any abnormality in the detector's ambient environment. (Ex. Ambient temperature, noise, grounding)	Take remedies according to the causes of the abnormality in the ambient environment.		○	
2	Check the repeatability.	Occurs frequently.	Replace the detector.	○	○
		Is not repeated.	Check the investigation item No. 1.		



## Appendix 2 Explanation of Alarms

Warning No. 9F		Battery voltage drop			
		The battery voltage that is supplied to the absolute position detector dropped. The absolute position data is retained.			
	Investigation details	Investigation results	Remedies	SV	SP
1	Change the used battery and check whether the warning does not occur. (Turning the power OFF and ON is required.)	The warning does not occur.	The battery has been drained.	○	
		The warning occurs.	Check the investigation item No. 2.		
2	Check whether the battery cable is disconnected, broken, or wired incorrectly.	The connection is faulty.	Correct the connection. Replace the cable.	○	
		The connection is normal.	Check the investigation item No. 3.		
3	Measure the new battery voltage.	Less than 3.4V.	Replace the battery.	○	
		3.4V or more.	Check the investigation item No. 6. When a battery box is used, check the investigation item No. 4.		
4	Check whether the cable connecting between the battery box and CN9 is short-circuited, broken, or wired incorrectly.	The connection is faulty.	Correct the connection. Replace the cable.	○	
		The connection is normal.	Check the investigation item No. 5.		
5	Disconnect the BT-LG cable of the battery box, and then measure the voltage between DO(ALM) and DOCOM terminals at power ON.	Low voltage.	Replace the battery box.	○	
		Equivalent of 24V.	Check the investigation item No. 6.		
6	Perform a conductivity check with the detector cable between BT and LG of the drive unit in which the warning was detected. (Note) Make sure that the detector side connector is disconnected.	Resistance value is low.	Replace the cable.	○	
		Resistance value is 100MΩ or more.	Replace the detector. (With the absolute position system, the zero point must be established.)		

(Note) When warning 9F occurs, do not turn the drive unit power OFF to ensure that the absolute position data is held.  
Replace the battery with the drive unit power ON.

Warning No. A3		Distance-coded reference check / initial setup warning			
		When the detector with distance-coded reference marks is used, this warning is issued until the axis reaches the reference position during the initial setup of the distance-coded reference check function. This warning disappears after the axis has reached the position.			
	Investigation details	Investigation results	Remedies	SV	SP
1	Warning does not disappear.	Stopped on the way to the reference position.	Setup again.	○	-

Warning No. A6		Fan stop warning			
		A cooling fan built in the drive unit stopped.			
	Investigation details	Investigation results	Remedies	SV	SP
1	Check the alarm No. "45" items.			○	○

Warning No. E0		Over regeneration warning			
		Over-regeneration detection level exceeded 80%.			
	Investigation details	Investigation results	Remedies	SV	SP
1	Check the acceleration/deceleration cycle.	The cycle operation being conducted is severe for the average output.	Extend the cycle operation time to the length that will not cause a warning.	○	○
		No problem.	Check the investigation item No. 2.		
2	Check the load inertia.	The load inertia is large.	Lower the load inertia.		

Warning No. E1		Overload warning			
		Overload detection level exceeded 80%.			
	Investigation details	Investigation results	Remedies	SV	SP
1	Check if the motor is hot.	Motor is hot.	Check the alarm No. "50" items.		○
		Motor is not hot.	Check the investigation item No. 2.		
2	Check if an error occurs when executing acceleration/deceleration operation.	Error is not found in operation. Thus, operation is possible.	Ease the operation patter, if possible. If no alarm occurs, operation can be continued as it is.		○
		Error is found in operation.	Check the investigation item 3 or later of Alarm No. 50.		
3	Check the alarm No. "50" items.			○	○

Warning No. E4		Set parameter warning			
		An incorrect parameter was detected among the parameters received from the CNC.			
	Investigation details	Investigation results	Remedies	SV	SP
1	Check the error parameter No.	SV001 to SV256 SP001 to SP256	Set the value within the designated setting range.	○	○
2	Check the spindle control input 4/bit 0 to 2.	Selected other than 000, 001, 010 and 100 when the alarm occurred.	Correctly select.		○

Warning No. E6		Control axis detachment warning			
		Control axis detachment was commanded.			
	Investigation details	Investigation results	Remedies	SV	SP
1	The status in which removal of the control axis was commanded from the NC is indicated.			○	

Warning No. E7		In NC emergency stop state			
		Emergency stop was input from the CNC.			
	Investigation details	Investigation results	Remedies	SV	SP
1	Check if the emergency stop is applied on the NC side.	The emergency stop is applied.	Check the investigation item No. 2.	○	○
		The emergency stop is cancelled.	Check the investigation item No. 3.		
2	Cancel the emergency stop.	Normally starts up.	Normal.	○	○
		"E7" remains displayed.	Check the investigation item No. 3.		
3	Check whether an alarm is occurring in another drive unit.	An alarm is occurring in another drive unit.	Reset the alarm in the other drive unit.	○	○
		An alarm is not occurring.	Check the investigation item No. 4.		
4	Turn the power of NC and 200VAC (400V) ON again			○	○

Warning No. E9		Instantaneous power interruption warning			
		The power was momentarily interrupted.			
	Investigation details	Investigation results	Remedies	CV	
1	Check the alarm No. "71" items.			○	

Warning No. EA		In external emergency stop state			
		External emergency stop signal was input.			
	Investigation details	Investigation results	Remedies	CV	
1	Check whether the specifications allow use of the external emergency stop.	Use is not allowed.	Invalidate the external emergency stop.	○	
		Use is allowed.	Check the investigation item No. 2.		
2	Measure the input voltage of the CN23 connector. (While emergency stop is cancelled.)	24V is input.	Replace the power supply unit.	○	
		24V is not input.	Check whether the external emergency stop cable is broken, or check the external contact operation.		

### Appendix 2.13.2.4 Parameter numbers during initial parameter error

If an initial parameter error (alarm 37) occurs, the alarm and the No. of the parameter set exceeding the setting range will appear on the NC Diagnosis screen as shown below.

S02 Initial parameter error ○○○○□

○○○○ : Error parameter No.

□ : Axis name

If an error No. larger than the servo parameter No. is displayed for the servo drive unit, the alarm is occurring for several related parameters. Refer to the following table, and correctly set the parameters.

Error parameter No.	Details	Related parameters
2301	The following settings are overflowing. [1] Electronic gears [2] Position loop gain [3] Speed feedback	SV001, SV002 SV003, SV018 SV019, SV020 SV049
2302	The absolute position parameter is valid when a high-speed serial incremental detector (OSE104 or OSE105) is connected. [1] Replace the detector to the one with absolute position specification.	SV017, SV025
2303	No servo option is found. [1] The closed loop (including the ball screw end) [2] Dual feedback control function	SV025 SV017
2304	No servo option is found. [1] SHG control function	SV057 SV058
2305	No servo option is found. [1] Adaptive filtering function	SV027
13001 to 13256	Parameter error The parameter value is outside the tolerable range. The alarm No. is the No. of the spindle parameter where an error occurred.	Check the indicated spindle parameter.

**Appendix 2.13.2.5 Troubleshooting the spindle system when there is no alarm or warning**

If an abnormality is observed in the spindle system but no alarm or warning has occurred, refer to the following table and check the state.

**[1] The rotation speed command and actual rotation speed do not match.**

	Investigation item	Investigation results	Remedies
1	Check the commanded speed and the spindle rotation speed displayed on the drive monitor screen.	The speed command is not input correctly.	Input the correct speed command.
		The speed command is correct.	Check the investigation item No. 2.
2	Check whether there is slipping between the motor and spindle. (When connected with a belt or clutch.)	There is slipping.	Repair the machine side.
		No particular problems found.	Check the investigation item No. 3.
3	Check the spindle parameters (SP026, SP129 and following).	The correct values are not set.	Set the correct values.
		The correct values are set.	Replace the spindle drive unit.

**[2] The acceleration/deceleration time is long or has increased in length.**

	Investigation item	Investigation results	Remedies
1	Check whether the friction torque or load inertia has increased.	The friction torque has increased.	Repair the machine side.
		No particular problems found.	Check the investigation item No. 2.
2	Check if there is any abnormality in the motor's rotation during coasting.	The bearings do not rotate smoothly.	Replace the spindle motor.
		The bearings rotate smoothly.	Check the investigation item No. 3.
3	Check whether the torque limit signal has been input.	The signal has been input.	Release the input signal.
		The signal is not input.	Replace the drive unit.

**[3] The motor stops during cutting.**

	Investigation item	Investigation results	Remedies
1	Check the load rate (load meter value) during cutting.	The load meter sways over 120% during cutting.	Reduce the cutting amount.
		No particular problems found.	Check the investigation item No. 2.
2	Carry out the same investigations and remedies as section (4).		

## Appendix 2 Explanation of Alarms

### [4] The vibration and noise (gear noise), etc., are large.

	Investigation item	Investigation results	Remedies
1	Check the machine's dynamic balance. (Coast from the maximum speed.)	The same noise is heard during coasting.	Repair the machine side.
		No particular problems found.	Check the investigation item No. 2.
2	Check whether there is a resonance point in the machine. (Coast from the maximum speed.)	Vibration and noise increase at a set rotation speed during coasting.	Repair the machine side.
		No particular problems found.	Check the investigation item No. 3.
3	Check the machine's backlash.	The backlash is great.	Repair the machine side.
		No particular problems found.	Check the investigation item No. 4.
4	Change the setting of the speed loop parameter (SP005:VGN1).	The vibration and noise are lost when the setting value is lowered by approx.100.	Change to the setting value. (Note) The impact response will drop.
		The symptoms do not change even if the above value is set.	Return the setting values to the original values. Check the investigation item No. 5.
5	Jiggle the detector connectors (drive unit side and detector side) and check if they are disconnected.	The connection is loosened.	Correctly connect the connector.
		The connector fixing is normal.	Check the investigation item No. 6.
6	Turn the power OFF, and check the connection of the speed detector cable with a tester.	The connection is faulty or disconnected.	Replace the detector cable. Correct the connection.
		The connection is normal.	Replace the drive unit.

### [5] The spindle coasts during deceleration.

	Investigation item	Investigation results	Remedies
1	When connected with a belt or clutch, check whether there is slipping between the motor and spindle.	There is slipping.	Check the machine side and repair it.
		No particular problems found.	Replace the drive unit.

**[6] The rotation does not stabilize.**

	Investigation item	Investigation results	Remedies
1	Check the spindle parameter SP005 (SP008) settings.	The rotation stabilizes when the settings values are both set to approx. double.	Change the setting value. Note that the gear noise may increase.
		The symptoms do not change even when the above value is set.	Return the setting values to the original values. Check the investigation item No. 2.
2	Manually shake the speed detector connectors (spindle drive unit side and speed detector side) to check if they are disconnected.	The connector is disconnected (or loose).	Correctly connect the connector.
		The connector is not disconnected (or loose).	Check the investigation item No. 3.
3	Turn the power OFF, and check the connection of the speed detector cable with a tester. (Especially check the shield wiring.)	The connection is faulty.	Replace the detector cable. Correct the connection.
		The connection is normal.	Check the investigation item No. 4.
4	Investigate the wiring and installation environment. 1) Is the ground correctly connected? 2) Are there any noise-generating devices near the drive unit?	1) The grounding is incomplete.	Correctly ground.
		2) The alarm occurs easily when a specific device operates.	Use noise measures on the device described on the left.
		No particular problems found.	Replace the spindle drive unit.

**[7] The speed does not rise above the command speed sometimes.**

	Investigation item	Investigation results	Remedies
1	Check the speed command. Check whether the override input is input from the machine operation panel.	The speed command is not input correctly.	Input the correct speed command.
		The speed command is input correctly.	Check the investigation item No. 2.
2	Check whether the load has suddenly become heavier.	The load has become heavier.	Repair the machine side.
		No particular problems found.	Check the investigation item No. 3.
3	Manually rotate the motor bearings and check the movement.	The bearings do not rotate smoothly.	Replace the spindle motor.
		The bearings rotate smoothly.	Check the investigation item No. 4.
4	Manually shake the speed detector connectors (spindle drive unit side and speed detector side) to check if they are disconnected.	The connector is disconnected (or loose).	Correctly connect the connector.
		The connector is not disconnected (or loose).	Check the investigation item No. 5.
5	Turn the power OFF, and check the connection of the speed detector cable with a tester. (Especially check the shield wiring.)	The connection is faulty.	Replace the detector cable. Correct the connection.
		The waveform is normal.	Replace the spindle drive unit.



## Revision History

Date of revision	Manual No.	Revision details
Nov. 2008	IB(NA)1500906-A	First edition created.
Jan. 2009	IB(NA)1500906-B	Mistakes were corrected.
May. 2010	IB(NA)1500906-C	<ul style="list-style-type: none"> <li>- Added "2.1.2 Setting up without Connecting to the Motor/ Drive unit" .</li> <li>- Changed the structure of Chapter 6.2.3 according to the changes made to the MS Configurator.</li> <li>Old: 6.2.3 First Measure Against Vibration</li> <li>New: 6.2.3 Servo Simplified Adjustment <ul style="list-style-type: none"> <li>6.2.3.1 First Measure Against Vibration</li> <li>6.2.3.2 MS Configurator</li> </ul> </li> <li>- Changed the structure of Chapter 8 as explanation of H/W OT was added.</li> <li>Old: 8 Setting the Stored Stroke Limit <ul style="list-style-type: none"> <li>8.1 Outline</li> <li>8.2 Detailed Explanation</li> </ul> </li> <li>New: 8 Setting the Tool Entry Prohibited Range <ul style="list-style-type: none"> <li>8.1 Stroke End (H/W OT)</li> <li>8.2 Stored stroke limit (S/W OT) <ul style="list-style-type: none"> <li>8.2.1 Outline</li> <li>8.2.2 Detailed Explanation</li> </ul> </li> </ul> </li> <li>- Corrected Alarms/Parameters to support the system software G1 version.</li> <li>- Mistakes were corrected.</li> </ul>
Jun. 2010	IB(NA)1500906-D	- Mistakes were corrected.
Nov. 2011	IB(NA)1500906-E	<ul style="list-style-type: none"> <li>- Added "Handling of our product".</li> <li>- Updated the contents of "6.2.3.2 MS Coinfigurator".</li> <li>- Reviewed "7. Setting the Position Detection System".</li> <li>- Added "12.1.2 Display Unit Cooling Fan.</li> <li>- Added "Appendix 2.13.1 Troubleshooting for NC".</li> <li>- Corrected Alarms/Parameters to support the system software H0 vresion.</li> <li>- Mistakes were corrected.</li> </ul>



# Global Service Network

## AMERICA

### MITSUBISHI ELECTRIC AUTOMATION INC. (AMERICA FA CENTER)

#### Central Region Service Center

500 CORPORATE WOODS PARKWAY, VERNON HILLS, ILLINOIS 60061, U.S.A.  
TEL: +1-847-478-2500 / FAX: +1-847-478-2650

#### Michigan Service Satellite

ALLEGAN, MICHIGAN 49010, U.S.A.  
TEL: +1-847-478-2500 / FAX: +1-269-673-4092

#### Ohio Service Satellite

LIMA, OHIO 45901, U.S.A.  
TEL: +1-847-478-2500 / FAX: +1-847-478-2650  
CLEVELAND, OHIO 44114, U.S.A.  
TEL: +1-847-478-2500 / FAX: +1-847-478-2650

#### Minnesota Service Satellite

MINNEAPOLIS, MINNESOTA 55413, U.S.A.  
TEL: +1-847-478-2500 / FAX: +1-847-478-2650

#### West Region Service Center

5665 PLAZA DRIVE, CYPRESS, CALIFORNIA 90630, U.S.A.  
TEL: +1-714-220-4796 / FAX: +1-714-229-3818

#### East Region Service Center

200 COTTONTAIL LANE SOMERSET, NEW JERSEY 08873, U.S.A.  
TEL: +1-732-560-4500 / FAX: +1-732-560-4531

#### Pennsylvania Service Satellite

ERIE, PENNSYLVANIA 16510, U.S.A.  
TEL: +1-814-897-7820 / FAX: +1-814-987-7820

#### Massachusetts Service Satellite

BOSTON, MASSACHUSETTS 02108, U.S.A.  
TEL: +1-508-216-6104

#### South Region Service Center

2810 PREMIERE PARKWAY SUITE 400, DULUTH, GEORGIA 30097, U.S.A.  
TEL: +1-678-258-4500 / FAX: +1-678-258-4519

#### Texas Service Satellites

GRAPEVINE, TEXAS 76051, U.S.A.  
TEL: +1-817-251-7468 / FAX: +1-817-416-5000  
FRIENDSWOOD, TEXAS 77546, U.S.A.  
TEL: +1-832-573-0787 / FAX: +1-678-573-8290

#### Florida Service Satellite

WEST MELBOURNE, FLORIDA 32904, U.S.A.  
TEL: +1-321-610-4436 / FAX: +1-321-610-4437

#### Canada Region Service Center

4299 14TH AVENUE MARKHAM, ONTARIO L3R 0J2, CANADA  
TEL: +1-905-475-7728 / FAX: +1-905-475-7935

#### Mexico City Service Center

MARIANO ESCOBEDO 69 TLALNEPANTLA, 54030 EDO. DE MEXICO  
TEL: +52-55-9171-7662 / FAX: +52-55-9171-7649

#### Monterrey Service Satellite

MONTERREY, N.L., 64720, MEXICO  
TEL: +52-81-8365-4171 / FAX: +52-81-8365-4171

#### Brazil Region Service Center

ACESSO JOSE SARTORELLI, KM 2.1 CEP 18550-000, BOITUVA-SP, BRAZIL  
TEL: +55-15-3363-9900 / FAX: +55-15-3363-9911

#### Brazil Service Satellites

PORTO ALEGRE AND CAXIAS DO SUL BRAZIL  
TEL: +55-15-3363-9927  
SANTA CATARINA AND PARANA STATES  
TEL: +55-15-3363-9927

## EUROPE

### MITSUBISHI ELECTRIC EUROPE B.V. (EUROPE FA CENTER)

GOTHAER STRASSE 10, 40880 RATINGEN, GERMANY  
TEL: +49-2102-486-0 / FAX: +49-2102-486-5910

#### Germany Service Center

KURZE STRASSE. 40, 70794 FILDERSTADT-BONLANDEN, GERMANY  
TEL: + 49-711-3270-010 / FAX: +49-711-3270-0141

#### France Service Center

25, BOULEVARD DES BOUVETS, 92741 NANTERRE CEDEX FRANCE  
TEL: +33-1-41-02-83-13 / FAX: +33-1-49-01-07-25

#### France (Lyon) Service Satellite

120, ALLEE JACQUES MONOD 69800 SAINT PRIEST FRANCE  
TEL: +33-1-41-02-83-13 / FAX: +33-1-49-01-07-25

#### Italy Service Center

VIALE COLLEONI 7-PALAZZO SIRIO CENTRO DIREZIONALE COLLEONI,  
20041 AGRATE BRIANZA MILANO ITALY  
TEL: +39-039-60531-342 / FAX: +39-039-6053-206

#### Italy (Padova) Service Satellite

VIA SAVELLI 24 - 35129 PADOVA ITALY  
TEL: +39-039-60531-342 / FAX: +39-039-6053-206

#### U.K. Service Center

TRAVELLERS LANE, HATFIELD, HERTFORDSHIRE, AL10 8XB, U.K.  
TEL: +44-1707-27-6100 / FAX: +44-1707-27-8992

#### Spain Service Center

CTRA. DE RUBI, 76-80-APDO. 420  
08190 SAINT CUGAT DEL VALLES, BARCELONA SPAIN  
TEL: +34-935-65-2236 / FAX: +34-935-89-1579

#### Poland Service Center

UL KRAKOWSKA 50, 32-083 BALICE, POLAND  
TEL: +48-12-630-4700 / FAX: +48-12-630-4727

#### Poland (Wroclaw) Service Center

UL KOBIERZYCKA 23, 52-315 WROCLAW, POLAND  
TEL: +48-71-333-77-53 / FAX: +48-71-333-77-53

#### Turkey Service Center

BAYRAKTAR BULVARI, NUTUK SOKAK NO.5, YUKARI DUDULLU  
ISTANBUL, TURKEY  
TEL: +90-216-526-3990 / FAX: +90-216-526-3995

#### Czech Republic Service Center

TECHNOLOGICKA 374/6, 708 00 OSTRAVA-PUSTKOVEC, CZECH REPUBLIC  
TEL: +420-59-5691-185 / FAX: +420-59-5691-199

#### Russia Service Center

213, B.NOVODMITROVSKAYA STR., 14/2, 127015 MOSCOW, RUSSIA  
TEL: +7-495-748-0191 / FAX: +7-495-748-0192

#### Sweden Service Center

STRANDKULLEN, 718 91 FROVI, SWEDEN  
TEL: +46-581-700-20 / FAX: +46-581-700-75

#### Bulgaria Service Center

4 A. LYAPCHEV BOUL., 1756 - SOFIA, BULGARIA  
TEL: +359-2-8176000 / FAX: +359-2-9744061

#### Ukraine (Kharkov) Service Center

APTEKARSKIY LANE 9-A, OFFICE 3, 61001 KHARKOV, UKRAINE  
TEL: +38-57-732-7744 / FAX: +38-57-731-8721

#### Ukraine (Kiev) Service Center

4-B, M. RASKOVOYI STR., 02660 KIEV, UKRAINE  
TEL: +38-044-494-3355 / FAX: +38-044-494-3366

#### Belarus Service Center

703, OKTYABRSKAYA STR., 16/5, 220030 MINSK, BELARUS  
TEL: +375-17-210-4626 / FAX: +375-17-227-5830

#### South Africa Service Center

P.O. BOX 9234, EDLEEN, KEMPTON PARK GAUTENG, 1625 SOUTH AFRICA  
TEL: +27-11-394-8512 / FAX: +27-11-394-8513

#### Denmark Service Center

KARETMAGERVEJ. 7A, DK-7000, FREDERICIA, DENMARK  
TEL: +45-7620-7514

## ASEAN

### MITSUBISHI ELECTRIC ASIA PTE. LTD. (ASEAN FA CENTER)

#### Singapore Service Center

307 ALEXANDRA ROAD #05-01/02 MITSUBISHI ELECTRIC BUILDING SINGAPORE 159943  
TEL: +65-6473-2308 / FAX: +65-6476-7439

#### Indonesia Service Center

THE PLAZZA OFFICE TOWER, 28TH FLOOR J.L.M.H. THAMRIN KAV.28-30, JAKARTA, INDONESIA  
TEL: +62-21-2992-2333 / FAX: +62-21-2992-2555

#### Malaysia (KL) Service Center

60, JALAN USJ 10 /1B 47620 UEP SUBANG JAYA SELANGOR DARUL EHSAN, MALAYSIA  
TEL: +60-3-5631-7605 / FAX: +60-3-5631-7636

#### Malaysia (Johor Baru) Service Center

NO. 16, JALAN SHAH BANDAR 1, TAMAN UNGKU TUN AMINAH, 81300 SKUDAI, JOHOR MALAYSIA  
TEL: +60-7-557-8218 / FAX: +60-7-557-3404

#### Vietnam Service Center-1

ROOM 1004, 1005, FLOOR 10, 255 TRAN HUNG DAO CO GIANG WARD, DIST. 1, HCMC, VIETNAM  
TEL: +84-8-3838-6931 / FAX: +84-8-3838-6932

#### Vietnam Service Center-2

LOT G10 - AREA 4 - HIEP BINH CHANH WARD - THU DUC DISTRICT - HCMC, VIETNAM  
TEL: +84-8-2240-3587 / FAX: +84-8-3726-7968

#### Vietnam (Hanoi) Service Center

5FL, 59 - XA DAN STR., DONG DA DIST., HN, VIETNAM  
TEL: +84-4-3573-7646 / FAX: +84-4-3573-7650

#### Philippines Service Center

UNIT NO.411, ALABAMG CORPORATE CENTER KM 25. WEST SERVICE ROAD  
SOUTH SUPERHIGHWAY, ALABAMG MUNTINLUPA METRO MANILA, PHILIPPINES 1771  
TEL: +63-2-807-2416 / FAX: +63-2-807-2417

### MITSUBISHI ELECTRIC AUTOMATION (THAILAND) CO., LTD. (THAILAND FA CENTER)

BANG-CHAN INDUSTRIAL ESTATE NO.111 SOI SERITHAI 54  
T.KANNAYAO, A.KANNAYAO, BANGKOK 10230, THAILAND  
TEL: +66-2906-8255 / FAX: +66-2906-3239

#### Thailand Service Center

898/19,20,21,22 S.V. CITY BUILDING OFFICE TOWER 1, FLOOR 7  
RAMA III RD., BANGPONGPANG, YANNAWA, BANGKOK 10120, THAILAND  
TEL: +66-2-682-6522 / FAX: +66-2-682-9750

## INDIA

### MITSUBISHI ELECTRIC INDIA PVT. LTD.

#### India Service Center

2nd FLOOR, DLF BUILDING No.9B, DLF CYBER CITY  
DLF PHASE-III, GURGAON 122002, HARYANA  
TEL: +91-124-4630300 / FAX: +91-124-4630399

#### India (Bangalore) Service Center

FIRST & SECOND FLOOR, AVR BASE, MUNICIPAL NO.BC-308,  
HENNURE BANASWADI ROAD, HRBR RING ROAD, BANGALORE-560 043, INDIA  
TEL: +91-80-4020-1600 / FAX: +91-80-4020-1699

**Chennai satellite office**  
**Coimbatore satellite office**

#### India (Pune) Service Center

UNIT: +91-998-7997651  
**Baroda satellite office**

## OCEANIA

### MITSUBISHI ELECTRIC AUSTRALIA LTD.

#### Oceania Service Center

348 VICTORIA ROAD, RYDALMERE, N.S.W. 2116 AUSTRALIA  
TEL: +61-2-9684-7269 / FAX: +61-2-9684-7245

## CHINA

### MITSUBISHI ELECTRIC AUTOMATION (CHINA) LTD. (CHINA FA CENTER)

#### China (Shanghai) Service Center

1-3,5-10,18-23/F, NO.1386 HONG QIAO ROAD, CHANG NING QU,  
SHANGHAI 200336, CHINA  
TEL: +86-21-2322-3030 / FAX: +86-21-2308-2830

#### China (Ningbo) Service Dealer

#### China (Wuxi) Service Dealer

#### China (Jinan) Service Dealer

#### China (Wuhan) Service Satellite

#### China (Beijing) Service Center

9/F. OFFICE TOWER 1, HENDERSON CENTER, 18 JIANGUOMENNEI DAJIE,  
DONGCHENG DISTRICT, BEIJING 100005, CHINA  
TEL: +86-10-6518-8830 / FAX: +86-10-6518-3907

#### China (Beijing) Service Dealer

#### China (Tianjin) Service Center

B-2 801/802, YOUYI BUILDING, NO.50 YOUYI ROAD, HEXI DISTRICT,  
TIANJIN 300061, CHINA  
TEL: +86-22-2813-1015 / FAX: +86-22-2813-1017

#### China (Shenyang) Service Satellite

#### China (Changchun) Service Satellite

#### China (Chengdu) Service Center

ROOM 407-408, OFFICE TOWER AT SHANGRI-LA CENTER, NO. 9 BINJIANG DONG ROAD,  
JINJIANG DISTRICT, CHENGDU, SICHUAN 610021, CHINA  
TEL: +86-28-8446-8030 / FAX: +86-28-8446-8630

#### China (Shenzhen) Service Center

ROOM 2512-2516, 25/F., GREAT CHINA INTERNATIONAL EXCHANGE SQUARE, JINTIAN RD.S.,  
FUTIAN DISTRICT, SHENZHEN 518034, CHINA  
TEL: +86-755-2399-8272 / FAX: +86-755-8218-4776

#### China (Xiamen) Service Dealer

#### China (Dongguan) Service Dealer

## KOREA

### MITSUBISHI ELECTRIC AUTOMATION KOREA CO., LTD. (KOREA FA CENTER)

#### Korea Service Center

1480-6, GAYANG-DONG, GANGSEO-GU SEOUL 157-200, KOREA  
TEL: +82-2-3660-9602 / FAX: +82-2-3664-8668

#### Korea Taegu Service Satellite

603 CRYSTAL BUILDING 1666, SANBYEOK-DONG, BUK-KU, DAEGU, 702-010, KOREA  
TEL: +82-53-604-6047 / FAX: +82-53-604-6049

## TAIWAN

### MITSUBISHI ELECTRIC TAIWAN CO., LTD. (TAIWAN FA CENTER)

#### Taiwan (Taichung) Service Center

NO.8-1, GONG YEH 16TH RD., TAICHUNG INDUSTRIAL PARK TAICHUNG CITY, TAIWAN R.O.C.  
TEL: +886-4-2359-0688 / FAX: +886-4-2359-0689

#### Taiwan (Taipei) Service Center

3RD. FLOOR, NO.122 WUKUNG 2ND RD., WU-KU HSIANG, TAIPEI HSIEN, TAIWAN R.O.C.  
TEL: +886-2-2299-2205 / FAX: +886-2-2298-1909

#### Taiwan (Tainan) Service Center

2F(C),1-1, CHUNGHWA-RD., YONGKANG CITY, TAINAN HSIEN, TAIWAN R.O.C.  
TEL: +886-6-313-9600 / FAX: +886-6-313-7713

**Notice**

Every effort has been made to keep up with software and hardware revisions in the contents described in this manual. However, please understand that in some unavoidable cases simultaneous revision is not possible. Please contact your Mitsubishi Electric dealer with any questions or comments regarding the use of this product.

**Duplication Prohibited**

This manual may not be reproduced in any form, in part or in whole, without written permission from Mitsubishi Electric Corporation.

COPYRIGHT 2008-2011 MITSUBISHI ELECTRIC CORPORATION  
ALL RIGHTS RESERVED



MODEL	M700VS Series
MODEL CODE	100-188
Manual No.	IB-1500906